


Table of Contents

Web Application	2	Data Models	14
Features	2	EtherNet/IP™ Data Model	14
First Login	2	Modbus TCP Data Model	19
Web Application Layout	4	Rockwell Automation Integration	24
AVT Status Page	4	Automatic Diagnostic AOP Items	24
Data Logs Page	7	Security	26
Settings Page	8	Troubleshooting	28
Documentation Page	13	Warranty	29
Support Page	13	Panduit Limited Product Warranty	29

The network module is designed to be an optional accessory that enables network capabilities for the VeriSafe 2.0 Absence of Voltage Tester (AVT). The network module provides an integrated web application that is delivered by an on board web server. The web application monitors data from the AVT and provides integration, configuration and firmware update capabilities. The network module supports AVT data over EtherNet/IP and Modbus TCP protocols. The voltage presence discrete outputs may be used as an indication of voltage presence with or without a network connection. The network module provides the ability to log various pieces of data based on built in triggers (see **Data Logs Page** for more information).

Before attempting to physically install the network module in hazardous or ordinary locations, refer to document no. B21148 (VeriSafe Network Module Installation Requirements Manual) for physical installation requirements including; connectivity, ratings and environmental specifications for the network module.



TO REDUCE THE RISK OF INJURY, USER MUST READ INSTRUCTION MANUAL

NOTE: In the interest of higher quality and value, Panduit™ products are continually being improved and updated. Consequently, pictures may vary from the enclosed product.

NOTE: Updates to this Instruction Manual may be available. Check www.panduit.com for the latest version of this manual.

Tech Support Emails

North America Tech Support:
techsupport@panduit.com

EU Tech Support :
techsupportemea@panduit.com

Asia Pacific Tech Support:
techsupportap@panduit.com

LATAM Tech Support:
techsupportlatam@panduit.com

For a copy of Panduit product warranties, log on to www.panduit.com/warranty

Web Application


FEATURES

The network module web application can be used to configure and monitor the AVT. Access the web application by typing the network module IP address in a supported browser.

FIRST LOGIN


1. Type the network module IP address (default: 192.168.2.10) in a supported browser using HTTPS and not HTTP.
 - Supported browsers: Chrome, Edge, Firefox
2. If the Browser displays “refused to connect” please double check that you are using “https://” protocol and not “http://”

FIGURE 1. REFUSED CONNECTION EXAMPLE




3. By Default, the Web Interface uses a self-signed certificate. Until a CA signed certificate / key is installed, browsers will display a security error. In Chrome browser, click advanced.

FIGURE 2. CERTIFICATE WARNING




4. Click on “Continue to 192.168.2.10 (unsafe)” and you will be prompted to the VeriSafe Network Module web application page.

FIGURE 3. CONTINUE TO WEB APPLICATION LINK



5. On first login the user is required to change the admin password
Web App Login (factory default setting)
 - Username: admin
Password: admin

FIGURE 4. CHANGE PASSWORD



6. Before using the Network Module with an AVT unit, please ensure the firmware is updated to the latest version by selecting the image below. This will take you to Panduit's products software/firmware page where the latest firmware version of the Network Module can be found.

[View Latest Network Module Firmware](#)

WEB APPLICATION LAYOUT

The web application layout consists of a left sidebar menu and a content area loaded with content cards.

FIGURE 5. WEB APPLICATION DASHBOARD

LOGIN
On login the user will be directed to the AVT Status page.

VeriSafe
Network Module
Pump 1

AVT Status

Data Logs
Settings
Documentation
Support
Logout

AVT Test Data
Name: Pump 1
Date & Time: 5/9/23, 12:26 PM

Updated	5/9/23, 12:26 PM
Battery Voltage	3.6 V
Test Temperature	25°C (77°F)

Updated	5/9/23, 12:26 PM
Connection Status L1	YES
Connection Status L2	YES
Connection Status L3	YES
Connection Status GND	YES

Test Result 1	Voltage Exceeded
Test Result 1 Date	5/9/23, 12:26 PM
Test Result 2	Pass
Test Result 2 Date	5/9/23, 12:25 PM

Activate AVT Test

Voltage Presence
Updated 0 seconds ago ✓
L1 L2 L3

Voltage Measurements

Line To Ground	RMS	Peak
L1	301 Vrms	426 V
L2	301 Vrms	427 V
L3	300 Vrms	425 V

Line To Line	RMS	Peak
L1-L2	521 Vrms	738 V
L1-L3	521 Vrms	739 V
L2-L3	521 Vrms	739 V

AVT Temperature
Current Temperature 25°C (77°F)

AVT STATUS PAGE

After the user has logged in they will be redirected to the AVT Status page. This page consists of two data cards with views that will be determined by the type of AVT in use and the user settings.

FIGURE 6. AVT STATUS PAGE 3-PHASE AVT (VS2-AVT-3P)

VeriSafe
Network Module
Pump 1

AVT Status

Data Logs
Settings
Documentation
Support
Logout

AVT Test Data
Name: Pump 1
Date & Time: 5/9/23, 12:26 PM

Updated	5/9/23, 12:26 PM
Battery Voltage	3.6 V
Test Temperature	25°C (77°F)

Updated	5/9/23, 12:26 PM
Connection Status L1	YES
Connection Status L2	YES
Connection Status L3	YES
Connection Status GND	YES

Test Result 1	Voltage Exceeded
Test Result 1 Date	5/9/23, 12:26 PM
Test Result 2	Pass
Test Result 2 Date	5/9/23, 12:25 PM

Activate AVT Test

Voltage Presence
Updated 0 seconds ago ✓
L1 L2 L3

Voltage Measurements

Line To Ground	RMS	Peak
L1	301 Vrms	426 V
L2	301 Vrms	427 V
L3	300 Vrms	425 V

Line To Line	RMS	Peak
L1-L2	521 Vrms	738 V
L1-L3	521 Vrms	739 V
L2-L3	521 Vrms	739 V

AVT Temperature
Current Temperature 25°C (77°F)

AVT STATUS PAGE FIRST CARD

Data presented in this card is updated as described in table 1. The user is presented with time stamps to indicate when the data was last updated. Some data will not be shown until an absence of voltage test is completed.

FIGURE 7. AVT STATUS PAGE 1ST CARD VIEWS




TABLE 1.

1. Name	User defined AVT name (Default blank). This is used to identify data log files and appears in the side bar menu. Changes are automatically saved.
2. Date/Time	Current Date/Time of the network module. Updated every 2 seconds.
3. Battery Voltage and Test Temperature	Last measured value of the battery voltage and Internal temperature of the AVT. <ul style="list-style-type: none"> Updated when the user presses the test button and during the wakeup cycle Recommended to replace battery in the AVT when measured below 2.9V.
4. Connection Status	Status of the connectivity between each pair of sensor leads based on the last completed test performed when no voltage is present.
5. Test Result 1	Show the most recent test result from the AVT
Test Result 1 Date	Date/Time of AVT test result 1
Test Result 2	Show the test result prior to test result 1
Test Result 2 Date	Date/Time of AVT test result 2
6. AC/DC Selection (VS-AVT-1P Single phase units only)	Selects the appropriate power system. This will update the card view. Changes are automatically saved.
7. Activate AVT Test Button	Starts the absence of voltage test

AVT STATUS PAGE SECOND CARD

Data in this card is updated every 2 seconds. For single phase systems the view shown is determined by selection on card 1 (table 1, item 6 AC/DC selection).

FIGURE 8. AVT STATUS PAGE SECOND CARD VIEWS




TABLE 2.

<p>1. AVT Connection Status</p>	<p>Indicates status of the connection between the isolation module and network module. ✔ OK ! DISCONNECTED</p>																					
<p>2. Voltage presence </p>	<ul style="list-style-type: none"> ■ Reflects the status of the voltage presence indicators (Red LEDs) on the indicator module ■ Reflects the status of the voltage presence contacts on the network module. 																					
<p>3. Voltage Measurements</p>	<ul style="list-style-type: none"> ■ Measured peak voltage line to ground ■ Calculated RMS and line to line voltages 	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr style="background-color: #004a7c; color: white;"> <th>AC Range</th> <th>*Accuracy</th> </tr> </thead> <tbody> <tr> <td>0-33 VAC</td> <td>± 7V</td> </tr> <tr> <td>34-99 VAC</td> <td>± 5V</td> </tr> <tr> <td>100-300 VAC</td> <td>± 2%</td> </tr> <tr> <td>301-1000 VAC</td> <td>± 1.5%</td> </tr> </tbody> </table> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr style="background-color: #004a7c; color: white;"> <th>DC Range</th> <th>*Accuracy</th> </tr> </thead> <tbody> <tr> <td>0-100 VDC</td> <td>± 5V</td> </tr> <tr> <td>101-300 VDC</td> <td>± 4%</td> </tr> <tr> <td>301-700 VDC</td> <td>± 2%</td> </tr> <tr> <td>701-1000 VDC</td> <td>± 1.5%</td> </tr> </tbody> </table> <p>To get the most accurate voltage readings, ensure the appropriate power system configuration is selected in the web application.</p> <p>*All values in this table are to be used as a reference and are expected to be within these ranges.</p> <p>Note: The absence of voltage indication from the AVT utilizes a separate circuit that is optimized for the 3V threshold.</p>	AC Range	*Accuracy	0-33 VAC	± 7V	34-99 VAC	± 5V	100-300 VAC	± 2%	301-1000 VAC	± 1.5%	DC Range	*Accuracy	0-100 VDC	± 5V	101-300 VDC	± 4%	301-700 VDC	± 2%	701-1000 VDC	± 1.5%
AC Range	*Accuracy																					
0-33 VAC	± 7V																					
34-99 VAC	± 5V																					
100-300 VAC	± 2%																					
301-1000 VAC	± 1.5%																					
DC Range	*Accuracy																					
0-100 VDC	± 5V																					
101-300 VDC	± 4%																					
301-700 VDC	± 2%																					
701-1000 VDC	± 1.5%																					
<p>4. AVT Temperature</p>	<ul style="list-style-type: none"> ■ Represents the current temperature inside the AVT that is updated every 2 seconds. 																					

DATA LOGS PAGE

This page allows the user to manage the log data stored on the network module SD card.

LOG TRIGGERS

Log entries are triggered by specific AVT events:

- Change in state of any voltage presence indicator
- Initiating the absence of voltage test
- Daily AVT wakeup cycle

FIGURE 9. DATA LOGS PAGE DETAILS

TABLE 3.

1. Request Data Logs	Request data log file from the network module
2. Download Logs (CSV)	Download the data log file to local PC in CSV form
3. Download Filtered Logs (CSV)	If filters are applied download the filtered data set only
4. Delete Logs	Deletes all entries from the data log file
5. Filters	Select filters. Use Update Filters and Clear Filters to manage selections.
6. Log Items	Data associated with each log entry.

NOTE: When log data is critical it is recommended the user periodically download the logs or to integrate the system (**EtherNet/IP™** or Modbus TCP) with an external data logging system.

SETTINGS PAGE

The settings page allows the user to configure and view the current state of the network module, retrieve AVT information, check active faults, and update firmware.

FIGURE 10. SETTINGS PAGE

VeriSafe
Network Module

Pump 1

AVT Status
Data Logs
Settings
Documentation
Support
Logout

Network Module Settings

Date & Time: 5/8/23, 12:45 PM [Set Time](#)

Network Module FW Version: 2.0.0

Use NTP Server:

NTP Server Address: pool.ntp.org

Power System Configuration: [Auto Detect](#)

Modbus:

EtherNet/IP:

DHCP:

IP Address: 192.168.2.10

Netmask: 255.255.255.0

Gateway: 0.0.0.0

DNS1: 8.8.8.8

DNS2: 8.8.4.4

Web Server Mode: [Unsecure \(HTTP\)](#)

[Download Certificate](#)

Select PEM Certificate
[Choose File](#) | No file chosen

[Upload Certificate](#)

Select PEM Private Key
[Choose File](#) | No file chosen

[Upload Private Key](#)

Use Custom Cert and Key:

Language: [English](#)

[Restart](#)

[Factory Reset](#)

[Save Settings and Restart](#)

About AVT

AVT FW Version: 2.0.0
AVT Model: 1
AVT UID: 540620856:1379094529:327726

Active Faults

ID	Description	Date & Time
----	-------------	-------------

[Clear Faults](#)

Change Password

current password:

new password:

Password Requirements:

- Between 8 and 40 characters.
- At least 1 Special Character (!@#%&'&*)
- At least one number.
- At least one capital letter.
- At least one lower case letter.

confirm new password:

Passwords do not match.

[Update Password](#)

Firmware Update

Select AVT Firmware
[Choose File](#) | No file chosen

[Update AVT](#)

Select Network Module Firmware
[Choose File](#) | No file chosen

[Update Network Module](#)

NETWORK MODULE SETTINGS
FIGURE 11. NETWORK MODULE SETTINGS CARD DETAILS

The screenshot shows the 'Network Module Settings' interface. It includes a 'Refresh' button (1), a 'Date & Time' section (2) with a 'Set Time' button (3), 'Network Module FW Version' (4), 'Use NTP Server' (5) checkbox, 'NTP Server Address' (6) field, 'Power System Configuration' (7) dropdown, 'Modbus' (8) checkbox, 'EtherNet/IP' (9) checkbox, 'DHCP' (10) checkbox, 'IP Address' (11) field, 'Netmask' field, 'Gateway' field, 'DNS1' field, 'DNS2' field, and 'Web Server Mode' (12) dropdown. There are sections for 'Download Certificate' (13), 'Select PEM Certificate' (14) with a 'Choose File' button, and 'Select PEM Private Key' (15) with a 'Choose File' button. A 'Use Custom Cert and Key' (16) checkbox and 'Language' (17) dropdown are also present. At the bottom, there are 'Restart' (18) and 'Factory Reset' (19) buttons, and a 'Save Settings and Restart' (20) button.

REFRESH 1
 Replace all data in fields with the last saved settings.

SAVE SETTINGS AND RESTART 20
 Saves modified settings and restarts the network module.

RESTART 18
 Restart the network module without saving changes to settings.

FACTORY RESET 19
 Reset the network module to factory default settings (see Table 4).
 NOTE: If the web application is unavailable, the network module can be physically reset by depressing the User Reset Button (refer to document no. B21148 VeriSafe Network Module Installation Requirements Manual under the System Overview Section for location on the Network Module).

TABLE 4.

1. Refresh	Replace all data in fields with the last saved settings
2. Date & Time	Displays current date and time associated with the network module.
3. Set Time	Applies local web browser time to the network module.
4. Network Module FW Version	Firmware version of the network module
5. Use NTP server	Check to enable the use of NTP (Network Time Protocol)
6. NTP server address	Enter server address to set time using NTP. Editable if Use NTP Server is checked.
7. Power System Configuration*	Configuration of the power system that the AVT is monitoring. To report accurate voltage data, the correct power system configuration must be selected. Default is Auto-Detect *
8. Modbus	Enable or disable the Modbus TCP interface (default enabled)
9. EtherNet/IP™	Enable or disable the EtherNet/IP™ interface (default enabled)
10. DHCP	Enable or disable DHCP (default disabled)
11. IP Address Netmask Gateway IP DNS1 DNS2	Current IP address, Netmask and Gateway IP (read-only when DHCP is enabled) DNS1 & DNS2 are always editable

Continued on next page

12. Web Server Mode	The web server can be configured for either HTTP or HTTPS (default is HTTPS)
13. Download Certificate	Download the network module certificate.
14. Upload PEM Certificate	Upload a user supplied PEM certificate (default uses on board PEM certificate)
15. Upload PEM Private Key	Upload a user supplied PEM private key (default uses on board PEM private key)
16. Use Custom Cert and Key	Check to enable use of the user supplied certificate and private key for HTTPS. Disabled if HTTPS is not selected for Web Server Mode.
17. Language	Select desired language from the drop-down menu. English, French, French (Canada), German, Italian, Korean, Spanish (Latin America), Chinese
18. Restart	Restart the network module without saving changes to settings
19. Factory Reset	Reset the network module to factory default settings
20. Save Settings and Restart	Saves modified settings and restarts the network module.

***POWER SYSTEM CONFIGURATION**


The AVT measures voltage between the sensor leads and ground leads and computes the associated phase-to-phase and RMS voltages. The voltage measurements are then reported to the network module.

To report accurate voltage data, the appropriate power system configuration must be selected. The Standard selection (default) assumes a wye or delta power system and is sufficient for most applications. If a special configuration (corner grounded delta, high-leg delta, and single-phase 3-wire) is desired, select the appropriate application from the drop-down menu.

ABOUT AVT

FIGURE 12. ABOUT AVT CARD DETAILS

Displays firmware version, model number and universal identifier (UID) of the AVT. Use the refresh button to update the card.



ACTIVE FAULTS

FIGURE 13. ACTIVE FAULTS CARD DETAILS

This card will display active faults in the network module. The fault information is updated automatically every 3 seconds. See Troubleshooting for additional information.



TABLE 5.

1. Faults

ID	Description
0	Network Module Hardware Failure. Flash code 2 during boot up
1	Power from the network module to the AVT is over the limit.
2	Indicate the network module has been reset to factory defaults
3	Data received from AVT was unable to be processed
4	Timeout while communicating with AVT
5	General SD card error
6	SD card is full
7	Time has not updated
8	Time not set
9	Web server could not load custom certificate

2. Clear Faults

The Clear Faults button allows the user to clear any faults on the network module. If the fault condition is still present then the fault may be presented after some time.

CHANGE PASSWORD

On initial login and factory reset the user will be prompted to change the password.

FIGURE 14.

Change Password

current password

new password

Password Requirements:

- Between 8 and 40 characters.
- At least 1 Special Character (@#%`'&*).
- At least one number.
- At least one capital letter.
- At least one lower case letter.

confirm new password

Passwords do not match.

Update Password

UPDATE FIRMWARE

Download the latest firmware at www.panduit.com

Select **Browse**, navigate to the firmware file, and click the appropriate **Update** button.. The firmware update process for both the network module and AVT should take approximately one minute.

FIGURE 15. UPDATE FIRMWARE CARD

Firmware Update

Select AVT Firmware

Browse... No file selected.

Update AVT 1

Select Network Module Firmware

Browse... No file selected.

Update Network Module 2

AVT Firmware Update 1

During a firmware update communication between the network module and the AVT will be temporarily lost. Upon successful update use the **About AVT** card refresh button to verify the firmware version matches what was downloaded.

About AVT

AVT FW Version	2.0.0
AVT Model	1
AVT UID	540620856:1379094529:327726

Network Module Firmware Update 2

Upon successful firmware update the network module will restart and you will be prompted to login.

DOCUMENTATION PAGE

This page provides the user with the information necessary to utilize the **EtherNet/IP™** (EDS file download) and Modbus TCP communications protocols. The web-application documentation page has the appropriate EDS file readily available. For all other information regarding the communication protocols, please refer to page 14 on this manual for the EtherNet/IP™ data model and page 19 for the Modbus TCP data model.

Data Item	Description
Date Time	Current date and time set in the gateway. Microseconds since epoch.
Battery Voltage	Last voltage reading of the AVT battery
Voltage Presence	Voltage Presence. Bits L3,L2,L1
Connectivity Status	Connected Status of each sensor lead L1, L2, L3, PE Ground during last test.
RMS Line Voltage L1 - G	RMS Voltage from L1 to Ground
RMS Line Voltage L2 - G	RMS Voltage from L2 to Ground
RMS Line Voltage L3 - G	RMS Voltage from L3 to Ground
Peak Line Voltage L1 - G	Peak Voltage from L1 to Ground
Peak Line Voltage L2 - G	Peak Voltage from L2 to Ground
Peak Line Voltage L3 - G	Peak Voltage from L3 to Ground
RMS Line Voltage L1 - L2	RMS Voltage from L1 to L2
RMS Line Voltage L1 - L3	RMS Voltage from L1 to L3
RMS Line Voltage L2 - L3	RMS Voltage from L2 to L3
Peak Line Voltage L1 - L2	Peak Voltage from L1 to L2
Peak Line Voltage L1 - L3	Peak Voltage from L1 to L3
Peak Line Voltage L2 - L3	Peak Voltage from L2 to L3
AVT Test Temperature	Temperature inside the AVT at the time of last AVT test (°C)
Disconnect State (Unused)	UNUSED
Status	Status bits associated with the network module and AVT.
AVT Result 1	Most recent Test Result of an AVT test.
AVT Result 2	Second Most recent Test Result of an AVT test.
AVT Result 1 Datetime	Datetime of AVT Result 1. Microseconds since epoch.
AVT Result 2 Datetime	Datetime of AVT Result 2. Microseconds since epoch.
Current Temperature	Current temperature inside the AVT (°C)
Activate AVT Test	Activates an AVT Test

SUPPORT PAGE

- Provides contact information and a link to the VeriSafe landing page on www.panduit.com
- Queries the AVT and network module for product information to assist in technical support.
- Contains a Licenses section outlining the Panduit License Agreement as well as the Web and System licenses used in the creation of this product.

FIGURE 16. SUPPORT PAGE

VeriSafe
Network Module

Pump 1

AVT Status

Data Logs

Settings

Documentation

Support

Logout

Support Information

[Verisafe Support Page](#)

Technical Support Email Address

North America	TechSupport@panduit.com
LATAM	TechSupportLATAM@panduit.com
EMEA	TechSupportEMEA@panduit.com
APAC	TechSupportAP@panduit.com

Customer Service Phone Number

North America	800-777-3300
Germany	+49 69 770626180
Ireland	0044-(0)208-6017219
Italy	0039-02-69633270
Netherlands	0031-(0)20-4874581
Belgium	0032-(0)2-714-31-42
Norway	0047-800-13602
Poland	0044-(0)208-6017238
United Kingdom	+44 208 601 7200
Brazil	(55 11)3280-6871
Mexico	01 800 360 86 00
Other LATAM Countries	1-708 532 1800 ext. 80502
Australia	1800-726384
China	400 820 1900
Hong Kong	800-965768
India	1800-103-3200
Indonesia	001-800-65-7571
Japan	81-3-68636060
Korea	02-2182-7300
Malaysia	1800-80-1435
Philippines/Vietnam	+65 93857800
Singapore	1800-7263848
Taiwan	0800-165-1487
Thailand	001-800-65-6285
Other APAC Countries	+65 9305 7575

Network Module FW Version	2.0.0
AVT FW Version	2.0.0
AVT Model	1
AVT UID	540620856.1379094529.327726

Licenses

[Panduit License Agreement](#)

[Web Licenses](#)

[System Licenses](#)

Data Models

The following data models will describe the parameters utilized in the EtherNet/IP™ and Modbus TCP communication protocols.

ETHERNET/IP™ DATA MODEL

- Network Module Unit Object (100~Decimal, 64~Hex - 1 Instance)
- All attribute IDs are in decimal value for each data item.
- All attribute IDs are Instance 1 except for the revision item located in the first row of the table.

Item Name	Description	Value Type (size bytes)	Range										
Revision (Instance 0)	Revision Number Attribute ID: 1 Access Rule: Get	UINT(2)	Data Value: 2										
Battery Voltage	Last voltage reading of the AVT battery (last test) Attribute ID: 1 Access Rule: Get	REAL(4)	0.0 to 4.0 V										
Date/Time	Current Date/Time set in the network module Attribute ID: 2 Access Rule: Get	ULINT(8)	microseconds since epoch										
Voltage Presence	Bit field status of the phase indicator LEDs (red LEDs) Attribute ID: 3 Access Rule: Get	WORD(2)	<table border="1"> <thead> <tr> <th>Bit</th> <th>Bit Name</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Present L1 POS</td> </tr> <tr> <td>1</td> <td>Present L2 NEG</td> </tr> <tr> <td>2</td> <td>Present L3</td> </tr> </tbody> </table> <p>0: Voltage not detected 1: Voltage detected</p>	Bit	Bit Name	0	Present L1 POS	1	Present L2 NEG	2	Present L3		
Bit	Bit Name												
0	Present L1 POS												
1	Present L2 NEG												
2	Present L3												
Connectivity Status	Connected status of each sensor lead L1, L2, L3, PE Ground during last test. Attribute ID: 4 Access Rule: Get	WORD(2)	<table border="1"> <thead> <tr> <th>Bit</th> <th>Bit Name</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Connected L1</td> </tr> <tr> <td>1</td> <td>Connected L2</td> </tr> <tr> <td>2</td> <td>Connected L3</td> </tr> <tr> <td>3</td> <td>Connected PE GND</td> </tr> </tbody> </table> <p>0: Sensor lead disconnected 1: Sensor lead connected</p>	Bit	Bit Name	0	Connected L1	1	Connected L2	2	Connected L3	3	Connected PE GND
Bit	Bit Name												
0	Connected L1												
1	Connected L2												
2	Connected L3												
3	Connected PE GND												

Continued on next page

Item Name		Description	Value Type (size bytes)	Range								
Line to Ground RMS Voltage	L1-G	L1 to Ground Attribute ID: 5 Access Rule: Get	INT(2)	0 to 1100 Vrms								
	L2-G	L2 to Ground Attribute ID: 6 Access Rule: Get										
	L3-G	L3 to Ground Attribute ID: 7 Access Rule: Get										
Line to Ground Peak Voltage	L1-G	L1 to Ground Attribute ID: 8 Access Rule: Get		INT(2)	0 to 1500 V							
	L2-G	L2 to Ground Attribute ID: 9 Access Rule: Get										
	L3-G	L3 to Ground Attribute ID: 10 Access Rule: Get										
Line to Line RMS Voltage	L1-L2	L1 to L2 Attribute ID: 11 Access Rule: Get			INT(2)	0 to 1100 Vrms						
	L1-L3	L1 to L3 Attribute ID: 12 Access Rule: Get										
	L2-L3	L2 to L3 Attribute ID: 13 Access Rule: Get										
Line to Line Peak Voltage	L1-L2	L1 to L2 Attribute ID: 14 Access Rule: Get		INT(2)		0 to 1500 V						
	L1-L3	L1 to L3 Attribute ID: 15 Access Rule: Get										
	L2-L3	L2 to L3 Attribute ID: 16 Access Rule: Get										
Test temperature	Temperature inside the AVT at the time of the last AVT test (°C) Attribute ID: 17 Access Rule: Get		-40°C to 85°C (-40°F to 185°F)									
Disconnect state [NOT IMPLEMENTED]	Disconnect phase open or closed Attribute ID: 18 Access Rule: Get	WORD(2)	<table border="1"> <thead> <tr> <th>Bit</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>L1 open</td> </tr> <tr> <td>1</td> <td>L2 open</td> </tr> <tr> <td>2</td> <td>L3 open</td> </tr> </tbody> </table> 0: Blade closed 1: Blade open		Bit	Description	0	L1 open	1	L2 open	2	L3 open
Bit	Description											
0	L1 open											
1	L2 open											
2	L3 open											

Continued on next page

Item Name	Description	Value Type (size bytes)	Range	
Status	Status bits associated with the network module and AVT Attribute ID: 19 Access Rule: Get	DWORD(4)	Bit	Bit Name
			0	Battery Warning Indicator 0: Battery OK 1: Check battery (low or not present)
			1	AVT Temperature Fault 0: OK 1: Fault
			2	AVT Power Source 0: Battery 1: Aux
			3	Phase Number 0: 3 Phase 1: Single phase
			4	User Threshold Triggered [NOT IMPLEMENTED] 0: Not triggered 1: Triggered If any user defined threshold is triggered this bit will go to active (1)
			5	Disconnect Module Present [NOT IMPLEMENTED] 0: No 1: Yes
			6	AVT Internal Fault 0: OK 1: Fault
7	Network Module Fault 0: OK 1: Fault			

Continued on next page

Item Name	Description	Value Type (size bytes)	Range																					
AVT Result 1	<p>Most recent test result of an AVT test</p> <p>Attribute ID: 20 Access Rule: Get</p>	WORD(2)	<table border="1"> <thead> <tr> <th data-bbox="1109 174 1237 216">Bit</th> <th data-bbox="1237 174 1529 216">Result</th> </tr> </thead> <tbody> <tr> <td data-bbox="1109 216 1237 296">0</td> <td data-bbox="1237 216 1529 296">Passed 0F</td> </tr> <tr> <td data-bbox="1109 296 1237 375">1</td> <td data-bbox="1237 296 1529 375">Battery Voltage Low 1F</td> </tr> <tr> <td data-bbox="1109 375 1237 455">2</td> <td data-bbox="1237 375 1529 455">Voltage Exceeded 2F</td> </tr> <tr> <td data-bbox="1109 455 1237 562">3</td> <td data-bbox="1237 455 1529 562">Temperature not in range 3F</td> </tr> <tr> <td data-bbox="1109 562 1237 709">4</td> <td data-bbox="1237 562 1529 709">Connectivity not Confirmed 4F</td> </tr> <tr> <td data-bbox="1109 709 1237 789">5</td> <td data-bbox="1237 709 1529 789">Diagnostic 5 5F</td> </tr> <tr> <td data-bbox="1109 789 1237 869">6</td> <td data-bbox="1237 789 1529 869">Diagnostic 6 6F</td> </tr> <tr> <td data-bbox="1109 869 1237 949">7</td> <td data-bbox="1237 869 1529 949">Diagnostic 7 7F</td> </tr> <tr> <td data-bbox="1109 949 1237 1037">8</td> <td data-bbox="1237 949 1529 1037">Diagnostic 8 8</td> </tr> </tbody> </table>	Bit	Result	0	Passed 0F	1	Battery Voltage Low 1F	2	Voltage Exceeded 2F	3	Temperature not in range 3F	4	Connectivity not Confirmed 4F	5	Diagnostic 5 5F	6	Diagnostic 6 6F	7	Diagnostic 7 7F	8	Diagnostic 8 8	<p>#F indicates the number of flashes that will be seen on the AVT indicator module for this error code</p> <p>0: false 1: true</p>
Bit	Result																							
0	Passed 0F																							
1	Battery Voltage Low 1F																							
2	Voltage Exceeded 2F																							
3	Temperature not in range 3F																							
4	Connectivity not Confirmed 4F																							
5	Diagnostic 5 5F																							
6	Diagnostic 6 6F																							
7	Diagnostic 7 7F																							
8	Diagnostic 8 8																							

Continued on next page

Item Name	Description	Value Type (size bytes)	Range	
			Bit	Result
AVT Result 2	Second most recent test result of an AVT test Attribute ID: 21 Access Rule: Get	WORD(2)	0	Passed 0F
			1	Battery Voltage Low 1F
			2	Voltage Exceeded 2F
			3	Temperature not in range 3F
			4	Connectivity not Confirmed 4F
			5	Diagnostic 5 5F
			6	Diagnostic 6 6F
			7	Diagnostic 7 7F
			8	Diagnostic 8 8
			#F indicates the number of flashes that will be seen on the AVT indicator module for this error code 0: false 1: true	
AVT Result 1 Date/Time	Date/Time of AVT result 1 Attribute ID: 22 Access Rule: Get	ULINT(8)	Microseconds since epoch	
AVT Result 2 Date/Time	Date/Time of AVT result 2 Attribute ID: 23 Access Rule: Get	ULINT(8)	Microseconds since epoch	
Current Temperature	Current Temperature inside the AVT (°C) Attribute ID: 24 Access Rule: Get	INT(2)	-40°C to 85°C (-40°F to 185°F)	
Activate AVT Test	Starts the absence of voltage test Attribute ID: 25 Access Rule: Get/Set	DINT(4)	0: Test not activated 1: Test activated	

MODBUS TCP DATA MODEL

INPUT DATA

All values are contained in input registers (offset 30000).

Input Data Item	Description	Value Type (size bytes)	Range										
Date/Time	<p>Current Date/Time set in the network module</p> <p>Start Address: 1 End Address: 4</p>	uint64_t(8)	Microseconds since epoch										
Battery Voltage	<p>Last voltage reading of the AVT battery (last test)</p> <p>Start Address: 5 End Address: 6</p>	float(4)	0.0 to 4.0 V										
Voltage Presence	<p>Bit field status of the phase indicator LEDs (red LEDs)</p> <p>Start Address: 7 End Address: 7</p>	uint16_t(2)	<table border="1"> <thead> <tr> <th>Bit</th> <th>Bit Name</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Present L1 POS</td> </tr> <tr> <td>1</td> <td>Present L2 NEG</td> </tr> <tr> <td>2</td> <td>Present L3</td> </tr> </tbody> </table> <p>0: Voltage not detected 1: Voltage detected</p>	Bit	Bit Name	0	Present L1 POS	1	Present L2 NEG	2	Present L3		
Bit	Bit Name												
0	Present L1 POS												
1	Present L2 NEG												
2	Present L3												
Connectivity Status	<p>Connected status of each sensor lead L1, L2, L3, PE Ground during last test.</p> <p>Start Address: 8 End Address: 8</p>	uint16_t(2)	<table border="1"> <thead> <tr> <th>Bit</th> <th>Bit Name</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Connected L1</td> </tr> <tr> <td>1</td> <td>Connected L2</td> </tr> <tr> <td>2</td> <td>Connected L3</td> </tr> <tr> <td>3</td> <td>Connected PE GND</td> </tr> </tbody> </table> <p>0: Sensor lead disconnected 1: Sensor lead connected</p>	Bit	Bit Name	0	Connected L1	1	Connected L2	2	Connected L3	3	Connected PE GND
Bit	Bit Name												
0	Connected L1												
1	Connected L2												
2	Connected L3												
3	Connected PE GND												

Continued on next page

Input Data Item		Description	Value Type (size bytes)	Range											
Line to Ground RMS Voltage	L1-G	L1 to Ground Start Address: 9 End Address: 9	int16_t(2)	0 to 1100 Vrms											
	L2-G	L2 to Ground Start Address: 10 End Address: 10													
	L3-G	L3 to Ground Start Address: 11 End Address: 11													
Line to Ground Peak Voltage	L1-G	L1 to Ground Start Address: 12 End Address: 12		int16_t(2)	0 to 1500 V										
	L2-G	L2 to Ground Start Address: 13 End Address: 13													
	L3-G	L3 to Ground Start Address: 14 End Address: 14													
Line to Line RMS Voltage	L1-L2	L1 to L2 Start Address: 15 End Address: 15			int16_t(2)	0 to 1100 Vrms									
	L1-L3	L1 to L3 Start Address: 16 End Address: 16													
	L2-L3	L2 to L3 Start Address: 17 End Address: 17													
Line to Line Peak Voltage	L1-L2	L1 to L2 Start Address: 18 End Address: 18				int16_t(2)	0 to 1500 V								
	L1-L3	L1 to L3 Start Address: 19 End Address: 19													
	L2-L3	L2 to L3 Start Address: 20 End Address: 20													
Test temperature	Temperature inside the AVT at the time of the last AVT test (°C) Start Address: 21 End Address: 21						-40°C to 85°C (-40°F to 185°F)								
Disconnect state [NOT IMPLEMENTED]	Disconnect phase open or closed Start Address: 22 End Address: 22	uint16_t(2)	<table border="1"> <thead> <tr> <th>Bit</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>L1 open</td> </tr> <tr> <td>1</td> <td>L2 open</td> </tr> <tr> <td>2</td> <td>L3 open</td> </tr> </tbody> </table>				Bit	Description	0	L1 open	1	L2 open	2	L3 open	0: Blade Closed 1: Blade Opened
Bit	Description														
0	L1 open														
1	L2 open														
2	L3 open														

Continued on next page

Input Data Item	Description	Value Type (size bytes)	Range	
			Bit	Bit Name
Status	Status bits associated with the network module and AVT Start Address: 23 End Address: 24	uint32_t(4)	0	Battery Warning Indicator 0: Battery OK 1: Check battery (low or not present)
			1	AVT Temperature Fault 0: OK 1: Fault
			2	AVT Power Source 0: Battery 1: Aux
			3	Phase Number 0: 3 Phase 1: Single phase
			4	User Threshold Triggered [NOT IMPLEMENTED] 0: Not triggered 1: Triggered If any user defined threshold is triggered this bit will go to active (1)
			5	Disconnect Module Present [NOT IMPLEMENTED] 0: No 1: Yes
			6	AVT Internal Fault 0: OK 1: Fault
			7	Network Module Fault 0: OK 1: Fault

Continued on next page

Input Data Item	Description	Value Type (size bytes)	Range	
AVT Result 1	Most recent test result of an AVT test Start Address: 25 End Address: 25	uint16_t(2)	Bit	Result
			0	Passed 0F
			1	Battery Voltage Low 1F
			2	Voltage Exceeded 2F
			3	Temperature not in range 3F
			4	Connectivity not Confirmed 4F
			5	Diagnostic 5 5F
			6	Diagnostic 6 6F
			7	Diagnostic 7 7F
8	Diagnostic 8 8			
#F indicates the number of flashes that will be seen on the AVT indicator module for this error code 0: false 1: true				

Continued on next page

Input Data Item	Description	Value Type (size bytes)	Range	
			Bit	Result
AVT Result 2	Second most recent test result of an AVT test Start Address: 26 End Address: 26	uint16_t(2)	0	Passed 0F
			1	Battery Voltage Low 1F
			2	Voltage Exceeded 2F
			3	Temperature not in range 3F
			4	Connectivity not Confirmed 4F
			5	Diagnostic 5 5F
			6	Diagnostic 6 6F
			7	Diagnostic 7 7F
			8	Diagnostic 8 8
			#F indicates the number of flashes that will be seen on the AVT indicator module for this error code 0: false 1: true	
AVT Result 1 Date/Time	Date/Time of AVT result 1 Start Address: 27 End Address: 30	uint64_t(8)	Microseconds since epoch	
AVT Result 2 Date/Time	Date/Time of AVT result 2 Start Address: 31 End Address: 34	uint64_t(8)	Microseconds since epoch	
Current Temperature	Current Temperature inside the AVT (°C) Start Address: 35 End Address: 35	int16_t(2)	-40°C to 85°C (-40°F to 185°F)	
Data Model Version	Version number of the data model Start Address: 36 End Address: 36	int16_t(2)	Data Value: 2	

OUTPUT DATA

Output Coils Available (offset 0)

Output Coil	Description	Bit Number
Activate AVT Test	0: Coil resets to 0 once test is complete 1: Activates an AVT test	1

Rockwell Automation Integration

The **EtherNet/IP™** protocol is supplemented by an Add-On Profile (AOP) for easy integration with products from Rockwell Automation. The AOP supports the Automatic Diagnostics feature.

- AOP available in Studio 5000 Logix Designer V33.01 or greater

AUTOMATIC DIAGNOSTIC AOP ITEMS

REQUIREMENTS

- Logix controller must be V33 or greater
- Factory Talk View software must be V12 or greater

CONNECTIVITY STATUS

WORD(2)

- Sensor lead status is based on the last completed test. This value will only be updated when a test is completed with no voltage present.

TABLE 6.

		Bit			
		0	1	2	3
Diagnostic Message	Connectivity Status	Connected L1	Connected L2	Connected L3	Connected PE GND
	Diagnostic Message	0: L1 Sensor lead disconnected 1: L1 Sensor lead connected	0: L2 Sensor lead disconnected 1: L2 Sensor lead connected	0: L3 Sensor lead disconnected 1: L3 Sensor lead connected	0: PE GND Sensor lead disconnected 1: PE GND Sensor lead connected

STATUS

DWORD(4)

- Status bits associated with the network module and AVT. This value will only be updated when an absence of voltage test is completed.

TABLE 7.

		Bit			
		0	1	6	7
Diagnostic Message	Status	Battery Warning Indicator 0: Battery OK 1: Check battery (Battery low or not present)	AVT Temperature Fault 0: OK 1: Fault	AVT Internal Fault 0: OK 1: Fault	Network Module Fault 0: OK 1: Fault
	Diagnostic Message	0: Battery OK 1: Check battery	0: AVT temperature OK 1: AVT temperature fault	0: AVT OK 1: AVT Internal fault	0: Network module OK 1: Network module fault

AVT RESULT 1

WORD(2)

- Most recent test result of an AVT test
 - This report has the following possible bit states to indicate a passed test or the reason for a failed AVT test

TABLE 8.

		Bit				
		0	1	2	3	4
AVT Result 1	Passed 0F	Battery voltage low 1F	Voltage exceeded 2F	Temperature not in range 3F	Connectivity not confirmed 4F	
Diagnostic Message	0: AVT test failed 1: AVT test passed	0: OK 1: AVT battery low	0: OK 1: Voltage exceeds AVT limits	0: OK 1: AVT temperature outside supported range	0: OK 1: AVT sensor lead disconnected	
		Bit continued				
		5	6	7	8	
AVT Result 1	Diagnostic 5 5F	Diagnostic 6 6F	Diagnostic 7 7F	Diagnostic 8		
Diagnostic Message	0: OK 1: AVT diagnostic 5	0: OK 1: AVT diagnostic 6	0: OK 1: AVT diagnostic 7	0: OK 1: AVT diagnostic 8		

Security

The Network Module contains software that stores user entered data. All data entered by the user is stored in non-volatile storage on the system running the software.

NON-VOLATILE STORAGE

- The Network Module uses non-volatile storage to store all configuration information.

AUTHENTICATION DATA

- Passwords used for managing the software are stored as a one way bcrpyt hash.
- Passwords that the user enters are not returned to the customer.
(They are 'write only' from a user perspective)

NETWORK TRANSPORT SECURITY

- The product generates a random SSH RSA 2048-bit private host key the first time the product starts up.
- The product has a randomly generated RSA 2048-bit private key configured by the factory. This key is used to generate a HTTPS certificate the first time the product boots up.
- The user may upload a custom HTTPS certificate and private key.
 - The HTTPS certificate should use a SHA-256 signature.
 - The private key should be RSA 2048-bit or prime256v1 (SECP256R1).
 - Other private key types may work, but performance may be negatively impacted if greater private key sizes are used: RSA 3072-bit, RSA 4096-bit; ECC curves: SECP192R1, SECP224R1, SECP256R1, SECP384R1, SECP521R1, SECP192K1, SECP224K1, SECP256K1, BP256R1, BP384R1, BP512R1, CURVE25519.
- The product uses TLS 1.2 to communicate with HTTPS browser clients.
- Secure communication cipher negotiation with HTTPS clients uses these Cipher Suites:
 - Cipher Suite: TLS_ECDHE_ECDSA_WITH_AES_128_GCM_SHA256 (0xc02b)
 - Cipher Suite: TLS_ECDHE_RSA_WITH_AES_128_GCM_SHA256 (0xc02f)
 - Cipher Suite: TLS_ECDHE_ECDSA_WITH_AES_256_GCM_SHA384 (0xc02c)
 - Cipher Suite: TLS_ECDHE_RSA_WITH_AES_256_GCM_SHA384 (0xc030)
 - Cipher Suite: TLS_ECDHE_ECDSA_WITH_CHACHA20_POLY1305_SHA256 (0xcca9)
 - Cipher Suite: TLS_ECDHE_RSA_WITH_CHACHA20_POLY1305_SHA256 (0xcca8)
 - Cipher Suite: TLS_DHE_RSA_WITH_AES_128_GCM_SHA256 (0x009e)
 - Cipher Suite: TLS_DHE_RSA_WITH_AES_256_GCM_SHA384 (0x009f)

NETWORK CONFIGURATION DATA

- Network Configuration, including Static IP addresses and addresses obtained by DHCP are exposed on a "Settings" page, to aid in network management of the product.

SECURE BOOT PROTECTION

- The product uses industry standard code signature algorithms to protect firmware booted by the device.
- A signature block is appended to the bootloader.
- The signature block contains a signature of the bootloader and the RSA 3072-bit public key.
- A digest of the RSA 3072-bit public key is stored in a write-once eFuse (which cannot be read or written to after being set) and used to verify the signature block.
- The public key signature is verified against the signature block and a digest of the bootloader to establish authenticity and integrity of the bootloader.
- The bootloader continues the chain of trust by verifying the authenticity and integrity of the application executable, by applying the same algorithm as used by the ROM bootloader to load the bootloader.

FIRMWARE UPDATE PROTECTION

- The product uses industry standard cryptography to verify a firmware update package, to establish authenticity and integrity.
- The package contains a manifest that describes items contained in the package payload.
- The items are described as a chunk size and a SHA256 hash of each sub-item and the payload container in the package.
- The manifest is hashed using SHA256 and signed using an RSA 4096 bit key.
- The package contains the signature of the hash of the manifest.
- The package contains a payload container holding the sub-items.
- The signature of the payload is verified before parsing the content of the manifest or the payload.

OTHER FEATURES

- The product includes a real-time clock and a capacitor that maintains time for a short amount of time when no power is applied. When combined with NTP, accurate timestamps on logs are provided.

Troubleshooting

FAULTS

When a fault is active the user will also see an exclamation point in the left sidebar and in the active faults menu of the settings page

Fault	Troubleshooting
Hardware Failure (0)	Contact Panduit support
Network module system status indicator 2 flash error code	
Power over limit (1)	<ul style="list-style-type: none">Power from the Network Module to the AVT is over the limit.Check AVT connection to the Network Module for proper termination.
Settings files reset to factory defaults(2)	Expected if new unit or user initiated a factory reset, do nothing in this case If repeatedly occurs replace unit
Data received from AVT was unable to be processed (3) Timeout while communicating with AVT (4)	<ul style="list-style-type: none">Check AVT connection to the Network ModuleCheck that the AVT and Network module termination resistor switches are positioned to the right (factory default) when facing the port. Refer to document no. B21148 (VeriSafe Network Module Installation Requirements Manual under the System Overview Section)Move AVT connection cable away from possible noise sourcesEnsure the Network Module and AVT have the latest firmware installed. This can be checked on the Network Module Settings Page.
SD card error (5)	Contact Panduit for support around SD Card errors and possibly reseating or replacing the SD Card.
SD card full (6)	download logs (if necessary) and then delete logs from the web interface. restart the unit and confirm the system is able to log.
Stale Time (7)	Check NTP server can be reached from device location
Time not set (8)	Set time using the settings page (set time button or NTP time setup)
Could not load custom certificate(9)	Check that the certificate was generated properly and upload again.

CLEARING FAULTS

The user has the ability to clear active faults (see **Settings Page** under the **Active Faults** section). If the network module determines the fault is still active it will repopulate. To verify a fault has been cleared restart the network module.

Warranty

PANDUIT LIMITED PRODUCT WARRANTY

- 1. Limited Product Warranty.** For purposes of this Limited Product Warranty, “**Panduit products**” mean all Panduit-branded products that Panduit sells. Unless a different time period is set forth in the Panduit product manual, user guide or other product documentation, Panduit warrants that the Panduit product, and each part or component of the Panduit product, will comply with Panduit’s published specifications and will be free from defects in material and workmanship for a period of 1 year from the date of invoice from Panduit or its authorized distributor, not to exceed 18 months from the original date of shipment from Panduit’s facility.
- 2. Firmware.** Unless otherwise provided in a separate license agreement, and subject to the limitations for third-party products set forth below, Panduit warrants that any firmware contained in any Panduit products, when used with Panduit-specified hardware and when installed properly, will perform in accordance with the Panduit published specifications for a period of 1 year from the date of invoice from Panduit or its authorized distributor, not to exceed 18 months from the original date of shipment from Panduit’s facility. Any exceptions to this 1 year warranty period will be identified in the Panduit product manual, user guide or other product documentation. Panduit does not warrant that the operation of the firmware will be uninterrupted or error-free, or that the functions contained therein will meet or satisfy Buyer’s intended use or requirements. Any warranties, if any, that Panduit provides for any standalone software that Panduit sells will be stated in the applicable End User License Agreement.
- 3. Remedies.** Panduit’s sole and exclusive obligation and Buyer’s exclusive remedy under this warranty is Panduit’s repair or replacement of the defective Panduit product. Panduit shall have sole discretion as to which of these remedies Panduit will provide to Buyer. Buyer requested on-site warranty service is not covered and will be at Buyer’s sole expense, unless authorized in writing by Panduit in advance of the commencement of the on-site warranty service. Panduit has the right to either examine the Panduit products where they are located or, in its sole discretion, issue shipping instructions for return of the product. Where applicable, Buyer must return the defective product, part or component, transportation prepaid to Panduit’s customer service department accompanied by Panduit’s Return Material Authorization. If Panduit confirms that there is a defect that is covered by this warranty, the repaired or replaced Panduit product will be warranted for the remainder of the warranty period applicable to the originally shipped Panduit product, or for a period of 90 days from the date of shipment to Buyer, whichever is longer.
- 4. No Warranty for Third-Party Products.** Panduit makes no representations and disclaims all warranties of any kind, express or implied relative to any third-party product or services, including any third-party software or firmware, which may be incorporated into a Panduit product and/or resold or sublicensed by Panduit. To the extent any warranties extended to Panduit by the third-party manufacturer are transferable, Panduit will transfer such warranties to Buyer and any enforcement of such third-party warranties shall be between the Buyer and the third-party. Panduit does not warrant the compatibility of the Panduit products with the products of other manufacturers or Buyer’s application except to the extent expressly represented in Panduit’s published specifications or written quotation.
- 5. Exclusions.** Before using, Buyer shall determine the suitability of the Panduit product for his intended use and Buyer assumes all risk and liability whatsoever in connection therewith. The warranties contained herein shall not apply to any Panduit products that have been subjected to misuse, neglect, improper storage, handling, installation or accidental damage or modified or altered by persons other than Panduit or persons authorized by Panduit. In addition, the firmware warranty does not cover any defects resulting from Buyer-supplied firmware or unauthorized interfacing, operation outside of the environmental specifications for the products, or improper or inadequate site preparation or maintenance by Buyer. Panduit products are not designed, intended or authorized to be used in medical applications or as components in medical devices that are used to sustain or support human life. Should Buyer purchase or use a Panduit product for any such unintended or unauthorized medical application, Buyer shall indemnify and hold Panduit harmless from any liability or damage whatsoever arising out of the use of Panduit products in such medical applications.
- 6. LIMITATION ON LIABILITY. THE WARRANTIES PROVIDED HEREIN ARE BUYER’S SOLE AND EXCLUSIVE WARRANTIES. ALL IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR USE ARE DISCLAIMED. TO THE EXTENT PERMITTED BY LAW, IN NO EVENT SHALL PANDUIT BE LIABLE FOR ANY LOSS OR DAMAGES ARISING FROM ANY PANDUIT PRODUCT WHETHER DIRECT, INDIRECT, CONSEQUENTIAL, INCIDENTAL OR SPECIAL, INCLUDING WITHOUT LIMITATION ANY CLAIM FOR LOSS OF DATA, LOSS OF ACTUAL OR ANTICIPATED REVENUE, PROFITS OR SAVINGS.**
- 7. General.** This Limited Product Warranty applies to the Panduit products only and not to any combination or assembly of the Panduit products. Nothing in this Limited Product Warranty shall be construed to provide Buyer with a warranty for any system implementation using Panduit products. The Panduit Certification Plus System Warranty is available for projects that are installed by Panduit Certified Installers, meet various requirements and are registered with Panduit in accordance with the terms of the Panduit Certification Plus System Warranty.