

# PANDUIT®

Instructions



Label Printer

# DP4300HD

MADE IN GERMANY

## Instruction for the following products

Family	Type
DP	DP4300HD
	DP4300HD/E

**Edition:** 06/2024 - **Part No.** DP4300HD-MAN-EN

### Copyright

This documentation as well as translation hereof are property of Panduit Corporation.

The replication, conversion, duplication or divulgement of the whole manual or parts of it for other intentions than its original intended purpose demand the previous written authorization by Panduit Corporation.

### Trademark

Windows is a registered trademark of the Microsoft Corporation.

For more information see [www.panduit.com](http://www.panduit.com).

### Editor

Regarding questions or comments please contact Panduit Corporation.

### Topicality

Due to the constant further development of our products discrepancies between documentation and product can occur.

Please check [www.panduit.com](http://www.panduit.com) for the latest update.

### Terms and conditions

Deliveries and performances are effected under the General conditions of sale of Panduit Corporation.

---

## Panduit SERVICE CONTACTS

### USA & Canada

Phone 1-866-871-4571

[Email\\_GA-Techsupport@panduit.com](mailto:Email_GA-Techsupport@panduit.com)

### Asia Pacific

Phone 65-6305-7575

[email\\_TechSupportAP@panduit.com](mailto:email_TechSupportAP@panduit.com)

### Latin America

Phone 1-708-532-1800

[Email\\_TechSupportLatAm@panduit.com](mailto:Email_TechSupportLatAm@panduit.com)

### Japan

Phone 81-3-6863-6060

[TechSupportAP@panduit.com](mailto:TechSupportAP@panduit.com)

### Europe/Middle East

Phone +31 -546-580-452

[Email\\_TechSupportEMEA@panduit.com](mailto:Email_TechSupportEMEA@panduit.com)

### Australia

Phone 613-9794-9020

[TechSupportAP@panduit.com](mailto:TechSupportAP@panduit.com)

<b>1</b>	<b>Introduction .....</b>	<b>4</b>
1.1	Instructions .....	4
1.2	Intended Use .....	4
1.3	Safety Instructions .....	5
1.4	Environment .....	5
<b>2</b>	<b>Installation .....</b>	<b>6</b>
2.1	Device Overview .....	6
2.2	Unpacking and Setting-up the Printer .....	8
2.3	Installing the Wi-Fi stick - Optional .....	8
2.4	Connecting the Device .....	9
2.4.1	Connecting to the Power Supply .....	9
2.4.2	Connecting to a Computer or Computer Network .....	9
2.5	Switching on the Device .....	9
<b>3</b>	<b>Touchscreen Display .....</b>	<b>10</b>
3.1	Start Screen .....	10
3.2	Navigation in the Menu .....	12
<b>4</b>	<b>Loading Material .....</b>	<b>13</b>
4.1	Loading Media from Roll .....	13
4.1.1	Positioning the Media Roll on the Roll Retainer .....	13
4.1.2	Inserting Media into the Print Mechanics .....	14
4.1.3	Setting the Label Sensor .....	15
4.1.4	Setting the Head Locking Systems .....	15
4.2	Loading Transfer Ribbon .....	16
4.3	Setting the Feed Path of the Transfer Ribbon .....	17
<b>5</b>	<b>Operation .....</b>	<b>18</b>
5.1	Printhead Protection .....	18
5.2	Single Side Printing .....	18
5.3	Ribbon Saving .....	18
5.4	Cutting and Perforating .....	18
5.5	Avoiding Loss of Data .....	18
5.6	Avoiding Loss of Material .....	19
<b>6</b>	<b>Cleaning .....</b>	<b>20</b>
6.1	Cleaning Information .....	20
6.2	Cleaning the Printheads .....	20
6.3	Cleaning the Label Sensor .....	21
<b>7</b>	<b>Fault Correction .....</b>	<b>22</b>
7.1	Error Display .....	22
7.2	Error Messages and Fault Correction .....	23
7.3	Problem Solution .....	25
<b>8</b>	<b>Approvals .....</b>	<b>26</b>
<b>9</b>	<b>Index .....</b>	<b>27</b>

## 1.1 Instructions

Important information and instructions in this documentation are designated as follows:

**Danger!**

Draws attention to an exceptionally great, imminent danger to your health or life due to hazardous voltages.

**Danger!**

Draws attention to a danger with high risk which, if not avoided, may result in death or serious injury.

**Warning!**

Draws attention to a danger with medium risk which, if not avoided, may result in death or serious injury.

**Caution!**

Draws attention to a danger with low risk which, if not avoided, may result in minor or moderate injury.

**Attention!**

Draws attention to potential risks of property damage or loss of quality.

**Note!**

Advice on how to make work easier or an important step to be carried out.

**Environment!**

Gives you tips on protecting the environment.



Handling instruction



Reference to section, position, illustration number or document.



Option (accessories, peripheral equipment, special fittings).

*Time*

Information in the display.

## 1.2 Intended Use

- The device is manufactured in accordance with the current technology standards and the recognized safety rules. However, danger to the life and limb of the user or third parties and/or damage to the device and other tangible assets can arise during use.
- The device may only be used for its intended purpose and if it is in perfect working order, and it must be used with regard to safety and dangers as stated in the operating manual.
- The device printer is intended exclusively for printing suitable materials. Any other use or use going beyond this shall be regarded as improper use. The manufacturer/supplier shall not be liable for damage resulting from unauthorized use; the user shall bear the risk alone.
- Usage for the intended purpose also includes complying with this manual.

### 1.3 Safety Instructions

- The device is configured for voltages of 100 to 240 V AC. It only has to be plugged into a grounded socket.
- Only connect the device to other devices which have a protective low voltage.
- Switch off all affected devices (computer, printer, accessories) before connecting or disconnecting.
- The device may only be used in a dry environment, do not expose it to moisture (sprays of water, mists, etc.).
- Do not use the device in an explosive atmosphere.
- Do not use the device close to high-voltage power lines.
- If the device is operated with the cover open, ensure that people's clothing, hair, jewelry etc. do not come into contact with the exposed rotating parts.
- The device or parts of it can become hot while printing. Do not touch during operation, and allow to cool down before changing material and before disassembly.
- Risk of crushing when closing the cover. Touch the cover at the outside only. Do not reach into the swivel range of the cover.
- Perform only those actions described in this operating manual.  
Work going beyond this may only be performed by trained personnel or service technicians.
- Unauthorized interference with electronic modules or their software can cause malfunctions.
- Other unauthorized work on or modifications to the device can also endanger operational safety.
- Always have service work done in a qualified workshop, where the personnel have the technical knowledge and tools required to do the necessary work.
- There are various warning stickers on the device. They draw your attention to dangers.  
Warning stickers must therefore not be removed, as then you and other people cannot be aware of dangers and may be injured.
- The maximum sound pressure level is less than 70 dB(A).

**Danger!**

**Danger to life and limb from power supply.**

- Do not open the device casing.

**Warning!**

**This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.**

### 1.4 Environment



Obsolete devices contain valuable recyclable materials that should be sent for recycling.

- Send to suitable collection points, separately from residual waste.

The modular construction of the printer enables it to be easily disassembled into its component parts.

- Send the parts for recycling.



The electronic circuit board of the device is equipped with a lithium battery.

- Take old batteries to collection boxes in shops or public waste disposal centers.

## 2.1 Device Overview




Figure 1 Overview




Figure 2 Print mechanism - upper print unit




Figure 3 Print mechanism - lower print unit




Figure 4 Connections

## 2.2 Unpacking and Setting-up the Printer

- ▶ Lift the label printer out of the box.
- ▶ Check label printer for damage which may have occurred during transport.
- ▶ Set up printer on a level surface.
- ▶ Remove foam transportation safeguards near the printhead.
- ▶ Check delivery for completeness.

Contents of delivery:

- Printer
- USB Cord
- USB Flash Drive
- Quick start guide
- Warranty card
- Knife
- 2 Rolls of Panduit Hybrid Ribbon
- 2 Spare Ribbon cores
- Power supply Cord US (DP4300HD)
- Power supply Cord Europe (DP4300HD/E)
- Power supply Cord Swiss (DP4300HD/E)
- Power supply Cord UK (DP4300HD/E)



### Note!

Please keep the original packaging in case the printer must be returned.



### Attention!

The device and printing materials will be damaged by moisture and wetness.

- ▶ Set up label printers only in dry locations protected from splash water.

## 2.3 Installing the Wi-Fi stick - Optional




Figure 5 Installing the Wi-Fi stick

- ▶ Remove the cover (1) with the Allen key (2).
- ▶ Connect the Wi-Fi stick (4) to the USB interface (3) in the control panel.



## **2.4 Connecting the Device**

The standard available interfaces and connectors are shown in Figure 4.

### **2.4.1 Connecting to the Power Supply**

The printer is equipped with a wide area power unit. The device can be operated with a supply voltage of 230 V~/50 Hz or 115 V~/60 Hz without adjustment.

1. Check that the device is switched off.
2. Plug the power cable into the power connection jack (33).
3. Plug the power cable into a grounded socket.

### **2.4.2 Connecting to a Computer or Computer Network**



#### **Attention!**

**Loss of material!**

The RS232 interface is unsuitable for fast transmission of changing data ▷ 5.6 on page 19.

- ▶ Use USB or Ethernet interface for print operation.



#### **Attention!**

Inadequate or no grounding can cause malfunctions during operations.

Ensure that all computers and cables connected to the label printer are grounded.

- ▶ Connect the label printer to a computer or network by a suitable cable.

For details of the configuration of the individual interfaces ▷ Configuration Manual.

## **2.5 Switching on the Device**

When all connections have been made:

- ▶ Switch the printer on at the power switch (32).  
The printer performs a system test, and then shows *Ready* in the display (2).

The user can control the operation of the printer with the touchscreen display, for example:

- Issuing, interrupting, continuing and canceling print jobs,
- Setting printing parameters, e.g. heat level of the printhead, print speed, interface configuration, language and time of day (▷ Configuration Manual),
- Control stand-alone operation with a memory module (▷ Configuration Manual),
- Update the firmware (▷ Configuration Manual).

Many functions and settings can also be controlled by software applications or by direct programming with a computer using the printer's own commands. ▷ Programming Manual for details.

Settings made on the touchscreen display make the basic settings of the label printer.



#### Note!

It is advantageous, whenever possible, to make adaptations to various print jobs in the software.

### 3.1 Start Screen




Figure 6 Start screen

The touchscreen display is operated directly by touch:

- To open a menu or select a menu item lightly touch the corresponding symbol.
- To scroll in lists slide finger up or down on the display.

	Open the menu		Repeat the last printed label
	Interrupt the print job		Short touch: Cancel the current print job Long touch: Cancel all print jobs
	Continue the print job		Feed a blank label

Table 1 Symbols on the start screen



#### Note!

Inactive symbols are shaded.

With special software or hardware configurations additional symbols appear on the start screen:




Figure 7 Optional symbols on the start screen

	Release printing of a single label within a print job including peeling-off, cutting...		Release a direct cut without media feed
--	---	--	---

Table 2 Optional symbols on the start screen

In the headline several information are displayed as widgets depending on the configuration:




Figure 8 Widgets in the start screen

	Displays the current data transfer in the form of a falling drop.
	The <i>Save data stream</i> function is active ▷ Configuration manual All received data are stored in a .lbl file.
	Warning ribbon end ▷ Configuration manual The remaining diameter of the ribbon supply roll undershoots the set value.
	SD card installed
	USB memory installed
	WiFi connection active The WiFi strength is displayed by the number of white arcs.
	Ethernet connection active
	USB connection active
	Clock time

Table 3 Widgets in the start screen

## 3.2 Navigation in the Menu







Figure 9 Menu levels

- ▶ To open the menu select  on the start screen.
- ▶ Select a theme in the selection level.  
Several themes have substructures again with selection levels.  
To return from the current level to the upper one select . To leave the menu select .
- ▶ Continue the selection until the parameter/function level is reached.
- ▶ Start a function. The function may only start after a preparatory dialog.  
- or -  
Select a parameter to set. The setup possibilities are depending from the parameter type.




Figure 10 Samples for parameter setting








	Scroll bar for rough value setting
	Decreasing the value step-by-step
	Increasing the value step-by-step
	Return without saving the setting
	Return with saving the setting
	Parameter is disabled, touching enables the parameter
	Parameter is enabled, touching disables the parameter

Table 4 Buttons for parameter setting

**Note!**

For adjustments and simple installation work, use the accompanying Allen key located in the upper section of the print unit. No other tools are required for the work described here.




**4.1 Loading Media from Roll****4.1.1 Positioning the Media Roll on the Roll Retainer**

Figure 11 Loading media from roll

1. Open cover.
2. Turn ring (6) counterclockwise, so that the arrow (5) points to the symbol .
3. Remove the margin stop (4) from the roll retainer (3).
4. Load label roll (2) on the roll retainer (3).
5. Re-mount the margin stop (4) onto the roll retainer (3). Push the margin stop (4) until both margin stops (1,4) touch the label roll (2) and a clear resistance is encountered.
6. Turn ring (6) clockwise, so that the arrow (5) points to the symbol .

## 4.1.2 Inserting Media into the Print Mechanics




Figure 12 Media feed path

1. Unroll a longer media strip. Guide the media strip to the print mechanics as shown in Figure 12.
2. Pull the detent pin (4). The pressing roller system (1) will swing upwards.
3. Turn lever (8) counterclockwise and lever (9) clockwise to lift both printheads.
4. Swivel the brush (6) from the roller (7).
5. Move guides (3) apart with the knob (5) until the media can pass between them.
6. Guide media strip through the print mechanics as shown in Figure 13 to the pinch roller (2) and place the strip between the guides (3).
7. Move the guides against the edges of the media by turning the knob (5).
8. Fix the media by closing the upper printhead.
9. Pull the detent pin (4). Push the pressing roller system (1) downwards and lock it with the detent pin.
10. Turn the media roll against the feed direction to tighten the media.
11. Close the lower printhead.
12. Swivel the brush (6) to the roller (7).

**Attention!**

► For single side printing (► 5.2 on page 18) do not close the lower printhead.




Figure 13 Inserting media into the print mechanics

## 4.1.3 Setting the Label Sensor




Figure 14 Setting the label sensor

The label sensor can be shifted perpendicular to the direction of paper flow for adaptation to the media. The sensor unit (2) of the label sensor is marked with an indentation in the label sensor retainer. When the printer is switched on, a yellow LED illuminates the sensor position.

- Loosen screw (3).
- Position label sensor with the tab (4) in such a way that the sensor (1) can detect the label gap or slot between the labels.
- Tighten screw (3).

## 4.1.4 Setting the Head Locking Systems




Figure 15 Setting the upper head locking system




Figure 16 Setting the lower head locking system

The printheads are pushed on via two plungers (1). In the basic setting the plungers are set in the middle of the printhead retainer. This setting can be used for the most applications.

If the print density decreases in the outer areas when using very large media, the plungers can be displaced :

1. Turn lever (3) clockwise and the lever (4) counterclockwise to lock the printheads.
2. Loosen threaded pins (2) at the plungers (1) with Allen key.
3. Displace plungers symmetrically as necessary maximal to the scale value 70.
4. Tighten the threaded pins (2).



## 4.2 Loading Transfer Ribbon

**Note!**

With direct thermal printing, do not load a transfer ribbon; if one has already been loaded, remove it.




Figure 17 Load transfer ribbon




Figure 18 Transfer ribbon feed path

1. Clean the printheads before loading the ribbon (▷ 6.2 on page 20).
2. Turn the lever (6) counterclockwise to lift the upper printhead.
3. Slide a ribbon roll (1) onto the ribbon supply hub (3) so that the color coating of the ribbon faces downward when being unwound.
4. Position the ribbon roll (1) in such a way that both ends of the roll show identical scale values.
5. Hold ribbon roll (1) firmly and turn knob (3) on ribbon supply hub counterclockwise until the ribbon roll is secured.

**Note!**

**To rewind the ribbon use a core with a width between the width of the supply roll and 115 mm.**

6. Slide suitable ribbon core (4) onto the ribbon take-up hub (5). Position and secure it in the same way like the supply roll.
7. Guide ribbon through the print unit as shown in Figure 18.
8. Secure starting end of ribbon to middle of the ribbon core (4) with adhesive tape. Ensure counterclockwise rotation direction of the ribbon take-up hub.
9. Turn ribbon take-up hub (5) counterclockwise to smooth out the feed path of the ribbon.
10. Turn lever (6) clockwise to lock the printhead.

11. Open the flap (8) and load ribbon to the lower print unit (7) in a similar way. All previous statements of direction apply contrariwise excepting the turning of the knobs.

**Note!**

**For single side printing (▷ 5.2 on page 18) do not insert ribbon into the lower print unit.**



### 4.3 Setting the Feed Path of the Transfer Ribbon

Ribbon wrinkling can lead to print image errors. Ribbon deflection can be adjusted so as to prevent wrinkles.

**Note!**

The adjustment is best carried out during printing.




Figure 19 Setting the upper ribbon feed path




Figure 20 Setting the lower ribbon feed path

1. Read current setting on the scale (1) and record if necessary.
2. Turn screw (2) with Allen key and observe the behavior of the ribbon.  
In the + direction, the inner edge of the ribbon is tightened, and the outer edge is tightened in the - direction.

## 5.1 Printhead Protection



### Attention!

Printhead damage caused by improper handling!

- ▶ Do not touch the heating elements of the printheads with the fingers or sharp objects.
- ▶ Ensure that the material is clean.
- ▶ Ensure that the label surfaces are smooth. Rough labels may reduce the service life of the printhead.

The printer is ready for operation when all connections have been made and labels and transfer ribbon have been loaded.

## 5.2 Single Side Printing

The lower printhead can be turned off for printing one-sided labels.

- ▶ Activate the parameter *Setup > Printing > Disable lower head*.
- ▶ Unlock the lower printhead.
- ▶ Remove the ribbon from the lower print unit.
- ▶ Send a print job with single label width.

## 5.3 Ribbon Saving

If there is no information to print during a longer label feed, in the lower print unit the printhead will be lifted, and the transfer ribbon will be paused from feeding. This will reduce the ribbon consumption. The minimum length for ribbon saving is defined in the firmware and depends on the print speed.

The ribbon saver can permanently be activated in the printer configuration (▷ Configuration Manual) or job-oriented by the software (▷ Programming Manual).

## 5.4 Cutting and Perforating

- \* Both full cutters and perforation cutters are available as accessories for DP4300HD. With a cutter installed labels and continuous material can be cut-off or perforated automatically after printing.  
The cutters have separate instructions for detailed information.

## 5.5 Avoiding Loss of Data



### Attention!

Loss of data!

When correctable errors occur labels/sections which are already printed by the lower printhead but not are completed by the upper printhead cannot be repeated after error correction. The data of those sections are lost for the printer.

- ▶ Avoid predictable error situations.
- ▶ To avoid the errors *Out of paper* or *Out of ribbon* switch the printer to the **Pause** state before the material runs out. Continue the print process by pressing the pause key after re-loading material. That way the data are saved.

### Pause on Media Low

The error *Out of ribbon* can be avoided automatically with the integrated ribbon low warning :

- ▶ Activate the parameter *Setup > Ribbon > Pause on warning*.
  - ▶ Set the rest diameter of the ribbon supply roll with the parameter *Setup > Ribbon > Warn level ribbon* to e.g. 35 mm.
- If the diameter of the ribbon roll falls below the set value the automatically switches to the *Pause* state.

## 5.6 Avoiding Loss of Material

**Attention!****Loss of material!**

The print images for the upper and the lower side of one label/section are printed at two different places in the media feed.

Therefore every interruption of the continuous print process has the following consequences :

- Material already printed at the lower side will be fed to the upper printhead to complete the print of the label/section, but the following media will not be printed at the lower side.
- A media backfeed to the lower printhead is not allowed due to the reliability of the media transport.
- Following blank sections in the media strip are generated, which cannot be used.
- For operation with cutter the length of the blank section is at least 110 mm / 4.3 in for continuous material.

For structured media where the print image has to be synchronized to the media transport the loss of material can reach a length of more than 300 mm / 12 in.

To minimize the loss of material it is necessary to avoid interruptions of the continuous print process.

- ▶ Interrupt the print process only if it is absolute necessary.
  - ▶ Avoid print jobs with a small amount of labels/sections, especially single prints.
  - ▶ Avoid predictable error situations ▶ 5.5 on page 18.
- If errors occur the loss of material is particular high. Besides the blank section also material must be rejected which is partly printed.

**Print Optimization**

To minimize the loss of material the parameter *Setup > Printing > Double print optim.* can be activated.

With this setting a print job will not be carried out immediately till the end. The printer stops at a position, where a following print job could be started without blank labels. In this position the printer waits for the next job. After the job is received the previous job will be completed and the new job will be started without blank labels between the jobs.

If no further job is pending, the current job can be completed with *Finalize print job*.

**Optimization of the Data Transfer**

If sequential labels/sections contain differing information, the internal preparation of the second sections must be completed before the printing by the lower printhead for the first section has been finished !

Otherwise the first section will be fed to the upper printhead to complete the print without printing the next section at the lower side. The print of the second section begins only after completion of the first section.

Therefore it is necessary to minimize the data to be transferred. i.e. to avoid transferring complete label descriptions and to transfer the changing data only:

**Note!**

Therefore the parameter "Software optimization" in the printer driver is activated permanently.

- ▶ For direct programming use the replace command **R** for changing data ▶ Programming Manual.

**Attention!****Loss of material!**

The RS232 interface is unsuitable for fast transmission of changing data.

- ▶ Use USB or Ethernet interface for print operation.

## 6.1 Cleaning Information

**Danger!**

Risk of death via electric shock!

- ▶ Disconnect the printer from the power supply before performing any maintenance work.

**Attention!**

The printer can be damaged by aggressive cleaners.

Do not use abrasive cleaners or solvents for cleaning the external surfaces or modules.

Recommended cleaning kit PTR-CLN.

## 6.2 Cleaning the Printheads

Cleaning intervals:

direct thermal printing	- every media roll change
thermal transfer printing	- every ribbon roll change

Substances may accumulate on the printheads during printing and adversely affect printing, e.g. differences in contrast or vertical stripes.

**Attention!**

Printheads can be damaged!

Do not use sharp or hard objects to clean the printheads.

Do not touch protective glass layer of the printheads.

**Attention!**

Risk of injury from the hot printhead lines.

Ensure that the printheads have cooled down before starting cleaning.

- ▶ Lift the printheads.
- ▶ Remove media and transfer ribbon from the printer.
- ▶ Clean printhead surfaces with any component from Panduit cleaning kit (PTR-CLN).
- ▶ Allow printheads to dry for 2–3 minutes before resuming printing.

## 6.3 Cleaning the Label Sensor

**Attention!****Label sensor can be damaged!****Do not use sharp or hard objects or solvents to clean the label sensor.**

The label sensor can become dirtied by paper dust. This can adversely affect label detection.




Figure 21 Cleaning the label sensor

1. Remove labels and transfer ribbon from the printer.
2. Remove screw (2).
3. Loosen screw (3).
4. Slowly pull label sensor outward via the tab (4). Ensure that the label sensor cable is not tensioned by this.
5. Clean label sensor and the slots (1) with electronics cleaning swab or cleaning wipe from Panduit cleaning kit (PTR-CLN).
6. Push label sensor back via tab (4) and set it (▷ 4.1.3 on page 15).
7. Insert screw (2).
8. Reload labels and transfer ribbon.

## 7.1 Error Display

The appearance of an error will be shown on the display:




Figure 22 Error display

The error correction depends on the error type ► 7.2 on page 23.

The display offers the following possibilities to continue after an error occurred:

<i>Repeat</i>	The print job will be continued after clearing the error cause.
<i>Cancel</i>	The print job will be cancelled.
<i>Feed</i>	The paper feed will be synchronized. Then the print job can be continued.
<i>Ignore</i>	The error message will be ignored. The print job will be continued, possibly with limited performance.
<i>Save log</i>	The error does not allow print operation. For detailed analysis several system files can be saved on an external memory.

Table 5 Button in the error display



### Attention!

The labels that have been printed by the lower printer but not yet printed by the upper printhead when the error occurs, cannot be repeated by the printer. So the amount of the printed label will be reduced within the print job.

- If necessary print more labels in a new job.

If the print job contains counters, after pressing *Repeat* the print job would be resumed with erroneous counter values.

- Quit the print job with *Cancel*.
- Start a new print job with adapted counter values.

## 7.2 Error Messages and Fault Correction

Error message	Cause	Remedy
<i>Barcode error</i>	Invalid barcode content, e.g. alphanumeric characters in a numerical barcode	Correct the barcode content.
<i>Barcode too big</i>	The barcode is too big for the allocated area of the label	Reduce the size of the barcode or move it.
<i>Check ribbon ink side (lower/upper printhead)</i>	Identified ribbon unwinding direction does not match to the setup setting	Ribbon loaded incorrectly. Clean the printhead ▷ 6.2 on page 20. Load the ribbon correctly.
		Setting does not match to the used ribbon. Correct the setting.
<i>Cutter blocked</i>	Cutter cannot return into its home position and stays in an undefined position	Switch off the printer. Remove material. Switch on the printer. Restart print job. Change material
	No cutter function	Switch the printer off and then on. If error recurs call service.
<i>Cutter jammed</i>	The cutter is unable to cut the labels but is able to return into its home position	Press <i>Cancel</i> Change material.
<i>Device not conn.</i>	Programming addresses a non-existent device	Either connect this device or correct the programming.
<i>File not found</i>	Requested file is not on the card	Check the contents of the card.
<i>Font not found</i>	Error with the selected download font	Cancel current print job, change font.
<i>Lower printhead disabled and closed</i>	The lower printhead is closed although the parameter <i>Disable lower head</i> is activated	For single side printing open the lower printhead. For double side printing deactivate the parameter <i>Disable lower head</i> .
<i>Lower/upper printhead open</i>	Printhead not locked	Lock printhead.
<i>Lower/upper printhead out of ribbon</i>	Out of transfer ribbon	Insert new transfer ribbon.
	Transfer ribbon melted during printing	Cancel current print job. Change the heat level via software. Clean the printhead ▷ 6.2 on page 20 Load transfer ribbon. Restart print job.
	The printer is loaded with direct thermal label material, but the software is set to transfer printing	Cancel current print job. Set software to direct thermal printing. Restart print job.
<i>Lower/upper printhead too hot</i>	Printhead is overheated	After pausing, the print job will be continued automatically. If the fault recurs repeatedly, reduce the heat level via software.
<i>Memory overflow</i>	Current print job contains too much information, e.g. selected font, large graphics	Cancel current print job. Reduce amount of data to be printed.
<i>Moving head failed</i>	Error of the ribbon saver, end position for lifting or lowering the printhead not reached	Switch the printer off and then on. If error recurs call service.
<i>Name exists</i>	Duplicate usage of field name in the direct programming	Correct programming
<i>No label found</i>	There are labels missing on the label material	Press <i>Repeat</i> repeatedly until printer recognizes the next label on the material.
	The label format as set in the software does not correspond with the real label format	Cancel current print job. Change the label format set in the software. Restart print job.
	Printer is loaded with continuous material, but the software is set on labels	Cancel current print job. Change the label format set in the software. Restart the print job.
<i>No label size</i>	The size of the label is not defined in the programming.	Check programming.

Error message	Cause	Remedy
<i>Out of paper</i>	Out of label roll	Load labels.
	Error in the paper feed	Check paper feed.
<i>Pinch roller open</i>	The pressing roller system is not locked.	Lock the pressing roller system.
<i>Read error</i>	Read error when reading from the memory card	Check data of the card. Backup data, reformat card.
<i>Remove lower/ upper ribbon</i>	Transfer ribbon is loaded although the printer is set to direct thermal printing	for direct thermal printing remove ribbon
		for thermal transfer printing set the printer in the configuration or in the software to transfer printing
<i>Syntax error</i>	Printer has received an unknown or invalid command from the computer.	Press <i>Ignore</i> to skip the command or press <i>Cancel</i> to cancel the print job.
<i>Unknown card</i>	Card not formatted, Type of card not supported	Format card, use different type of card.
<i>Voltage error</i>	Hardware error	Switch the printer off and then on. If error recurs call service. It is shown which voltage has failed. Please note.
<i>Write error</i>	Hardware error	Repeat the write process, reformat card.

Table 6 Error Messages and Fault Correction



## 7.3 Problem Solution

Problem	Cause	Remedy
Transfer ribbon creases	Transfer ribbon deflection not adjusted	Adjust the transfer ribbon deflection. ▷ 4.3 on page 17
	Head locking system not adjusted	Adjust the head locking system. ▷ 4.1.4 on page 15
	Transfer ribbon too wide	Use a transfer ribbon slightly wider than the width of label.
Print image has smears or voids	Printhead is dirty	Clean the printhead ▷ 6.2 on page 20
	Temperature too high	Decrease temperature via software.
	Unsuitable combination of labels and transfer ribbon	Use different type of ribbon.
Printer does not stop after transfer ribbon runs out	Thermal printing is chosen in the software	Change to thermal transfer printing.
Printer prints a sequence of characters instead of the label format	Printer is in ASCII dump mode	Cancel the ASCII dump mode.
Printer transports label media, but transfer ribbon does not move	Transfer ribbon incorrectly inserted.	Check and, if necessary, correct the transfer ribbon web and the orientation of the label side.
	Unsuitable combination of labels and transfer ribbon	Use different type of ribbon.
Vertical white lines in the print image	Printhead is dirty	Clean the printhead. ▷ 6.2 on page 20
	Printhead is defective (failure of heat elements)	Change the printhead. ▷ Service Manual.
Horizontal white lines in the print image	Printer is used with the <i>backfeed &gt; smart</i> in the cut or peel-off mode	Set the <i>backfeed &gt; always</i> in the setup. ▷ Configuration Manual.
Print image is irregular, one side is lighter	Printhead is dirty	Clean the printhead. ▷ 6.2 on page 20
	Head locking system not adjusted	Adjust the head locking system. ▷ 4.1.4 on page 15

Table 7 Problem solution

Reference to the EU Declaration of Conformity and other approvals:

<https://www.panduit.com/DP4300HD>



#### FCC

**NOTE :** This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. The equipment generates, uses, and can radiate radio frequency and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user may be required to correct the interference at his own expense.

**C**

Cleaning	
label sensor .....	21
printhead .....	20
Cleaning information .....	20
Connecting .....	9
Contents of delivery .....	8
Cutting .....	18

**D**

Designing print image .....	18
Device overview .....	6
Display .....	10

**E**

Environment .....	5
Errors	
correction .....	23
messages .....	23

**H**

Head locking systems	
setting .....	15

**I**

Important information .....	4
Intended use .....	4

**L**

Label sensor	
cleaning .....	21
setting .....	14
Lithium battery .....	5
Loading transfer ribbon .....	16
Loss of data .....	18
Loss of material .....	19

**P**

Pause on media low .....	18
Perforating .....	18
Power supply .....	5
Printhead	
cleaning .....	20
damage .....	18
Problem solution .....	25

**R**

Ribbon deflection, setting .....	17
Ribbon feed path, setting .....	17
RS232 interface .....	19

**S**

Safety instructions .....	5
Service work .....	5
Setting-up .....	8
Supply voltage .....	9
Switching on .....	9

**U**

Unpacking .....	8
USB device interface .....	7

**V**

Voltage .....	5
---------------	---

**W**

Warning stickers .....	5
Wi-Fi stick .....	8