


TeSys™ island

System Guide

Instruction Bulletin

This instruction bulletin introduces and describes the main functions of TeSys island.

8536IB1901EN
Release date 06/2019



Legal Information

The Schneider Electric brand and any trademarks of Schneider Electric SE and its subsidiaries referred to in this guide are the property of Schneider Electric SE or its subsidiaries. All other brands may be trademarks of their respective owners.

This guide and its content are protected under applicable copyright laws and furnished for informational use only. No part of this guide may be reproduced or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), for any purpose, without the prior written permission of Schneider Electric.

Schneider Electric does not grant any right or license for commercial use of the guide or its content, except for a non-exclusive and personal license to consult it on an "as is" basis. Schneider Electric products and equipment should be installed, operated, serviced, and maintained only by qualified personnel.

As standards, specifications, and designs change from time to time, information contained in this guide may be subject to change without notice.

To the extent permitted by applicable law, no responsibility or liability is assumed by Schneider Electric and its subsidiaries for any errors or omissions in the informational content of this material or consequences arising out of or resulting from the use of the information contained herein.

Schneider Electric, EcoStruxure, Modbus, SoMove, and TeSys are trademarks and the property of Schneider Electric SE, its subsidiaries, and affiliated companies. All other trademarks are the property of their respective owners.

Table of Contents

About the Book.....	7
Document Scope.....	7
Validity Note.....	7
Related Documentation.....	8
Precautions.....	9
Qualified Personnel.....	9
Intended Use.....	10
Introduction to TeSys™ island.....	11
Island Concept.....	11
Industrial Communication Protocols.....	12
TeSys™ Island Specifications.....	12
Technical Specifications.....	12
Operating Conditions.....	12
Derating Guidelines.....	13
Electromagnetic Interference.....	14
Heat Dissipation.....	15
Durability Curves.....	16
Hardware Descriptions.....	20
Bus Coupler.....	20
Power Devices.....	21
Power Interface Module.....	21
Standard Starters.....	22
SIL Starters.....	23
SIL Interface Module.....	25
I/O Modules.....	26
Digital I/O Module.....	26
Analog I/O Module.....	27
Voltage Interface Module.....	29
Digital Tools.....	30
TeSys™ island Configurator.....	30
Engineering Tools.....	31
Operation and Maintenance Tool.....	32
Fieldbus Communication.....	33
Industrial Communication Protocols.....	33
Degraded Mode.....	33
Recovering from Degraded Mode.....	33
TeSys™ Avatar Introduction.....	34
Avatar Definition.....	34
List of TeSys™ Avatars.....	35
Avatar Functional Description.....	38
Avatar Function Allocation.....	38
Protection Functions.....	39
About Motor Start and Run States.....	40
Load Protection Functions.....	42
Thermal Protection Functions.....	50
Electrical Protection Functions.....	51
Alarm and Trip Counters.....	54

- Trip Reset Command 56
- Trip Auto-Reset Function 58
- Monitoring Data 60**
 - Upstream Voltage Presence 60
 - Current Monitoring 60
 - Energy Monitoring 60
 - System Monitoring 60
 - Avatar Monitoring 61
- Avatar Composition 62**
 - Avatar Wiring Schematics and Accessory Diagrams 65
 - Bus Coupler with I/O Modules and Voltage Interface Modules 65
 - Switch 66
 - Switch - Safe Stop, W. Cat 1/2 66
 - Digital I/O 67
 - Analog I/O 67
 - Power Interface without I/O (Measure) 68
 - Power Interface with I/O (Control) 68
 - Motor One Direction 69
 - Motor One Direction - Safe Stop, W. Cat 1/2 69
 - Motor Two Directions 70
 - Motor Two Directions - Safe Stop, W. Cat 1/2 71
 - Motor Y/D One Direction 72
 - Motor Y/D Two Directions 73
 - Motor Two Speeds 74
 - Motor Two Speeds - Safe Stop, W. Cat 1/2 75
 - Motor Two Speeds Two Directions 76
 - Motor Two Speeds Two Directions - Safe Stop, W. Cat 1/2 77
 - Resistor 78
 - Power Supply 78
 - Transformer 79

Hazard Categories and Special Symbols

Read these instructions carefully and look at the equipment to become familiar with the device before trying to install, operate, service, or maintain it. The following special messages may appear throughout this bulletin or on the equipment to warn of hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of either symbol to a “Danger” or “Warning” safety label indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

⚠ DANGER

DANGER indicates a hazardous situation which, if not avoided, **will result in** death or serious injury.

⚠ WARNING

WARNING indicates a hazardous situation which, if not avoided, **could result in** death or serious injury.

⚠ CAUTION

CAUTION indicates a hazardous situation which, if not avoided, **could result in** minor or moderate injury.

NOTICE

NOTICE is used to address practices not related to physical injury.

NOTE: Provides additional information to clarify or simplify a procedure.

Please Note

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction, installation, and operation of electrical equipment and has received safety training to recognize and avoid the hazards involved.

About the Book

Document Scope

This instruction bulletin introduces and describes:

- TeSys™ island
- The physical modules that comprise TeSys island
- Digital tools
- TeSys Avatars and their functions
- Avatar hardware and wiring

⚠ DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

Read and understand this instruction bulletin and all related documents before installing, operating, or maintaining your TeSys island. Installation, adjustment, repair, and maintenance must be performed by qualified personnel.

Failure to follow these instructions will result in death or serious injury.

Validity Note

This instruction bulletin is valid for all TeSys™ island configurations. The availability of some functions described in this bulletin depends on the communication protocol used and the physical modules installed on the island.

For product compliance with environmental directives such as RoHS, REACH, PEP, and EOL, go to www.se.com/green-premium.

For technical characteristics of the physical modules described in this bulletin, go to www.se.com.

The technical characteristics presented in this bulletin should be the same as those that appear online. We may revise content over time to improve clarity and accuracy. If you see a difference between the information contained in this bulletin and online information, use the online information.

Related Documentation

Table 1 - Related Documentation

Document Title	Description	Document Number
<i>TeSys™ island System Guide</i>	Introduces and describes the main functions of TeSys island	8536IB1901
<i>TeSys™ island Installation Guide</i>	Describes the mechanical installation, wiring, and commissioning of TeSys island	8536IB1902
<i>TeSys™ island Operating Guide</i>	Describes how to operate and maintain TeSys island	8536IB1903
<i>TeSys™ island Functional Safety Guide</i>	Describes the Functional Safety features of TeSys island	8536IB1904
<i>TeSys™ island Third Party Function Block Guide</i>	Contains the information needed to create function blocks for third party hardware	8536IB1905
<i>TeSys™ island EtherNet/IP™ Function Block Library Guide</i>	Describes the TeSys island library used in the Rockwell Software® Studio 5000® environment	8536IB1914
<i>TeSys™ island EtherNet/IP™ Quick Start Guide</i>	Describes how to quickly integrate TeSys island into the Rockwell Software Studio 5000 environment	8536IB1906
<i>TeSys™ island DTM Online Help Guide</i>	Describes how to install and use various functions of TeSys island configuration software and how to configure the parameters of TeSys island	8536IB1907
<i>TeSys™ island Product Environmental Profile, Bus Coupler</i>	Describes constituent materials, recyclability potential, and environmental impact information for the TeSys island bus coupler	8536IB1908
<i>TeSys™ island Product Environmental Profile, Starters and Power Interface Modules</i>	Describes constituent materials, recyclability potential, and environmental impact information for the TeSys island starters and power interface modules	8536IB1909
<i>TeSys™ island Product Environmental Profile, Accessories</i>	Describes constituent materials, recyclability potential, and environmental impact information for the TeSys island accessories	8536IB1910
<i>TeSys™ island Product End of Life Instructions, Bus Coupler</i>	Contains end of life instructions for the TeSys island bus coupler	8536IB1911
<i>TeSys™ island Product End of Life Instructions, Starters and Power Interface Modules</i>	Contains end of life instructions for TeSys island starters and power interface modules	8536IB1912
<i>TeSys™ island Product End of Life Instructions, Accessories</i>	Contains end of life instructions for TeSys island accessories	8536IB1913
<i>TeSys™ island Instruction Sheet, Bus Coupler</i>	Describes how to install the TeSys island bus coupler	MFR44097
<i>TeSys™ island Instruction Sheet, Starters and Power Interface Modules, Size 1 and 2</i>	Describes how to install size 1 and 2 TeSys island starters and power interface modules	MFR77070
<i>TeSys™ island Instruction Sheet, Starters and Power Interface Modules, Size 3</i>	Describes how to install size 3 TeSys island starters and power interface modules	MFR77085
<i>TeSys™ island Instruction Sheet: Input/Output Modules</i>	Describes how to install the TeSys island analog and digital I/O modules	MFR44099
<i>TeSys™ island Instruction Sheet: SIL Interface and Voltage Interface Modules</i>	Describes how to install the TeSys island voltage interface modules and SIL interface modules	MFR44100

Precautions

Read and understand the following precautions before performing any procedures in this guide.

⚠ DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

- This equipment must only be installed and serviced by qualified electrical personnel.
- Turn off all power supplying this equipment before working on or inside this equipment.
- Use only the specified voltage when operating this equipment and any associated products.
- Always use a properly rated voltage sensing device to confirm power is off.
- Use appropriate interlocks where personnel and/or equipment hazards exist.
- Power line circuits must be wired and protected in compliance with local and national regulatory requirements.
- Apply appropriate personal protective equipment (PPE) and follow safe electrical work practices per NFPA 70E, NOM-029-STPS, or CSA Z462 or local equivalent.

Failure to follow these instructions will result in death or serious injury.

⚠ WARNING

UNINTENDED EQUIPMENT OPERATION

- For complete instructions about functional safety, refer to the *TeSys™ island Functional Safety Guide*, 8536IB1904.
- Do not disassemble, repair, or modify this equipment. There are no user serviceable parts.
- Install and operate this equipment in an enclosure appropriately rated for its intended application environment.
- Each implementation of this equipment must be individually and thoroughly tested for proper operation before being placed into service.

Failure to follow these instructions can result in death, serious injury, or equipment damage.



WARNING: This product can expose you to chemicals including Antimony oxide (Antimony trioxide), which is known to the State of California to cause cancer. For more information go to www.P65Warnings.ca.gov.

Qualified Personnel

Only appropriately trained persons who are familiar with and understand the content of this guide and all other related product documentation are authorized to work on and with this product.

The qualified person must be able to detect possible hazards that may arise from modifying parameter values and generally from mechanical, electrical, or electronic equipment. The qualified person must be familiar with the standards, provisions, and regulations for the prevention of industrial accidents, which they must observe when designing and implementing the system.

The use and application of the information contained in this guide requires expertise in the design and programming of automated control systems. Only you,

the user, machine builder, or integrator, can be aware of all the conditions and factors present during installation, setup, operation, and maintenance of the machine or process, and can therefore determine the automation and associated equipment and the related safeties and interlocks which can be effectively and properly used when selecting automation and control equipment, and any other related equipment or software, for a particular application. You must also consider applicable local, regional, or national standards and/or regulations.

Pay particular attention to conformance with any safety information, electrical requirements, and normative standards that apply to your machine or process in the use of this equipment.

Intended Use

The products described in this guide, together with software, accessories, and options, are starters for low-voltage electrical loads, intended for industrial use according to the instructions, directions, examples, and safety information contained in the present document and other supporting documentation.

The product may only be used in compliance with all applicable safety regulations and directives, the specified requirements, and the technical data.

Before using the product, you must perform a risk assessment of the planned application. Based on the results, appropriate safety-related measures must be implemented.

Since the product is used as a component of a machine or process, you must ensure the safety of persons by means of the overall system design.

Operate the product only with the specified cables and accessories. Use only genuine accessories and spare parts.

Any use other than the use explicitly permitted is prohibited and can result in unanticipated hazards.

Introduction to TeSys™ island

Island Concept

TeSys™ island is an innovative digital load management solution—providing data for higher machine efficiency and ease of servicing, and allowing faster time to market.

TeSys island is a modular, multifunctional system providing integrated functions inside an automation architecture, primarily for the direct control and management of low-voltage loads. TeSys island can switch, help protect, and manage motors and other electrical loads up to 80 A (AC3) installed in an electrical control panel.


This system is designed around the concept of TeSys Avatars. These Avatars

- Represent both the logical and physical aspects of the automation functions
- Determine the configuration of the island

The logical aspects of the island are managed with software tools, covering all phases of product and application lifecycle: design, engineering, commissioning, operation, and maintenance.

The physical island consists of a set of devices installed on a single DIN rail, and connected together with flat cables providing the internal communication between modules. The external communication with the automation environment is made through a single bus coupler module, and the island is seen as a single node on the network. The other modules include starters, power interface modules, analog and digital I/O modules, voltage interface modules, and SIL (Safety Integrity Level according to standard IEC 61508) interface modules, covering a wide range of operational functions.

Figure 1 - TeSys island Overview



A	Bus Coupler	E	Power Interface Module
B	Analog I/O Module	F	Standard Starter
C	Digital I/O Module	G	SIL Starter
D	Voltage Interface Module	H	SIL Interface Module

Industrial Communication Protocols

TeSys™ island supports the EtherNet/IP™ and Modbus™ TCP industrial communication protocols.

TeSys™ Island Specifications

Technical Specifications

Table 2 - TeSys™ island Specifications

Width	up to 112.5 cm (3.83 ft)
Modules	up to 20 modules, excluding the bus coupler and the voltage interface modules
Control power consumption per system	3 A / 72 W maximum
Maximum load current per starter	80 A, 37 kW (50 hp), maximum
Internal data refresh time	10 ms
Mounting	Metallic DIN rail, horizontal or vertical

Operating Conditions

TeSys™ island is designed to durably sustain the following conditions. Other conditions may apply to specific modules as described in their data sheet document, available on www.se.com/tesys.

- 40 °C (104 °F) ambient temperature
- 400/480 V motor
- 50% humidity
- 80% load
- Horizontal mounting orientation
- All inputs activated
- All outputs activated
- 24 hours/day, 365 days/year run time

Derating Guidelines

TeSys™ island standard starters, SIL starters, and power interface modules are designed for operation **without derating** under the following conditions:

- Horizontal mounting position
- Ambient temperature up to 50 °C (122 °F)

For vertical mounting or ambient temperatures above 50 °C (122 °F), apply the derating values in the following table to the load rating requirements. If both derating conditions apply, then you must apply both derating factors. Derating is calculated by the digital tools.

Table 3 - Derating Guidelines for Mounting Position and Ambient Operating Temperature

Derating Condition	Derating Factor
Mounting position	20% derating required in the vertical mounting position
Ambient operating temperature	2% derating per °C of temperature rise above 50 °C (122 °F), with a maximum of 60 °C (140 °F)

The derating conditions apply to all standard starters, SIL starters, and power interface modules. The derating conditions do not affect short-circuit protection devices.

Derating Examples

Table 4 - Example 1—Derating Required

Load rating	8 A
Derating factor: Temperature inside the enclosure is 60 °C (140 °F)	1.20
Maximum load rating of starter TPRST009	9 A

$$8 \text{ A} * 1.20 = 9.60 \text{ A}$$

Since 9.60 A is greater than the maximum load rating of 9 A, derating is required. Upgrade from the TPRST009 reference number to the TPRST025 reference number with a maximum load rating of 25 A.

Table 5 - Example 2—Derating Not Required

Load Rating	6 A
Derating Factor: Temperature inside the enclosure is 60 °C (140 °F) + Vertical Mounting	$1.2 + (1.2 \times 20\%) = 1.44$
Maximum Load Rating of TPRST009	9 A

$$6 \text{ A} * 1.44 = 8.64 \text{ A}$$

Since 8.64 A is less than the maximum load rating of 9 A, derating is not required. The TPRST009 reference number is appropriate.

Electromagnetic Interference

The protection and energy monitoring features of TeSys™ island devices are based on current sensors. To reduce the risk of electromagnetic interference between two adjacent devices, we recommend that you implement one of the following installation rules if the ratio between the FLA settings of two adjacent devices is $>100:1$.

- Option 1: Using the engineering tool, reorganize the order of the Avatars on the island so there are no adjacent devices with FLA ratios $>100:1$
- Option 2: Leave a spacing of 30 mm (1.18 in.) between the two adjacent devices.

The figure below illustrates Option 2.

Figure 2 - Avoiding Electromagnetic Interference: Option 2




Table 6 - Legend

A	A TeSys island device with an FLA setting of 0.6 A
C	An adjacent TeSys island device with an FLA of 65 A ($>0.6 \text{ A} \times 100$)
B	The recommended 30 mm (1.18 in.) spacing between the two adjacent devices with an FLA ratio $>100:1$

Additionally:

1. Maintain a minimum distance of 30 cm (11.8 in.) between the island and sources of extremely high 50/60 Hz magnetic fields, such as three-phase bus systems.
2. TeSys island modules have integrated electrostatic discharge (ESD) protection. Discharge potential body charge to the equipment ground before handling or installing a module to reduce the risk of ESD damage.
3. Keep mobile communication devices at least 20 cm (7.87 in.) away from the island to reduce the likelihood of interference with the island.
4. Integrating radio communication devices in the same panel or in a near-by panel requires specific precautions related to transmit power and antenna location. Contact a Schneider Electric representative for more information.
5. TeSys island is a Class A device designed for use in environment A (according to *FCC Rules & Regulations*, Title 47, Part 15, Subpart B). Using TeSys island in environment B may cause radio interference necessitating additional mitigation methods.
6. For additional information on EMC installation practices, refer to Schneider Electric's *Electrical Installation Guide*, EIGED306001, or contact a Schneider Electric representative.

Heat Dissipation

To allow adequate heat dissipation, always leave a spacing of 10 cm (3.94 in.) between the short-circuit protection devices and the TeSys™ island starters.

Additional installation recommendations pertain under the following conditions:

- Three or more starters are mounted on the island side-by-side
- The starters have ratings (I_e) greater than or equal to 25 A
- The starters are used with a motor having a nominal current $I_n > 85\% \times I_e$

Under these conditions, we recommend that you implement one of the following installation rules:


- Option 1: Using the engineering tool, reorganize the Avatars on the island to avoid these conditions.
- Option 2: Use 50 cm (1.64 ft) cables to wire the short-circuit protection devices with the affected middle starters. In a group of three starters, which all meet the conditions itemized above, the extra length is only recommended for the starter in the middle. In a group of four starters, the extra length is only recommended for the two starters in the middle.

Durability Curves

For utilisation category AC-3

Table 7 - Selection according to required electrical durability, in category AC-3 ($U_e \leq 440$ V)

- Control of three-phase asynchronous squirrel-cage motors with breaking while running.
- The current broken (I_c) in category AC-3 is equal to the rated operational current (I_e) of the motor.




Operational power in kW (hp)—50 Hz.

Example:

- Asynchronous motor with
 - $P = 5.5$ kW (7.4 hp) - $U_e = 400$ V - $I_e = 11$ A - $I_c = I_e = 11$ A, or
 - $P = 5.5$ kW (7.4 hp) - $U_e = 415$ V - $I_e = 11$ A - $I_c = I_e = 11$ A
- 5 million operating cycles required.
- The above selection curves show the starter rating needed: TPRS•025.

Table 8 - Selection according to required electrical durability, in category AC-3 (Ue = 660/690 V)


- Control of three-phase asynchronous squirrel-cage motors with breaking while running.
- The current broken (Ic) in category AC-3 is equal to the rated operational current (Ie) of the motor.



For utilisation category AC-1

Table 9 - Selection according to required electrical durability, in category AC-1 (Ue ≤ 690 V)

- Control of resistive circuits (cos φ ≥ 0.95).
- The current broken (Ic) in category AC-1 is equal to the current (Ie) normally drawn by the load.




Example:

- Ue = 220 V – Ie = 50 A – θ ≤ 40 °C – Ic= Ie = 50 A
- 2 million operating cycles required
- The above selection curves show the starter rating needed: TPRS•065 or TPRS•080.

For utilisation categories AC-2 or AC-4

Table 10 - Selection according to required electrical durability, in categories AC-2 or AC-4 ($U_e \leq 440$ V)

- Control of 3-phase asynchronous squirrel cage motors (AC-4) or slip ring motors (AC-2) with breaking while the motor is stalled.
- The current broken (I_c) in AC-2 is equal to $2.5 \times I_e$.
- The current broken (I_c) in AC-4 is equal to $6 \times I_e$ (I_e = rated operational current of the motor).




Example:

- asynchronous motor with
 - $P = 5.5$ kW (7.4 hp) – $U_e = 400$ V – $I_e = 11$ A. $I_c = 6 \times I_e = 66$ A, or
 - $P = 5.5$ kW (7.4 hp) – $U_e = 415$ V – $I_e = 11$ A. $I_c = 6 \times I_e = 66$ A
- 200,000 operating cycles required
- The above selection curves show the starter rating needed: TPRS•025

Table 11 - Selection according to required electrical durability, use in category AC-4 (440 V < Ue ≤ 690 V)

- Control of 3-phase asynchronous squirrel cage motors with breaking while the motor is stalled.
- The current broken (Ic) in AC-2 is equal to 2.5 × Ie.
- The current broken (Ic) in AC-4 is equal to 6 × Ie (Ie = rated operational current of the motor).



Hardware Descriptions

Bus Coupler

A single bus coupler is always present in the island as the fieldbus communication interface, and to control all other modules of the island. The bus coupler reference number is TPRBCEIP.

The following are the main functions of the bus coupler:

- Communicating with the PLC
- Managing the TeSys™ Avatars and their associated modules
- Collecting operational status and diagnostic data from the island's modules
- Communicating with configuration, operation and maintenance digital tools
- Supplying the modules with control power

The bus coupler is connected:


- Upstream to the fieldbus
- Downstream to the island devices with the daisy-chain flat cable
- Upstream to the control power supply
- Optionally, upstream through its service port, to a software tool (EcoStruxure™ Machine Expert programming tool)

The bus coupler service port and dual port Ethernet switch are located on the same network.

The bus coupler is equipped with a micro SD card slot, to allow upload and backup functions on a micro SD card.

For the position of the bus coupler on the island, refer to *TeSys™ island Overview*, page 11.

Figure 3 - Bus Coupler Features



A	Terminal/Service port: 1 x RJ45	E	Slot for micro SD card
B	Dual port Ethernet switch: 2 x RJ45	F	Name tag
C	24 Vdc control power supply connector with spring terminals	G	QR code
D	LED status indicators		

Power Devices

TeSys™ island offers two types of power devices:

- Standard and SIL starters that include a contactor and provide the following functionality as part of a TeSys Avatar:
 - load control management
 - electrical protection functions
 - digital asset management
- Power interface modules that monitor current but do not provide load control. Load control must be provided by a downstream external power device like a solid-state relay or a soft starter.

Avatars that include power devices can provide load level energy monitoring when a voltage interface module (VIM) is installed in the island.

SIL starters in combination with a SIL interface module (SIM) can achieve certified Stop Category 0 and Stop Category 1 functions. ¹

Power Interface Module

Power interface modules (PIMs) provide the following:

- Electrical and thermal protection functions
- Digital asset management

TeSys™ Avatars that include power devices can provide full-load energy monitoring when a voltage interface module is installed on the island.

A PIM can be associated with an analog I/O module to measure temperature through an external sensor. A PIM can also control and monitor the current supplied to an external device.

The main functions of the PIMs are as follows:

- Measure electrical downstream data related to the load
- Provide energy monitoring data when a voltage interface module is installed on the island

The PIMs are connected:

- Upstream to a circuit breaker
- Downstream to an external power device like a contactor, soft starter, or variable speed drive


The PIMs communicate with the bus coupler, sending operational data and receiving commands.

Table 12 - Power Interface Module Ratings

Power Ratings		Amperage	Reference
kW	hp		
4	5	0.18–9	TPRPM009
18.5	20	0.76–38	TPRPM038
37	40	4–80	TPRPM080

1. Stop categories according to EN/IEC 60204-1.

Figure 4 - Power Interface Module Features



A	Flat cable (for connection with the module to the left)	D	QR code
B	LED status indicators	E	Name tag
C	Upstream power connections	F	Downstream power connections

Standard Starters

Standard starters provide load control, electrical and thermal protection functions, and digital asset management.

Starters provide the following main functions:

- On/Off power control for loads (three phase or single phase)
- Electrical data measurement related to the load
- Energy monitoring when a voltage interface module is installed on the island
- Functional testing and simulation
- Event logging and counters

Multiple starters might be needed for a single TeSys™ Avatar function. For example, a motor two-direction Avatar includes two standard starters.

The standard starters are connected:


- Upstream to a circuit breaker
- Downstream to the load (three phase or single phase)

The starters communicate with the bus coupler, sending operational data and receiving commands.

Table 13 - Standard Starter Ratings

Power Ratings		Amperage	Reference
kW	hp		
4	5	0.18–9	TPRST009
11	15	0.5–25	TPRST025
18.5	20	0.76–38	TPRST038
30	40	3.25–65	TPRST065
37	40	4–80	TPRST080

Figure 5 - Standard Starter Features



A	Flat cable (for connection with the module to the left)	E	Name tag
B	LED status indicators	F	Mobile bridge
C	Upstream power connections	G	Downstream power connections
D	QR code		

SIL Starters

⚠ WARNING
UNINTENDED EQUIPMENT OPERATION
For complete instructions about functional safety, refer to the <i>TeSys™ island Functional Safety Guide</i> , 8536IB1904.
Failure to follow these instructions can result in death, serious injury, or equipment damage.

SIL² starters provide similar functions to standard starters but are associated with a SIL interface module.

The main functions of the SIL starters are as follows:

- Provide Stop Category 0 and Stop Category 1 functionality³
- Provide operational control for loads
- Measure electrical data related to the load
- Provide energy monitoring data when a voltage interface module is installed in the island

Multiple SIL starters might be needed for a single TeSys Avatar function. For example, the *Avatar Motor Two Directions - Safe Stop, W. Cat 1/2*⁴ includes two SIL starters. In addition, Avatars using SIL starters always include a SIL interface module.

The SIL starters are connected:

- Upstream to a circuit breaker
- Downstream to the load


2. Safety Integrity Level according to standard IEC 61508
 3. Stop categories as defined in EN/IEC 60204-1.
 4. Safe Stop according to EN 61800-5-2.

The SIL starters communicate with the bus coupler, sending operational data and receiving commands.

Table 14 - SIL Starter Ratings

Power Ratings		Amperage	Reference
kW	hp		
4	5	0.18–9	TPRSS009
11	15	0.5–25	TPRSS025
18.5	20	0.76–38	TPRSS038
30	40	3.25–65	TPRSS065
37	40	4–80	TPRSS080

Figure 6 - SIL Starter Features



A	Flat cable (for connection with the module to the left)	E	Name tag
B	LED status indicators	F	Mobile bridge
C	Upstream power connections	G	Downstream power connections
D	QR code		

SIL Interface Module

⚠ WARNING
<p>UNINTENDED EQUIPMENT OPERATION</p> <p>For complete instructions about functional safety, refer to the <i>TeSys island Functional Safety Guide</i>, 8536IB1904.</p> <p>Failure to follow these instructions can result in death, serious injury, or equipment damage.</p>

A SIL⁵ interface module (SIM), associated with one or several SIL starters, allows the design of Stop functions according to EN/IEC 60204-1:

- Stop Category 0: immediate machine power disconnection
- Stop Category 1: electrical power is maintained on the machine actuators until the stop process fully ends (absence of motion)

The reference number is TPRSM001.

The following are the main functions of the SIM:

- Interface with an external interlocking device
- Command the stop function of its SIL group of SIL starters

Several SIL groups of SIL starters can be set up on the island. Each SIL group is delimited by a SIM on the right side (or the top side if vertically mounted).


The SIM is connected upstream:

- To the 24 Vdc source
- To an interlock (for example, a Preventa™ XPS-AC module)

The SIM communicates with the bus coupler, sending operational data.

The Stop function is achieved by electromechanical means without any digital communication or bus coupler involvement.

Figure 7 - SIL Interface Module Features



A	Flat cable (for connection with the module to the left)	D	QR code
B	LED status indicators	E	Name tag
C	Connector with spring terminals		

5. Safety Integrity Level according to standard IEC 61508

I/O Modules

Analog and digital I/O modules are typically used to get data from sensors and control actuators.

Digital I/O Module

The main functions of the digital I/O module are as follows:

- Monitor binary sensors and switches via four 24 Vdc sink/source inputs
- Control devices like relays, signaling lights, or controller binary inputs via two 0.5 A, 24 Vdc transistor-type outputs
- Capture statistical operational data of the I/O module:
 - Number of power cycles
 - Number of detected events
 - Time the module is on
- Perform I/O Channel testing and simulation

The reference number is TPRDG4X2.

The digital I/O module is connected:

- Upstream to the 24 Vdc source needed to power the downstream actuators
- Input channel: downstream to a binary sensor or switch
- Output channel: downstream to the 24 Vdc input of the actuator

Refer to *Avatar Wiring Schematics*, page 65 for module wiring.

Devices connected to the digital I/O module must be protected against short-circuits by external means like fuses. Use one 0.5 A Type T fuse per output. Recommended are Littlefuse 215, 218, FLQ, or FLSR series or equivalent.

The digital I/O module communicates with the bus coupler, sending operational data and receiving commands.


Table 15 - Input Specifications

Channel	Inputs
Rated power supply	24 Vdc
Input type	Type 1 (IEC/EN 61131-2)
Number of discrete inputs	4 isolated with common point
Discrete input current	7 mA at 24 V
Discrete input voltage	24 Vdc (voltage limits: 19.2–28.8 V)
Cable type	Refer to instruction sheet MFR44099, <i>Analog I/O and Digital I/O Modules</i> , and instruction bulletin 8536IB1902, <i>Installation Guide</i> .
Cable length, maximum	30 m (98 ft)

Table 16 - Output Specifications

Channel	Inputs
Number of discrete outputs	2 isolated with common point
Discrete output voltage	24 Vdc (voltage limits: 19.2–28.8 V)
Rated output current	0.5 A, resistive
Cable type	Refer to instruction sheet MFR44099, <i>Analog I/O and Digital I/O Modules</i> , and instruction bulletin 8536IB1902, <i>Installation Guide</i> .
Cable length, maximum	30 m (98 ft)

Figure 8 - Digital I/O Module Features



A	Flat cable (for connection with the module to the left)	D	QR code
B	LED status indicators	E	Name tag
C	Connector with spring terminals		

Analog I/O Module

The main functions of the analog I/O module are as follows:

- Monitor voltage or current from analog sensors (such as thermocouple, PT100, PT1000, NI100, NI1000) via two -10 to +10 V / 0 to 20 mA capable inputs
- Control voltage-driven actuators (such as variable speed drives or a current loop to the controller’s analog input) via one -10 to +10 V / 0 to 20 mA capable output
- Capture statistical operational data:
 - Number of power cycles
 - Number of device events
 - Time the module is on

The reference number is TPRAN2X1.

The analog I/O module is connected:

- Upstream to the 24 Vdc source needed to power the downstream actuators
- Input channel: downstream to an analog sensor or sensor transmitter
- Output channel: downstream to the control input of a voltage-driven actuator, such as a variable speed drive

Refer to *Avatar Wiring Schematics*, page 65 for module wiring.

Devices connected to the analog I/O module must be protected against short circuits by external means like fuses.

The analog I/O module communicates with the bus coupler, sending operational data and receiving commands.

NOTE: No per-channel LEDs are provided.

Table 17 - Input/Output Specifications

Channel	Inputs	Output
Number of analog inputs and outputs	2 isolated with common point	1 isolated
Rated power supply	24 Vdc	
Resolution, maximum	16 bits, or 15 bits + sign	12 bits (4096 points)
Cable type	Twisted pair shielded	
Cable length, maximum	30 m (98 ft)	


Table 18 - Signal Type: Inputs

Channel	Inputs			
Signal type	Voltage (Vdc)	Current (mA)	Thermocouple	3-wire RTD (Resistance Temperature Detector)
Range	<ul style="list-style-type: none"> 0 to 10 -10 to +10 	<ul style="list-style-type: none"> 0–20 4–20 	Type K, J, R, S, B, E, T, N, C	PT100, PT1000, NI100, NI1000

Table 19 - Signal Type: Outputs

Channel	Output	
Signal type	Voltage	Current
Range	<ul style="list-style-type: none"> 0 to 10 Vdc -10 to +10 Vdc 	<ul style="list-style-type: none"> 0–20 mA 4–20 mA

Figure 9 - Analog I/O Module Features



A	Flat cable (for connection with the module to the left)	D	QR code
B	LED status indicators	E	Name tag
C	Connector with spring terminals		

Voltage Interface Module

The voltage interface module (VIM) enables voltage, power, and energy monitoring for the island.

The reference number is TPRVM001.

The main functions of the VIM are as follows:


- Measure single-phase and three-phase line voltages (47–63 Hz) at one connection point of the island
- Monitor the energy-related data at the island level
- Monitor the voltages in single-phase systems L-N or L-L
- Monitor the voltages in three-phase systems without neutral N connection
- Calculate the RMS phase voltages and the voltage phase sequence
- Monitor for fundamental frequency
- Identify the level and duration of dip and swell events

Refer to *Avatar Wiring Schematics, page 65* for module wiring.

The VIM is connected upstream to the island common power supply.

The VIM communicates with the bus coupler, sending operational data.

The connection specifications for measuring input are as follows: removable spring terminal block with three rigid cables sized 0.2–2.5 mm² (AWG 24–14).



A	Flat cable (for connection with the module to the left)	D	QR code
B	LED status indicators	E	Name tag
C	Connector with spring terminals		

Digital Tools

The TeSys™ island digital tools are online and offline software interfaces used to manage the island through all offer life-cycle phases—from component selection, to operational monitoring, to maintenance.

Three tools are available:

- TeSys island Configurator: an online tool for the initial design of the island: www.se.com/en/work/products/industrial-automation-control/tools/motor-control-configurator.jsp
- Engineering tools: personal computer software for configuring, monitoring, and controlling the island (TeSys island DTM within Machine Expert or SoMove™ software)
- Operation and Maintenance Tool (OMT): an online tool embedded in the bus coupler for operation, maintenance, and troubleshooting

These powerful tools offer a wide range of functions. In many cases, the functionalities overlap—different tools can be used to achieve the same result.

Table 20 - Digital Tools

Functions	TeSys island Configurator	Engineering (EcoStruxure™ Machine Expert)	Operation and Maintenance
Build	X	X	
Configure		X	
Adjust Settings		X	X
Document	X	X	
Test		X	X
Command		X	X
Monitor		X	X
Diagnostics		X	X

TeSys™ island Configurator

The TeSys island Configurator is an online tool accessible from the Schneider Electric website. The configurator is an intelligent catalog, computing and providing the island's configuration based on the requirements entered for the specific application.

The TeSys island Configurator's main purpose is as follows:

- Capture the functional requirements of the application, and the electrical characteristics of the island
- Compute the list of required TeSys island devices automatically
- Generate the physical topology of the island
- Generate the associated bill of materials
- Generate the configuration files, which can be downloaded for re-use by EcoStruxure™ Machine Expert.
- Provide access to technical documentation related to electrical panel engineering and automation control programming

The TeSys island Configurator can be found at www.se.com/en/work/products/industrial-automation-control/tools/motor-control-configurator.jsp.

Engineering Tools

The engineering tools include EcoStruxure™ Machine Expert, SoMove™ software, and the TeSys™ island DTM.

These tools allow you to configure, monitor, control, and customize TeSys island. The engineering tools assist with the design, engineering, and commissioning phases of the island, as well as with PLC programming. The TeSys island engineering tools are built using open FDT/DTM technology.

Design Functions

- Design the island topology.
- Generate a bill of material.

Engineering Functions

- Adjust the settings of TeSys Avatars to customize the electrical and load protection parameters.
- Communicate with the PLC (Machine Expert).

Commissioning Functions

- Check the electrical wiring and test the electrical lines in Test mode without loading a configuration.
- Simulate commands from the PLC and set the status of the Avatars in Force mode.
- Check the island's status and monitor the Avatars with diagnostic features.
- Compare the loaded configuration and topology against the project file.
- Operate the island directly from a control panel.

Programming Functions

- Generate exchange files for third-party PLC programming environments (SoMove software).
- Access a library of function blocks (Machine Expert) for control, diagnostics, energy monitoring, and asset management.

The engineering tool can be downloaded from www.se.com by entering *TeSys island DTM* in the Search field. SoMove software can also be downloaded directly from the Schneider Electric website.

Full Integration into SoMove Software

Aided design to determine

- The bill of materials of the island
- The topology of the island

Aided engineering

- Generation of exchange files with a third party programming environment (EDS files)
- Fast programming using function blocks
- Customized functions for Electrical protections, Motor protections, and Energy monitoring
- Contextual setting of parameters for communication with the controller and Avatars

Aided commissioning

- Test mode: Check the electrical wiring and test the electrical lines without loading a configuration.
- Force mode: Force the commands and Avatar status to ease commissioning.
- Diagnostic tab: Check the status, monitor the Avatars and their associated modules, and compare the loaded configuration and topology with the project file.
- Control panel: Operate the island directly.

Operation and Maintenance Tool

The Operation and Maintenance tool (OMT) is web-based and optimized for use with a tablet so a technician can troubleshoot and diagnose the island without opening the electrical panel. The operation and maintenance tool offers the following features to aid in operation, maintenance, and troubleshooting:

- Customizable user interface
- User access and rights management for secure login
- Monitoring of device behavior, load behavior, and energy consumption
- Test mode and Force mode available for ease of maintenance
- Diagnostics to check the island's status and monitor the TeSys™ Avatars
- Control panel to operate the island directly
- Maintenance alarms to help avoid machine down time
- Access to product data for asset management
- Accessibility from the engineering tools with a QR scan

Fieldbus Communication

Industrial Communication Protocols

TeSys™ island supports the EtherNet/IP™ and Modbus™ TCP industrial communication protocols.

Degraded Mode

When fieldbus communication with the controller is lost, TeSys™ island remains in the operational state but enters Degraded mode. A communication loss is defined as follows:

- EtherNet/IP fieldbus: a communication loss is detected when an established exclusive owner connection times out.
- Modbus™/TCP fieldbus: a communication loss is detected after receiving no write requests to the cyclic I/O scanning data for the duration specified by the Communication Loss Timeout setting in the DTM.

NOTE: Loss of communication with the DTM or OMT does not trigger the transition to Degraded mode.

During Degraded mode:

- The Fieldbus ports remain active.
- The Service port remains active.
- The TeSys Avatars enter Fallback state. For the definition of Fallback state, see *System States*.

Recovering from Degraded Mode

You can enable the Degraded mode auto-reset option in the DTM. If *Enable Degraded Mode Auto-Reset* is set to Yes, then TeSys™ island exits Degraded mode when communication is restored. Refer to the *TeSys™ island Operating Guide* for more information.

If the option *Enable Degraded Mode Auto-Reset* is set to No, then a System Restart command or power cycle is required to exit Degraded mode.

TeSys™ Avatar Introduction

Avatar Definition

TeSys™ Avatars bring ready-to-use functions through their predefined logic and associated physical devices. The Avatar logic is executed in the bus coupler. The bus coupler manages data exchanges internally within the island, and also externally with the PLC.

The TeSys Avatars include three types:

System Avatar

Represents the whole island as a system. The system avatar allows setting the network configuration and computes island level data.

Device Avatars

Represent functions performed by switches and I/O modules.

Load Avatars










Represent functions related to specific loads, such as a forward-reverse motor. Load Avatars include the appropriate modules and operating characteristics to serve the load type. For example, a Motor Two Directions Avatar includes two starter modules, accessories, pre-programmed control logic, and a pre-configuration of the available protection functions.

The Avatars installed on the TeSys island are controlled by the island's bus coupler. Each Avatar includes predefined logic for managing its physical modules, while also providing easy data exchange with PLCs through function blocks. Avatars include preconfiguration of the available protection functions. Data exchanges between PLCs and all the Avatars on the island are managed through the bus coupler.

Information accessible through the Avatar includes:










- Control data
- Advanced diagnostics data
- Asset management data
- Energy data

List of TeSys™ Avatars



Name	Icon	Description
System Avatar		A required Avatar that enables a single point of communication to the island.
Switch		To make or break a power line in an electrical circuit
Switch - Safe Stop, W. Cat 1/2 ⁶		To make or break a power line in an electrical circuit with Safe Stop, Wiring Category 1 and Category 2. Safe Stop according to EN 61800-5-2.
Digital I/O		To provide control of 2 digital outputs and status of 4 digital inputs
Analog I/O		To provide control of 1 analog output and status of 2 analog inputs
Power Interface without I/O (measure)		To monitor current supplied to an external device, such as a solid-state relay, soft starter, or variable speed drive
Power Interface with I/O (control)		To monitor current supplied to and to control an external device, such as a solid-state relay, soft starter, or variable speed drive
Motor One Direction		To manage ⁷ a motor in one direction
Motor One Direction - Safe Stop, W. Cat 1/2 ⁶		To manage a motor in one direction, with Safe Stop, Wiring Category 1 and Category 2. Safe Stop according to EN 61800-5-2.

6. Safe Stop, Wiring Category 1 and Category 2. Safe Stop according to EN 61800-5-2.

7. "Manage" in this context encompasses energizing, controlling, monitoring, diagnosing, and protecting the load.

Name	Icon	Description
Motor Two Directions		To manage a motor in two directions (forward and reverse)
Motor Two Directions - Safe Stop, W. Cat 1/2 ⁸		To manage a motor in two directions (forward and reverse), with Safe Stop, Wiring Category 1 and Category 2. Safe Stop according to EN 61800-5-2.
Motor Y/D One Direction		To manage a wye-delta (star-delta) motor in one direction
Motor Y/D Two Directions		To manage a wye-delta (star-delta) motor in two directions (forward and reverse)
Motor Two Speeds		To manage a two-speed motor
Motor Two Speeds - Safe Stop, W. Cat 1/2 ⁸		To manage a two-speed motor, with Safe Stop, Wiring Category 1 and Category 2. Safe Stop according to EN 61800-5-2.
Motor Two Speeds Two Directions		To manage a two-speed motor in two directions (forward and reverse)
Motor Two Speeds Two Directions - Safe Stop, W. Cat 1/2 ⁸		To manage a two-speed motor in two directions (forward and reverse), with Safe Stop, Wiring Category 1 and Category 2. Safe Stop according to EN 61800-5-2.
Resistor		To manage a resistive load

8. Safe Stop, Wiring Category 1 and Category 2. Safe Stop according to EN 61800-5-2.

Name	Icon	Description
Power Supply		To manage a power supply
Transformer		To manage a transformer

Avatar Functional Description

Avatar Function Allocation

In the following table, a check mark ✓ indicates the function groups that are possible with each TeSys™ Avatar.

Table 21 - Avatar Function Allocation

Name	Current Monitoring	Upstream Voltage Presence	Electrical Protection	Load Protection	Motor Overheat Protection ⁹	Energy Monitoring ¹⁰
System Avatar	—	—	—	—	—	✓
Switch	✓	✓	✓	—	—	—
Switch - Safe Stop, W. Cat 1/2 ¹¹	✓	✓	✓	—	—	—
Digital I/O	—	—	—	—	—	—
Analog I/O	—	—	—	—	—	—
Power Interface without IO (measure)	✓	✓	✓	✓	✓	✓
Power Interface with IO (control)	✓	✓	✓	✓	✓	✓
Motor One Direction	✓	✓	✓	✓	✓	✓
Motor One Direction - Safe Stop, W. Cat 1/2 ¹¹	✓	✓	✓	✓	✓	✓
Motor Two Directions	✓	✓	✓	✓	✓	✓
Motor Two Directions - Safe Stop, W. Cat 1/2 ¹¹	✓	✓	✓	✓	✓	✓
Motor Y/D One Direction	✓	✓	✓	✓	✓	✓
Motor Y/D Two Directions	✓	✓	✓	✓	✓	✓
Motor Two Speeds	✓	✓	✓	✓	✓	✓
Motor Two Speeds - Safe Stop, W. Cat 1/2 ¹¹	✓	✓	✓	✓	✓	✓
Motor Two Speeds Two Directions	✓	✓	✓	✓	✓	✓
Motor Two Speeds Two Directions - Safe Stop, W. Cat 1/2 ¹¹	✓	✓	✓	✓	✓	✓
Resistor	✓	✓	✓	✓	—	✓
Power Supply	✓	✓	✓	✓	—	✓
Transformer	✓	✓	✓	✓	—	✓

9. With analog I/O module.

10. With voltage interface module.

11. Safe Stop, Wiring Category 1 and Category 2. Safe Stop according to EN 61800-5-2.

Protection Functions

TeSys™ island offers a wide range of load protection functions (including thermal protection) and electrical protection functions. These functions can be enabled for each applicable TeSys Avatar, and configured to react to given operational conditions, by signaling alarm messages and triggering load trips.

⚠ WARNING
<p>UNINTENDED EQUIPMENT OPERATION</p> <p>Make sure to set the protection functions' parameters according to the required protection level of the controlled motors and loads.</p> <p>Failure to follow these instructions can result in death, serious injury, or equipment damage.</p>

The following table lists the protection functions available for all Avatars. The functions can be enabled and configured individually.

Table 22 - Protection Functions

Load Protection Functions	Thermal Protection Functions
<ul style="list-style-type: none"> • Jam • Long Start • Stall • Undercurrent • Overcurrent • Rapid Cycle Lockout • Rapid Restart Lockout 	<ul style="list-style-type: none"> • Thermal Overload • Motor Overheat
	<p>Electrical Protection Functions</p> <ul style="list-style-type: none"> • Phase Configuration • Current Phase Unbalance • Current Phase Loss • Ground Current Detection • Current Phase Reversal

The following table defines parameters that are associated with multiple protection functions. They are referred to throughout the protection function sections in this instruction bulletin.

Table 23 - Common Protection Function Parameters

Parameter	Definition
<function name> Trip Enable	A setting to enable the trip function
<function name> Trip Delay	A time setting specifying the duration that a trip condition must exist to trigger a trip
<function name> Trip Level	A setting to define the level of an input that triggers a trip
<function name> Alarm Enable	A setting to enable the alarm function
<function name> Alarm Level	A setting to define the level of an input that triggers an alarm

About Motor Start and Run States

Based on the electrical consumption of the driven motor, TeSys™ island identifies whether the motor is in the Off, Start, or Run state. These states, along with the enable setting, determine which protection functions apply. For instance, the Undercurrent protection function does not apply to a motor in the Off state.


The motor states are defined by the following:

- Off state: the measured current is less than or equal to 30% I_r .
- Start state: this state begins after the Off state, with the detection of a measured current greater than 30% I_r . It continues until a transition occurs to Run state (or Off).
- Run State (condition 1): The Long Start Trip protection function is disabled. The detected current stays between 30% I_r and the Long Start Trip Level for the time defined by the Long Start Trip Delay. (The timer starts at the beginning of the Start state.)
- Run State (condition 2): The Long Start Trip protection function is disabled. The detected current rises above the Long Start Trip Level, and does not fall below the Long Start Trip Level within the time defined by Long Start Trip Delay. (The timer starts at the beginning of the Start state.)
- Run State (condition 3): The detected current rises above Long Start Trip Level and then falls below the Long Start Trip Level.

Run State


The following figures illustrate the different transitions from the Start State to Run State.

Figure 10 - Run State (Condition 1)




I	Current	I_r	Rated Current
A	Long Start Trip Level	B	Long Start Trip Delay
C	Start State	D	Run State
t	Time		

Figure 11 - Run State (Condition 2)



I	Current	Ir	Rated Current
A	Long Start Trip Level	B	Long Start Trip Delay
C	Start State	D	Run State
t	Time		

Figure 12 - Run State (Condition 3)



I	Current	Ir	Rated Current
A	Long Start Trip Level	C	Start State
D	Run State	t	Time

Load Protection Functions


Jam

The Jam function detects when a motor is jammed during the Run state. The motor either stops or is suddenly overloaded and draws excessive current.

If enabled, this protection function performs the following when the motor is in the Run state:

- Signals a Jam Alarm when the maximum phase current (I_{max}) exceeds the specified Jam Alarm Level
- Triggers a Jam Trip when the maximum phase current (I_{max}) exceeds the specified Jam Trip Level for a time longer than the specified Jam Trip Delay

Figure 13 - Jam Trip and Alarm



I1	Phase 1 Current	I2	Phase 2 Current
I3	Phase 3 Current	T	Jam Trip Delay
A	I_{max}	B	Run State
C	$I_{max} \geq \text{Jam Alarm Level}$	D	$I_{max} \geq \text{Jam Trip Level}$
E	Jam Alarm	F	Jam Trip


Long Start

The Long Start function detects when a motor remains in the Start state for an excessive period of time.

If enabled, this protection function triggers a Long Start trip when the motor is in the Start state, and one of the following conditions occur during the specified Long Start Trip Delay:

- Average current too low: the average current remains below the specified Long Start Trip Level
- Average current too high: the average current rises above the specified Long Start Trip Level but does not fall below it again.


Figure 14 - Long Start Trip



I1	Phase 1 Current	I2	Phase 2 Current
I3	Phase 3 Current	T	Long Start Trip Delay
A	l_{avg}	B	$l_{avg} \geq 30\%$
C	$l_{avg} \leq \text{Long Start Trip Level}$	D	$l_{avg} \geq \text{Long Start Trip Level}$
E	# of Crossings = 1	F	Long Start Trip


NOTE: Number of Crossings = the number of times the value of current crossed (from above to below, or below to above) the Long Start Trip Level.

Figure 15 - Average Current Continuously Exceeds the Long Start Trip Level (1 Crossing)



G	Long Start Trip Level	H	Long Start Trip Delay (in Start State)
I	Current	Ir	Rated Current
t	Time		

Figure 16 - Average Current Does Not Reach the Long Start Trip Level



G	Long Start Trip Level	H	Long Start Trip Delay (in Start State)
I	Current	I_r	Rated Current
J	Run State	t	Time


Stall

The Stall function detects high current intensity, typically associated with a locked or stalled motor, while in the Start state.

If enabled, this protection function triggers a Stall trip when the motor is in the Start state, and the maximum phase current exceeds the specified Stall Trip Level for a time longer than the specified Stall Trip Delay.

NOTE: No Stall detection alarm is associated with this function.


Figure 17 - Stall and Trip



I1	Phase 1 Current	I2	Phase 2 Current
I3	Phase 3 Current	A	I_{max}
B	$I_{max} \geq \text{Stall Trip Level}$	C	Start State
D	Stall Trip	T	Stall Trip Delay

This function is typically enabled in addition to the Long Start protection function, setting a higher acceptable current intensity level and a shorter trip delay.

Figure 18 - Stall Trip Versus Long Start Trip



D	Stall Trip	E	Stall Level
F	Long Start Trip Level	G	Long Start Trip Delay
I	Current	Ir	Rated Current
t	Time	T	Stall Trip Delay

NOTE: In this illustration, the Stall protection function triggers a trip—while the Long Start protection function does not (because the Long Start Trip Delay has not elapsed yet).


Undercurrent

The Undercurrent function detects unexpected low current consumption during the Run state. This condition is typically associated with motors running free, without a load—for instance, if a drive belt or shaft has broken.

If enabled, this protection function performs the following:

- Signals an Undercurrent Alarm when the average phase current remains below the specified Undercurrent Alarm Level
- If the motor is in the Run state, triggers an Undercurrent Trip when the average phase current remains below the specified Undercurrent Trip Level, for a time longer than the specified Undercurrent Trip Delay

Figure 19 - Undercurrent Trip and Alarm




I1	Phase 1 Current	I2	Phase 2 Current
I3	Phase 3 Current	A	l_{avg}
B	$l_{avg} \leq \text{Undercurrent Alarm Level}$	C	$l_{avg} \leq \text{Undercurrent Trip Level}$
D	Run State	E	Undercurrent Alarm
F	Undercurrent Trip	T	Undercurrent Trip Delay

Overcurrent

TeSys™ Avatars with Overcurrent Alarm enabled signal an Overcurrent Alarm if the maximum phase current exceeds the Overcurrent Alarm Level in the motor Run state.

Avatars with Overcurrent Trip enabled signal an Overcurrent Trip if the maximum phase current exceeds the Overcurrent Trip Level in the motor Run state for a time longer than the Overcurrent Trip Delay.

Figure 20 - Overcurrent Trip and Alarm



I1	Phase 1 Current	I2	Phase 2 Current
I3	Phase 3 Current	A	I_{max}
B	$I_{max} \geq \text{Overcurrent Alarm Level}$	C	$I_{max} \geq \text{Overcurrent Trip Level}$
D	Run State	E	Overcurrent Alarm
F	Overcurrent Trip	T	Overcurrent Trip Delay


Rapid Cycle Lockout

The Rapid Cycle Lockout function helps prevent potential harm to the motor caused by repetitive, successive inrush currents resulting from too little time between starts.

If this protection function is enabled, the TeSys™ Avatar ignores Run commands for the duration specified by the Rapid Cycle Lockout Timeout, starting from the last transition to the motor Start state.

No alarm or trip is associated with this function.

Figure 21 - Rapid Cycle Lockout Timeout



Ir	Rated Current	A	Rapid Cycle Lockout Timeout
B	New Run Commands Ignored	C	New Run Commands Not Ignored
D	Transition into Motor Start State	t	Time


Rapid Restart Lockout

The Rapid Restart Lockout function helps prevent potential harm to the motor caused by repetitive, successive stop and start events.

If this protection function is enabled, the TeSys™ Avatar ignores Run commands for the duration specified by the Rapid Restart Lockout Timeout, starting from the last transition to the motor Off state .

No alarm or trip is associated with this function.

Figure 22 - Rapid Restart Lockout



Ir	Rated Current	I	Current
A	Rapid Restart Lockout Timeout	B	New Run Commands Ignored
C	New Run Commands Not Ignored	D	Transition to Motor Off State
t	Time		

Thermal Protection Functions

Thermal Overload

The Thermal Overload protection function is based on a thermal model which calculates the used thermal capacity of the motor.


If enabled, this function performs the following:

- Signals a Thermal Overload Alarm when the motor thermal capacity used exceeds the Overload Alarm Level
- Triggers a Thermal Overload Trip when the motor thermal capacity used exceeds 100%

The Thermal Reset Threshold parameter sets the percentage below which the motor thermal capacity used must fall, before a thermal overload trip reset is allowed.

NOTE: For single phase, thermal overload protection uses only I1 and I3.

Figure 23 - Thermal Overload Protection Trip and Alarm



I1	Phase 1 Current	I2	Phase 2 Current
I3	Phase 3 Current	A	Motor Thermal Model
B	Motor Thermal Capacity Used \geq 100%	C	Motor Thermal Capacity Used \geq Thermal Overload Alarm Level
D	Thermal Overload Trip	E	Thermal Overload Alarm

Motor Overheat


The Motor Overheat function is only available for TeSys™ Avatars whose Temperature Sensor Available parameter is activated. These Avatars include an analog I/O module, which is wired to the temperature input from the temperature sensor associated with the protected motor.

If enabled, this protection function performs the following:

- Signals a Motor Overheat Alarm when the motor temperature exceeds the Motor Overheat Alarm Level
- Triggers a Motor Overheat Trip when the motor temperature exceeds the Motor Overheat Trip Level, for a time longer than the Motor Overheat Trip Delay

The Motor Overheat Trip Reset Threshold parameter sets the percentage below which the temperature must fall, before a trip reset is allowed.

Figure 24 - Motor Overheat Trip and Alarm



A	Motor Temperature	B	Motor Temperature \geq Motor Overheat Alarm Level
C	Motor Temperature \geq Motor Overheat Trip Level	D	Alarm
E	Trip	T	Motor Overheat Trip Delay

Electrical Protection Functions

Electrical protection functions detect electrical problems.

- Phase Configuration
- Current Phase Unbalance
- Current Phase Loss
- Ground Current Detection
- Current Phase Reversal

Phase Configuration

The Phase Configuration function applies only to single-phase TeSys™ Avatars. In a single-phase system, this feature is automatically enabled. It triggers a Phase Configuration trip if the current in phase two is greater than 50% I_r FLA for more than 1 s.

NOTE: Phase Configuration protection does not apply to three-phase operation.

Current Phase Unbalance


The Current Phase Unbalance function only applies to three-phase TeSys™ Avatars.

If enabled, this protection function performs the following:

- Signals a Current Phase Unbalance Alarm when the current phase unbalance exceeds the specified Current Phase Unbalance Alarm Level
- Triggers a Current Phase Unbalance Trip when the current phase unbalance exceeds the specified Current Phase Unbalance Trip Level for a time longer than the specified Current Phase Unbalance Trip Delay

NOTE: Separate trip delays are configurable for Run State and Start State.

Figure 25 - Current Phase Unbalance Trip and Alarm



I1	Phase 1 Current	I2	Phase 2 Current
I3	Phase 3 Current	%lunb	%Current Phase Unbalance
lalarm	Current Phase Unbalance Alarm Level	ltrip	Current Phase Unbalance Trip Level
T1	Current Phase Unbalance Trip Delay —Start	T2	Current Phase Unbalance Trip Delay —Run
A	Motor Start State	B	Motor Run State
C	Current Phase Unbalance Alarm	D	Current Phase Unbalance Trip

NOTE: The %Current Phase Unbalance value is

- The maximum difference between any individual phase RMS current (in absolute value) and the average of the three-phase RMS currents
- Divided by the average of the three-phase RMS currents

Current Phase Loss


The Current Phase Loss function only applies to three-phase TeSys™ Avatars.

If enabled, then in the motor Start or Run state, this protection function triggers a Current Phase Loss Trip when the current phase unbalance exceeds the Current Phase Loss Trip Level, for a time longer than the Current Phase Loss Trip Delay.

NOTE: The Current Phase Unbalance value is the ratio of the following:

- The maximum difference between any individual phase RMS current (in absolute value) and the average of the three-phase RMS currents
- Divided by the average of the three-phase RMS currents

Figure 26 - Current Phase Loss Trip



I1	Phase 1 Current	I2	Phase 2 Current
I3	Phase 3 Current	%lunb	%Current Phase Unbalance
lalarm	Current Phase Loss Alarm Level	ltrip	Current Phase Loss Trip Level
A	Current Phase Loss Alarm	B	Current Phase Loss Trip
C	Motor Start or Run State	T	Current Phase Loss Trip Delay


Ground Current Detection

The Ground Current Detection function detects ground currents.

If enabled, this protection function performs the following:

- Signals a Ground Current Detection Alarm when the ground current exceeds the specified Ground Current Alarm Level
- Triggers a Ground Current Detection Trip when the ground current exceeds the specified Ground Current Trip Level, for a time longer than the specified Ground Current Trip Delay

Figure 27 - Ground Current Trip and Alarm



I1	Phase 1 Current	I2	Phase 2 Current
I3	Phase 3 Current	IΣ	Summation of the Current
IΣs1	Ground Current Alarm Level	IΣs2	Ground Current Trip Level
A	Ground Current Alarm	B	Ground Current Trip
T	Ground Current Trip Delay		


Phase Reversal

The Phase Reversal function detects incorrect phase sequence in a three-phase system, causing a connected three-phase motor or other rotating equipment to run in the opposite direction than expected.

If enabled, this protection function triggers a Phase Reversal trip if the detected current phase sequence does not match the Current Phase Sequence setting over a time period of 100 ms.

No alarm is associated with this function. The 100 ms time period is not adjustable.

Figure 28 - Phase Reversal for Setting ABC



Alarm and Trip Counters

Protection functions increment alarm and trip event counters, both at the TeSys™ Avatar level and overall at the island level. Counters can be reset to zero on demand.

The following tables describe counter behavior.

Table 24 - Counter Inputs

Inputs	Description
Alarm Counter Reset	Resets all alarm counters (see the following table) to zero.
Trip Counter Reset	Resets all trip counters (see the following table) to zero. All Avatars store the last five trip records, each containing the timestamp and cause of the trip.

Table 25 - List of Alarm Counters

Outputs	Description
Thermal Overload Alarm Count	Increments when an individual alarm is triggered. Reset by Alarm Counter Reset
Jam Alarm Count	
Undercurrent Alarm Count	
Overcurrent Alarm Count	
Current Phase Unbalance Alarm Count	
Ground Current Alarm Count	
All Alarms Count	Increments when any type of protection alarm is triggered. Reset by Alarm Counter Reset.

Table 26 - List of Trip Counters

Outputs	Description
Thermal Overload Trip Count	Increments when an individual trip is triggered. Reset by Trip Counter Reset
Jam Trip Count	
Undercurrent Trip Count	
Long Start Trip Count	
Overcurrent Trip Count	
Stall Trip Count	
Current Phase Unbalance Trip Count	
Phase Configuration Trip Count	
Ground Current Detection Trip Count	
Current Phase Reversal Trip Count	
Current Phase Loss Trip Count	
All Trips Count	Increments when any type of protection trip is triggered. Reset by Trip Counter Reset.

Table 27 - Records of the Last Five Trips

Outputs	Description
Trip Record Register 1 (most recent)	First In First Out registers without reset
Trip Record Register 2	
Trip Record Register 3	
Trip Record Register 4	
Trip Record Register 5 (least recent)	

Table 28 - List of Auto-Reset Counters

Outputs	Description
Thermal Protection Auto-Reset Retry Count	Provides the number of auto-reset retry attempts for Thermal Protection functions. If there is no trip within one minute after a retry attempt, the start is considered successful and Auto Reset Retry Count is reset to 0.
Electrical Protection Auto-Reset Retry Count	Provides the number of auto-reset retry attempts for Electrical Protection functions. If there is no trip within one minute after a retry attempt, the start is considered successful and Auto Reset Retry Count is reset to 0.
Load Protection Auto-Reset Retry Count	Provides the number of auto-reset retry attempts for Load Protection functions. If there is no trip within one minute after a retry attempt, the start is considered successful and Auto Reset Retry Count is reset to 0.

Trip Reset Command

NOTE: The Reset function may lead to immediate energizing of the load, with an active command from the PLC or the Force mode function.

⚠ WARNING

UNINTENDED EQUIPMENT OPERATION

Before resetting the protection functions, verify that this function does not result in unsafe conditions.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

A tripped TeSys™ Avatar can only reset protection trips after receiving a Trip Reset command and if all the trip reset conditions are met for all its protection functions. This mechanism helps ensure that, after a trip, normal operation can only resume when all the defined normal operational conditions are met again.

When a protection function has caused an Avatar to trip, the Avatar remains in the tripped state until both of the following occur:

- The operational conditions again match the trip reset conditions of the protection function
- The Avatar receives a Trip Reset command

The Trip Reset command applies to all the protection functions enabled for a given Avatar, but only the protection functions whose trip reset conditions are met will actually get their Tripped state output set to false. The other protection functions whose trip reset conditions are still not met will keep their Tripped status output set to true.

A tripped Avatar has at least one tripped protection function (with a Tripped status set to true).

According to the same logic, an Avatar that is not tripped has no tripped protection functions (no protection with a Tripped status set to true).

Tripped protection functions can be reset by the Auto-Reset function, via the controller or by using one of the digital tools.

Note that the Tripped status of all protection functions is maintained through a power cycle of the system—with the exception of the Current Phase Reversal and Phase Configuration functions. For these functions, a power cycle resets the Tripped status (to not tripped).

The following table describes the Trip Reset Conditions, including hysteresis, for all Avatars.

Table 29 - Trip Reset Conditions


Protection Function	Trip Reset Conditions
Thermal Overload	Thermal capacity has decreased below Thermal Reset Threshold (no hysteresis).
Motor Overheat	Motor temperature has decreased below Motor Overheat Reset Threshold (no hysteresis).
Current Phase Unbalance	Current unbalance has decreased below Current Phase Unbalance Trip Level.
Current Phase Loss	Current unbalance has decreased below Current Phase Loss Trip Level.
Jam	Maximum phase current has decreased below Jam Trip Level.
Undercurrent	Average current has increased above Undercurrent Trip Level.
Long Start	Average current has decreased below 30% I _r (no hysteresis).
Overcurrent	Maximum phase current has decreased below Overcurrent Trip Level.
Stall	Maximum phase current has decreased below Stall Trip Level.
Ground Current	Ground current has decreased below Ground Current Trip Level.
Current Phase Reversal	Average current has decreased below 30% I _r (no hysteresis).
Phase Configuration	Average current has decreased below 30% I _r (no hysteresis).

Where indicated, protection functions apply a 5% hysteresis value to the trip reset conditions. This increases the stability of the protection functions' behavior. The trip reset is only authorized when normal conditions and this extra 5% margin are recovered.

For instance, the Jam protection function triggers a trip when the maximum phase current exceeds the defined Jam trip level. The trip reset conditions are met when the maximum phase current decreases below the Jam trip level minus 5%.

Additionally, setting the Trip Enable parameter for a protection function to Disable meets the Trip reset condition for that protection function.

Figure 29 - Hysteresis



NOTE: d = Hysteresis percentage

Trip Auto-Reset Function

NOTE: The Auto-Reset function may lead to immediate energizing of the load, with an active command from the PLC or the Force mode function.

⚠ WARNING
UNINTENDED EQUIPMENT OPERATION
Configure this function in a such a way that it does not result in unsafe conditions.
Failure to follow these instructions can result in death, serious injury, or equipment damage.

The Automatic Reset function triggers trip reset commands automatically, without the intervention of a human operator. This function can be configured separately for each Thermal group, Electrical group, and Load group of protection functions of a TeSys™ Avatar.

The following table defines the Auto-Reset groups.

Table 30 - Auto-Reset Groups

Auto-Reset Group	Protection Trip Cause
Load Protection	Jam
	Long Start
	Stall
	Undercurrent
	Overcurrent
Thermal Protection	Thermal Overload
	Motor Overheat
Electrical Protection	Phase Configuration
	Current Phase Unbalance
	Current Phase Loss
	Ground Current Detection
	Current Phase Reversal

For each group, you can configure the following:

- A delay before a reset attempt
- Functionality to repeat reset attempts

The Auto-Reset function ultimately works as the Trip Reset command: the tripped protection functions are reset only if their trip reset conditions are met.

Two parameters can be configured for each group of protection functions.

- The Auto-Reset Timer is a delay between the moment a protection function detects the presence of trip conditions (and triggers a trip), and the first auto-reset attempt. The actual reset can occur only after the delay elapses and the trip reset conditions are met. For instance, if the delay is set to 60 s and it takes 70 s for the system to meet the trip reset conditions, then the reset occurs after 70 s (that is, the shortest duration that satisfies both rules). If it only takes 50 s to meet the trip reset conditions, then the delay still applies and the reset occurs after 60 s.
- The Auto-Reset Retry Attempt Maximum specifies the number of reset attempts made if the previous ones are unsuccessful (for instance, if the external conditions causing the trip to occur still exist.). If the Auto-Reset Retry Attempt Maximum parameter is set to A, the reset attempts are repeated indefinitely until the reset is successful. Otherwise, only the specified number of resets is attempted.

These parameters apply to each protection function within the group. If multiple protection functions are tripped within a given group, then the delay, the criteria of the trip reset conditions, and the retry attempt maximum setting apply to all the tripped functions of that group. For example, if both the Stall and Long Start protection functions are tripped, the Auto-Reset triggers a trip reset only after the delay set for the Load Protection group elapses, and the trip reset conditions are met for both protection functions.

The Group Auto-Reset Retry counter increments for each retry attempt. It is reset to zero one minute after a successful trip reset (in the absence of further trips).

The following table describes Auto-Reset parameters.

Table 31 - Auto-Reset Parameters

Setting Name	Description	Value Range	Units	Default Value	Increment	
Load Protection	Auto-Reset Retry Attempt Maximum	Parameter to limit Auto-Reset operations	0–10 (A)	—	0	1
	Auto-Reset Timer	Timer to trigger Auto-Reset	0–65,535	s	60	1
Thermal Protection	Auto-Reset Retry Attempt Maximum	Parameter to limit Auto-Reset operations	0–10 (A)	—	A	1
	Auto-Reset Timer	Timer to trigger Auto-Reset	0–65,535	s	480	1
Electrical Protection	Auto-Reset Retry Attempt Maximum	Parameter to limit Auto-Reset operations	0–10 (A)	—	0	1
	Auto-Reset Timer	Timer to trigger Auto-Reset	0–65,535	s	1,200	1

Monitoring Data

Upstream Voltage Presence

The Upstream Voltage Presence function detects the presence of voltage in the upstream power connections of the devices. This information typically indicates the open/closed state of upstream protection devices (like circuit breakers).

Current Monitoring

The Current Monitoring function provides average and per-phase current information at the TeSys™ Avatar level. It can also detect the maximum current seen since last reset, along with an associated timestamp. Average current is available in the Control function block for each Avatar, with additional information in the Diagnostics function block.

Energy Monitoring

The Energy Monitoring functions provide several voltage, power, and energy measurements, both at the TeSys™ Avatar level and for the full island.

These functions can be activated through the Avatars' Load Energy Monitoring setting, and require one voltage interface module to be installed in the island.

Energy is measured within a 10% accuracy for loads running under nominal conditions (50–125% FLA, power factor 0.7, 47–63 Hz).

System Monitoring

The monitoring functions described in the following tables apply to the TeSys™ island as a whole.

Table 32 - Voltage Monitoring

- Phase RMS Voltage
- Average RMS Voltage
- Maximum RMS Voltage and Timestamp
- Voltage Fluctuation Status (Dip and Swell)
- Percentage of Unbalance Voltage
- Maximum Unbalance Voltage and Timestamp
- Voltage Frequency (Hz)
- Voltage Phase Sequence

Table 33 - Power Monitoring

- Instantaneous Total Active Power (kW)
- Maximum Total Active Power (kW) and Timestamp
- Instantaneous Total Reactive Power (kVAR)
- Maximum Total Reactive Power (kVAR) and Timestamp
- True Power Factor
- Minimum True Power Factor and Timestamp
- Maximum True Power Factor and Timestamp

Table 34 - Energy Monitoring

- Total Active Energy (kWh)
- Total Reactive Energy (kVARh)

Avatar Monitoring

The monitoring functions described in the following tables apply to the TeSys™ Avatars individually.

Table 35 - Power Monitoring

- Instantaneous Total Active Power (kW)
- Maximum Total Active Power (kW) and Timestamp
- Instantaneous Total Reactive Power (kVAR)
- Maximum Total Reactive Power (kVAR) and Timestamp
- True Power Factor
- Minimum True Power Factor and Timestamp
- Maximum True Power Factor and Timestamp

Table 36 - Energy Monitoring

- Total Active Energy (kWh)
- Total Reactive Energy (kVARh)

Avatar Composition

Standard Starter (ST)



Power Interface Module (PM)



SIL Starter (SS)



SIL Interface Module (SM)



Digital I/O Module (DG)



Analog I/O Module (AN)



Table 37 - Avatar Modules

TeSys™ Avatar	Module 1	Module 2	Module 3	Module 4	Module 5	Optional
Switch	ST					
Switch - Safe Stop, W. Cat 1/2 ¹²	SS	SM				
Digital I/O	DG					
Analog I/O	AN					
Power Interface without I/O (Measure)	PM					AN
Power Interface with I/O (Control)	DG	PM				AN
Motor One Direction	ST					AN
Motor One Direction - Safe Stop, W. Cat 1/2 ¹²	SS	SM				AN
Motor Two Directions	ST	ST				AN
Motor Two Directions - Safe Stop, W. Cat 1/2 ¹²	SS	SS	SM			AN
Motor Y/D One Direction	ST	ST	ST			AN
Motor Y/D Two Directions	ST	ST	ST	ST		AN
Motor Two Speeds	ST	ST				AN
Motor Two Speeds - Safe Stop, W. Cat 1/2 ¹²	SS	SS	SM			AN
Motor Two Speeds Two Directions	ST	ST	ST	ST		AN
Motor Two Speeds Two Directions - Safe Stop, W. Cat 1/2 ¹²	ST	ST	SS	SS	SM	AN
Resistor	ST					
Power Supply	ST					
Transformer	ST					

12. Safe Stop according to EN 61800-5-2.

Table 38 - LAD9R1 Assembly Kit for 9–38 A (Size 1 and 2) Starters


LAD9R1 Assembly Kit	For Use with Avatars:	Kit Components	Description
	Motor Two Directions	LAD9V5	Parallel link between two starters
	Motor Two Directions - Safe Stop, W. Cat 1/2 ¹³	LAD9V6	Reversing link between two starters
	Motor Y/D One Direction	LAD9V2	Mechanical interlock with assembly staple
	Motor Two Speeds Two Directions		

Table 39 - LAD9R3 Assembly Kit for 40–65 A (Size 3) Starters


LAD9R3 Assembly Kit	For Use with Avatars:	Kit Components	Description
	Motor Two Directions	LA9D65A6	Parallel link between two starters
	Motor Two Directions - Safe Stop, W. Cat 1/2 ¹³	LA9D65A9	Reversing link between two starters
	Motor Y/D One Direction	LAD4CM	Mechanical interlock
	Motor Two Speeds Two Directions		

Table 40 - Shorting Blocks for Y/D Avatars





Shorting Blocks	For Use with Avatars:	Reference Number	Description
	Motor Y/D One Direction Motor Y/D Two Directions	LAD9P3	Shorting block / 3P parallel link for 9–38 A (size 1 and 2) starters Used for linking 3 poles of a contactor in a wye-delta (Y/D) starter
	Motor Y/D One Direction Motor Y/D Two Directions	LAD9SD3S	Shorting block / 3P parallel link for 40–65 A (size 3) starters and hazard label Used for linking 3 poles of a contactor in a wye-delta (Y/D) starter

Table 41 - Mechanical Interlocks

Mechanical Interlocks	For Use with Avatars:	Reference Number	Description
	Motor Y/D One Direction Motor Y/D Two Directions Motor Two Speeds Motor Two Speeds - Safe Stop, W. Cat 1/2 ¹³ Motor Two Speeds Two Directions	LAD9V2	Mechanical interlock for 9–38 A (size 1 and 2) starters
	Motor Y/D One Direction Motor Y/D Two Directions Motor Two Speeds Motor Two Speeds - Safe Stop, W. Cat 1/2 ¹³ Motor Two Speeds Two Directions	LAD4CM	Mechanical interlock for 40–65 A (size 3) starters

13. Safe Stop according to EN 61800-5-2.

Table 42 - Reversing Links





Reversing Links	For Use with Avatars:	Reference Number	Description
	Motor Y/D One Direction Motor Y/D Two Directions	LAD9V6	Reversing link for 9–38 A (size 1 and 2) starters
	Motor Y/D One Direction Motor Y/D Two Directions	LA9D65A9	Reversing link for 40–65 A (size 3) starters

Table 43 - Parallel Links

Parallel Links	For Use with Avatars:	Reference Number	Description
	Motor Two Speeds Motor Two Speeds - Safe Stop, W. Cat 1/2 ¹⁴ Motor Two Speeds Two Directions	LAD9V5	Parallel link for 9–38 A (size 1 and 2) starters
	Motor Two Speeds Motor Two Speeds - Safe Stop, W. Cat 1/2 ¹⁴ Motor Two Speeds Two Directions	LA9D65A6	Parallel link for 40–65 A (size 3) starters

14. Safe Stop according to EN 61800-5-2.

Avatar Wiring Schematics and Accessory Diagrams

Bus Coupler with I/O Modules and Voltage Interface Modules

Figure 30 - Wiring




Table 44 - Legend

BC	Bus Coupler
AIOM	Analog I/O Module
DIOM	Digital I/O Module
VIM	Voltage Interface Module

Switch

Figure 31 - Wiring




Table 45 - Legend

E	Electrical circuit
----------	--------------------

Switch - Safe Stop, W. Cat 1/2

NOTE: Safe Stop according to EN 61800-5-2.

Figure 32 - Wiring





Table 46 - Legend

E	Electrical circuit
----------	--------------------

Digital I/O

Figure 33 - Wiring



Analog I/O

Figure 34 - Current/Voltage Analog Device Input




Figure 35 - Thermocouples




Figure 36 - Resistance Temperature Detector





Figure 37 - Current/Voltage Analog Device Output



Power Interface without I/O (Measure)

Figure 38 - Wiring




Table 47 - Legend

G	Relay, soft starter, or variable speed drive
----------	--

Power Interface with I/O (Control)

Figure 39 - Wiring





Table 48 - Legend

G	Relay, soft starter, or variable speed drive
----------	--

Motor One Direction


Figure 40 - Wiring



Motor One Direction - Safe Stop, W. Cat 1/2

NOTE: Safe Stop according to EN 61800-5-2.

Figure 41 - Wiring



Motor Two Directions

Figure 42 - Wiring (See Legend Table below.)




Figure 43 - Accessories




Table 49 - Legend

A	Mechanical interlock
B	Parallel link
C	Reversing link
F	Forward starter
R	Reverse starter
ST-1	Starter 1
ST-2	Starter 2

Motor Two Directions - Safe Stop, W. Cat 1/2

NOTE: Safe Stop according to EN 61800-5-2.

Figure 44 - Wiring (See Legend Table below.)




Figure 45 - Accessories




Table 50 - Legend

A	Mechanical interlock
B	Parallel link
C	Reversing link
F	Forward
R	Reverse
SS-1	SIL starter 1
SS-1	SIL starter 2

Motor Y/D One Direction

Figure 46 - Wiring (See Legend Table below.)




Figure 47 - Accessories




Table 51 - Legend

A	Mechanical interlock
C	Reversing link
D	Shorting block
Y	Wye
Δ	Delta
ST-1	Starter 1
ST-2	Starter 2
ST-3	Starter 3

Motor Y/D Two Directions

Figure 48 - Wiring (See Legend Table below.)




Figure 49 - Accessories




Table 52 - Legend

A	Mechanical interlock
B	Parallel link
C	Reversing link
D	Shorting block
F	Forward
R	Reverse
Y	Wye
Δ	Delta
ST-1	Starter 1
ST-2	Starter 2
ST-3	Starter 3
ST-4	Starter 4

Motor Two Speeds

Figure 50 - Wiring (See Legend Table below.)




Figure 51 - Accessories




Table 53 - Legend

A	Mechanical interlock
B	Parallel link
LS	Low speed
HS	High speed
ST-1	Starter 1
ST-2	Starter 2

Motor Two Speeds - Safe Stop, W. Cat 1/2

NOTE: Safe Stop according to EN 61800-5-2.

Figure 52 - Wiring (See Legend Table below.)




Figure 53 - Accessories




Table 54 - Legend

A	Mechanical interlock
B	Parallel link
LS	Low speed
HS	High speed
SS-1	SIL starter 1
SS-2	SIL starter 2

Motor Two Speeds Two Directions

Figure 54 - Wiring (See Legend Table below.)




Figure 55 - Accessories




Table 55 - Legend

A	Mechanical interlock
B	Parallel link
C	Reversing link
F	Forward
R	Reverse
LS	Low speed
HS	High speed
ST-1	Starter 1
ST-2	Starter 2
ST-3	Starter 3
ST-4	Starter 4

Motor Two Speeds Two Directions - Safe Stop, W. Cat 1/2

NOTE: Safe Stop according to EN 61800-5-2.

Figure 56 - Wiring (See Legend Table below.)




Figure 57 - Accessories





Table 56 - Legend

A	Mechanical interlock
B	Parallel link
C	Reversing link
F	Forward starter
R	Reverse starter
LS	Low speed
HS	High speed
ST-1	Starter 1
ST-2	Starter 2
SS-1	SIL starter 1
SS-2	SIL starter 2


Resistor

Figure 58 - Wiring




Power Supply

Figure 59 - Wiring



Transformer

Figure 60 - Wiring



Schneider Electric
800 Federal Street
Andover, MA 01810
USA

<https://www.se.com/en/work/support/>

www.se.com

As standards, specifications, and design change from time to time,
please ask for confirmation of the information given in this publication.

© 2019 – Schneider Electric. All rights reserved.

8536IB1901EN