TOSHIBA

SERVICE MANUAL

AIR-CONDITIONER (SPLIT TYPE)

INDOOR UNIT <4-way cassette type>

RAV-RM561UTP Series
RAV-RM801UTP Series
RAV-RM1101UTP Series
RAV-RM1401UTP Series
RAV-RM1601UTP Series

R32 or R410A









Original instruction

Adoption of New Refrigerant

This Air Conditioner is a new type which adopts a new refrigerant HFC (R32 or R410A) instead of the conventional refrigerant R22 in order to prevent destruction of the ozone layer.

CONTENTS

SAF	ETY	CAUTION	3
1.	CON	STRUCTION VIEWS (EXTERNAL VIEWS)	15
		RAV-RM561UTP*	15
		RAV-RM801UTP*	16
	1-3.	RAV-RM1101UTP*, RM1401UTP*, RM1601UTP*	17
2.	SYS	TEMATIC REFRIGERATING CYCLE DIAGRAM	18
3.	WIRI	NG DIAGRAM	21
4.	SPE	CIFICATIONS OF ELECTRICAL PARTS	22
5.	INDO	OOR CONTROL CIRCUIT	23
	5-1.	Indoor Controller Block Diagram	23
	5-2.	Control Specifications	26
	5-3.	Indoor Print Circuit Board	38
6.	TRO	UBLESHOOTING	40
	6-1.	Summary of Troubleshooting	40
	6-2.	Troubleshooting	42
7.	REP	LACEMENT OF SERVICE P.C. BOARD	60
8.	SET	JP AT LOCAL SITE AND OTHERS	65
	8-1.	Indoor Unit	65
	8-2.	Setup at Local Site / Others	76
	8-3.	How to Set up Central Control Address Number	78
	8-4.	How to set up type of swing	80
	8-5.	How to set louver lock (Louver fix)	81
_	8-6.	How to clear louver lock	81
9.		RESS SETUP	82
	9-1.	•	82
	9-2.	Address Setup & Group Control	83
	9-3.	Address Setup (Manual Setting from Remote Controller) Confirmation of Indoor Unit No. Position	86
	9-4.		87
10.	DET	ACHMENTS	89
11.		LODED VIEWS AND PARTS LIST	99
	11-1.	RAV-RM561UTP-E, RM801UTP-E, RM1101UTP-E,	
		RM1401UTP-E, RM1601UTP-E	99
	11-2.	RAV-RM561UTP-TR, RM801UTP-TR, RM1101UTP-TR, RM1401UTP-TR, RM1601UTP-TR	101

SAFETY CAUTION

Please read carefully through these instructions that contain important information which complies with the "Machinery" Directive (Directive 2006/42/EC), and ensure that you understand them.

Generic Denomination: Air Conditioner

Definition of Qualified Installer or Qualified Service Person

The air conditioner must be installed, maintained, repaired and removed by a qualified installer or qualified service person. When any of these jobs is to be done, ask a qualified installer or qualified service person to do them for you.

A qualified installer or qualified service person is an agent who has the qualifications and knowledge described in the table below.

Agent	Qualifications and knowledge which the agent must have			
Qualified installer	 The qualified installer is a person who installs, maintains, relocates and removes the air conditioners made by Toshiba Carrier Corporation. He or she has been trained to install, maintain, relocate and remove the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such operations by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to these operations. The qualified installer who is allowed to do the electrical work involved in installation, relocation and removal has the qualifications pertaining to this electrical work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to electrical work on the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work. The qualified installer who is allowed to do the refrigerant handling and piping work involved in installation, relocation and removal has the qualifications pertaining to this refrigerant handling and piping work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to refrigerant handling and piping work on the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained in matters relating to working at heights with the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work. 			
Qualified service person	 The qualified service person is a person who installs, repairs, maintains, relocates and removes the air conditioners made by Toshiba Carrier Corporation. He or she has been trained to install, repair, maintain, relocate and remove the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such operations by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to these operations. The qualified service person who is allowed to do the electrical work involved in installation, repair, relocation and removal has the qualifications pertaining to this electrical work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to electrical work on the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work. The qualified service person who is allowed to do the refrigerant handling and piping work involved in installation, repair, relocation and removal has the qualifications pertaining to this refrigerant handling and piping work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to refrigerant handling and piping work on the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained in matters relating to working at heights with the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work. 			

Definition of Protective Gear

When the air conditioner is to be transported, installed, maintained, repaired or removed, wear protective gloves and 'safety' work clothing.

In addition to such normal protective gear, wear the protective gear described below when undertaking the special work detailed in the table below.

Failure to wear the proper protective gear is dangerous because you will be more susceptible to injury, burns, electric shocks and other injuries.

Work undertaken	Protective gear worn		
All types of work	Protective gloves 'Safety' working clothing		
Electrical-related work	Gloves to provide protection for electricians and from heat Insulating shoes Clothing to provide protection from electric shock		
Work done at heights (50 cm or more)	Helmets for use in industry		
Transportation of heavy objects	Shoes with additional protective toe cap		
Repair of outdoor unit	Gloves to provide protection for electricians and from heat		

The important contents concerned to the safety are described on the product itself and on this Service Manual.

Please read this Service Manual after understanding the described items thoroughly in the following contents (Indications / Illustrated marks), and keep them.

[Explanation of indications]

Indication	Explanation		
<u></u> ♠ DANGER	Indicates contents assumed that an imminent danger causing a death or serious injury of the repair engineers and the third parties when an incorrect work has been executed.		
⚠ WARNING	Indicates possibilities assumed that a danger causing a death or serious injury of the repair engineers, the third parties, and the users due to troubles of the product after work when an incorrect work has been executed.		
⚠ CAUTION	Indicates contents assumed that an injury or property damage (*) may be caused on the repair engineers, the third parties, and the users due to troubles of the product after work when an incorrect work has been executed.		

^{*} Property damage: Enlarged damage concerned to property, furniture, and domestic animal / pet

[Explanation of illustrated marks]

Indication	n Explanation		
\Diamond	Indicates prohibited items (Forbidden items to do) The sentences near an illustrated mark describe the concrete prohibited contents.		
0	Indicates mandatory items (Compulsory items to do) The sentences near an illustrated mark describe the concrete mandatory contents.		
<u> </u>	Indicates cautions (Including danger / warning) The sentences or illustration near or in an illustrated mark describe the concrete cautious contents.		

MEANING OF SYMBOLS DISPLAYED ON THE UNIT

	WARNING (Risk of fire) This mark is for R32 refrigerant only. Refrigerant type is written on nameplate of outdoor In case that refrigerant type is R32, this unit uses a flammable refrigerant. Ir refrigerant leaks and comes in contact with fire or heating part, it will create harmful gas there is risk of fire.		
	Read the OWNER'S MANUAL carefully before operation.		
	Service personnel are required to carefully read the OWNER'S MANUAL and INSTALLATION MANUAL before operation.		
Further information is available in the OWNER'S MANUAL, INSTALLATION MANU		nation is available in the OWNER'S MANUAL, INSTALLATION MANUAL, and the like.	

Warning Indications on the Air Conditioner Unit

[Confirmation of warning label on the main unit]

Confirm that labels are indicated on the specified positions
If removing the label during parts replace, stick it as the original.

Warning indication	Description
WARNING ELECTRICAL SHOCK HAZARD Disconnect all remote electric power supplies before servicing.	WARNING ELECTRICAL SHOCK HAZARD Disconnect all remote electric power supplies before servicing.
WARNING Moving parts. Do not operate unit with grille removed. Stop the unit before the servicing.	WARNING Moving parts. Do not operate unit with grille removed. Stop the unit before the servicing.
CAUTION High temperature parts. You might get burned when removing this panel.	CAUTION High temperature parts. You might get burned when removing this panel.
CAUTION Do not touch the aluminium fins of the unit. Doing so may result in injury.	CAUTION Do not touch the aluminium fins of the unit. Doing so may result in injury.
CAUTION BURST HAZARD Open the service valves before the operation, otherwise there might be the burst.	CAUTION BURST HAZARD Open the service valves before the operation, otherwise there might be the burst.
CAUTION Do not climb onto the fan guard. Doing so may result in injury.	CAUTION Do not climb onto the fan guard. Doing so may result in injury.

PRECAUTIONS FOR SAFETY

The manufacturer shall not assume any liability for the damage caused by not observing the description of this manual.



MANGER

	Before carrying out the installation, maintenance, repair or removal work, be sure to set the circuit breaker for both the indoor and outdoor units to the OFF position. Otherwise, electric shocks may result.
	Before opening the electrical box cover of the indoor unit or service panel of the outdoor unit, set the circuit breaker to the OFF position. Failure to set the circuit breaker to the OFF position may result in electric shocks through contact with the interior parts. Only a qualified installer (*1) or qualified service person (*1) is allowed to remove the intake grille of the indoor unit or service panel of the outdoor unit and do the work required.
Turn off	Before starting to repair the outdoor unit fan or fan guard, be absolutely sure to set the circuit breaker to the OFF position, and place a "Work in progress" sign on the circuit breaker.
braeaker	When cleaning the filter or other parts of the indoor unit, set the circuit breaker to OFF without fail, and place a "Work in progress" sign near the circuit breaker before proceeding with the work.
	When you have noticed that some kind of trouble (such as when an error display has appeared, there is a smell of burning, abnormal sounds are heard, the air conditioner fails to cool or heat or water is leaking) has occurred in the air conditioner, do not touch the air conditioner yourself but set the circuit breaker to the OFF position, and contact a qualified service person. Take steps to ensure that the power will not be turned on (by marking "out of service" near the circuit breaker, for instance) until qualified service person arrives. Continuing to use the air conditioner in the trouble status may cause mechanical problems to escalate or result in electric shocks or other failure.
	When you access inside of the service panel to repair electric parts, wait for about five minutes after turning off the breaker. Do not start repairing immediately. Otherwise you may get electric shock by touching terminals of high-voltage capacitors. Natural discharge of the capacitor takes about five minutes.
Electric shock hazard	When checking the electric parts, removing the cover of the electric parts box of Indoor Unit and/or service panel of Outdoor Unit inevitably to determine the failure, use gloves to provide protection for electricians, insulating shoes, clothing to provide protection from electric shock and insulating tools. Be careful not to touch the live part. Electric shock may result. Only "Qualified service person" is allowed to do this work.
	Place a "Work in progress" sign near the circuit breaker while the installation, maintenance, repair or removal work is being carried out. There is a danger of electric shocks if the circuit breaker is set to ON by mistake.
	When checking the electric parts, removing the cover of the electric parts box of Indoor Unit and/or front panel of Outdoor Unit inevitably to determine the failure, put a sign "Do not enter" around the site before the work. Failure to do this may result in third person getting electric shock.
Prohibition	Before operating the air conditioner after having completed the work, check that the electrical parts box cover of the indoor unit and service panel of the outdoor unit are closed, and set the circuit breaker to the ON position. You may receive an electric shock if the power is turned on without first conducting these checks.
Stay on protection	If, in the course of carrying out repairs, it becomes absolutely necessary to check out the electrical parts with the electrical parts box cover of one or more of the indoor units and the service panel of the outdoor unit removed in order to find out exactly where the trouble lies, wear insulated heat-resistant gloves, insulated boots and insulated work overalls, and take care to avoid touching any live parts. You may receive an electric shock if you fail to heed this warning. Only qualified service person (*1) is allowed to do this kind of work.

№ WARNING

Before starting to repair the air conditioner, read carefully through the Service Manual, and repair the air conditioner by following its instructions.

Only qualified service person (*1) is allowed to repair the air conditioner.

Repair of the air conditioner by unqualified person may give rise to a fire, electric shocks, injury, water leaks and / or other problems.

Do not use any refrigerant different from the one specified for complement or replacement. Otherwise, abnormally high pressure may be generated in the refrigeration cycle, which may result in a failure or explosion of the product or an injury to your body.

Only a qualified installer (*1) or qualified service person (*1) is allowed to carry out the electrical work of the air conditioner.

Under no circumstances must this work be done by an unqualified individual since failure to carry out the work properly may result in electric shocks and / or electrical leaks.

When the air conditioner is to be transported, installed, maintained, repaired or removed, wear protective gloves and 'safety' work clothing.

To connect the electrical wires, repair the electrical parts or undertake other electrical jobs, wear gloves to provide protection for electricians, insulating shoes and clothing to provide protection from electric shocks. Failure to wear this protective gear may result in electric shocks.

Electrical wiring work shall be conducted according to law and regulation in the community and installation manual. Failure to do so may result in electrocution or short circuit.

Use wiring that meets the specifications in the Installation Manual and the stipulations in the local regulations and laws. Use of wiring which does not meet the specifications may give rise to electric shocks, electrical leakage, smoking and/or a fire.



Only a qualified installer (*1) or qualified service person (*1) is allowed to undertake work at heights using a stand of 50 cm or more or to remove the intake grille of the indoor unit to undertake work.

When working at heights, use a ladder which complies with the ISO 14122 standard, and follow the procedure in the ladder's instructions.

Also wear a helmet for use in industry as protective gear to undertake the work.

Before working at heights, put a sign in place so that no-one will approach the work location, before proceeding with the work. Parts and other objects may fall from above, possibly injuring a person below. While carrying out the work, wear a helmet for protection from falling objects.

When executing address setting, test run, or troubleshooting through the checking window on the electric parts box, put on insulated gloves to provide protection from electric shock. Otherwise you may receive an electric shock.

Do not touch the aluminum fin of the outdoor unit.

You may injure yourself if you do so. If the fin must be touched for some reason, first put on protective gloves and safety work clothing, and then proceed.

Do not climb onto or place objects on top of the outdoor unit.

You may fall or the objects may fall off of the outdoor unit and result in injury.

Use forklift to carry in the air conditioner units and use winch or hoist at installation of them.

When transporting the air conditioner, wear shoes with protective toe caps, protective gloves and other protective clothing.

When transporting the air conditioner, do not take hold of the bands around the packing carton. You may injure yourself if the bands should break.

Be sure that a heavy unit (10 kg or heavier) such as a compressor is carried by two persons.

This air conditioner has passed the pressure test as specified in IEC 60335-2-40 Annex EE.



Before troubleshooting or repair work, check the earth wire is connected to the earth terminals of the main unit, otherwise an electric shock is caused when a leak occurs. If the earth wire is not correctly connected, contact an electric engineer for rework.

After completing the repair or relocation work, check that the ground wires are connected properly.

Be sure to connect earth wire. (Grounding work) Incomplete grounding causes an electric shock. Do not connect ground wires to gas pipes, water pipes, and lightning rods or ground wires for telephone wires.

Prohibition of modification.	Do not modify the products. Do not also disassemble or modify the parts. It may cause a fire, electric shock or injury.
Use specified parts.	When any of the electrical parts are to be replaced, ensure that the replacement parts satisfy the specifications given in the Service Manual (or use the parts contained on the parts list in the Service Manual). Use of any parts which do not satisfy the required specifications may give rise to electric shocks, smoking and / or a fire.
Do not bring a child close to the equipment.	If, in the course of carrying out repairs, it becomes absolutely necessary to check out the electrical parts with the electrical parts box cover of one or more of the indoor units and the service panel of the outdoor unit removed in order to find out exactly where the trouble lies, put a sign in place so that no-one will approach the work location before proceeding with the work. Third-party individuals may enter the work site and receive electric shocks if this warning is not heeded.
Insulating measures	Connect the cut-off lead wires with crimp contact, etc., put the closed end side upward and then apply a watercut method, otherwise a leak or production of fire is caused at the users' side.
No fire	 When performing repairs using a gas burner, replace the refrigerant with nitrogen gas because the oil that coats the pipes may otherwise burn. When repairing the refrigerating cycle, take the following measures. 1) Be attentive to fire around the cycle. When using a gas stove, etc., be sure to put out fire before work; otherwise the oil mixed with refrigerant gas may catch fire. 2) Do not use a welder in the closed room. When using it without ventilation, carbon monoxide poisoning may be caused. 3) Do not bring inflammables close to the refrigerant cycle, otherwise fire of the welder may catch the inflammables.
	The refrigerant used by this air conditioner is the R32 or R410A.
	Check the used refrigerant name and use tools and materials of the parts which match with it. For the products which use R32 or R410A refrigerant, the refrigerant name is indicated at a position on the outdoor unit where is easy to see. To prevent miss-charging, the route of the service port is changed from one of the former R22.
	Do not use any refrigerant different from the one specified for complement or replacement. Otherwise, abnormally high pressure may be generated in the refrigeration cycle, which may result in a failure or explosion of the product or an injury to your body.
	For an air conditioner which uses R32 or R410A, never use other refrigerant than R32 or R410A. For an air conditioner which uses other refrigerant (R22, etc.), never use R32 or R410A. If different types of refrigerant are mixed, abnormal high pressure generates in the refrigerating cycle and an injury due to breakage may be caused.
Refrigerant	When the air conditioner has been installed or relocated, follow the instructions in the Installation Manual and purge the air completely so that no gases other than the refrigerant will be mixed in the refrigerating cycle. Failure to purge the air completely may cause the air conditioner to malfunction.
	Do not charge refrigerant additionally. If charging refrigerant additionally when refrigerant gas leaks, the refrigerant composition in the refrigerating cycle changes resulted in change of air conditioner characteristics or refrigerant over the specified standard amount is charged and an abnormal high pressure is applied to the inside of the refrigerating cycle resulted in cause of breakage or injury. Therefore if the refrigerant gas leaks, recover the refrigerant in the air conditioner, execute vacuuming, and then newly recharge the specified amount of liquid refrigerant. In this time, never charge the refrigerant over the specified amount.
	When recharging the refrigerant in the refrigerating cycle, do not mix the refrigerant or air other than R410A into the specified refrigerant. If air or others is mixed with the refrigerant, abnormal high pressure generates in the refrigerating cycle resulted in cause of injury due to breakage.
	After installation work, check the refrigerant gas does not leak. If the refrigerant gas leaks in the room, poisonous gas generates when gas touches to fire such as fan heater, stove or cocking stove though the refrigerant gas itself is innocuous.
	Never recover the refrigerant into the outdoor unit. When the equipment is moved or repaired, be sure to recover the refrigerant with recovering device. The refrigerant cannot be recovered in the outdoor unit; otherwise a serious accident such as breakag or injury is caused.

	T		
Assembly / Wiring	After repair work, surely assemble the disassembled parts, and connect and lead the removed wires as before. Perform the work so that the cabinet or panel does not catch the inner wires. If incorrect assembly or incorrect wire connection was done, a disaster such as a leak or fire is caus at user's side.		
Insulator check	After the work has finished, be sure to use an insulation tester set (500 V Megger) to check the resistance 1 $M\Omega$ or more between the charge section and the non-charge metal section (Earth position). If the resistance value is low, a disaster such as a leak or electric shock is caused at user's side.		
	When the refrigerant gas leaks during work, execute ventilation. If the refrigerant gas touches to a fire, poisonous gas generates. A case of leakage of the refrigerant and the closed room full with gas is dangerous because a shortage of oxygen occurs. Be sure to execute ventilation.		
Ventilation	If refrigerant gas has leaked during the installation work, ventilate the room immediately. If the leaked refrigerant gas comes in contact with fire, noxious gas may generate.		
	After installation work, check the refrigerant gas does not leak. If the refrigerant gas leaks in the room, poisonous gas generates when gas touches to fire such as fan heater, stove or cocking stove though the refrigerant gas itself is innocuous.		
	When the refrigerant gas leaks, find up the leaked position and repair it surely. If the leaked position cannot be found up and the repair work is interrupted, pump-down and tighten the service valve, otherwise the refrigerant gas may leak into the room. The poisonous gas generates when gas touches to fire such as fan heater, stove or cocking stove though the refrigerant gas itself is innocuous. When installing equipment which includes a large amount of charged refrigerant such as a multi air conditioner in a sub-room, it is necessary that the density does not the limit even if the refrigerant leaks. If the refrigerant leaks and exceeds the limit density, an accident of shortage of oxygen is caused.		
Compulsion	Tighten the flare nut with a torque wrench in the specified manner. Excessive tighten of the flare nut may cause a crack in the flare nut after a long period, which may result in refrigerant leakage.		
	Nitrogen gas must be used for the airtight test.		
	The charge hose must be connected in such a way that it is not slack.		
	For the installation / moving / reinstallation work, follow to the Installation Manual. If an incorrect installation is done, a trouble of the refrigerating cycle, water leak, electric shock or fire is caused.		
_	Once the repair work has been completed, check for refrigerant leaks, and check the insulation resistance and water drainage. Then perform a trial run to check that the air conditioner is running properly.		
	After repair work has finished, check there is no trouble. If check is not executed, a fire, electric shock or injury may be caused. For a check, turn off the power breaker.		
Check after repair	After repair work (installation of front panel and cabinet) has finished, execute a test run to check there is no generation of smoke or abnormal sound. If check is not executed, a fire or an electric shock is caused. Before test run, install the front panel and cabinet.		
	Be sure to fix the screws back which have been removed for installation or other purposes.		
Check the following matters before a test run after repairing piping. Connect the pipes surely and there is no leak of refrigerant. The valve is opened. Running the compressor under condition that the valve closes causes an abnormal high resulted in damage of the parts of the compressor and etc. and moreover if there is lead at connecting section of pipes, the air is sucked and causes further abnormal high presults or injury.			
	Only a qualified installer (*1) or qualified service person (*1) is allowed to relocate the air conditioner. It is dangerous for the air conditioner to be relocated by an unqualified individual since a fire, electric shocks, injury, water leakage, noise and / or vibration may result.		
Check after reinstallation	Check the following items after reinstallation. 1) The earth wire is correctly connected. 2) The power cord is not caught in the product. 3) There is no inclination or unsteadiness and the installation is stable. If check is not executed, a fire, an electric shock or an injury is caused.		
	When carrying out the pump-down work shut down the compressor before disconnecting the refrigerant pipe. Disconnecting the refrigerant pipe with the service valve left open and the compressor still operating will cause air, etc. to be sucked in, raising the pressure inside the refrigeration cycle to an abnormally high level, and possibly resulting in reputing, injury, etc.		

tł
Т
rı

When the service panel of the outdoor unit is to be opened in order for the compressor or the area around this part to be repaired immediately after the air conditioner has been shut down, set the circuit breaker to the OFF position, and then wait at least 10 minutes before opening the service panel. If you fail to heed this warning, you will run the risk of burning yourself because the compressor pipes and other parts will be very hot to the touch. In addition, before proceeding with the repair work, wear the kind of insulated heat-resistant gloves designed to protect electricians.

Take care not to get burned by compressor pipes or other parts when checking the cooling cycle while running the unit as they get heated while running. Be sure to put on gloves providing protection for heat.

Cooling check

When the service panel of the outdoor unit is to be opened in order for the fan motor, reactor, inverter or the areas around these parts to be repaired immediately after the air conditioner has been shut down, set the circuit breaker to the OFF position, and then wait at least 10 minutes before opening the service panel.

If you fail to heed this warning, you will run the risk of burning yourself because the fan motor, reactor, inverter heat sink and other parts will be very hot to the touch.

In addition, before proceeding with the repair work, wear the kind of insulated heat-resistant gloves designed to protect electricians.

Only a qualified installer or service person is allowed to do installation work. Inappropriate installation may result in water leakage, electric shock or fire.

Before starting to install the air conditioner, read carefully through the Installation Manual, and follow its instructions to install the air conditioner.

Be sure to use the company-specified products for the separately purchased parts. Use of non-specified products may result in fire, electric shock, water leakage or other failure. Have the installation performed by a qualified installer.

Do not supply power from the power terminal block equipped on the outdoor unit to another outdoor unit. Capacity overflow may occur on the terminal block and may result in fire.



Do not install the air conditioner in a location that may be subject to a risk of expire to a combustible gas. If a combustible gas leaks and becomes concentrated around the unit, a fire may occur.

Install the indoor unit at least 2.5 m above the floor level since otherwise the users may injure themselves or receive electric shocks if they poke their fingers or other objects into the indoor unit while the air conditioner is running.

Install a circuit breaker that meets the specifications in the installation manual and the stipulations in the local regulations and laws.

Install the circuit breaker where it can be easily accessed by the qualified service person (*1).

If you install the unit in a small room, take appropriate measures to prevent the refrigerant from exceeding the limit concentration even if it leaks. Consult the dealer from whom you purchased the air conditioner when you implement the measures. Accumulation of highly concentrated refrigerant may cause an oxygen deficiency accident.

Do not place any combustion appliance in a place where it is directly exposed to the wind of air conditioner, otherwise it may cause imperfect combustion.

Explanations given to user

If you have discovered that the fan grille is damaged, do not approach the outdoor unit but set the circuit breaker to the OFF position, and contact a qualified service person to have the repairs done. Do not set the circuit breaker to the ON position until the repairs are completed.

Relocation

- Only a qualified installer (*1) or qualified service person (*1) is allowed to relocate the air conditioner. It is dangerous for the air conditioner to be relocated by an unqualified individual since a fire, electric shocks, injury, water leakage, noise and / or vibration may result.
- When carrying out the pump-down work shut down the compressor before disconnecting the refrigerant pipe.
 Disconnecting the refrigerant pipe with the service valve left open and the compressor still operating will cause air, etc. to be sucked in, raising the pressure inside the refrigeration cycle to an abnormally high level, and possibly resulting in reputing, injury, etc.
- (*1) Refer to the "Definition of Qualified Installer or Qualified Service Person"

Declaration of Conformity

Manufacturer: TOSHIBA CARRIER (THAILAND) CO., LTD.

144 / 9 Moo 5, Bangkadi Industrial Park, Tivanon Road,

Amphur Muang, Pathumthani 12000, Thailand

TCF holder: TOSHIBA CARRIER EUROPE S.A.S

Route de Thil

01120 Montluel FRANCE

Hereby declares that the machinery described below: Generic Denomination: Air Conditioner

Model/type: RAV-RM561UTP-E RAV-RM561UTP-TR

RAV-RM801UTP-E RAV-RM801UTP-TR
RAV-RM1101UTP-E RAV-RM1401UTP-TR
RAV-RM1601UTP-E RAV-RM1601UTP-TR

Commercial name: Digital Inverter Series / Super Digital Inverter Series Air Conditioner

Complies with the provisions of the "Machinery" Directive (Directive 2006/42/EC) and the regulations transposing into national law.

NOTE

This declaration becomes invalid if technical or operational modifications are introduced without the manufacturer's consent.

Specifications

Model	Sound power level (dBA)		Weight (kg)
Model	Cooling	Heating	Main unit (Ceiling panel)
RAV-RM561UTP-E	*	*	20 (4.2)
RAV-RM801UTP-E	*	*	20 (4.2)
RAV-RM1101UTP-E	*	*	24 (4.2)
RAV-RM1401UTP-E	*	*	24 (4.2)
RAV-RM1601UTP-E	*	*	24 (4.2)
RAV-RM561UTP-TR	*	*	20 (4.2)
RAV-RM801UTP-TR	*	*	20 (4.2)
RAV-RM1101UTP-TR	*	*	24 (4.2)
RAV-RM1401UTP-TR	*	*	24 (4.2)
RAV-RM1601UTP-TR	*	*	24 (4.2)

★: Under 70 dBA

Refrigerant (R32 or R410A)

This air conditioner adopts a refrigerant HFC (R32 or R410A) which does not deplete the ozone layer.

1. Safety Caution Concerned to Refrigerant R32 or R410A

The pressure of R32 or R410A is high 1.6 times of that of the former refrigerant (R22).

Accompanied with change of refrigerant, the refrigerating oil has been also changed.

Therefore, be sure that water, dust, the former refrigerant or the former refrigerating oil is not mixed into the refrigerating cycle of the air conditioner with refrigerant R32 or R410A during installation work or service work. If an incorrect work or incorrect service is performed, there is a possibility to cause a serious accident. Use the tools and materials exclusive to R32 or R410A to purpose a safe work.

2. Cautions on Installation/Service

- Do not mix the other refrigerant or refrigerating oil.
 For the tools exclusive to R32 or R410A, shapes of all the joints including the service port differ from those of the former refrigerant in order to prevent mixture of them.
- 2) As the use pressure of the refrigerant R32 or R410A is high, use material thickness of the pipe and tools which are specified for R32 or R410A.
- 3) In the installation time, use clean pipe materials and work with great attention so that water and others do not mix in because pipes are affected by impurities such as water, oxide scales, oil, etc. Use the clean pipes.
 - Be sure to brazing with flowing nitrogen gas. (Never use gas other than nitrogen gas.)
- 4) For the earth protection, use a vacuum pump for air purge.
- 5) R32 or R410A refrigerant is azeotropic mixture type refrigerant.

 Therefore use liquid type to charge the refrigerant. (If using gas for charging, composition of the refrigerant changes and then characteristics of the air conditioner change.)

3. Pipe Materials

For the refrigerant pipes, copper pipe and joints are mainly used.

It is necessary to select the most appropriate pipes to conform to the standard.

Use clean material in which impurities adhere inside of pipe or joint to a minimum.

1) Copper pipe

<Piping>

The pipe thickness, flare finishing size, flare nut and others differ according to a refrigerant type. When using a long copper pipe for R32 or R410A, it is recommended to select "Copper or copper-

base pipe without seam" and one with bonded oil amount 40mg/10m or less.

Also do not use crushed, deformed, discolored (especially inside) pipes.

(Impurities cause clogging of expansion valves and capillary tubes.)

<Flare nut>

Use the flare nuts which are attached to the air conditioner unit.

2) Joint

The flare joint and socket joint are used for joints of the copper pipe.

The joints are rarely used for installation of the air conditioner. However clear impurities when using them.

4. Tools

1. Required Tools for R32 or R410A

Mixing of different types of oil may cause a trouble such as generation of sludge, clogging of capillary, etc. Accordingly, the tools to be used are classified into the following three types.

- 1) Tools exclusive for R32 or R410A (Those which cannot be used for conventional refrigerant (R22))
- 2) Tools exclusive for R32 or R410A, but can be also used for conventional refrigerant (R22)
- 3) Tools commonly used for R32 or R410A and for conventional refrigerant (R22)

The table below shows the tools exclusive for R32 or R410A and their interchangeability.

Tools exclusive for R32 or R410A (The following tools for R410A are required.)

Tools whose specifications are changed for R32 or R410A and their interchangeability

				R410A er installation	Conventional air conditioner installation
No.	Used tool	Usage	Existence of new equipment for R410A	Whether conventional equipment can be used	Whether conventional equipment can be used
1	Flare tool	Pipe flaring	Yes	*(Note)	Yes
2	Copper pipe gauge for adjusting projection margin	Flaring by conventional flare tool	Yes	*(Note)	*(Note)
3	Torque wrench	Tightening of flare nut	Yes	No	No
4	Gauge manifold	Evacuating, refrigerant	Yes	No	No
(5)	Charge hose	charge, run check, etc.	163	NO	NO
6	Vacuum pump adapter	Vacuum evacuating	Yes	No	Yes
7	Electronic balance for refrigerant charging	Refrigerant charge	Yes	Yes	Yes
8	Refrigerant cylinder	Refrigerant charge	Yes	No	No
9	Leakage detector	Gas leakage check	Yes	No	Yes

(Note) When flaring is carried out for R32 or R410A using the conventional flare tools, adjustment of projection margin is necessary. For this adjustment, a copper pipe gauge, etc. are necessary.

General tools (Conventional tools can be used.)

In addition to the above exclusive tools, the following equipments which serve also for R22 are necessary as the general tools.

- 1) Vacuum pump. Use vacuum pump by attaching vacuum pump adapter.
- 2) Torque wrench
- 3) Pipe cutter
- 4) Reamer
- 5) Pipe bender
- 6) Level vial

- 7) Screwdriver (+, -)
- 8) Spanner or Monkey wrench
- 9) Hole core drill
- 10) Hexagon wrench (Opposite side 4mm)
- 11) Tape measure
- 12) Metal saw

Also prepare the following equipments for other installation method and run check.

1) Clamp meter


3) Insulation resistance tester (Megger)

2) Thermometer


4) Electroscope

1. CONSTRUCTION VIEWS (EXTERNAL VIEWS)


1-1. Indoor Unit RAV-RM561UTP*



RAV-RM801UTP*



RAV-RM1101UTP*, RAV-RM1401UTP*, RAV-RM1601UTP*




Heating

2. SYSTEMATIC REFRIGERATING CYCLE DIAGRAM

2-1. Indoor Unit

• Single type (Combination of 1 indoor unit and 1 outdoor unit)




Dimension table

Indoor unit	Outer diameter o	of refrigerant pipe		
indoor unit	Gas side ØA	Liquid side ØB		
RM56 type	12.7	6.4		
RM80, 110, 140, 160 type	15.9	9.5		


Model RAV-RM***UTP* Inner dia. × Length × Q'ty RM56 type Ø2 × 250 × 2, Ø2 × 350 × 1 Ø2 × 700 × 1 RM80 type Ø2 × 250 × 3, Ø2 × 500 × 1 RM110, 140, 160 type Ø2 × 200 × 1, Ø2 × 300 × 2 Ø2 × 350 × 2, Ø2 × 700 × 1





Indoor unit	Branch pipe RBC-	Α	В	С	D
RM56 × 2	TWP30E2	6.4	12.7	9.5	15.9


• Triple type (3 indoor units and 1 outdoor unit)



Dimension table

Indoor unit	Branch pipe	Α	В	С	D
RM56X3	RBC-TRP100E	6.4	12.7	9.5	15.9

Double-twin type (4 indoor units and 1 outdoor unit)



Dimension table


Indoor unit	Branch pipe 1	Branch pipe 2	Α	В	С	D	E	F
RM56x4	RBC-TWP30E2x2	RBC-TWP101E	6.4	12.7	9.5	15.9	12.7	28.6

3. WIRING DIAGRAM

3-1. Indoor Unit

3-1-1. 4-Way Cassette Type

RAV-RM561UTP*, RAV-RM801UTP*, RAV-RM1101UTP*, RAV-RM1401UTP*, RAV-RM1601UTP*



4. SPECIFICATIONS OF ELECTRICAL PARTS

4-1. Indoor Unit

RAV-RM561UTP*, RAV-RM801UTP*

No.	Parts name	Туре	Specifications
1	Fan motor (for indoor)	SWF-230-60-2R	Output (Rated) 60 W
2	Thermo. sensor (TA-sensor)	328 mm	10 kΩ at 25°C
3	Heat exchanger sensor (TCJ-sensor)	Ø6 mm, 1000 mm	10 kΩ at 25°C
4	Heat exchanger sensor (TC-sensor)	Ø6 mm, 1000 mm	10 kΩ at 25°C
5	Float switch	FS-1A-31-3	_
6	Drain pump motor	MDP-1401	_


RAV-RM1101UTP*, RAV-RM1401UTP*, RAV-RM1601UTP*

No.	Parts name	Туре	Specifications
1	Fan motor	ICF-280-150-1	Output (Rated) 150 W
2	Thermo. sensor (TA-sensor)	328 mm	10 kΩ at 25°C
3	Heat exchanger sensor (TCJ-sensor)	Ø6 mm, 1000 mm	10 kΩ at 25°C
4	Heat exchanger sensor (TC-sensor)	Ø6 mm, 1000 mm	10 kΩ at 25°C
5	Float switch	FS-1A-31-3	_
6	Drain pump motor	MDP-1401	_

5. INDOOR CONTROL CIRCUIT


5-1. Indoor Controller Block Diagram

5-1-1. Connection of Wired (Simple) Remote Controller




5-1-2. Connection of Wireless Remote Controller Kit

Indoor unit #1 (Header)



5-1-3. Connection of Both Wired (Simple) Remote Controller and Wireless Remote Controller Kit



5-2. Control Specifications

No.	Item	Outli	ine of spec	ifications		Remarks
1	When power supply is reset	Distinction of outdoo When the power sur guished and the cor distinguished result.	oply is reset atrol is selec			
		Setting of indoor fan adjustment		existence of	air direction	
		Based on EEPROM speed and the existe				Air speed (rpm)/ Air direction adjustment
2	Operation mode selection	Based on the operative remote controller, the				
		Remote controller command		Control outli	ne	
		STOP	Air condition	oner stops.		
		FAN	Fan operat	ion		
		COOL	Cooling op			
		DRY	Dry operat			
		HEAT	Heating op			Ta: Room temp.
		AUTO	COOL/HI automatic and To fo The oper shown in according time only. α –1 < Τα thermo. Covolume o	EAT operation cally selected roperation. ation is perfor the following to Ta value a (In the range a < Ts + α + 10FF (Fan)/Set peration conti	med as figure tt the first of Ts + , Cooling up air	Ts: Setup temp. To: Outside temp.
		+1.0 - Ta (°C) Ts+α - -1.0 -	Cooling t - • Setup a	eration //// hermo. OFF (I ir volume – ting ///// ration /////		
		• α is corrected a	·			
		Outside temp.		rrection value (<u> </u>	
		No To		0K		k = deg
		To ≥ 24°C		-1K		= 309
		24 > To ≥ 18°C		0K		
		To < 18°C		+1K		
		To error		0K		
3	Room temp.	Adjustment range: Ro	emote contro	oller setup ten	nperature (°C)	
	control		COOL/DRY	HEAT	AUTO	
		Wired type	18 to 29	18 to 29	18 to 29	
		Wireless type	17 to 30	17 to 30	17 to 30	
			ļ			

No.	Item	Outline of s	Remarks						
3	Room temp. control (Continued)	Using the CODE No. 06, to operation can be corrected.	Shift of suction temperature in heating						
	(Continued)	Setup data	0	2	4	6		operation	
		Setup temp. correction	+0°C	+2°C	+4°C	+6°C			
		Setting at shipment							
		Setup data 2							
4	Automatic capacity control	Based on the difference be frequency is instructed to				operation	on		
	capacity control	Cooling operation	ine out	.door ar					
	(GA control)	Every 90 seconds, the roo between temperature dete varied room temperature varied room temperature value of the the present frequency con	ected by alue a freque	y Ta and re calcu ency col	d Ts and ulated to mmand	I the obtain	n		
		Ta (n) – Ts (n) : Room to n : Counts Ta (n-1) – Ts (n) : Varied i	of dete	ection					
		n – 1 : Counts				nds befo	re		
		3) Heating operation							
		ence between temperature varied room temperature the correction value of the the present frequency con	Every 1 minute (60 sec.), the room temperature difference between temperature detected by Ta and Ts and the varied room temperature value are calculated to obtain the correction value of the frequency command and then the present frequency command is corrected. Ts (n) – Ta (n) : Room temp. difference						
		n : Counts Ta (n) – Ta (n – 1): Varied n – 1 : Counts	room t	emp. va		ute befo	re		
		4) Dry operation							
		The frequency correction of cooling operation.	control	is same	e as tho	se of the	Э		
		However the maximum fre mately "S6".	quency	y is limit	ted to ap	proxi-			
		Note) When LOW is set up, limited to approximate			frequer	icy is			
5	Automatic cooling/heating control	1) The judgment of selecting shown below. When +1.5 e and after thermoOFF, he exchanges to cooling open parentheses shows an example of the selecting shows a select	exceed ating o ration. I	s again peratio Descrip	st Tsh 1 n (Thern tion in th	0 minute no. OFF ne	es	Tsc: Setup temp. in cooling operation Tsh: Setup temp. in heating operation	
		or Tsc -1.5 - (Coo	+ temp. correction of room temp. control						
		When –1.5 lowers against thermo. OFF, cooling operato to heating operation.	Tsc 10				es		
		For the automatic capacity cooling/heating, see Item		ol after j	udgmer	nt of			
		For temperature correction automatic heating, see Ite		om temp	o. contro	l in			

No.	Item	Outline of specifications	Remarks
6	Air speed selection	1) Operation with (HH), (H), (L) or [AUTO] mode is carried out by the command from the remote controller. 2) When the air speed mode [AUTO] is selected, the air speed varies by the difference between Ta and Ts. COOL> Ta (°C) +3.0 HH (HH) C +1.5 +1.0 H (HH) D H (HH) L+ (H+) Tsc L (H) -0.5 L (H) C G	HH > H+ > H > L+ > L > UL
		 Controlling operation in case when thermo of remote controller works is same as a case when thermo of the body works. If the air speed has been changed once, it is not changed for 3 minutes. However when the air volume is exchanged, the air speed changes. When cooling operation has started, select a downward slope for the air speed, that is, the high position. If the temperature is just on the difference boundary, the air speed does not change. Mode in the parentheses indicates one in automatic cooling operation. Ta (°C)	
		Ta (°C) (-0.5) -1.0	
		 Value in the parentheses indicates one when thermostat of the remote controller works. Value without parentheses indicates one when thermostat of the body works. If the air speed has been changed once, it is not changed for 1 minute. However when the air speed I exchanged, the air speed changes. When heating operation has started, select an upward slope for the air speed, that is, the high position. If the temperature is just on the difference boundary, the air speed does not change. Mode in the parentheses indicates one in automatic heating operation. In Tc ≥ 60°C, the air speed increases by 1 step. 	Tc: Indoor heat exchanger sensor temperature

No.	Item	Outline of specifications									Remarks
6	Air speed selection	CODE No. [5d]		dard	-	pe 1		pe 3		De 6	Selection of high
	(Continued):	SW501 (1)/(2)		/OFF		OFF	OFF/ON			/ON	ceiling type
			COOL			HEAT		HEAT		HEAT	CODE No.:
		Tap	COOL	HEAL	COOL	HEAT	HH	_			[5d] or selection of
		F1 F2			HH	HH	ПП	HH	HH	HH	high ceiling on P.C.
		F3			ПП	H+	H+. H	H+, H	H+, H		board SW501
							,	1,	L+, L	L+, L	
		F4			H+						
		F5		HH		Н		+.			
		F6	HH		Н		L+	L+			
		F7	H+	H+			L	L			
		F8		Н		L+					
		F9	Н		L+	L					
		FA		L+	L						
		FB	L+	L							
		FC	L							l	
		FD		UL		UL		UL		UL	
			RM56	R	M80	RM1	10	RM140	R	M160	
		Tap –				ıtion sp					
		F1	610	(630	700)	700		700	
		F2	550		590	670)	670		670	
		F3	500		530	660		660		660	
		F4	450	4	470	640)	650		650	
		F5	400	4	450	620)	640		640	
		F6	390	4	440	610)	630		630	
		F7	370	4	410	550)	560		580	
		F8	350	;	380	490)	490		530	
		F9	340		370	480		480		520	
		FA	330		350	450		460		490	
		FB	320	;	330	420)	430		450	
		FC	310		320	400		420		440	
		FD	250		250	300)	300		300	
		3) In heating of is turned of		ion, th	e mod	le cha	nges	to [UL]	if the	rmostat	Tcj:
		4) If Ta ≥ 25°C defrost operates w entered in (Item 7).	ration ith (H)	has b mode	een cl	eared gher m	, the a lode f	air con or 1 m	ditione inute a	er after Tc	Indoor heat exchanger sensor temperature
		5) In automati frequency cooling/hea	of (HH ating o) is se peratio	t large						However only when the high ceiling selection is set to [Standard]
		Tc (°C) 47	F5	→F4 \ 	\	freque auton	ency inatic h	e revolus restrineating	icted i opera	ation as	
		6) Self-clean When performs cooling ope	rming	self-c							[Self-clean ⊕] is displayed.

Cool air discharge preventive control	 In heating operation, the indoor fan is controlled based on the detected temperature of Tc sensor or Tcj sensor. As shown below, the upper limit of the revolution frequency is restricted. However B zone is assumed as C zone for 6 minutes and after when the compressor activated. In defrost operation, the control value of Tc is shifted by 6°C. 	In D and E zones, the priority is given to air volume selection setup of remote controller. In A zone while thermo is ON, [PRE-HEAT (Heating ready)] is displayed.
	Tc (°C) HH 32 H L E zone UL D zone OFF C zone B zone A zone	
Freeze preventive control (Low temperature release)	 The cooling operation (including Dry operation) is performed as follows based on the detected temperature of Tc sensor or Tcj sensor. When [J] zone is detected for 6 minutes (Following figure), the commanded frequency is decreased from the real operation frequency. After then the commanded frequency changes every 30 seconds while operation is performed in [J] zone. In [K] zone, time counting is interrupted and the operation is held. When [I] zone is detected, the timer is cleared and the operation returns to the normal operation. If the commanded frequency becomes S0 because the operation continues in [J] zone, the return temperature A is raised from 5°C to 12°C until [I] zone is detected and the indoor fan operates with [L] mode. 	Tcj: Indoor heat exchanger sensor temperature
	In heating operation, the freeze-preventive control works if 4-way valve is not exchanged and the	Tcn: Tc temperature when 5
	following conditions are satisfied. (However the temperature for J zone dashing control is changed from 2°C to –5°C.)	minutes elapsed after activation Tc (n – 1):
	 When ① or ② is established 5 minutes after activation. ① Tcn ≤ Tc (n - 1) - 5 ② Tcn < Tc (n - 1) - 1 and Tcn ≤ Ta < 5°C 	Tc temperature at start time
	•	Freeze preventive control (Low temperature release) 1) The cooling operation (including Dry operation) is performed as follows based on the detected temperature of Tc sensor or Tcj sensor. When [J] zone is detected for 6 minutes (Following figure), the commanded frequency is decreased from the real operation frequency. After then the commanded frequency changes every 30 seconds while operation is performed in [J] zone. In [K] zone, time counting is interrupted and the operation is held. When [I] zone is detected, the timer is cleared and the operation returns to the normal operation. If the commanded frequency becomes S0 because the operation continues in [J] zone, the return temperature A is raised from 5°C to 12°C until [I] zone is detected and the indoor fan operates with [L] mode. (*C) 1

No.	Item	Outline of specifications	Remarks
9	High-temp. release control	 The heating operation is performed as follows based on the detected temperature of Tc sensor or Tcj sensor. When [M] zone is detected, the commanded frequency is decreased from the real operation frequency. After then the commanded frequency changes every 30 seconds while operation is performed in [M] zone. In [N] zone, the commanded frequency is held. When [L] zone is detected, the commanded frequency is returned to the original value by approx. 6Hz every 60 seconds. 	However this control is ignored in case of the follower unit of the twin.
		Setup at shipment Control temp. (°C) Tc (°C) A B R410A 56 (54) 52 (52) R32 55 (53) 51 (51)	
		NOTE: When the operation has started or when Tc or Tcj < 30°C at start of the operation or after operation start, temperature is controlled between values in parentheses of A and B.	Same status as that when "thermostat-OFF" (status that the air conditioner enters in the room temp. monitor mode when the temperature reached the setup temperature on the remote controller)
10	Drain pump control	 In cooling operation (including Dry operation), the drain pump is usually operated. If the float switch works while drain pump drives, the compressor stops, the drain pump continues the operation, and a check code is output. If the float switch works while drain pump stops, the compressor stops and the drain pump operates. If the float switch keeps operating for approx. 4 minutes, a check code is output. The drain pump doesn't stop immediately to decrease the drain water in the drain pan when the cooling operation (including Dry operation) was stopped and drive the drain pump for five minutes. 	Check code [P10]
11	After-heat elimination	When heating operation stops, in some cases, the indoor fan operates with (L) for approx. 30 seconds.	

No.	Item	Outline of specifications	Remarks
12	Louver control	1) Louver position setup • When the louver position is changed, the position moves necessarily to downward discharge position once to return to the set position. • The louver position can be set up in the following operation range. In cooling/dry operation In heating/fan operation	The louver position at horizontal discharge position at under RM80 differs from that at over RM110.
		In group twin/triple operation, the louver positions can be set up collectively or individually. Swing setup In all operations In all operations In all operations In all operations In group twin/triple operation, the louver positions can be set up collectively or individually. When the unit stopped or the warning was output, the louver is automatically set to full closed position. When PRE-HEAT (Heating ready) is displayed (Heating operation started or defrost operation is performed), heating thermo is off or self-cleaning is performed, the louver is automatically set to horizontal discharge position. The louver which air direction is individually set or the locked louver closes fully when the unit stops and the louver is automatically set to horizontal discharge position when PRE-HEAT (Heating ready) is displayed, heating thermo is off or self-cleaning is performed. **CIndividual air direction setup>> Pushing Louver select button enables every discharge port to set up the air direction. In case of no input (key operation) for approx. 5 seconds during setting of individual air direction (during displaying of louver No. on the remote controller screen), the remote controller screen returns to the normal display screen. For the air direction illustration during normal operation, the air direction of the least No. among the louvers which are block-set is displayed. While individual air direction is being set, the remote controller operation of the real machine are linked. When selecting a case, Louver select button is not pushed or louver No. is not displayed, the air directions of all the louvers are collectively set up.	The swinging louver moves usually up to the ceiling side from the louver position of the set time. Setup from the remote controller without button is unavailable. For the setup operation, refer to "How to set up louver individually" of Item "Setup at local site/Others".

No.	Item		Outline of s	Remarks		
12	Louver control (Continued)	For the Sw selectable button push operation operat	ing mode, the follow and settable by keep ned for 4 seconds or (4 pieces: same is: [0001 (At shipmer Swing operation is stal discharge position at the same time ving —> Data: [000 peration is selected of louver No. [02] age position and the	Carry out setting operation during stop of the unit; otherwise the unit stops operation. The standard swing performs the same swing operation as the present operation (2 series). For the setting operation, refer to [How to set up type of the swings] in Item "Setup at local site/Others".		
		< <louver (louver="" fix)="" lock="">> For the air direction setup for each discharge port, the louver position can be locked during the normal operation. An arbitrary air direction of an arbitrary louver can be registered and set by keeping button pushed for 4 seconds or more on the remote controller. The louver lock can be set by registering the setup data to CODE No. (DN) [F1] to [F4] according to the following table. CODE No. Objective louver No. Setup data F1 01 0000: Release (At shipment) F2 02 0001: Horizontal discharge position F3 03 03 ~ F4 04 04 0005: Downward discharge position </louver>				

No.	Item		Outline of spec	Remarks	
12	Louver control (Continued)	remo	ere is the locked louver in the ote controller screen. The the following controls are prate even if executing the lour	For the setting operation, refer to [How to set louver lock] of Installation Manual.	
			Control which ignores lock	Manual.	
			Operation stop	Objective louver No. Full-close position	
			When heating operation started	Horizontal discharge position	
		3	Heating thermo. OFF	Horizontal discharge position	
		4	During defrost operation	Horizontal discharge position	It is position check operation and it
		(5)	Initialize operation	Full-close position	does not link with
		6	Self-clean operation	Horizontal discharge position	the real louver and
		remo	real louver corresponding to to the controller screen during se ging.		air direction setup (Illustration on the remote controller screen).
13	HA control	2) Th 3) I/C 4) Th ou [O] [00 cas	is control is connected to TV (setc, and start/stop are available remote position. is control outputs start/stop so a specifications conform to JE is control outputs [Operation Of the terminal while self-cleaning peration ON (Operating) signal (O) (At shipment)] of CODE No se, if HA is input during self-cleaning topics, it stops.)	In the group operation, use this control by connecting to either header or follower indoor unit.	
14	Frequency fixed operation (Test run)	1) WI is 6 Te: 2) Pu 3) Us 6 E 6 A 7 A 4) Afti (Di 5) Pu ([T	nen pushing [TEST] button for displayed on the display screet run mode. It is a possible for the following [MODE] button, set the mode than [MODE] button, set the mode on the use other mode than [MODE] button, the tradjusted. It is a possible for the test run, push [ON/OFF] is play in the display part is same the test run, push [ON/OFF] is play in the display part is same the test run, the display part is same test run the display part is same test run the display part is same test run, the display part is same test run the display the display part is same test run the display test run the display part is same test run the display test run t	Command frequency is approximately [S7]	
15	Filter sign display (Except wireless type)	sig (25 2) Wi rer In	e operation time of the indoor final is sent to the remote control (500H) has passed, and it is distinct the filter reset signal has mote controller, time of the cathis case, the measurement in has passed, and display of	[FILTER III] goes on.	


No.	Item	Outline of specifications	Remarks
16	Central control mode selection	Setting at the centerl controller side enables to select the contents which can be operated on the remote controller at indoor unit side. Setup contents.	
		2) Setup contents64 line central controller (TCB-SC642TLE2)	5
		[Individual]: Operated on the remote controller (Priority to second pushing)	Display at remote controller side (No display)
		[Central 1]: ON/OFF operation cannot be operated on the remote controller.	[Central 🗗] goes on
		[Central 2]: ON/OFF, mode selection, temp. setup operations cannot be operated on the remote controller.	[Central 🕞] goes on
		[Central 3]: Mode selection and temp. setup operations cannot be operated on the remote controller.	[Central 👝] goes on
		[Central 4]: Mode selection cannot be operated on the remote controller.	[Central 👝] goes on
17	Energy-saving control		
		Data (Input value room temp. Ta, Outside temp. To, Air volume, Indoor heat exchanger sensor temp. Tc) for 20 minutes are taken the average to calculate correction value of the setup temperature.	
		 The setup temperature is shifted every 20 minutes, and the shifted range is as follows. In cooling time: +1.5 to - 1.0K 	
		In heating time: -1.5 to +1.0K	
18	Max. frequency cut control	This control is operated by selecting [AUTO] operation mod COOL operation mode: It is controlled according to the following figure if To < 28°C.	on mode: according to the
		resti	frequency is icted to approximately rated heating frequency

No.	Item	Outline of specifications					Remarks				
19	DC motor	 When the fan operation has started, positioning of the stator and the rotor are performed. (Moves slightly with tap sound) The motor operates according to the command from the indoor controller. Notes) When the fan rotates while the air conditioner stops due to entering of outside air, etc, the air conditioner may operate while the fan motor stops. When a fan lock is found, the air conditioner stops, and an error is displayed. 						Check code [P12]			
20	Self-clean operation (Dry operation)			g operation mode ean operations are			DRY)	stopped, the following			
			ompressor N period	Self-clean operation period	FAN	Drain pump		Louver			
		0	to 10 min.	None							
		10	to 60 min.	1 hour	Fan only (UL)	STOP	Hor	izontal discharge position			
		6	60 min. to	2 hours	, ,						
21	Save operation	rei (G 3) To [O (S) ab 4) WI gra wii * I ([I * 1] c ((mote control Green LED To stop the so N/OFF] but Itop the op Toove: 10 m Then the folloup connect The self-clear The self-clea	self-clean operation atton on the remoteration as compresented in the segment of controller screen operation is not use) of the self-clean operation of CODI of the self-clean operation of the self-clean operation of the self-clean operation of the self-clean operation on the self-clean operation of the self-clean operation operation operation of the self-clean operation opera	ever the open, push two econtrolle essor ON to see self-clean of (a) is disvia master used, set in ean operation [DO00: District of the control of the contr	ceration lamp ice the r continuously me in the tab operation in the splayed on the unit. nvalidity on by changin [D3] to [0000 on of self-cleans	/. le he ng)].	It is recognized as [STOP] from the remote monitor side.			
		 During operation of save operation, lights on the wired remote controller. During save operation, the current release control is performed with the restriction ratio set in EEPROM on the outdoor unit. The restriction ratio can be set by keeping button pushed for 4 seconds or more on the remote controller. When validating the save operation, the next operation starts with save operation valid because contents are held even when operation stops, operation mode changes or power supply is reset. The restriction ratio can be set by changing the setup data of CODE No. (DN) [C2] in the range of 50 to 100% (every 1%, Setting at shipment: 75%). 				Carry out setting operation during stop of the unit; otherwise the unit stops operation. For the setup operation, refer to "How to set up contents of save operation" of Installation Manual.					

No. Item	Outline of specifications	Remarks
No. Item 22 8°C heating/ Frost protective operation	Outline of specifications 1) This functional is intended for the cold latitudes and performs objective heating operation (8°C heating operation). 2) This function is valid only for combination with the outdoor units (Super Digital Inverter (SDI) 4-series outdoor units). 3) Using the indoor DN code [D1] (1 bit), Valid/Invalid of this function is set up at the customer's side. * The setup by DN code is Invalid [0]/Valid [1] and Invalid [0] has been set at the shipment. 4) This operation is the heating operation which sets 8°C as the setup temperature of the target. 5) This function starts operation by pushing temperature button ▼ during heating operation; besides by pushing ▼ button for 4 seconds or more after temperature reached the minimum set temperature. 6) To stop/release this operation, select and execute one from the following operations. ① Push ▲ button: Heating operation (18°C setting) continues. ② Push [START/STOP] button: Air conditioner stops. (Heating 18°C operation at the next start) ③ Push ★ Dobe ★ Other operation mode is selected and the operation continues.	Remarks In a group connection, if there is even one combination with other unit, "This function is not provided." is displayed. The setup temperature jumps from [18] to [8].
	operation continues. 7) As the setup temperature is 8°C and the human heating is not targeted, the cold air discharge preventive control (Item 7) is made invalid to suppress the intermittent operation. 8) The settings of the air direction and air volume are changeable during this operation. 9) The indoor fan stops to protect the compressor for 2 minutes after start of heating operation (Thermo-ON) by this function.	

5-3. Indoor Print Circuit Board

<MCC-1570>



Optional Connector Specifications of Indoor P.C. Board

Function	Connector No.	Pin No.	Specifications	Remarks
Ventilation acitality	00	1	DC12V	Setting at shipment: Interlock of ON by indoor unit operation, with OFF by stop operation
Vernination Output	CINSZ	2	Output (Open collector)	* The single operation setting by FAN button on the remote controller is performed on the remote controller (DN [31] = $0000 \rightarrow 0001$)
		~	ON/OFF input	HA ON/OFF input (J01: YES/NO=Pulse (At shipment from factory) /Static input selection)
		2	//0	
<u> </u>	0	3	Remote controller prohibited input	Permission/Prohibition of remote controller operation stop is performed by input.
¥ E		4	Operation output (Open collector)	Operation ON (Answer back of HA)
		2	DC12V	
		9	Warning output (Open collector)	Warning output ON
		-	DC12V	
		2	Defrost output (Open collector)	ON when outdoor unit is defrosted
1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1	0	3	Thermostat ON output (Open collector)	ON when real thermostat is on. (Compressor ON)
Option output	0000	4	Cooling output (Open collector)	ON when operation mode is cooling system (COOL, DRY, Cooling/Heating automatic cooling)
		2	Heating output (Open collector)	ON when operation mode is heating system (HEAT, Cooling/Heating automatic heating)
		9	Fan output (Open collector)	ON when indoor fan is on. (When air cleaner is used) OFF while clean operation is performed.
		_	DC12V	
Outside error input	CN80	2	NC	Generate the warning code "L30" (continuously for 1 minute) and stop the operation forcibly.
		8	Outside error input	
FILTER	!	~		Selection of option error input (Protective operation display of device attached to outside) setting input (Agnorizing + Drain prima ON)
Option error /	O N C N	2	Λ0	* Setting of option error input is performed on the remote controller. (DN [2A] = $0002 \rightarrow 0001$)
CHK	11	-		This check is used to check indoor operation. (Performs operation of indoor fan "H", Louver horizontal
Operation check	CIVI	2	00	and Drain pump ON without communication with outdoor and remote controller)
DISP	08173	1		Communication is available by indeed unit and remarks controller walk
Exhibition mode	CINIZ	2	0/	COLITIONICATION IS AVAILABLE BY INCOOL UTIL AND TENTIONE COLLIDIES ONLY.
EXCT	21	_	Demand input	Indoor unit forced thermostat OFF operation
Demand	2/2/2	2	//0	

6. TROUBLESHOOTING

6-1. Summary of Troubleshooting

<Wired remote controller type>

1. Before troubleshooting

- 1) Required tools/instruments
 - (+) and (-) screwdrivers, spanners, radio cutting pliers, nippers, push pins for reset switch
 - · Tester, thermometer, pressure gauge, etc.
- 2) Confirmation points before check
 - a) The following operations are normal.
 - 1. Compressor does not operate.
 - Is not 3-minutes delay (3 minutes after compressor OFF)?
 - Is not the outdoor unit in standby status though the remote controller reached the setup temperature?
 - Does not timer operate during fan operation?
 - Is not an overflow error detected on the indoor unit?
 - Is not outside high-temperature operation controlled in heating operation?
 - 2. Indoor fan does not rotate.
 - Does not cool air discharge preventive control work in heating operation?
 - 3. Outdoor fan does not rotate or air volume changes.
 - Does not high-temperature release operation control work in heating operation?
 - Does not outside low-temperature operation control work in cooling operation?
 - Is not defrost operation performed?
 - 4. ON/OFF operation cannot be performed from remote controller.
 - Is not the control operation performed from outside/remote side?
 - Is not automatic address being set up?
 (When the power is turned on at the first time or when indoor unit address setting is changed, the operation cannot be performed for maximum approx. 5 minutes after power-ON.)
 - Is not being carried out a test run by operation of the outdoor controller?
 - b) Did you return the cabling to the initial positions?
 - c) Are connecting cables of indoor unit and remote controller correct?

2. Troubleshooting procedure

When a trouble occurred, check the parts along with the following procedure.



NOTE:

For cause of a trouble, power conditions or malfunction/erroneous diagnosis of microcomputer due to outer noise is considered except the items to be checked. If there is any noise source, change the cables of the remote controller to shield cables.

<Wireless remote controller type>

1. Before troubleshooting

- 1) Required tools/instruments
 - + and screwdrivers, spanners, radio cutting pliers, nippers, etc.
 - Tester, thermometer, pressure gauge, etc.
- 2) Confirmation points before check
 - a) The following operations are normal.
 - 1. Compressor does not operate.
 - Is not 3-minutes delay (3 minutes after compressor OFF)?
 - Is not the outdoor unit in standby status though the remote controller reached the setup temperature?
 - Does not timer operate during fan operation?
 - Is not an overflow error detected on the indoor unit?
 - Is not outside high-temperature operation controlled in heating operation?
 - 2. Indoor fan does not rotate.
 - Does not cool air discharge preventive control work in heating operation?
- 3) Outdoor fan does not rotate or air volume changes.
 - Does not high-temperature release operation control work in heating operation?
 - Does not outside low-temperature operation control work in cooling operation?
 - Is not defrost operation performed?
- 4) ON/OFF operation cannot be performed from remote controller.
 - Is not forced operation performed?
 - Is not the control operation performed from outside/remote side?
 - Is not automatic address being set up?
 - Is not being carried out a test run by operation of the outdoor controller?
 - a) Did you return the cabling to the initial positions?
 - b) Are connecting cables between indoor unit and receiving unit correct?

2. Troubleshooting procedure

(When the power is turned on at the first time or when indoor unit address setting is changed, the operation cannot be performed for maximum approx. 5 minutes after power-ON.)

When a trouble occurred, check the parts along with the following procedure.



1) Outline of judgment

The primary judgment to check where a trouble occurred in indoor unit or outdoor unit is performed with the following method.

Method to judge the erroneous position by flashing indication on the display part of indoor unit (sensors of the receiving unit)

The indoor unit monitors operating status of the air conditioner, and the blocked contents of self-diagnosis are displayed restricted to the following cases if a protective circuit works.

6-2. Troubleshooting

6-2-1. Outline of judgment

The primary judgment to check whether a trouble occurred in the indoor unit or outdoor unit is carried out with the following method.

Method to judge the erroneous position by flashing indication on the display part of the indoor unit (sensors of the receiving part)

The indoor unit monitors the operating status of the air conditioner, and the blocked contents of self-diagnosis are displayed restricted to the following cases if a protective circuit works.

● : Go off, ○ : Go on, - ं : Flash (0.5 sec.)

Lamp in	ndicati	on	Check code	Cause of trouble occurrence	
Operation Tir	•	Ready • t all	_	Power supply OFF or miswiring between receiving unit and indoor unit	
			E01	Receiving error Receiving unit Receiving unit	
			E02	Sending error Miswiring or wire connection error between receiving unit and indoor unit	
On a ration Tim		Daadu	E03	Communication stop	
Operation Tir	mer	Ready	E08	Duplicated indoor unit No.	
-;Ċ- Flash			E09	Duplicated master units of remote controller Setup error	
i iasii			E10	Communication error between CPUs on indoor unit P.C. board	
			E18	Wire connection error between indoor units, Indoor power OFF (Communication stop between indoor master and follower or between main and sub indoor twin)	
Operation Tir	mer •	Ready -\'\'- Flash	E04	Miswiring between indoor unit and outdoor unit or connection erorr (Communication stop between indoor and outdoor units)	
Operation Tir	mer	Ready	P10	Overflow was detected. Protective device of indoor unit worked.	
A	lternat	e flash	P12	Indoor DC fan error	
			P03	Outdoor unit discharge temp. error Protective device of *1	
		P04	Outdoor high pressure system error outdoor unit worked.		
		P05	Negative phase detection error		
			P07	Heat sink overheat error Outdoor unit error	
Operation Tir	mer		P15	Gas leak detection error	
-0-	•		P19	4-way valve system error (Indoor or outdoor unit judged.)	
Alterna	nate flas		P20	Outdoor unit high pressure protection	
			P22	Outdoor unit: Outdoor unit error	
			P26	Outdoor unit: Inverter Idc operation Protective device of outdoor unit worked. *1	
			P29	Outdoor unit: Position detection error	
			P31	Stopped because of error of other indoor unit in a group (Check codes of E03/L03/L07/L08)	

^{*1:} These are representative examples and the check code differs according to the outdoor unit to be combined.

Lamp indication	Check code	Cause of trouble occurrence
Operation Timer Ready	/ F01	Heat exchanger sensor (TCJ) error
	F02	Heat exchanger sensor (TC) error Indoor unit sensor error
Alternate flash	F10	Heat exchanger sensor (TA) error
	F04	
	F06	Discharge temp. sensor (TD) error
Operation Timer Ready	/ F07	Temp. sensor (TE) error Temp. sensor (TL) error
	F08	Temp. sensor (TO) error Sensor error of outdoor unit *1
Alternate flash	F12	Temp. sensor (TS) error Temp. sensor (TH) error
	F13	Temp. Sensor miswiring (TE, TS)
	F15	
Operation Timer Ready	/ F29	Indoor EEPROM error
Operation Timer Ready -\(\frac{1}{2}\)-\(\frac{1}{2}\)-\(\frac{1}{2}\)-\(\frac{1}{2}\) Simultaneous flash	/ F31	Outdoor EEPROM error
	H01	
Operation Timer Ready	/ H02	Compressor break down Compressor lock
• ->	H03	Current detection circuit error Outdoor compressor system error *1
Flash	H04	Case thermostat worked. Outdoor unit low pressure system error
	H06	Suidoor uniclow pressure system error
L03 Duplicated master indoor units There is indoor unit of group connection		·
Operation Timer Ready	/ L07	There is indoor unit of group connection in individual indoor unit. ★ AUTO address ★ If group construction and
Simultaneous flash	L08	Unsetting of group address and address are not normal when power supply turned on, automatically goes to address
Cimulaneous nasm	L09	setup mode.
	L10	1
Operation Timer Ready	/ L20	Unset model type (Service board) Duplicated indoor central addresses
-\documents-	L29	Outdoor unit and other error Cothers
Simultaneous flash	L30	Outside interlock error
Omnananoodo naon		Negative phase error

^{*1:} These are representative examples and the check code differs according to the outdoor unit to be combined.

6-2-2. Others (Other than Check Code)

Lam	p indica	tion	Check code	Cause of trouble occurrence
Operation	->-	Ready	_	During test run
Simul	taneous	flash		
Operation	-)-	Ready ate flash	_	Disagreement of cool/heat (Automatic cool/heat prohibited model, or setting of heating to cooling-only model)

6-2-3. Check Code List (Indoor)

O: Go on, @: Flash, •: Go off ALT (Alternate): Alternate flashing when there are two flashing LED SIM (Simultaneous): Simultaneous flashing when there are two flashing LED

(Indoor unit detected)

Check code indication	Lai	Lamp indication	_			Air condition	Air conditioner operation
TCC-LINK central &	BK	Block indication	_	Representative defective position	Explanation of error contents	Automatic	Operation
Wired remote controller	Operation Timer	Fimer Ready	/ Flash			reset	continuation
E03	0	•		Regular communication error between indoor and remote controller	No communication from remote controller and network adapter (Also no communication from central control system)	0	×
E04	•	<!--</th--><td></td><td>Indoor/Outdoor serial error</td><td>There is error on serial communication between indoor and outdoor units</td><td>0</td><td>×</td>		Indoor/Outdoor serial error	There is error on serial communication between indoor and outdoor units	0	×
E08	0	•		Duplicated indoor addresses	Same address as yours was detected.	0	×
E10	0	•		Communication error between indoor MCU	MCU communication error between main motor and micro computer	0	×
E18	0	•		Regular communication error between indoor master and follower units	Regular communication between indoor header and follower units is impossible, Communication between twin header (main) and follower (sub) units is impossible.	0	×
F01	0	• ©	ALT	Indoor unit, Heat exchanger (TCJ) error	Open/short was detected on heat exchanger (TCJ).	0	×
F02	0	 <td>ALT</td><td>Indoor unit, Heat exchanger (TC) error</td><td>Open/short was detected on heat exchanger (TC).</td><td>0</td><td>×</td>	ALT	Indoor unit, Heat exchanger (TC) error	Open/short was detected on heat exchanger (TC).	0	×
F10	0	 <td>ALT</td><td>Indoor unit, Room temp. sensor (TA) error</td><td>Open/short was detected on room temp. sensor (TA).</td><td>0</td><td>×</td>	ALT	Indoor unit, Room temp. sensor (TA) error	Open/short was detected on room temp. sensor (TA).	0	×
F29	0	 <td>SIM</td><td>Indoor unit, other indoor P.C. board error</td><td>EEPROM error (Other error may be detected. If no error, automatic address is repeated.</td><td>×</td><td>×</td>	SIM	Indoor unit, other indoor P.C. board error	EEPROM error (Other error may be detected. If no error, automatic address is repeated.	×	×
E07	0	<!--</th--><td>SIM</td><td>Duplicated setting of indoor group master unit ♦</td><td>There are multiple master units in a group.</td><td>×</td><td>×</td>	SIM	Duplicated setting of indoor group master unit ♦	There are multiple master units in a group.	×	×
٢٥٦	0		SIM	There is group cable in individual indoor unit.	When even one group connection indoor unit exists in individual indoor unit.	×	×
807	0	<!--</th--><td>SIM</td><td>♦ Unset indoor group address</td><td>Indoor group address is unset.</td><td>×</td><td>×</td>	SIM	♦ Unset indoor group address	Indoor group address is unset.	×	×
607	0		SIM	Unset indoor capacity	Capacity of indoor unit is unset.	×	×
120	0	©	SIM	Duplicated central control system address	Duplicated setting of central control system address	0	×
087	0	©	SIM	Outside error input to indoor unit (Interlock)	Abnormal stop by outside error (CN80) input	×	×
P01	•	@ @	ALT	Indoor unit, AC fan error	An error of indoor AC fan was detected. (Fan motor thermal relay worked.)	×	×
P10	•	<!--</th--><td>ALT</td><td>Indoor unit, overflow detection</td><td>Float switch worked.</td><td>×</td><td>×</td>	ALT	Indoor unit, overflow detection	Float switch worked.	×	×
P12	•	@ @	ALT	Indoor unit, DC fan error	Indoor DC fan error (Over-current/Lock, etc.) was detected.	×	×
P19	0		ALT	4-way valve system error	In heating operation, an error was detected by temp. down of indoor heat exchanger sensor.	0	×
P31	0	<!--</th--><td>ALT</td><td>Other indoor unit error</td><td>Follower unit in group cannot operate by warning from [E03/L03/L03/L08] of header unit.</td><td>0</td><td>×</td>	ALT	Other indoor unit error	Follower unit in group cannot operate by warning from [E03/L03/L03/L08] of header unit.	0	×

When this warning was detected before group construction/address check finish at power supply was turned on, the mode shifts automatically to AUTO address setup mode.

(Remote controller detected)

Check code indication	Lamp	Lamp indication	_			Air conditioner operation	er operation
"ollowbaco obomos bosiM	Block	Block indication	,	Representative defective position	Explanation of error contents	Automatic	Automatic Operation
Wiled lefflore controller	Operation Timer Ready Flash	er Ready	Flash			reset	continuation
E01	• ©	•		No master remote controller, Remote controller communication (Receive) error	Signal cannot be received from indoor unit. Master remote controller was not set. (including 2 remote controllers)	I	I
E02	• ⊚	•		Remote controller communication (Send) error	Signal cannot be sent to indoor unit.	1	1
E09		•		Duplicated master remote controller	In 2-remote controller control, both were set as master. (Indoor master unit stops warning and follower unit continues operation.)	×	◁

(Central control devices detected)

Check code indication	Lamp indication			Air conditioner operation	er operation
7141 OOF	Block indication	Representative defective position	Explanation of error contents	Automatic	Automatic Operation
I CC-LINA CENTRAL	Operation Timer Ready Flash			reset	continuation
C05	Is not displayed. (Common use of wired	Central control system communication (send) error	Signal sending operation of central control system is impossible. There are multiple same central devices. (AI-NET)	1	I
900	remote controller, etc.)	Central control system communication (receive) error	Signal receiving operation of central control system is impossible.	I	ı
C12	ı	General-purpose device control interface batched warning	General-purpose device control interface batched warning An error on device connected to general-purpose device control interface of exclusive to TCC-LINK/AI-NET	ı	I
P30	By warning unit (Above-mentioned)	Group follower unit is defective.	Group follower unit is defective. (For remote controller, above-mentioned [***] details are displayed with unit No.	Ι	I

Even for the same contents of error such as communication error, the display of check code may differ according to detection device.
When wired remote controller or central controller detects an error, it is not necessarily related to operation of the air conditioner. In this list, the check codes that outdoor unit detects are not described. NOTE:

Error mode detected by indoor unit

Operation of diagnostic function					
Check code	Cause of operation	Status of air conditioner	Condition	Judgment and measures	
E03	No communication from remote controller (including wireless) and communication adapter	Stop (Automatic reset)	Displayed when error is detected	Check cables of remote controller and communication adapters. Remote controller LCD display OFF (Disconnection) Central remote controller [97] check code	
E04	The serial signal is not output from outdoor unit to indoor unit. Miswiring of inter-unit wire Defective serial sending circuit on outdoor P.C. board Defective serial receiving circuit on indoor P.C. board	Stop (Automatic reset)	Displayed when error is detected	Outdoor unit does not completely operate. Inter-unit wire check, correction of miswiring Check outdoor P.C. board. Correct wiring of P.C. board. When outdoor unit normally operates Check P.C. board (Indoor receiving / Outdoor sending).	
E08	Duplicated indoor unit address			Check whether remote controller connection (Group/Individual) was changed or not after power supply turned on	
L03	Duplicated indoor master unit		Displayed when	(Finish of group construction/Address check).	
L07	There is group wire in individual indoor unit.	Stop	error is detected	* If group construction and address are not normal when the power has been turned on, the mode automatically shifts to address setup mode. (Resetting of address)	
L08	Unset indoor group address				
L09	Unset indoor capacity	Stop	Displayed when error is detected	Set indoor capacity (DN=11)	
L30	Abnormal input of outside interlock	Stop	Displayed when error is detected	Check outside devices. Check indoor P.C. board.	
P10	Float switch operation • Float circuit, Disconnection, Coming-off, Float switch contact error	Stop	Displayed when error is detected	Trouble of drain pump Clogging of drain pump Check float switch. Check indoor P.C. board.	
P12	Indoor DC fan error	Stop	Displayed when error is detected	Position detection error Over-current protective circuit of indoor fan driving unit operated. Indoor fan locked. Check indoor P.C. board.	
P19	4-way valve system error After heating operation has started, indoor heat exchangers temp. is down.	Stop (Automatic reset)	Displayed when error is detected	1. Check 4-way valve. 2. Check 2-way valve and check valve. 3. Check indoor heat exchanger (TC/TCJ). 4. Check indoor P.C. board.	
P31	Own unit stops while warning is output to other indoor units.	Stop (Follower unit) (Automatic reset)	Displayed when error is detected	Judge follower unit while master unit is [E03], [L03], [L07] or [L08]. Check indoor P.C. board.	
F01	Coming-off, disconnection or short of indoor heat exchanger temp. sensor (TCJ)	Stop (Automatic reset)	Displayed when error is detected	Check indoor heat exchanger temp. sensor (TCJ). Check indoor P.C. board.	
F02	Coming-off, disconnection or short of indoor heat exchanger temp. sensor (TC)	Stop (Automatic reset)	Displayed when error is detected	Check indoor heat exchanger temp. sensor (TC). Check indoor P.C. board.	
F10	Coming-off, disconnection or short of indoor heat exchanger temp. sensor (TA)	Stop (Automatic reset)	Displayed when error is detected	Check indoor heat exchanger temp. sensor (TA). Check indoor P.C. board.	
F29	Indoor EEPROM error • EEPROM access error	Stop (Automatic reset)	Displayed when error is detected	Check indoor EEPROM. (including socket insertion) Check indoor P.C. board.	
E10	Communication error between indoor MCU Communication error between fan driving MCU and main MCU	Stop (Automatic reset)	Displayed when error is detected	Check indoor P.C. board.	
E18	Regular communication error between indoor aster and follower units and between main and sub units	Stop (Automatic reset)	Displayed when error is detected	Check remote controller wiring. Check indoor power supply wiring. Check indoor P.C. board.	

Error mode detected by remote controller or central controller (TCC-LINK)


	Operation of diagnostic fur	ection		
Check code	Cause of operation	Status of air conditioner	Condition	Judgment and measures
Not displayed at all (Operation on remote controller is impossible.)	No communication with master indoor unit Remote controller wiring is not correct. Power of indoor unit is not turned on. Automatic address cannot be completed.	Stop	_	Power supply error of remote controller, Indoor EEPROM error 1. Check remote controller inter-unit wiring. 2. Check remote controller. 3. Check indoor power wiring. 4. Check indoor P.C. board. 5. Check indoor EEPROM. (including socket insertion) → Automatic address repeating phenomenon generates.
E01 *2	No communication with master indoor unit Disconnection of inter-unit wire between remote controller and master indoor unit (Detected by remote controller side)	Stop (Automatic reset) * If center exists, operation continues.	Displayed when error is detected	Receiving error from remote controller 1. Check remote controller inter-unit wiring. 2. Check remote controller. 3. Check indoor power wiring. 4. Check indoor P.C. board.
E02	Signal send error to indoor unit (Detected by remote controller side)	Stop (Automatic reset) * If center exists, operation continues.	Displayed when error is detected	Sending error of remote controller 1. Check sending circuit inside of remote controller. → Replace remote controller.
E09	There are multiple main remote controllers. (Detected by remote controller side)	Stop (Follower unit continues operation.)	Displayed when error is detected	In 2-remote controllers (including wireless), there are multiple header units. Check that there are 1 main remote controller and other sub remote controllers.
L20 Central controller L20	Duplicated indoor central addresses on communication of central control system (Detected by indoor/central controller side)	Stop (Automatic reset)	Displayed when error is detected	Check setting of central control system network address. (Network adapter SW01) Check network adapter P.C. board.
*3	Communication circuit error of central control system (Detected by central controller side)	Continues (By remote controller)	Displayed when error is detected	Check communication wire / miswiring Check communication (U3, U4 terminals) Check network adapter P.C. board. Check central controller (such as central control remote controller, etc.) Check terminal resistance. (TCC-LINK)
Central controller	Indoor Gr sub unit error (Detected by central controller side)	Continuation/Stop (According to each case)	Displayed when error is detected	Check the check code of the corresponding unit from remote controller.

- *2 The check code cannot be displayed by the wired remote controller. (Usual operation of air conditioner becomes unavailable.)


 For the wireless models, an error is notified with indication lamp.
- *3 This trouble is related to communication of remote controller (A, B), central system (TCC-LINK U3, U4), and [E01], [E02], [E03], [E09] or [E18] is displayed or no check display on the wired remote controller according to the contents.

6-2-4. Diagnostic Procedure for Each Check Code (Indoor Unit)


Check code [E01 error]




[E09 error]




[E04 error]



[E10 error]



[E18 error]



[E08, L03, L07, L08 error]

E08: Duplicated indoor unit No.

L03: There are 2 or more master units in a group control.


L07: There is 1 or more group address [Individual] in a group control.

L08: The indoor group address is unset. (9. ADDRESS SETUP)


If the above error is detected when power supply turned on, the mode enters automatically in the automatic address set mode. (Check code is not output.)

However, if the above error is detected during the automatic address set mode, a check code may be output.


[L09 error]




[L20 error]




[L30 error]



[P30 error] (Central controller)




[P10 error]




* Check that voltage of 1-2 pin of CN504 on the indoor P.C. board is +12V. (1 pin is plus (+).)


[F10 error]



[P12 error]




[P19 error]



Operation check direction of the outdoor P.C. board (In case of self-preservation valve)

- 1) Set the Dip switch SW804 as same as the following table and push SW801 for approx. 1 second. It enables you to check the exchange operation to cooling cycle or heating cycle.
 - Only for approx. 10 seconds, the power is turned on.
 - As the heat value of part (coil: resistance R700) is large, when checking the operation continuously, wait 1 minute or more until the next check. (There is no problem if a coil is not connected.)
- 2) After check, turn off all the Dip switches SW804.




Check by tester


Analog tester: Good article if over DC180V

Digital tester: Although in some cases, the value varied and indicated. If the maximum value is DC180V or more, it is good article.


[F02 error]



[F01 error]



[C06 error] ("1:1 model" connection interface)



[E03 error] (Header indoor unit)

[E03 error] is detected when the indoor unit cannot receive a signal from the remote controller (also central controller).

Check A and B remote controllers and communication lines of the central control system U3 and U4.


As communication is impossible, this check code [E03] is not displayed on the remote controller and the central controller. [E01] is displayed on the remote controller and [C06 error] is displayed on the central controller.

If these check codes generate during operation, the air conditioner stops.

[F29 error]

This check code indicates a detection error of IC10 non-volatile memory (EEPROM) on the indoor unit P.C. board, which generated during operation of the air conditioner. Replace the service P.C. board.

* When EEPROM was not inserted when power supply turned on or when the EEPROM data read/write operation is impossible at all, the automatic address mode is repeated. In this time, [97 error] is displayed on the central controller.



[P31 error] (Follower indoor unit)

When the header unit of a group operation detected [E03], [L03], [L07] or [L08] error, the follower unit of the group operation detects [P31 error] and then the unit stops.

There is no display of the check code or alarm history of the wired remote controller. (In this model, the mode enters in automatic address set mode when the header unit detected [L03], [L07] or [L08] error.)

Temperature – Resistance value characteristic table

Temperature sensor

TA, TC, TCJ, TE, TS, TO sensors

TD, TL sensors

Representative value

100

Temperature	Re	esistance value (k	(Ω)
(°C)	(Minimum value)	(Standard value)	(Maximum value)
0	32.33	33.80	35.30
10	19.63	20.35	21.09
20	12.23	12.59	12.95
25	9.75	10.00	10.25
30	7.764	7.990	8.218
40	5.013	5.192	5.375
50	3.312	3.451	3.594
60	2.236	2.343	2.454
70	1.540	1.623	1.709
80	1.082	1.146	1.213
90	0.7740	0.8237	0.8761

0.6023


0.5634

Representative value


Temperature	Re	sistance value (k	(Ω)
(°C)	(Minimum value)	(Standard value)	(Maximum value)
0	150.5	161.3	172.7
10	92.76	99.05	105.6
20	58.61	62.36	66.26
25	47.01	49.93	52.97
30	37.93	40.22	42.59
40	25.12	26.55	28.03
50	17.00	17.92	18.86
60	11.74	12.34	12.95
70	8.269	8.668	9.074
80	5.925	6.195	6.470
90	4.321	4.507	4.696
100	3.205	3.336	3.468

TA, TC, TCJ, TE, TS, TO sensors

0.6434



TD, TL sensors



^{*} As TH sensor (Outdoor unit heat sink temp. sensor) is incorporated in the outdoor control P.C. board, the resistance value cannot be measured.

Winding Resistance of Fan Motor

Part name	Checking procedure		
SWF-230-60-2R RAV-RM561UTP*,	Measure the resistance value of each winding by using the tester.		
RAV-RM801UTP*	SWF-230-60-2R		-230-60-2R
		Position	Resistance value
	Fan motor inside wiring diagram	Black – Red	87±8.7 Ω
		Black – White	87±8.7 Ω
		Red – White	87±8.7 Ω
ICF-280-150-1 RAV-RM1101UTP*, RAV-RM1401UTP*,	Red 3	ICF-280-150-1	
RAV-RM1601UTP*	3 00 00	Position	Resistance value
	4 Black	Black – Red	32.4±3.3 Ω
	5	Black – White	32.4±3.3 Ω
		Red – White	32.4±3.3 Ω
			Under 20°C

7. REPLACEMENT OF SERVICE P.C. BOARD

7-1. Indoort Unit

<Note: when replacing the P.C. board for indoor unit servicing>

The nonvolatile memory (hereafter called EEPROM, IC503) on the indoor unit P.C. board before replacement includes the model specific type information and capacity codes as the factory-set value and the important setting data which have been automatically or manually set when the indoor unit is installed, such as system/indoor/group addresses, high ceiling select setting, etc.

When replacing the P.C. board for indoor unit servicing, follow the procedures below.

After replacement completes, confirm whether the settings are correct by checking the indoor unit No., Group header unit/follower unit settings and perform the cooling cycle confirmation through the trial operation.

<Replacement procedures>

CASE 1

Before replacement, the indoor unit can be turned on and the setting data can be read out by wired remote control operation.

EEPROM data read out [1]

Û

Replacement of P.C. board for Indoor unit servicing and power on [2]

Û

Writing the read out EEPROM data [3]

Ω

Power reset

(for all indoor units connected to the remote control when the group operation control is performed.)

CASE 2

The EEPROM before replacement is defective and the setting data cannot be read out.

EEPROM data read out [2]



Writing the setting data to EEPROM, such as high ceiling installation setting and optional connection setting, etc., based on the customer information. [3]



Power reset

(for all indoor units connected to the remote control when the group operation control is performed.)

[1] Setting data read out from EEPROM

The setting data modified on the site, other than factory-set value, stored in the EEPROM shall be read out.

- Step 1 Push CL and CD button on the remote controller simultaneously for more than 4 seconds.
 - * When the group operation control is performed, the unit No. displayed for the first time is the header unit No. At this time, the CODE No. (DN) shows "/G". Also, the fan of the indoor unit selected starts its operation and the swing operation also starts if it has the louvers.
- **Step 2** Every time when the (left side button) button is pushed, the indoor unit No. under the group control is displayed in order. Specify the indoor unit No. to be replaced.
 - 1. Change the CODE No. (DN) to $/\mathcal{Q} \to \mathcal{Q}/$ by pushing \checkmark / \blacktriangle buttons for the temperature setting. (this is the setting for the filter sign lighting time.)
 - At this time, be sure to write down the setting data displayed.
 - 2. Change the CODE No. (DN) by pushing \(\nefta\) / \(\text{\$\text{\$\text{\$\text{\$\text{buttons}}}}\) for the temperature setting. Similarly, be sure to write down the setting data displayed.
 - 3. Repeat the step 2-2 to set the other settings in the same way and write down the setting data as shown in the table 1 (example).
 - * The CODE No. (DN) are ranged from " $\mathcal{U}/$ " to " \mathcal{FF} ". The CODE No. (DN) may skip.
- Step 3 After writing down all setting data, push $\stackrel{\text{TEST}}{\nearrow}$ button to return to the normal stop status. (It takes approx. 1 min until the remote controller operation is available again.)

CODE No. required at least

DN	Contents	
10	Туре	
11	Indoor unit capacity	
12	System address	
13	Indoor unit address	
14	Group address	

- 1. The CODE No. for the Indoor unit type and Indoor unit capacity are required to set the rotation number setting of the fan.
- If the system/indoor/group addresses are different from those before replacement, the auto-address setting mode starts and the manual resetting may be required again. (when the multiple units group operation including twin system.)

[2] P.C. Board for indoor unit servicing replacement procedures

- Step 1 Replace the P.C. board to the P.C. board for indoor unit servicing.

 At this time, perform the same setting of the jumper wire (J01) setting (cut), switch SW501, (short-circuit) connector CN34 as the setting of the P.C. board before replacement.
- **Step 2** According to the system configuration, turn on the indoor unit following to the either methods shown below.
 - a) Single operation (Indoor unit is used as standalone.)

Turn on the indoor unit.

- 1. After completion of the auto-address setting mode (required time: approx. 5 min.), proceed to [3]. (System address = 1, Indoor unit address = 1, Group address = 0 (standalone) are automatically set.)
- 2. Push $\stackrel{\text{SET}}{\bigcirc}$, $\stackrel{\text{CL}}{\bigcirc}$ and $\stackrel{\text{TEST}}{\cancel{\cancel{E}}}$ buttons simultaneously for more than 4 seconds to interrupt the auto-address setting mode, and proceed to [3]. (The unit No. " *FLL*" is displayed.)
- b) Group operation (including twin triple and double twin system)

Turn on the indoor unit(s) with its P.C. board replaced to the P.C. board for indoor unit servicing, according to either methods 1 or 2 shown below.

- Turn on only the indoor unit with its P.C. board replaced. (Be sure to confirm the remote controller is surely connected. If not, the operation [3] cannot be performed.)
 - Perform either methods 1 or 2 described in item a) above.
- 2. Turn on the multiple indoor units including the indoor unit with its P.C. board replaced.
 - Twin or triple or double twin 1 system only
 - All group connections


After completion of the auto-address setting mode (required time: approx. 5 min.), proceed to [3].

* The header unit of the group may be changed by performing the auto-address setting.

Also, the system address/Indoor unit address of the indoor unit with its P.C. board replaced may be assigned to the addresses (not used) other than those of the indoor units without its P.C. board replaced. It is recommended to keep the information in advance, which cooling system the indoor unit belongs to or whether the indoor unit works as the header unit or the follower unit in the group control operation.

Setting 4-way cassette Indoor Unit model only

- 1. Using the set temperature ▼ / ▲ buttons, set "∠E" to the CODE No. (DN).
- 2. Using the timer time () / (buttons, set the data. (0002)
- Push ET button. (The setting completes if the setting data are displayed.)



[3] Writing the setting data to EEPROM

The settings stored in the EEPROM of the P.C. board for indoor unit servicing are the factory-set values.

- Step 1 Push SET, CL and EST buttons on the remote controller simultaneously for more than 4 seconds.
- * In the group control operation, the unit No. displayed for the first time is the header unit No.

 At this time, the CODE No. (DN) shows " / ②". Also, the fan of the indoor unit selected starts its operation and the swing operation starts if it has the louvers.


(The unit No. " FLL" is displayed if the auto-address setting mode is interrupted in [2] step 2 a))

Step 2 Every time when when left side button) button is pushed, the indoor unit No. in the group control operation are displayed in order.

(The settings stored in the EEPROM of the P.C. board for indoor unit servicing are the factory-set values.) Specify the indoor unit No. with its P.C. board replaced to the P.C. board for indoor unit servicing. (You cannot perform this operation if " *FLL*" is displayed.)

- Step 3 Select the CODE No. (DN) can be selected by pushing the 🔻 / (*) button for the temperature setting.
 - Set the indoor unit type and capacity.
 The factory-set values shall be written to the EEPROM by changing the type and capacity.
 - 1. Set the CODE No. (DN) to " $\mathcal{I}\mathcal{D}$ ". (without change)
 - Select the type by pushing ▼ / ▲ buttons for the timer setting. (For example, 4-way Air Cassette Type is set to "0001". Refer to table 2)
 - 3. Push $\stackrel{\text{set}}{\bigcirc}$ button. (The operation completes if the setting data is displayed.)
 - 4. Change the CODE No. (DN) to " / / " by pushing ▼ / ▲ buttons for the temperature setting.
 - 5. Select the capacity by pushing ▼ / ▲ buttons for the timer setting. (For example, 80 Type is set to "0012". Refer to table 3)
 - Push ^{SET} button. (The setting completes if the setting data are displayed.)

<Fig. 1 RBC-AMT32E>



- **Step 4** Write the on-site setting data to the EEPROM, such as address setting, etc. Perform the steps 1 and 2 above again.
- Step 5 Change the CODE No. (DN) to "𝒰/" by pushing ▼ / ▲ buttons for the temperature setting. (this is the setting for the filter sign lighting time.)
- **Step 6** Check the setting data displayed at this time with the setting data put down in [1].
 - 1. If the setting data is different, modify the setting data by pushing 👽 / 📤 buttons for the timer setting to the data put down in [1].
 - The operation completes if the setting data is displayed.
 - 2. If the data is the same, proceed to next step.
- Step 7 Change the CODE No. (DN) by pushing ▼ / ▲ buttons for the temperature setting.

 As described above, check the setting data and modify to the data put down in [1].
- **Step 8** Repeat the steps 6 and 7.
- **Step 9** After the setting completes, push $\overset{\text{TEST}}{\nearrow}$ button to return to the normal stop status. (It takes approx. 1 min until the remote control operation is available again.)
 - * The CODE No. (DN) are ranged from "## " to "FF". The CODE No. (DN) is not limited to be serial No. Even after modifying the data wrongly and pushing button, it is possible to return to the data before modification by pushing button if the CODE No. (DN) is not changed.

<Fig. 2 EEPROM layout diagram>

The EEPROM (IC503) is attached to the IC socket. When detaching the EEPROM, use a tweezers, etc. Be sure to attach the EEPROM by fitting its direction as shown in the figure.

* Do not bend the IC lead when replacing.




Table 1. Setting data (CODE No. table (example))

DN	ltem	Setting data	Factory-set value
01	Filter sign lighting time		Depending on Type
02	Filter pollution level		0000: Standard
03	Central control address		0099: Not determined
06	Heating suction temperature shift		0002: +2°C (flooring installation type: 0)
OF	Cooling only		0000: Heat pump
10	Туре		Depending on model type
11	Indoor unit capacity		Depending on capacity type
12	System address		0099: Not determined
13	Indoor unit address		0099: Not determined
14	Group address		0099: Not determined
19	Louver type (wind direction adjustment)		Depending on Type.
1E	Temperature range of cooling/heating automatic SW control point		0003: 3 deg (Ts ± 1.5)
28	Power failure automatic recovery		0000: None
2A	Option/Abnormal input (CN70) SW		0002: Humidifier
2b	Thermo output SW (T10 ③)		0000: Thermo ON
31	Ventilation fan (standalone)		0000: Not available
32	Sensor SW (Selection of static pressure)		0000: Body sensor
40	Humidifier control (+ drain pump control)		0003: Humidifier ON + Pump OFF
5d	High ceiling SW		0000: Standard
60	Timer setting (wired remote controller)		0000: Available
C2	Demand setting (outdoor unit current demand)		0075: 75 %
d0	Remote controller operation save function		0001: Enable
d1	Frost protection function		0000: None
d3	Rotation number of the self-clean operation		0001: 210rpm(at self-clean operation)
d6	Fan speed tab		0001: 5 tab
F0	Swing mode		0001: Standard
F1	Louver fixing position (Flap No. 1)		0000: Not fixed
F2	Louver fixing position (Flap No. 2)		0000: Not fixed
F3	Louver fixing position (Flap No. 3)		0000: Not fixed
F4	Louver fixing position (Flap No. 4)		0000: Not fixed

Table 2. Type: CODE No. 10

Setting data	Туре	Type name abb.	
0001*1*2	0001 ^{*1*2} 4-way Cassette Type		

*1 EEPROM initial value on the P.C. board for indoor unit servicing *2



<Model Name: RAV-RM***UTP*>

For the above models, set the CODE No. to " [F" and the setting data 0000 (initial) to "0002".

Table 3. Indoor unit capacity: CODE No. 11

Setting data	Туре
0000*	Disable
0006	40
0007	45
0009	56
0012	80
0015	110
0017	140
0018	160

* EEPROM initial value on the P.C. board for indoor unit servicing.

8. SETUP AT LOCAL SITE AND OTHERS

8-1. Indoor Unit

8-1-1. Test Run Setup on Remote Controller

<Wired remote controller>

- 1. When pushing button on the remote controller for 4 seconds or more, "TEST" is displayed on LC display. Then push button.
 - "TEST" is displayed on LC display during operation of Test Run.
 - During Test Run, temperature cannot be adjusted but air volume can be selected.
 - In heating and cooling operation, a command to fix the Test Run frequency is output.
 - Detection of error is performed as usual. However, do not use this function except case of Test Run because it applies load on the unit.
- 2. Use either heating or cooling operation mode for [TEST].
 - **NOTE :** The outdoor unit does not operate after power has been turned on or for approx. 3 minutes after operation has stopped.
- 3. After a Test Run has finished, push button again and check that [TEST] on LC display has gone off. (To prevent a continuous test run operation, 60-minutes timer release function is provided to this remote controller.)

<Wireless remote controller>

- 1. When TEMPORARY button is pushed for 10 seconds or more, "Pi!" sound is heard and the operation changes to a forced cooling operation. After approx. 3 minutes, a cooling operation starts forcedly. Check cool air starts blowing. If the operation does not start, check wiring again.
- 2. To stop a test operation, push TEMPORARY button once again (Approx. 1 second).
 - Check wiring / piping of the indoor and outdoor units in forced cooling operation.



8-1-2. Forced Defrost Setup of Remote Controller (For wired remote controller only)

(Preparation in advance)

1 Push (Push buttons simultaneously for 4 seconds or more on the remote controller. (Push buttons while the air conditioner stops.)

The first displayed unit No. is the master indoor unit address in the group control.

2 Every pushing button, the indoor unit No. in the group control is displayed one after the other.

Select a main indoor unit (outdoor unit is connected) which is to be defrosted. In this time, fan and louver of the selected indoor unit operate.

- **3** Using the set temperature buttons, specify the CODE No. (DN) 8C.
- **4** Using the timer time **▼** buttons, set time to data 0001. (0000 at shipment)
- **5** Push ^{SET} button. (OK if indication lights)
- **6** Pushing button returns the status to the normal stop status.

(Practical operation)

- Push ON/OFF (UON/OFF) button.
- · Select the HEAT mode.
- After while, the forced defrost signal is sent to the outdoor unit and then the outdoor unit starts defrost operation. (The forced defrost operation is performed for Max. 12 minutes.)
- After defrost operation finished, the operation returns to the heating operation.

To execute the defrost operation again, start procedure from above item 1.

(If the forced defrost operation was executed once, setting of the above forced defrost operation is cleared.)

8-1-3. LED Display on P.C. Board

1. D501 (Red)

- It goes on (Goes on by operation of the main microcomputer) at the same time when the power supply is turned on.
- It flashes with 1-second interval (every 0.5 second): When there is no EEPROM or writing-in operation fails.
- It flashes with 10-seconds interval (every 5 second): During DISP mode
- It flashes with 2-seconds interval (every 1 second): While setting of function select (EEPROM)

2. D403 (Red)

• It goes on when power supply of the remote controller is turned on. (Lights on hardware)

3. D503 (Yellow): Main bus communication

• It goes on for 5 seconds in the first half of communication with the central controller.

4. D504 (Green): Sub bus communication

- It flashes for 5 seconds in the first half of communication with the remote controller. (Group master unit)
- It flashes with 0.2-second interval (for 0.1 second) for 5 second in the latter half of communication between master and follower in the Gr indoor unit.

5. D14 (Orange)

• It flashes while receiving the serial signal from the outdoor unit. (Hardware)

6. D15 (Green)

• It flashes while sending the serial signal to the outdoor unit. (Hardware)

8-1-4. Function Selection Setup

<Procedure> Perform setting while the air conditioner stops.

1 Push ⊕ + ⊕ + ⊕ buttons simultaneously for 4 seconds or more.

The first displayed unit No. is the master indoor unit address in the group control. In this time, fan and louver of the selected indoor unit operate.

Ú

2 Every pushing button (button at left side), the indoor unit No. in the group control is displayed one after the other. In this time, fan and louver of the selected indoor unit only operate.

Д

3 Using the set temperature ** buttons, specify the CODE No. (DN).

Û

4 Using the timer time buttons, select the set data.


Û

5 Push $\stackrel{\text{SET}}{\bigcirc}$ button. (OK if indication lights)

- ullet To change the selected indoor unit, proceed to Procedure $oldsymbol{2}$.
- To change item to be set up, proceed to Procedure $oldsymbol{3}$.

Û

6 Pushing button returns the status to the normal stop status.



<Operation procedure>

$$1 \rightarrow 2 \rightarrow 3 \rightarrow 4 \rightarrow 5 \rightarrow 6$$
 END

Function selection CODE No. (DN) list

DN	ltem	Contents		At shipment from factory
01	Filter sign lighting time	0000: None 0002: 2500H 0004: 10000H	0001: 150H 0003: 5000H 0005: Clogging sensor used	According to type
02	Filter stain level	0000: Standard 0001: Heavy stain (Half of standa	ard time)	0000: Standard
03	Central control address	0001: No.1 unit to 0099: Undecided	0064: No.64 unit	0099: Undecided
06	Heating suction temp. shift	0000: No shift 0002: +2°C to	0001: +1°C 0010: +10°C (Up to +6 is recommended.)	0002: +2°C (Floor type 0000: 0°C)
0F	Cooling-only	0000: Heat pump 0001: Cooling only (No display fo	or [AUTO] [HEAT])	0000: Heat pump
10	Туре	0000: (1-way cassette) 0001: (4-way cassette) to 0037		According to model type
11	Indoor unit capacity	0000: Undecided	0001 to 0034	According to capacity type
12	Line address	0001: No.1 unit to	0030: No.30 unit	0099: Undecided
13	Indoor unit address	0001: No.1 unit to	0064: No.64 unit	0099: Undecided
14	Group address	0000: Individual 0002: Follower unit in group	0001: Master unit in group	0099: Undecided
19	Louver type (Adjustment of air direction)	0000: No louver model (0002:1-way) 0004: 4-way	0001: Swing only (0003:2-way)	According to model type
1E	In automatic cooling/heating, temp. width of cool → heat, heat → cool mode selection control point	0000: 0 deg to (Cool/heat are reversed w 2 against the set temperat		0003: 3 deg (Ts±1.5)
28	Automatic reset of power failure	0000: None	0001: Provided	0000: None
2A	Selection of option / error input (CN70)	0000: Filter input 0002: Humidifier input	0001: Alarm input (Air cleaner, etc.)	0002: Humidifier
2b	Selection of thermostat output (T10 ③)	0000: Indoor thermostat ON 0001: ON receiving output of out	door compressor	0000: Thermostat ON
2E	Selection of HA (T10) terminal	0000: Normal (JEMA) 0002: Fire alarm input	0001: Card input (Forgotten to be off)	0000: Normal (HA terminal)
31	Vent fan (Single operation)	0000: Impossible	0001: Possible	0000: Impossible
32	Sensor selection	0000: Body TA sensor	0001: Remote controller sensor	0000: Body sensor
5d	High ceiling selection (Air volume selection)	Type	8 3.2 3.5 3 3.3 3.6 2 3.5 3.8 3.3 3.5 3.8 5 3.8 - 3.6 3.8 - 1110, SM140, SM160 ay 3-way 2-way 9 4.2 4.5 2 4.4 4.6	0000: Standard
60	Timer setting (Wired remote controller)	0000: Operable	0001: Operation prohibited	0000: Operable

DN	ltem	Contents	At shipment from factory
42	Self-clean operation time	0000: None 0000: 0.5 h to 0.012: 0 h Set when compressor-ON time is 10 to 60 minutes. When ON-time is 60 minutes or more, the double of this operation time setting is set.	0002: 1 hour
45	Selection of louver horizontal discharge position	0000: Smudging-less setting 0002: Cold draft preventive setting	0000: Smudging- less setting
C2	Current demand X% to outdoor unit	0050: 50% to 0100: 100%	0075: 75%
СС	Setting of self-clean operation forced stop	 0000: No Clean operation is performed in case of stop by HA input. HA operation output OFF during clean operation in case of stop by remote controller 0001: Yes Clean operation is not performed in case of stop by HA input. HA operation output ON during clean operation in case of stop by remote controller 	0000: None
CD	Clean operation stop function when [ON/OFF] operation is prohibited.	The air conditioner stops (including fire alarm such as remote monitor system) while setup of [ON/OFF] operation prohibited (Central 1, 2) is performed from the central controller side. 0000: Valid (Clean operation) 0001: Invalid (No clean operation)	0000: Valid
D0	Existence of remote controller save function	0000: Invalid (Impossible) 0001: Valid (Possible)	0001: Valid (Possible)
D1	Existence of 8°C heating operation function	0000: Invalid (Impossible) 0001: Valid (Possible)	0001: Valid (Possible)
D3	Revolution frequency of self clean operation	0000: Invalid (Self clean operation is not carried out.) 0001: Valid (Self clean operation is practiced with 210 rpm.)	0001: Valid (210 rpm / operation)
D4	Display / No display of [Dry operation] during self clean operation	0000: Display 0001: No display	0000: Display
D6	Fan speed tab	0000: 3 tab 0001: 5 tab	0001: 5 tab
F0	Louver swing mode	0000: No synchronization 0001: 4-way synchronization 0002: Dual 0003: Cycle	0001: 4-way synchronization
F1	Louver No.1 fixed position	0000: Release (Free) 0001 to 0005: Horizontal discharge position to Downward discharge position	0000: Release
F2	Louver No.2 fixed position	0000: Release (Free) 0001 to 0005: Horizontal discharge position to Downward discharge position	0000: Release
F3	Louver No.3 fixed position	0000: Release (Free) 0001 to 0005: Horizontal discharge position to Downward discharge position	0000: Release
F4	Louver No.4 fixed position	0000: Release (Free) 0001 to 0005: Horizontal discharge position to Downward discharge position	0000: Release


^{*} The swing mode selection (DN code No. [F0]), louver fix (DN code No. [F1] to [F4]) and restriction ratio setting for save operation (DN code No. [C2]) can be set/changed from the normal DN setup (Detail DN setup).

8-1-5. Wiring and Setting of Remote Controller Control


2-remote controller control (Controlled by 2 remote controllers)

This control is to operate 1 or multiple indoor units are operated by 2 remote controllers. (Max. 2 remote controllers are connectable.)

When connected 2 remote controllers operate an indoor unit



When connected 2 remote controllers operate the twin



(Setup method)

One or multiple indoor units are controlled by 2 remote controllers.

(Max. 2 remote controllers are connectable.)


[Operation]

- 1. The operation contents can be changed by Last-push-priority.
- 2. Use a timer on either Master remote controller or Sub remote controller.

<Wired remote controller>

How to set wired remote controller as sub remote controller

Change DIP switch inside of the rear side of the remote controller switch from remote controller master to sub. (In case of RBC-AMT32E)




<Wireless remote controller>

Remote controller address (A-B selection) setting

- When two or more signal receiving units are installed in a room, a unique address can be set for each signal receiving unit to prevent interference.
- Address (A-B selection) must be changed on both signal receiving unit and wireless remote controller.
- For the details of address change (A-B selection) on wireless remote controller, refer to the owner's manual.

Turn off the indoor unit power supply. Turn on the bit 4 of DIP switch SW30 on the signal receiving unit P.C. board.

The setting change is shown below.




Wireless remote controller (A-B selection)

Using 2 wireless remote controllers for the respective air conditioners, when the 2 air conditioners are closely installed.

Wireless remote controller B setup

- 1. Start the air conditioner.
- Point the wireless remote controller at the indoor unit.
- Push and hold _{CHK} button on the wireless remote controller by the tip of the pencil.
 "00" will be shown on the display.
- 4. Push MODE button during CHK pushing .
 "B" will be shown on the display and "00" will be disappear and the air conditioner will turn OFF.

The wireless remote controller B is memorized.



NOTE

- Repeat above step to reset wireless remote controller to be A.
- The wireless remote controllers do not display "A".
- The factory default of the wireless remote controllers is "A".
- A-B selection can be set with signal receiving unit
 - For the further details, refer to the installation manual.

8-1-6. Monitor Function of Remote Controller Switch

Calling of sensor temperature display

<Contents>

Each data of the remote controller, indoor unit and outdoor unit can be understood by calling the service monitor mode from the remote controller.

<Procedure>


1 Push ♠ + □ buttons simultaneously for 4 seconds to call the service monitor mode.

The service monitor goes on, the master indoor unit No. is displayed at first and then the temperature of CODE No. $\mathcal{U}\mathcal{U}$ is displayed.

Û

2 Push temperature set * buttons and then change the CODE No. of data to be monitored.

The CODE No. list is shown below.



	CODE No.	Data name	Unit
	01	Room temperature (Remote controller)	°C
a	02	Indoor suction temperature (TA)	°C
unit data	03	Indoor heat exchanger (Coil) temperature (TCJ)	°C
	04	Indoor heat exchanger (Coil) temperature (TC)	°C
Indoor	07	Indoor fan revolution frequency	rpm
-	F2	Indoor fan calculated operation time	×100h
	F3	Filter sign time	×1h
	F8	Indoor discharge temperature*1	°C

	CODE No.	Data name	Unit
	60	Outdoor heat exchanger (Coil) temperature (TE)	°C
	61	Outside temperature (TO)	°C
data	62	Compressor discharge temperature (TD)	°C
t d	63	Compressor suction temperature (TS)	°C
unit	65	Heat sink temperature (THS)	°C
Outdoor	6A	Operation current (x 1/10)	Α
호	6D	Outdoor heat exchanger (Coil) temperature (TL)	°C
ŏ	70	Compressor operation frequency	rps
	72	Outdoor fan revolution frequency (Lower)	rpm
	73	Outdoor fan revolution frequency (Upper)	rpm
	F1	Compressor calculated operation time	×100h



Push one (left side button) button to select the indoor unit to be monitored. Each data of the indoor unit and its outdoor units can be monitored.



- **4** Pushing button returns the status to the usual display.
 - *1 The indoor discharge temperature of CODE No. [F8] is the estimated value from TC or TCJ sensor.

 Use this value to check discharge temperature at test run.

 (A discharge temperature sensor is not provided to this model.)
 - The data value of each item is not the real time, but value delayed by a few seconds to ten-odd seconds.
 - If the combined outdoor unit is one before 2 or 3 series, the outdoor unit data [6D], [70], [72] and [73] are not displayed.

■ Calling of error history

<Contents>

The error contents in the past can be called.

<Procedure>

1 Push ⊕ + ★ buttons simultaneously for 4 seconds or more to call the service check mode.


Service Check goes on, the **CODE No.** 01 is displayed, and then the content of the latest alarm is displayed.

The number and error contents of the indoor unit in which an error occurred are displayed.

2 In order to monitor another error history, push the set temperature history No. (CODE No.)

CODE No. \mathcal{O} / (Latest) \rightarrow **CODE No.** \mathcal{O} 4 (Old) **NOTE** : 4 error histories are stored in memory.

3 Pushing [™] button returns the display to usual display.



Returned to usual display

REQUIREMENT

Do not push button, otherwise all the error histories of the indoor unit are deleted. If the error histories are deleted by pushing CL button, turn off the power supply once and then turn on the power supply again. When the error which is same as one occurred at the last before deletion continuously occurs again, it may not be stored in memory.


(Group control operation)

In a group control, operation of maximum 8 indoor units can be controlled by a remote controller.

Twin, triple or double twin of an outdoor unit is one of the group controls.

The indoor unit connected with outdoor unit (Individual/Header of twin) controls room temperature according to setting on the remote controller.

<System example>



1. Display range on remote controller

The setup range (Operation mode/Air volume select/Setup temp) of the indoor unit which was set to the header unit is reflected on the remote controller.

- 1) Concealed duct high static pressure type (RAV-RMXXX) is not set up on the header unit.
 - If the Concealed duct high static pressure type is the header unit:
 Operation mode: [Cooling/Heating AUTO] [HEAT] [COOL] [FAN] and no [DRY]
 Air volume select: [HIGH]
 - When the operation mode is [DRY], [FAN] stops in concealed duct high static pressure models.

2. Address setup


If there is no serial communication between indoor and outdoor when the power is turned on, it is judged as follower unit of the twin. (Every time when the power is turned on)

• The judgment of header (wired) / follower (simple) of twin is carried out every time. It is not stored in non-volatile memory.

Turn on power of the indoor unit to be controlled in a group within 3 minutes after setting of automatic address. If power of the indoor unit is not turned on within 3 minutes (completion of automatic address setting), the system is rebooted and the automatic address setting will be judged again.

- 1) Connect indoor/outdoor connecting wire surely.
- Check line address/indoor address/group address of the unit one by one.
 Especially in case of twin, triple, double twin, check whether they are identical system address or not.
- 3) The unit No. (line/indoor gout address) which have been set once keep the present status as a rule if the unit No. is not duplicated with one of another unit.

■ Indoor unit power-ON sequence



- In a group operation, if the indoor unit which was fed power after judgment of automatic address cannot receive regular communication from the header unit and regular communication on identical pipe within 120 seconds after power was turned on, it reboots (system reset).
 - → The operation starts from judgment of automatic address (Gr construction check) again. (If the address of the header unit was determined in the previous time, the power fed to the header unit and reboot works, the header unit may change though the indoor unit line address is not changed.)

8-2. Setup at Local Site / Others


Model name: TCB-PCNT30TLE2

8-2-1. 1:1 Model Connection Interface (TCC-LINK adapter)

1. Function

This model is an optional P.C. board to connect the indoor unit to 1:1 model connection interface.

2. Microprocessor block diagram




3. 1:1 model connection interface wiring connection

CAUTION

- 1) When controlling DI, SDI series collectively, 1:1 model connection interface (This option) is required.
- 2) In case of group operation, twin-triple operation, the 1:1 model connection interface is necessary to be connected to the header unit.
- 3) Connect the central control devices to the central control system wiring.
- 4) When controlling DI, SDI series only, turn on only Bit 1 of SW01 of the least line of the system address No. (OFF when shipped from the factory)

* In case of DI, SDI series, the address is necessary to be set up again from the wired remote controller after automatic addressing.



Indoor units in all refrigerant lines: Max. 64 units [If mixed with SMMS (Link wiring), multi indoor units are included.]

^{*} However group follower units of SDI, DI series are not included in number of the units.

4. Wiring Specifications


- Use 2-core with no polar wire.
- Match the length of wire to wire length of the central control system. If mixed in the SMMS system, the wire length is lengthened with all indoor/outdoor inter-unit wire length at side.

No. of wires	Size	
2	Up to 1000m: twisted wire 1.25mm² Up to 2000m: twisted wire 2.0mm²	

- To prevent noise trouble, use 2-core shield wire.
- Connect the shield wire by closed-end connection and apply open process (insulating process) to the last terminal. Ground the earth wire to 1 point at indoor unit side. (In case of central controlling of digital inverter (DI, SDI) unit setup)

⚠ CAUTION


- 1) Closed-end connection of shield wire (Connect all the connecting parts of each indoor unit)
- 2) Apply open process to the last terminal (insulating process).
- 3) Ground earth wire to 1 point at indoor unit side.



5. P.C. Board Switch (SW01) Setup

When performing collective control by customized setup only, the setup of terminator is necessary.


- Using SW01, set up the terminator.
- Set up the terminator to only the interface connected to the indoor unit of least line address No.



(Reference) Setup contents of switch

(11010101100)	reserved a study a stu				
SW01		Terminator	Remarks		
Bit 1	Bit 1	rerminator	Remarks		
OFF	OFF	None	Mixed with SMMS (Link wiring) at shipment from factory		
ON	OFF	100Ω	Central control by digital inverter only		
OFF	ON	75Ω	Spare		
ON	ON	43Ω	Spare		

6. External view of P.C. board assembly



7. Address setup

In addition to set up the central control address, it is necessary to change the indoor unit number. (Line/Indoor/Group address). For details, refer to 1:1 model connection interface Installation Manual.

8-3. How to Set up Central Control Address Number

When connecting the indoor unit to the central control remote controller using 1:1 model connection interface, it is necessary to set up the central control address number.

• The central control address number is displayed as the line No. of the central control remote controller.

How to set up from indoor unit side by remote controller

<Pre><Pre>cedure> Perform setup while the unit stops.

1 Push + vent buttons for 4 seconds or more.

When group control is executed, first the unit No. *FLL* is displayed and all the indoor units in the group control are selected. In this time, fans of all the selected indoor units are turned on. **(Fig. 1)** (Keep *FLL* displayed status without pushing button.)

In case of individual remote controller which is not group-controlled, Line address and Indoor unit address are displayed.


- **2** Using temperature setup buttons, specify CODE No. $\mathcal{G}\overline{\mathcal{F}}$.
- **3** Using timer time **→ (A)** buttons, select the SET DATA. The setup data is shown in the table below (Table 1).
- **4** Push ^{SET} button. (OK if display goes on.)
 - To change the item to be set up, return to Procedure 2.

5 Push ♠ button.

The status returns to usual stop status.

(Table 1)

| SET DATA | Central control address No. |
|--------------|--|
| 0001
0002 | 1 2 |
| 0003 | 3 |
| 0064 | 64 |
| 0099 | Unset (Setup at shipment from factory) |



How to confirm the central control address (New function for AMT32E remote controller)

<Procedure> It can be confirmed even during operation or stopping.

1 Push button for 4 seconds or more.

Ú

2 In the frame at left side of the remote controller screen, the lighting set contents are displayed. During unset time, 0099 (At shipment from factory) is displayed.


Û

3 After lighting display for 3 seconds, the display automatically disappears.

If any button is pushed during display, immediately the display disappears and then the pushed button is displayed.


8-4. How to set up type of swing

- 1 Push for 4 seconds or more during stop of the operation.
 - SETTING flashes.
- 2 Push (At the left side of the button) and select the unit to be selected.
 - Every pushing the button, the unit No. changes.



The fan of the selected unit rotates and the louver swings.


3 Using TIMER SET ▼ / ▲ buttons, select type of the swing.




| Swing setup code | Louver operation |
|------------------|------------------------------|
| 0001 | Standard swing (At shipment) |
| 0002 | Dual swing |
| 0003 | Cycle swing |

REQUIREMENT


- Do not set 0000. (Louver may cause a trouble.)
- **4** Push $\stackrel{\text{SET}}{\bigcirc}$.
- **5** Push $\stackrel{\text{TEST}}{\cancel{\mathcal{E}}}$ to finish the setup.
 - Standard swing
 Four louvers swing simultaneously with the same angel.



- * Dual swing (Recommended for heating operation)
 - The adjoined louvers repeat horizontal discharge/Downward discharge alternately to clear irregularity of the temperature in heating operation.
 - The vertical discharge spreads hot air to the floor, and the horizontal discharge stirs.
 Both suppress the temperature irregularity.




- Cycle swing (Recommended for cooling operation)
- 4 louvers swing with time lag as if they heave.



8-5. How to set louver lock (Louver fix)

- Push (At the right side of the button) for 4 seconds or more during stop of the operation.
 - SETTING flashes.
- Push (At the left side of the button) and select the unit to be set.
 - Every pushing the button, the unit No. changes.




The fan of the selected unit rotates and the louver swings.


- Push temp. set 1 to display the louver No. of which air direction is to be fixed.
 - · The selected louver swings.




4 Push TIMER SET ▼ / ▲ and select air direction of the louver of which swinging you do not want.



- * If selecting above " and …, there may be fear of dewing in cooling time.
- **5** Push $\stackrel{\text{SET}}{\sim}$ to determine the setup contents.
 - When the setup was determined, mark goes on.
 To set continuously the louver lock of the other unit, repeat operations from 2 but from 3 to set the other louver lock in the same unit, respectively.
- 6 Push (2) to finish the setup.



* F1 displayed at the CODE No. on the remote controller means that the 01 louver was selected as shown in the figure.



NOTIFICATION

- Even if louver lock works, the louver temporarily moves in the following cases.
 - 1) During stop
 - 2) At start of heating operation
 - 3) During defrost operation
 - 4) During thermostat OFF

8-6. How to clear louver lock

In the item 4 of the louver lock setup procedure, set the air direction to 0000.

• # mark goes off.


The operations from 1 to 3, 5 and 6 are same as those of the louver lock.




6. How to set contents of save operation

In combination with outdoor units before 4 series, the displayed setup value exchanges, but the real operation is "75% fixed".

- 1 Push for 4 seconds or more during stop of the operation.
 - SETTING flashes.
- Push (At the left side of the button) and select the unit to be set.
 - Every pushing the button, the unit No. changes.
 The fan of the selected unit rotates and the louver swings.



- **3** Determine the capacity restricted value when pushing the save button of TIMER SET ▼ / ▲.
 - Every pushing the button, the capacity restricted value can be set at 1% interval in the range between 100% and 50%.
 - * The setting at shipment is 75%.




4 Push $\stackrel{\text{SET}}{\bigcirc}$ and then push $\stackrel{\text{TEST}}{\nearrow}$ to finish the setup.

9. ADDRESS SETUP

9-1. Address Setup

<Address setup procedure>

When an outdoor unit and an indoor unit are connected and they are twin-triple, or when an outdoor unit is connected to each indoor unit respectively in the group operation even if multiple refrigerant lines are provided, the automatic address setup completes with power-ON of the outdoor unit. The operation of the remote controller is not accepted while automatic address works. (Approx. 4 to 5 minutes)



• When the following addresses are not stored in the neutral memory (IC10) on the indoor P.C. board, a test run operation cannot be performed. (Unfixed data at shipment from factory)

| | CODE No. | Data at shipment | SET DATA range |
|---------------------|----------|------------------|--|
| Line address | 12 | 0099 | 0001 (No. 1 unit) to 0030 (No. 30 unit) |
| Indoor unit address | 13 | 0099 | 0001 (No. 1 unit) to 0064 (No. 64 unit) Max. value of indoor units in the identical refrigerant line (Double twin = 4) |
| Group
address | 14 | 0099 | 0000 : Individual (Indoor units which are not controlled in a group) 0001 : Header unit (1 indoor unit in group control) 0002 : Follower unit (Indoor units other than header unit in group control) |

9-2. Address Setup & Group Control

<Terminology>

Indoor unit No. : N - n = Outdoor unit line address N (Max. 30) - Indoor unit address n (Max. 64)

: 0 = Single (Not group control) Group address

1 = Header unit in group control 2 = Follower unit in group control

: The representative of multiple indoor units in group operation sends/receives signals to/ Header unit (= 1)

from the remote controllers and follower indoor units.

(*It has no relation with an indoor unit which communicates serially with the outdoor units.) The operation mode and setup temperature range are displayed on the remote controller

LCD. (Except air direction adjustment of louver)

Follower unit (= 2): Indoor units other than header unit in group operation

Basically, follower units do not send/receive signals to/from the remote controllers.

(Except errors and response to demand of service data)

Master unit (Header Twin)

: This unit communicates with the indoor unit (sub) which serial-communicates with the (Representative unit) outdoor units and sends/receives signal (Command from compressor) to/from the outdoor units as the representative of the cycle control in the indoor units of the identical line address within the minimum unit which configures one of the refrigerating cycles of Twin,

Triple, Double twin.

Sub unit : Indoor units excluding the header unit in Twin, Triple, Double twin

(Subordinate unit) This unit communicates with (Master) indoor unit in the identical line address and per-


forms

(Follower Twin) control synchronized with (Master) indoor unit.

This unit does not perform the signal send/receive operation with the outdoor units.:


N judgment for serial signal error.

9-2-1. System configuration




Remote controller

2. Single group operation




3. Triple




4. Single group operation

• Each indoor unit controls the outdoor unit individually.



5. Multiple groups operation (Manual address setting)



 Master unit: The master unit receives the indoor unit data (thermo status) of the sub (Without identical line address & indoor/outdoor serial) and then finally controls the outdoor compressor matching with its own thermo status.

The master unit sends this command information to the sub unit.

• Sub unit: The sub unit receives the indoor unit data from the master (With identical line address & indoor/outdoor serial) and then performs the thermo operation synchronized with the master unit.


The sub unit sends own thermo ON/OFF demand to the master unit.

(Example)

No. 1-1 master unit sends/receives signal to/from No. 1-2 and No. 1-3 sub units. (It is not influenced by the line 2 or 3 address indoor unit.)

9-2-2. Automatic Address Example from Unset Address (No miswiring)


1. Standard (One outdoor unit)



Only turning on source power supply (Automatic completion)


2. Group operation

(Multiple outdoor units = Multiple indoor units with serial communication only, without twin)



Only turning on source power supply (Automatic completion)


3. Multiple groups operation



9-3. Address Setup (Manual Setting from Remote Controller)

In case that addresses of the indoor units will be determined prior to piping work after wiring work

- Set an indoor unit per a remote controller.
- Turn on power supply.



Group address Individual : 0000 Header unit : 0001

Follower unit: 0002

For the above example, perform setting by


connecting singly the wired remote controller without remote controller inter-unit wire.

In case of group control

(Example of 2-lines wiring) (Real line: Wiring, Broken line: Refrigerant pipe)

- 1 Push ^{SET} + ^{CL} + ^{EST} buttons simultaneously for 4 seconds or more.
- 2 (Line address)
 Using the temperature setup ▼ / ▲ buttons, set 12 to the CODE No.
- **3** Using timer time **1 a** buttons, set the line address.
- **4** Push ^{SET} button. (OK when display goes on.)
- 5 (Indoor unit address)
 Using the temperature setup ▼ / ▲ buttons, set /∃ to the CODE No.
- **6** Using timer time **1** / **a** buttons, set 1 to the line address.
- **7** Push ^{SET} button. (OK when display goes on.)
- 8 (Group address)
 Using the temperature setup ▼ / ▲ buttons, set / ⁴ to the CODE No.
- 9 Using timer time **▼** / **△** buttons, set *0000* to Individual, *0001* to Header unit, and *0002* to Folloer unit.
- **10** Push [™] button. (OK when display goes on.)
- **11** Push button.

Setup completes. (The status returns to the usual stop status.)



<Operation procedure>

$$1 \rightarrow 2 \rightarrow 3 \rightarrow 4 \rightarrow 5 \rightarrow 6 \rightarrow 7 \rightarrow 8 \rightarrow 9 \rightarrow 10 \rightarrow 11$$
 END

9-4. Confirmation of Indoor Unit No. Position

1. To know the indoor unit addresses though position of the indoor unit body is recognized

• In case of individual operation (Wired remote controller: indoor unit = 1:1) (Follow to the procedure during operation)

<Procedure>


1 Push ON/OFF button if the unit stops.

2 Push object button.

Unit No. /-/ is displayed on LCD.

(It disappears after several seconds.)

The displayed unit No. indicate line address and indoor unit address. (When other indoor units are connected to the identical remote controller (Group control unit), other unit numbers are also displayed every pushing button.



<Operation procedure>

1 → 2 END


2. To know the position of indoor unit body by address

• To confirm the unit No. in the group control (Follow to the procedure during operation) (in this procedure, the indoor units in group control stop.)

<Procedure>

The indoor unit numbers in the group control are successively displayed, and fan, louver, and drain pump of the corresponding indoor unit are turned on. (Follow to the procedure during operation)

- 1 Push nand buttons simultaneously for 4 seconds or more.
 - Unit No. *FLL* is displayed.
 - Fans and louvers of all the indoor units in the group control operate.
- 2 Every pushing button, the unit numbers in the group control are successively displayed.
 - The unit No. displayed at the first time indicates the header unit address.
 - Fan and louver of the selected indoor unit only operate.
- 3 Push [™] button to finish the procedure.
 All the indoor units in the group control stop.



<Operation procedure>

1 → 2 → 3 END

<Maintenance/Check list>

Aiming in environmental preservation, it is strictly recommended to clean and maintain the indoor/outdoor units of the operating air conditioning system regularly to secure effective operation of the air conditioner.

It is also recommended to maintain the units once a year regularly when operating the air conditioner for a long time.

Check periodically signs of rust or scratches, etc. on coating of the outdoor units.

Repair the defective position or apply the rust resisting paint if necessary.

If an indoor unit operates for approx. 8 hours or more per day, usually it is necessary to clean the indoor/outdoor units once three months at least.

These cleaning and maintenance should be carried out by a qualified dealer.

Although the customer has to pay the charge for the maintenance, the life of the unit can be prolonged.

Failure to clean the indoor/outdoor units regularly will cause shortage of capacity, freezing, water leakage or trouble on the compressor.

| Don't mame | Object | | Contents of sheet | 0 | |
|------------------------------|--------|---------|---|--|--|
| Part name | Indoor | Outdoor | Contents of check | Contents of maintenance | |
| Heat exchanger | 0 | 0 | Blocking with dust, damage check | Clean it when blocking is found. | |
| Fan motor | 0 | 0 | Audibility for sound | When abnormal sound is heard | |
| Filter | 0 | _ | Visual check for dirt and breakage | Clean with water if dirty Replace if any breakage | |
| Fan | 0 | 0 | Visual check for swing and balance Check adhesion of dust and external appearance. | Replace fan when swinging or
balance is remarkably poor. If a large dust adheres, clean it with
brush or water. | |
| Suction/
Discharge grille | 0 | _ | Visual check for dirt and scratch | Repair or replace it if deformation or damage is found. | |
| Drain pan | 0 | _ | Check blocking by dust and dirt of drain water. | Clean drain pan, Inclination check | |
| Face panel, Louver | 0 | _ | Check dirt and scratch. | Cleaning/Coating with repair painting | |
| External appearance | _ | 0 | Check rust and pealing of insulator Check pealing and floating of coating film | Coating with repair painting | |

10. DETACHMENTS

10-1. 4-Way Cassette Type RAV-RM561UTP*, RAV-RM801UTP*, RAV-RM1101UTP*, RAV-RM1401UTP*, RAV-RM1601UTP*

| No. | Part name | Procedure | Remarks |
|-----|----------------------|--|--|
| 1 | Suction grille | CAUTION Be sure to put on the gloves at disassembling work; otherwise an injury will be caused by a part, etc. 1. Detachment 1) Stop operation of the air conditioner and then turn off switch of the breaker. 2) Slide the 2 knobs of the suction grille inward and then hang down the suction grille. 3) Remove a strap connecting the panel and the suction grille and then remove the suction grille. 2. Attachment 1) Hook the suction grille to the panel. 2) Attach strap of the suction grille to the panel as before. 3) Close the suction grille, slide the knobs outward and then fix the panel. | Suction grille Knobs of the suction grille hook Ceiling panel Hook for falling-preventive strap Hole for ceiling panel hook Hinge |
| 2 | Electric parts cover | Detachment Carry out work of item 1. of ①. Remove the fixing screw A which fixes the electric parts cover and loosen the fixing screw B. Pull down the electric parts cover, remove pin of the bell mouth and then slide it to the arrow direction in order to open the claws and the electric parts box cover. Attachment Close the electric parts cover and slide it, hook claw of the electric parts box, claw of the electric parts box cover and the Dharma doll hole, and then insert pin of the bell mouth into hole of the electric parts box cover. Tighten the fixing screws A and B and then fix the electric parts box cover. Following to work of item 2 of ①, mount the suction grille as before. | Bell mouth pin Claw of electric parts box Potbelly hole (Dharma doll hole) Claw of electric parts box cover Fixing screw A Electric parts box cover |

| No. | Part name | Procedure | Remarks |
|-----|----------------------------------|---|--|
| 2 | Electric parts cover (Continued) | | |
| 3 | Adjust corner cap | 1. Detachment 1) Pull knob of the adjust corner cap to the arrow direction, remove strap of the adjust corner cap from pin of the panel and then remove all the 4 corners of the cap. NOTE: The knob is provided to only one side. Be sure to remove the cap of the knob side at first. 2. Attachment 1) Hook strap of the adjust corner cap securely to pin of the ceiling panel. 2) Insert claw of the adjust corner cap into the square hole of the panel. (2 positions) 3) Push claws of the adjust corner cap into the positions indicated with arrow marks so that they fit in 3 positions. | Adjust corner cap Rnob Pulling direction Strap of adjust corner cap Claws (3 positions) Claws (3 positions) |

No. Part name **Procedure** Remarks 1. Detachment (4) Ceiling panel Clamp 1) Carry out works of item 1 of (2) and item 1 of (3). Louver motor wiring 2) Remove the flap connector (CN510, White, 20P) connected to the control P.C. board and then remove the lead wire from the clamp. CN510 NOTE: Unlock the lock of the housing part and then remove the connector. Square hole of indoor unit 3) Loosen the panel fixing 4 screws. 4) Slide the panel fixing brackets (4 positions) outward. 5) Push the tentative bracket outward and then remove the ceiling panel. Panel fixing screw Electric parts box 2. Attachment Louver motor wiring 1) Insert the tentative brackets (2 positions) of the ceiling panel into square holes of the indoor unit and then hook the panel tentatively. Ceiling panel Tentative bracket NOTE: The ceiling panel has the directional Square hole of indoor unit properties against the indoor unit. Direct the louver motor wire to the electric parts box side of the indoor unit. 2) Pass the head of the panel fixing screw through hole of the panel fixing bracket Push in case of removing and then slide the panel fixing bracket inward. 3) Tighten in the panel fixing screw to fix the Tentative bracket ceiling panel. 4) Following to work of item 2 of (3), attach the adjust corner cap as before. Square hole of indoor unit 5) Connect the louver connector (CN510, White, 20P) as before and then fix the lead wire with clamp. Panel fixing screw 6) Following to work of item 2 of (2), mount the electric parts box cover and the suction grille as before. Inner side Panel fixing bracket Outer side Sliding direction

| No. | Part name | Procedure | Remarks |
|-----|-----------------------|--|------------------|
| (S) | Control
P.C. board | 1. Detachment 1) Carry out work of item 1 of ②. 2) Remove connectors which are connected from the control P.C. board to the other parts and then remove wiring from the clamp. CN510: Louver motor (20P, White) CN34: Float switch (3P, Red) CN504: Drain pump (2P, White) CN101: TC sensor (2P, Black) CN102: TCJ sensor (2P, Red) CN104: Room temp. Sensor (2P, Yellow) CN333: Fan motor power supply (5P, White) CN334: Fan motor position detection (3P, White) NOTE: Unlock the lock of the housing part and then remove the connector. 3) Unlock the locks of the card edge spacer (6 positions) and then remove the control P.C. board. 2. Attachment 1) Fix the control P.C. board to the card edge spacer (6 positions) 2) Connect the connector removed in item 1 as before and then fix the wiring with the clamp. 3) Following to work of item 2 of ②, mount the electric parts box cover and the suction grille as before. | Cardledge spacer |

| No. | Part name | Procedure | Remarks |
|-----|-----------|---|---|
| 6 | Drain cap | Detachment Carry out work of item 1 of ①. Loosen screws (3 positions) fixing the drain cap (outside) and then turn the drain cap to the arrow mark direction to remove it. | Drain cap (outside) |
| | | NOTE: The drain cap is hung down because a strap is attached to it (outside). | CLOSE |
| | | Loosen the cap by turn the drain cap
(inside) for approx. 1 turn to OPEN →
direction and then drain the drain water
accumulated in the drain pan. | OPEN |
| | | NOTE: Be sure to catch drain water using a bucket, etc. when loosening the drain cap. | Strap Drain cap fixing screws Drain cap (inside) |
| | | The insulating materials are adhered to the drain cap (outside) and opening part of the drain pan; be careful that they are not come off. If they are come off, stick them as before using double-faces tape, etc. | CLOSE |
| | | 4) Turn the drain cap once again to OPEN → direction to remove it. | OPEN |
| | | 2. Attachment 1) Insert the drain cap (inside), turn it to CLOSE → direction until the position where "Clashed sound" is heard and it cannot be turned more over (Position where △ mark of the drain pan matches with △ mark of the drain cap (inside)) and then fix it. | Drain cap Δ mark |
| | | NOTE: When attaching the drain cap (inside), remove dirt attached to the packing. And tighten in it noting so that the cap is not slantingly set. If attaching the drain cap as dust or dirt is attached or the cap is set slantingly, water leakage is caused. | |
| | | 2) Turn the drain cap (outside) to → direction and then attach it using the fixing screw as original. 3) Following to work of item 2 of ①, mount the suction grille as before. | |
| | | | |

| No. | Part name | Procedure | Remarks |
|--------------|-----------|---|---|
| No. ⑦ | Fan motor | 1. Detachment 1) Carry out work of item 1 of ②. 2) Remove connectors which are connected from the control P.C. board to the other parts and then remove each wiring from the clamp. CN510: Louver motor (20P, White) CN34: Float switch (3P, Red) CN504: Drain pump (2P, White) CN101: TC sensor (2P, Black) CN102: TCJ sensor (2P, Red) CN104: Room temp. Sensor (2P, Orange) CN333: Fan motor power supply (5P, White) CN334: Fan motor position detection (3P, White) NOTE: Unlock the lock of the housing part and then remove the connector. 3) Remove the fixing screws A and B, and then remove the electric parts box. (Fixing screw A: Ø4 × 10, 3 pcs, Fixing screw B: Ø4 × 10, 1 pc.) 4) Remove the fan motor lead, TC sensor and TCJ sensor from clamp of the bell mouth. 5) Remove the fixing screws and then remove the bell mouth. (Ø4 × 10, 8 pcs.) 6) Remove the fixing screws and then remove the hut cap. (Ø4 × 10, 2 pcs.) 7) Remove the fixing nut and then remove the turbo fan. (M8 nut with flange, 1 pc.) 8) Remove the fixing screws and then remove the motor lead holding bracket. (Ø4 × 8, 2 pcs.) 9) Cut the bundling band and then remove the flamp. 10) Remove the fixing nut and then remove the flamp. 11) Fix the parts as before in order of fan motor → motor lead holding bracket → turbo fan → nut cap → bell mouth. NOTE: Fix the motor lead to the clamp without slack as before using bundling band. When fixing the turbo fan, be sure to match the D-cut of the fan boss with D-cut of the motor shaft. Using a torque wrench, fix the turbo fan and tighten it to 5.4 ±0.2 Nm. | Fixing screw A Fixing screw B Electric parts box Clamp Fan motor lead TC sensor TCJ sensor Bell mouth Nut cap Fixing screw Turbo fan |

| No. | Part name | Procedure | Remarks |
|-----|-----------------------|--|--|
| | Fan motor (Continued) | Attachment Fix the fan motor lead, TC sensor and TCJ sensor with the clamp of the bell mouth. Mount the electric parts box with the fixing screws A and B. (Ø4 × 10, 3 pcs. Ø4 × 10, 1 pc.) Connect the connector removed in item 1 as before and then fix wiring with the clamp. Following to work of item 2 of ②, mount the electric parts box cover and the suction grille as before. | Fan motor Motor lead holding bracket Fixing screws (Ø4 × 8) Clamp Fan motor lead |


| No. Part name | Procedure | Remarks |
|---------------|--|---|
| 8 Drain pump | 1. Detachment 1) Carry out works of item 1 of ② and item 1 of ⑥. 2) Remove the drain pump connector (CN504, White, 2P) connected to the control P.C. board and then remove the lead wire from the clamp. 3) Remove the fixing screws and then remove the drain pump. (Ø4 × 10, 3 pcs.) 4) As shown in the right figure, first pull out the connecting part of the drain pump and the drain hose from the drain port and then take out the drain pump. 5) Set direction of the knob of the hose band downward, slide it from the pump connecting part to the hose side and then remove the drain hose from the drain pump. 6) Pass the connector of the drain pump lead wire through the wiring taking-out port and then take out the drain pump. 2. Attachment 1) Enter your hand into the drain port and pass the connector of the drain pump lead wire through the wiring taking-out port. 2) Connect the drain hose to the drain pump as before. NOTE: Insert the drain hose up to the end of the drain pump connecting part, apply band to the white mark position of the hose and then set the band knob upward. 3) Return the drain pump to the indoor unit and then mount it as before using the fixing screws. (Ø4 × 10, 3 pcs.) 4) Connect the drain pump connector (CN504, White, 2P) to the control P.C. board and then fix it as before with the clamp. 5) Following to words of item 2 of ⑥ and item 2 of ②, mount the drain cap, the electric parts box cover and the suction grille as before. | Drain pump CN504 Drain pump lead wire Wiring taking-out port Clamp Drain hose Pump connecting part Slide to drain hose side. |

| No. | Part name | Procedure | Remarks |
|-----|-----------------------|--|--|
| 9 | Float switch assembly | Detachment Carry out works of item 1 of ⑦ and works from 1) to 5). Remove the fixing screw and then remove the float switch assembly. (Ø4 × 25, 1 pc.) Attachment Mount the float switch assembly as before with the fixing screw. NOTE: When mounting, match hole of the float switch assembly with projection of the drain pan. Mount the bell mouth as before. Ø4 × 10, 8 pcs.) Following to works of item 2 of ⑦ and works from 2) to 5), attach the parts as before. | Fixing screw (Ø4 x 25) Hole of float switch assembly Projection of drain pan |
| 100 | Drain pan | Detachment Carry out works of item 1 of ④, item 1 of ⑥, item 1 of ⑦ and works from 2) to 5). Remove the fixing screws to remove the drain pan. (Ø4 x 8, 4 pcs.) Attachment Fix parts as before in order of drain cap → drain pan → bell mouth. Following to works of item 2 of ⑦ and works from 2) to 5), attach parts as before. | Fixing screws (Ø4 x 8) |

| No. | Part name | Procedure | Remarks |
|-----|----------------|---|---|
| 1 | Heat exchanger | Detachment Recover the refrigerant gas. Carry out work of item 1 of ①. Remove refrigerant pipe at indoor unit side. Remove the fixing screws and then remove the piping cover. (Ø4 x 10, 3 pcs.) Remove the drain hose from the drain pump and remove the fixing screws to remove the drain pump stand. (Ø4 x 8, 3 pcs.) While pushing the heat exchanger, remove the fixing band, fixing screws and the heat exchanger. (Ø4 x 8, 3 pcs.) Attachment Mount the heat exchanger with the fixing band and the fixing screws. (Ø4 x 8, 3 pcs.) Fix the parts as before in order of drain pump stand → piping cover. Connect the refrigerant pipe as before and then apply vacuuming. Following to work of item 2 of ⑩, attach the parts as before. | Fixing screws (Ø4 x 10) Piping cover Fixing screws (Ø4 x 8) Drain pump stand |
| | | Fixing band Heat exchanger | Fixing screws (Ø4 x 8) Fixing screw Fixing band |


11. EXPLODED VIEWS AND PARTS LIST

11-1. RAV-RM561UTP-E, RM561UTP-TR, RM801UTP-E, RM801UTP-TR




| Dof No | Dart No. | Doscription | RAV-RM | | | | |
|---------|----------|----------------------------|----------|-----------|----------|-----------|--|
| Ref.No. | Part No. | Description | 561UTP-E | 561UTP-TR | 801UTP-E | 801UTP-TR | |
| 201 | 43T20335 | FAN, ASSY TURB | 1 | 1 | 1 | 1 | |
| 204 | 43T44609 | REFRIGERANT CYCLE ASSEMBLY | 1 | 1 | | | |
| 205 | 43T44610 | REFRIGERANT CYCLE ASSEMBLY | | | 1 | 1 | |
| 207 | 43T22322 | BELL MOUTH | 1 | 1 | 1 | 1 | |
| 208 | 43T72320 | PAN ASSY, DRAIN | 1 | 1 | 1 | 1 | |
| 212 | 43T70326 | HOSE, DRAIN | 1 | 1 | 1 | 1 | |
| 215 | 43T83307 | BAND, HOSE | 1 | 1 | 1 | 1 | |
| 216 | 43T63348 | CLAMP, DOWN | 1 | 1 | 1 | 1 | |
| 217 | 43T63349 | CLAMP, UP | 1 | 1 | 1 | 1 | |
| 218 | 43T63347 | CLAMP, WIRE | 4 | 4 | 4 | 4 | |
| 219 | 43T97322 | NUT, FLARE, 1/2 IN | 1 | 1 | | | |
| 219 | 43T97321 | NUT, FLARE, 3/8 IN | | | 1 | 1 | |
| 220 | 43T97320 | NUT, FLARE, 1/4 IN | 1 | 1 | | | |
| 220 | 43T97323 | NUT, FLARE, 5/8 IN | | | 1 | 1 | |
| 221 | 43T82338 | SOCKET | 1 | 1 | | | |
| 221 | 43T82337 | SOCKET | | | 1 | 1 | |
| 222 | 43T82336 | SOCKET | 1 | 1 | | | |
| 222 | 43T82339 | SOCKET | | | 1 | 1 | |
| 223 | 43T11323 | RUBBER, CUSHION | 3 | 3 | | | |
| 224 | 43T39352 | PLATE, WIND | | | 4 | 4 | |
| 225 | 43T97315 | SCREW, FIX PANEL | 4 | 4 | 4 | 4 | |
| 226 | 43T11324 | RUBBER, CUSHION | | | 3 | 3 | |
| 227 | 43T97316 | WASHER | | | 1 | 1 | |
| 229 | 43T21441 | MOTOR, FAN, SWF-230-60-2R | 1 | 1 | 1 | 1 | |
| 230 | 43T04318 | COVER ASSY | 1 | 1 | 1 | 1 | |
| 231 | 43T39353 | CAP, NUT | 1 | 1 | 1 | 1 | |
| 233 | 43T19358 | COVER, SENSOR | 1 | 1 | 1 | 1 | |
| 234 | 43T77301 | PUMP ASSY, MDP-1401 | 1 | 1 | 1 | 1 | |
| 235 | 43T51314 | SWITCH ASSY, FLOAT | 1 | 1 | 1 | 1 | |
| 236 | 43T79319 | LID ASSY, OUTSIDE | 1 | 1 | 1 | 1 | |
| 237 | 43T71303 | SOCKET, ASSY DRAIN | 1 | 1 | 1 | 1 | |
| 238 | 43T97310 | WASHER | 3 | 3 | 3 | 3 | |
| 239 | 43T97001 | NUT | 1 | 1 | 1 | 1 | |
| 240 | 43T47333 | BONNET, 12.70 DIA | 1 | 1 | | | |
| 240 | 43T47332 | BONNET, 9.52 DIA | | | 1 | 1 | |
| 241 | 43T47331 | BONNET, 6.35 DIA | 1 | 1 | | | |
| 241 | 43T47334 | BONNET, 15.88 DIA | | | 1 | 1 | |
| 242 | 43T19333 | HOLDER, SENSOR | 2 | 2 | 2 | 2 | |
| 243 | 43T83311 | BAND, HOSE | 1 | 1 | 1 | 1 | |
| 245 | 43T83312 | STRING | 1 | 1 | 1 | 1 | |
| 246 | 43T85713 | OWNER'S MANUAL | 1 | | 1 | | |
| 246 | 43T85714 | OWNER'S MANUAL | | 1 | | 1 | |
| 247 | 43T79318 | GLASS | 1 | 1 | 1 | 1 | |
| 249 | 43T79317 | LID ASSY, INSIDE | 1 | 1 | 1 | 1 | |

11-2. RAV-RM1101UTP-E, RM1101UTP-TR, RM1401UTP-E, RM1401UTP-TR, RM1601UTP-E, RM1601UTP-TR




| 5 (1) | | Description | RAV-RM | | | | | | |
|---------|----------|----------------------------|-----------|------------|-----------|------------|-----------|------------|--|
| Ref.No. | Part No. | | 1101UTP-E | 1101UTP-TR | 1401UTP-E | 1401UTP-TR | 1601UTP-E | 1601UTP-TR | |
| 202 | 43T20334 | FAN, ASSY TURB | 1 | 1 | 1 | 1 | 1 | 1 | |
| 206 | 43T44611 | REFRIGERANT CYCLE ASSEMBLY | 1 | 1 | 1 | 1 | 1 | 1 | |
| 207 | 43T22322 | BELL MOUTH | 1 | 1 | 1 | 1 | 1 | 1 | |
| 208 | 43T72320 | PAN ASSY, DRAIN | 1 | 1 | 1 | 1 | 1 | 1 | |
| 212 | 43T70326 | HOSE, DRAIN | 1 | 1 | 1 | 1 | 1 | 1 | |
| 215 | 43T83307 | BAND, HOSE | 1 | 1 | 1 | 1 | 1 | 1 | |
| 216 | 43T63348 | CLAMP, DOWN | 1 | 1 | 1 | 1 | 1 | 1 | |
| 217 | 43T63349 | CLAMP, UP | 1 | 1 | 1 | 1 | 1 | 1 | |
| 218 | 43T63347 | CLAMP, WIRE | 4 | 4 | 4 | 4 | 4 | 4 | |
| 219 | 43T97321 | NUT, FLARE, 3/8 IN | 1 | 1 | 1 | 1 | 1 | 1 | |
| 220 | 43T97323 | NUT, FLARE, 5/8 IN | 1 | 1 | 1 | 1 | 1 | 1 | |
| 221 | 43T82337 | SOCKET | 1 | 1 | 1 | 1 | 1 | 1 | |
| 222 | 43T82339 | SOCKET | 1 | 1 | 1 | 1 | 1 | 1 | |
| 224 | 43T39352 | PLATE, WIND | 4 | 4 | 4 | 4 | 4 | 4 | |
| 225 | 43T97315 | SCREW, FIX PANEL | 4 | 4 | 4 | 4 | 4 | 4 | |
| 226 | 43T11324 | RUBBER, CUSHION | 3 | 3 | 3 | 3 | 3 | 3 | |
| 227 | 43T97316 | WASHER | 1 | 1 | 1 | 1 | 1 | 1 | |
| 228 | 43T21439 | MOTOR, FAN, ICF-280-150-1 | 1 | 1 | 1 | 1 | 1 | 1 | |
| 230 | 43T04318 | COVER ASSY | 1 | 1 | 1 | 1 | 1 | 1 | |
| 231 | 43T39353 | CAP, NUT | 1 | 1 | 1 | 1 | 1 | 1 | |
| 233 | 43T19358 | COVER, SENSOR | 1 | 1 | 1 | 1 | 1 | 1 | |
| 234 | 43T77301 | PUMP ASSY, MDP-1401 | 1 | 1 | 1 | 1 | 1 | 1 | |
| 235 | 43T51314 | SWITCH ASSY, FLOAT | 1 | 1 | 1 | 1 | 1 | 1 | |
| 236 | 43T79319 | LID ASSY, OUTSIDE | 1 | 1 | 1 | 1 | 1 | 1 | |
| 237 | 43T71303 | SOCKET, ASSY DRAIN | 1 | 1 | 1 | 1 | 1 | 1 | |
| 239 | 43T97001 | NUT | 1 | 1 | 1 | 1 | 1 | 1 | |
| 241 | 43T47334 | BONNET, 5/8 IN | 1 | 1 | 1 | 1 | 1 | 1 | |
| 242 | 43T19333 | HOLDER, SENSOR | 2 | 2 | 2 | 2 | 2 | 2 | |
| 243 | 43T83311 | BAND, HOSE | 1 | 1 | 1 | 1 | 1 | 1 | |
| 245 | 43T83312 | STRING | 1 | 1 | 1 | 1 | 1 | 1 | |
| 246 | 43T85713 | OWNER'S MANUAL | 1 | - | 1 | - | - | - | |
| 246 | 43T85714 | OWNER'S MANUAL | - | 1 | - | 1 | - | - | |
| 246 | 43T85740 | OWNER'S MANUAL | - | - | - | - | 1 | - | |
| 246 | 43T85741 | OWNER'S MANUAL | - | - | - | - | - | 1 | |
| 247 | 43T79318 | GLASS | 1 | 1 | 1 | 1 | 1 | 1 | |
| 249 | 43T79317 | LID ASSY, INSIDE | 1 | 1 | 1 | 1 | 1 | 1 | |
| 250 | 43T39406 | BAND-FIX-EVA | 2 | 2 | 2 | 2 | 2 | 2 | |
| 251 | 43T39407 | BAND-FIX-EVA | 1 | 1 | 1 | 1 | 1 | 1 | |

Electric parts



| | | | RAV-RM | | | | | |
|---------|----------|------------------------|-----------------------|-----------------------|-------------------------|-------------------------|-------------------------|--|
| Ref.No. | Part No. | Description | 561UTP-E
561UTP-TR | 801UTP-E
801UTP-TR | 1101UTP-E
1101UTP-TR | 1401UTP-E
1401UTP-TR | 1601UTP-E
1601UTP-TR | |
| 401 | 43T50347 | SERVICE-SENSOR, Ø6 | 2 | 2 | 2 | 2 | 2 | |
| 402 | 43T50476 | SERVICE-SENSOR, TA | 1 | 1 | 1 | 1 | 1 | |
| 403 | 43T60427 | SERV-TERMINAL, 3P, 20A | 1 | 1 | 1 | 1 | 1 | |
| 404 | 43T60434 | TERMINAL BLOCK, 2P | 1 | 1 | 1 | 1 | 1 | |
| 405 | 43TN9322 | PC BOARD ASSY | 1 | 1 | 1 | 1 | 1 | |





| Location | Don't No. | Description | Model Name RBC- | | | | | |
|----------|-----------|-------------------------|-----------------|--------------|--------------|---------------|--|--|
| No. | Part No. | Description | U31PG (W)-E | U31PG (WS)-E | U31PGS (W)-E | U31PGS (WS)-E | | |
| 301 | 43409207 | Grille, Air Inlet | 1 | 1 | 1 | 1 | | |
| 302 | 43480017 | Air Filter, ABS + PPNET | 1 | 1 | 1 | 1 | | |
| 303 | 4302D003 | Motor, Louver, MP24Z3N | 4 | 4 | 4 | 4 | | |
| 304 | 43407145 | Outlet, Air Form, PS-F | 2 | 2 | 2 | 2 | | |
| 305 | 43407146 | Outlet, Air Form, PS-F | 2 | 2 | 2 | 2 | | |
| 306 | 43409212 | Louver, ABS | 4 | | | | | |
| 307 | 43409216 | Louver, ABS | | 4 | | | | |
| 308 | 43401037 | Cover, Panel Ass'y | 3 | | 3 | | | |
| 309 | 43401041 | Cover, Panel Ass'y | | 3 | | 3 | | |
| 310 | 43401043 | Cover, Panel Ass'y | 1 | | 1 | | | |
| 311 | 43401047 | Cover, Panel Ass'y | | 1 | | 1 | | |
| 312 | 43407148 | Plate, Fix, Panel | 2 | 2 | 2 | 2 | | |
| 313 | 43407149 | Plate, Fix, Panel | 2 | 2 | 2 | 2 | | |
| 314 | 43407150 | Hook, ABS | 2 | 2 | 2 | 2 | | |
| 315 | 43407154 | Cap, AXIS, POM | 4 | 4 | 4 | 4 | | |
| 316 | 43403010 | Cover Ass'y, Motor | 2 | 2 | 2 | 2 | | |
| 317 | 43403011 | Cover Ass'y | 1 | 1 | 1 | 1 | | |
| 318 | 43403012 | Cover Ass'y | 1 | 1 | 1 | 1 | | |
| 319 | 43407155 | Fix, Motor, ABS | 2 | 2 | 2 | 2 | | |
| 320 | 43407156 | Fix, Motor, ABS | 2 | 2 | 2 | 2 | | |
| 321 | 43460125 | Lead, Motor | 1 | 1 | 1 | 1 | | |
| 322 | 43400077 | Panel, Front, PS (W) | 1 | 1 | 1 | 1 | | |
| 323 | 43109423 | Louver, ABS | | | 4 | | | |
| 324 | 43109424 | Louver, ABS | | | | 4 | | |

WARNINGS ON REFRIGERANT LEAKAGE

Check of Concentration Limit

The room in which the air conditioner is to be installed requires a design that in the event of refrigerant gas leaking out, its concentration will not exceed a set limit.

The refrigerant R410A which is used in the air conditioner is safe, without the toxicity or combustibility of ammonia, and is not restricted by laws to be imposed which protect the ozone layer. However, since it contains more than air, it poses the risk of suffocation if its concentration should rise excessively. Suffocation from leakage of R410A is almost non-existent.

If a conditioner system is to be installed in a small room, select a suitable model and installation procedure so that if the refrigerant accidentally leaks out, its concentration does not reach the limit (and in the event of an emergency, measures can be made before injury can occur).

In a room where the concentration may exceed the limit, create an opening with adjacent rooms, or install mechanical ventilation combined with a gas leak detection device.

The concentration is as given below.


Total amount of refrigerant (kg) ≤ Concentration limit (kg/m³)

Min. volume of the indoor unit installed room (m³)

The concentration limit of R410A which is used in air conditioners is 0.3 kg/m³.

NOTE

The minimum indoor floor area compared with the amount of refrigerant is roughly as follows: (When the ceiling is 2.7m high)



Toshiba Carrier (Thailand) Co., Ltd. 144/9 MOO 5, BANGKADI INDUSTRIAL PARK, TIVANON ROAD, TAMBOL BANGKADI, AMPHUR MUANG, PATHUMTHANI 12000, THAILAND.