TOSHIBA

AIR CONDITIONER (MULTI TYPE)

SERVICE MANUAL

FILE NO. A10-2004 Revision 1: Mar.,2021 Revision 2: Apr., 2021 Revision 3: Jun., 2021 Revision 4: Nov., 2021 Revision 5: Aug., 2022

Indoor unit

<Compact 4-way cassette type>

MMU-UP0051MH-E(TR) MMU-UP0071MH-E(TR) MMU-UP0091MH-E(TR) MMU-UP0121MH-E(TR) MMU-UP0151MH-E(TR) MMU-UP0181MH-E(TR)

<4-way cassette type>

MMU-UP0091H-E(TR)
MMU-UP0121H-E(TR)
MMU-UP0151H-E(TR)
MMU-UP0181H-E(TR)
MMU-UP0241H-E(TR)
MMU-UP0271H-E(TR)
MMU-UP0301H-E(TR)
MMU-UP0361H-E(TR)
MMU-UP0481H-E(TR)
MMU-UP0561H-E(TR)

<1-way cassette type>

MMU-UP0151SH-E(TR) MMU-UP0181SH-E(TR) MMU-UP0241SH-E(TR)

<Floor standing concealed type>

MML-UP0071BH-E(TR) MML-UP0091BH-E(TR) MML-UP0121BH-E(TR) MML-UP0151BH-E(TR) MML-UP0181BH-E(TR) MML-UP0241BH-E(TR)

<2-way cassette type>

MMU-UP0071WH-E(TR)
MMU-UP0091WH-E(TR)
MMU-UP0121WH-E(TR)
MMU-UP0151WH-E(TR)
MMU-UP0181WH-E(TR)
MMU-UP0241WH-E(TR)
MMU-UP0271WH-E(TR)
MMU-UP0301WH-E(TR)
MMU-UP0361WH-E(TR)
MMU-UP0481WH-E(TR)
MMU-UP0561WH-E(TR)

<Floor standing cabinet type>

MML-UP0071H-E(TR) MML-UP0091H-E(TR) MML-UP0121H-E(TR) MML-UP0151H-E(TR) MML-UP0181H-E(TR) MML-UP0241H-E(TR)

<Floor standing type>

MMF-UP0151H-E(TR) MMF-UP0181H-E(TR) MMF-UP0241H-E(TR) MMF-UP0271H-E(TR) MMF-UP0361H-E(TR) MMF-UP0481H-E(TR) MMF-UP0561H-E(TR)

CONTENTS

PRECAUTIONS FOR SAFETY	7
1. SPECIFICATIONS	19
1-1. Compact 4-way cassette type	19
1-2. 2-way cassette type	
1-3. 1-way cassette type	
1-4. Floor standing cabinet type	
1-5. Floor standing concealed type	
1-6. Floor standing type	
1-7. 4-way cassette type	
2. CONSTRUCTION VIEWS (EXTERNAL VIEWS)	
2-1. Compact 4-way cassette type	
2-2. 2-way cassette type	
2-3. 1-way cassette (SH) type	
2-4. Floor standing cabillet type	
2-6. Floor standing type	
2-7. 4-way cassette type	
3. WIRING DIAGRAMS	42
3-1. Compact 4-way cassette type	42
3-2. 2-way cassette type	
3-3. 1-way cassette (SH) type	44
3-4. Floor standing cabinet type	
3-5. Floor standing concealed type	
3-6. Floor standing type	
3-7. 4-way cassette type	
4. PARTS RATING	49
5. REFRIGERANT CYCLE DIAGRAM	51
6. CONTROL OUTLINE	52
7. COMMUNICATION TYPE, MODEL NAMES AND THE MAXIMUM NUMBER O	F
CONNECTABLE UNITS	67
8. APPLIED CONTROL AND FUNCTIONS	
(INCLUDING CIRCUIT CONFIGURATION)	68
8-1. Indoor controller block diagram (MCC-1643)	
8-1-1. In case of connection of wired remote controller	
8-1-2. In case of connection of wireless remote controller	
8-1-2. In case of connection of wireless remote controller	
(Compact 4-way cassette type)	70
8-1-3. Connection of both wired remote controller and wireless remote controlled	
8-2. Indoor controller block diagram (MCC-1744)	
8-2-1. In case of connection of wired remote controller	
8-2-2. In case of connection of wireless remote controller	
8-2-3. Connection of both wired remote controller and wireless remote controlle 8-3. Indoor Print Circuit Board	
8-3-1. MCC-1643	
8-3-2. MCC-1744	
8-4. Test run of indoor unit	

	8-5. Method to set indoor unit function DN code	
	8-6. Applied control of indoor unit	89
9. 1	FROUBLESHOOTING	108
	9-1. Overview	108
	9-2. Troubleshooting method	109
	9-3. Troubleshooting based on information displayed on remote controller	
	9-4. Check Codes list	
	9-5. Diagnostic Procedure for Each Check Code (Indoor Unit)	135
	9-6. Sensor characteristics	144
	9-7. Maintenance list	145
	9-8. Notice code	146
10.	P.C. BOARD EXCHANGE PROCEDURES	147
	10-1. Replacement of indoor P.C. boards	
	•	
11.	DETACHMENTS	
	11-1. Compact 4-way cassette	
	11-2. 2-way cassette	
	11-3. 1-way cassette (SH)	
	11-4. Floor standing cabinet	
	11-5. Floor standing concealed	
	11-6. Floor standing	
	11-7. 4-way cassette	205
12.	EXPLODED VIEWS AND PARTS LIST	216
	12-1. Compact 4-way cassette type	216
	12-2. 2-way cassette type	
	12-3. 1-way Cassette Type (SH)	229
	12-4. Floor Standing Cabinet Type	
	12-5. Floor Standing Concealed Type	
	12-6. Floor Standing Type	
	12-7. 4-way cassette type	244

<Information>

These air conditioner has adopted a refrigerant HFC (R32 or R410A) which does not destroy the ozone layer. When combining with an outdoor unit of R32 refrigerant, it is legally necessary to connect a refrigerant leak detection system. For details, refer to the service manual of the outdoor unit to be connected.

Please read carefully through these instructions that contain important information which complies with the "Machinery Directive" (Directive 2006/42/EC), and ensure that you understand them.

Definition of Qualified Installer or Qualified Service Person

The air conditioner must be installed, maintained, repaired and removed by a qualified installer or qualified service person. When any of these jobs is to be done, ask a qualified installer or qualified service person to do them.

A qualified installer or qualified service person is an agent who has the qualifications and knowledge described in the table below.

Agent	Qualifications and knowledge which the agent must have
Qualified installer (*1)	 The qualified installer is a person who installs, maintains, relocates and removes the air conditioners made by Toshiba Carrier Corporation. He or she has been trained to install, maintain, relocate and remove the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such operations by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to these operations. The qualified installer who is allowed to do the electrical work involved in installation, relocation and removal has the qualifications pertaining to this electrical work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to electrical work on the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work. The qualified installer who is allowed to do the refrigerant handling and piping work involved in installation, relocation and removal has the qualifications pertaining to this refrigerant handling and piping work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to refrigerant handling and piping work on the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work. The qualified installer who is allowed to work at heights has been trained in matters relating to working at heights with the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge rel
Qualified service person (*1)	 The qualified service person is a person who installs, repairs, maintains, relocates and removes the air conditioners made by Toshiba Carrier Corporation. He or she has been trained to install, repair, maintain, relocate and remove the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such operations by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to these operations. The qualified service person who is allowed to do the electrical work involved in installation, repair, relocation and removal has the qualifications pertaining to this electrical work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to electrical work on the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work. The qualified service person who is allowed to do the refrigerant handling and piping work involved in installation, repair, relocation and removal has the qualifications pertaining to this refrigerant handling and piping work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to refrigerant handling and piping work on the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work. The qualified service person who is allowed to work at heights has been trained in matters relating to working at heights with the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and

Definition of Protective Gear

When the air conditioner is to be transported, installed, maintained, repaired or removed, wear protective gloves and 'safety' work clothing.

In addition to such normal protective gear, wear the protective gear described below when undertaking the special work detailed in the table below.

Failure to wear the proper protective gear is dangerous because you will be more susceptible to injury, burns, electric shocks and other injuries.

Work undertaken	Protective gear worn
All types of work	Protective gloves 'Safety' working clothing
Electrical-related work	Gloves to provide protection for electricians Insulating shoes Clothing to provide protection from electric shock
Work done at heights (50 cm or more)	Helmets for use in industry
Transportation of heavy objects	Shoes with additional protective toecap
Repair of outdoor unit	Gloves to provide protection for electricians

The important contents concerned to the safety are described on the product itself and on this Service Manual. Please read this Service Manual after understanding the described items thoroughly in the following contents (Indications / Illustrated marks), and keep them.

[Explanation of indications]

Indication	Explanation	
<u></u> ♠ DANGER	Indicates contents assumed that an imminent danger causing a death or serious injury of the repair engineers and the third parties when an incorrect work has been executed.	
⚠ WARNING	Indicates possibilities assumed that a danger causing a death or serious injury of the repair engineers, the third parties, and the users due to troubles of the product after work when an incorrect work has been executed.	
⚠ CAUTION	Indicates contents assumed that an injury or property damage (*) may be caused on the repair engineers, the third parties, and the users due to troubles of the product after work when an incorrect work has been executed.	

^{*} Property damage: Enlarged damage concerned to property, furniture, and domestic animal / pet

[Explanation of illustrated marks]

Indication	Explanation	
	Indicates prohibited items (Forbidden items to do) The sentences near an illustrated mark describe the concrete prohibited contents.	
	Indicates mandatory items (Compulsory items to do) The sentences near an illustrated mark describe the concrete mandatory contents.	
\triangle	Indicates cautions (Including danger / warning) The sentences or illustration near or in an illustrated mark describe the concrete cautious contents.	

Warning Indications on the Air Conditioner Unit

[Confirmation of warning label on the main unit]

Confirm that labels are indicated on the specified positions If removing the label during parts replace, stick it as the original.

Warning indication	Description
WARNING ELECTRICAL SHOCK HAZARD Disconnect all remote electric power supplies before servicing.	WARNING ELECTRICAL SHOCK HAZARD Disconnect all remote electric power supplies before servicing.
WARNING Moving parts. Do not operate unit with grille removed. Stop the unit before the servicing.	WARNING Moving parts. Do not operate unit with grille removed. Stop the unit before the servicing.
CAUTION High temperature parts. You might get burned when removing this panel.	CAUTION High temperature parts. You might get burned when removing this panel.
CAUTION Do not touch the aluminum fins of the unit. Doing so may result in injury.	CAUTION Do not touch the aluminium fins of the unit. Doing so may result in injury.
CAUTION BURST HAZARD Open the service valves before the operation, otherwise there might be the burst.	CAUTION BURST HAZARD Open the service valves before the operation, otherwise there might be the burst.

PRECAUTIONS FOR SAFETY

The manufacturer shall not assume any liability for the damage caused by not observing the description of this manual.



⚠ DANGER

Before carrying out the installation, maintenance, repair or removal work, be sure to set the circuit breaker for both the indoor and outdoor units to the OFF position. Otherwise, electric shocks may result Before opening the intake grille of the indoor unit or service panel of the outdoor unit, set the circuit breaker to the OFF position. Failure to set the circuit breaker to the OFF position may result in electric shocks through contact with the interior parts. Only a qualified installer (*1) or qualified service person (*1) is allowed to remove the intake grille of the indoor unit or service panel of the outdoor unit and do the work required. Before opening the electric box cover set the circuit breaker to the OFF position. Failure to set the circuit breaker to the OFF position may result in injury through contact with the rotation parts. Only a qualified installer (*1) or qualified service person (*1) is allowed to remove the electric box cover and do the work required. Turn off Before starting to repair the outdoor unit fan or fan guard, be absolutely sure to set the circuit breaker to the OFF position, and place a "Work in progress" sign on the circuit breaker. breaker When cleaning the filter or other parts of the indoor unit, set the circuit breaker to OFF without fail, and place a "Work in progress" sign near the circuit breaker before proceeding with the work. When you have noticed that some kind of trouble (such as when a check code display has appeared. there is a smell of burning, abnormal sounds are heard, the air conditioner fails to cool or heat or water is leaking) has occurred in the air conditioner, do not touch the air conditioner yourself but set the circuit breaker to the OFF position, and contact a qualified service person. Take steps to ensure that the power will not be turned on (by marking "out of service" near the circuit breaker, for instance) until qualified service person arrives. Continuing to use the air conditioner in the trouble status may cause mechanical problems to escalate or result in electric shocks or other failure. When you access inside of the electric cover to repair electric parts, wait for about five minutes after turning off the breaker. Do not start repairing immediately. Otherwise you may get electric shock by touching terminals of high-voltage capacitors. Natural discharge of the capacitor takes about five minutes. When checking the electric parts, removing the cover of the electric parts box of Indoor Unit and/or service panel of Outdoor Unit inevitably to determine the failure, use gloves to provide protection for Electric electricians, insulating shoes, clothing to provide protection from electric shock and insulating tools. shock hazard Be careful not to touch the live part. Electric shock may result. Only "Qualified service person" is allowed to do this work. Place a "Work in progress" sign near the circuit breaker while the installation, maintenance, repair or removal work is being carried out. There is a danger of electric shocks if the circuit breaker is set to ON by mistake. When checking the electric parts, removing the cover of the electric parts box of Indoor Unit and/or front panel of outdoor unit inevitably to determine the failure, put a sign "Do not enter" around the site before the work. Failure to do this may result in third person getting electric shock. Prohibition Before operating the air conditioner after having completed the work, check that the electrical parts box cover of the indoor unit and service panel of the outdoor unit are closed, and set the circuit breaker to the ON position. You may receive an electric shock if the power is turned on without first conducting these checks. If, in the course of carrying out repairs, it becomes absolutely necessary to check out the electrical parts with the electrical parts box cover of one or more of the indoor units and the service panel of the outdoor unit removed in order to find out exactly where the trouble lies, wear insulated heat-resistant gloves, insulated boots and insulated work overalls, and take care to avoid touching any live parts. Stay on You may receive an electric shock if you fail to heed this warning. Only qualified service person (*1) is protection allowed to do this kind of work.

(*1) Refer to the "Definition of Qualified Installer or Qualified Service Person"



Before starting to repair the air conditioner, read carefully through the Service Manual, and repair the air conditioner by following its instructions.

Only qualified service person (*1) is allowed to repair the air conditioner.

Repair of the air conditioner by unqualified person may give rise to a fire, electric shocks, injury, water leaks and / or other problems.

Do not use any refrigerant different from the one specified for complement or replacement. Otherwise, abnormally high pressure may be generated in the refrigeration cycle, which may result in a failure or explosion of the product or an injury to your body.

Only a qualified installer (*1) or qualified service person (*1) is allowed to carry out the electrical work of the air conditioner.

Under no circumstances must this work be done by an unqualified individual since failure to carry out the work properly may result in electric shocks and / or electrical leaks.

When the air conditioner is to be transported, installed, maintained, repaired or removed, wear protective gloves and 'safety' work clothing.

To connect the electrical wires, repair the electrical parts or undertake other electrical jobs, wear gloves to provide protection for electricians, insulating shoes and clothing to provide protection from electric shocks. Failure to wear this protective gear may result in electric shocks.

Electrical wiring work shall be conducted according to law and regulation in the community and Installation Manual. Failure to do so may result in electrocution or short circuit.



Use wiring that meets the specifications in the Installation Manual and the stipulations in the local regulations and laws. Use of wiring which does not meet the specifications may give rise to electric shocks, electrical leakage, smoking and/or a fire.

Only a qualified installer (*1) or qualified service person (*1) is allowed to undertake work at heights using a stand of 50 cm or more or to remove the intake grille of the indoor unit to undertake work.

When working at heights, use a ladder which complies with the ISO 14122 standard, and follow the procedure in the ladder's instructions.

Also wear a helmet for use in industry as protective gear to undertake the work.

Before working at heights, put a sign in place so that no-one will approach the work location, before proceeding with the work. Parts and other objects may fall from above, possibly injuring a person below. While carrying out the work, wear a helmet for protection from falling objects.

When executing address setting, test run, or troubleshooting through the checking window on the electric parts box, put on insulated gloves to provide protection from electric shock. Otherwise you may receive an electric shock.

Do not touch the aluminum fin of the unit.

You may injure yourself if you do so. If the fin must be touched for some reason, first put on protective gloves and safety work clothing, and then proceed.

Do not climb onto or place objects on top of the outdoor unit.

You may fall or the objects may fall off the outdoor unit and result in injury.

Use forklift truck to carry in the air conditioner units and use winch or hoist at installation of them.

When transporting the air conditioner, wear shoes with protective toe caps, protective gloves and other protective clothing.

When transporting the air conditioner, do not hold the bands around the packing carton. You may injure yourself if the bands should break.

Be sure that a heavy unit (10 kg or heavier) such as a compressor is carried by four persons.



Before troubleshooting or repair work, check the earth wire is connected to the earth terminals of the main unit, otherwise an electric shock is caused when a leak occurs. If the earth wire is not correctly connected, contact an electric engineer for rework.

After completing the repair or relocation work, check that the ground wires are connected properly.

Connect earth wire. (Grounding work) Incomplete grounding causes an electric shock.

Do not connect earth wires to gas pipes, water pipes, and lightning rods or ground wires for telephone wires.

(*1) Refer to the "Definition of Qualified Installer or Qualified Service Person"

Prohibition of modification.	Do not modify the products.Do not also disassemble or modify the parts. It may cause a fire, electric shock or injury.
Use specified parts.	When any of the electrical parts are to be replaced, ensure that the replacement parts satisfy the specifications given in the Service Manual (or use the parts contained on the parts list in the Service Manual). Use of any parts which do not satisfy the required specifications may give rise to electric shocks, smoking and / or a fire.
Do not bring a child close to the equipment.	If, in the course of carrying out repairs, it becomes absolutely necessary to check out the electrical parts with the electrical parts box cover of one or more of the indoor units and the service panel of the outdoor unit removed in order to find out exactly where the trouble lies, put a sign in place so that no-one will approach the work location before proceeding with the work. Third-party individuals may enter the work site and receive electric shocks if this warning is not heeded.
Insulating measures	Connect the cut-off lead wires with crimp contact, etc., put the closed end side upward and then apply a watercut method, otherwise a leak or production of fire is caused at the users' side.
No fire	 When performing repairs using a gas burner, replace the refrigerant with nitrogen gas because the oil that coats the pipes may otherwise burn. When repairing the refrigerating cycle, take the following measures. 1) Be attentive to fire around the cycle. When using a gas stove, etc., be sure to put out fire before work; otherwise the oil mixed with refrigerant gas may catch fire. 2) Do not use a welder in the closed room. When using it without ventilation, carbon monoxide poisoning may be caused. 3) Do not bring inflammables close to the refrigerant cycle, otherwise fire of the welder may catch the inflammables.
	The refrigerant used by this air conditioner is the R32 or R410A.
	Check the used refrigerant name and use tools and materials of the parts which match with it. The refrigerant name is indicated at a position on the outdoor unit where is easy to see. To prevent miss charging, the route of the service port is changed from one of the former R22.
	Do not use any refrigerant different from the one specified for complement or replacement. Otherwise, abnormally high pressure may be generated in the refrigeration cycle, which may result in a failure or explosion of the product or an injury to your body.
	Never use refrigerants other than those indicated on the outdoor unit (R32 or R410A). For an air conditioner which uses other refrigerant (R22, etc.), never use R32 or R410A. If different types of refrigerant are mixed, abnormal high pressure generates in the refrigerating cycle and an injury due to breakage may be caused.
0	When the air conditioner has been installed or relocated, follow the instructions in the Installation Manual and purge the air completely so that no gases other than the refrigerant will be mixed in the refrigerating cycle. Failure to purge the air completely may cause the air conditioner to malfunction.
Refrigerant	Do not charge refrigerant additionally. If charging refrigerant additionally when refrigerant gas leaks, the refrigerant composition in the refrigerating cycle changes resulted in change of air conditioner characteristics or refrigerant over the specified standard amount is charged and an abnormal high pressure is applied to the inside of the refrigerating cycle resulted in cause of breakage or injury. Therefore if the refrigerant gas leaks, recover the refrigerant in the air conditioner, execute vacuuming, and then newly recharge the specified amount of liquid refrigerant. In this time, never charge the refrigerant over the specified amount.
	When recharging the refrigerant, do not mix air and any refrigerant other than the specified refrigerant. If air or others is mixed with the refrigerant, abnormal high pressure generates in the refrigerating cycle resulted in cause of injury due to breakage.

Never recover the refrigerant into the outdoor unit. When the equipment is moved or repaired, be sure to recover the refrigerant with recovering device.

The refrigerant cannot be recovered in the outdoor unit; otherwise a serious accident such as

After installation work, check the refrigerant gas does not leak. If the refrigerant gas leaks in the room, poisonous gas generates when gas touches to fire such as fan heater, stove or cooking stove though the refrigerant gas itself is innocuous.

breakage or injury is caused.

Assembly / Wiring	After repair work, surely assemble the disassembled parts, and connect and lead the removed wires as before. Perform the work so that the cabinet or panel does not catch the inner wires. If incorrect assembly or incorrect wire connection was done, a disaster such as a leak or fire is caused at user's side.		
Insulator check	After the work has finished, be sure to use an insulation tester set $(500VM\Omega)$ to check the resistance is 1 $M\Omega$ or more between the charge section and the non-charge metal section (Earth position). If the resistance value is low, a disaster such as a leak or electric shock is caused at user's side.		
	When the refrigerant gas leaks during work, execute ventilation. If the refrigerant gas touches to a fire, poisonous gas generates. A case of leakage of the refrigerant and the closed room full with gas is dangerous because a shortage of oxygen occurs. Be sure to execute ventilation.		
Ventilation	If refrigerant gas has leaked during the installation work, ventilate the room immediately. If the leaked refrigerant gas comes in contact with fire, noxious gas may generate.		
Ventuation	After installation work, check the refrigerant gas does not leak. If the refrigerant gas leaks in the room, poisonous gas generates when gas touches to fire such as fan heater, stove or cooking stove though the refrigerant gas itself is innocuous.		
	When the refrigerant gas leaks, find out the leaked position and repair it surely. If the leaked position cannot be found out and the repair work is interrupted, reclaim and tighten the service valve, otherwise the refrigerant gas may leak into the room. The poisonous gas generates when gas touches to fire such as fan heater, stove or cooking stove though the refrigerant gas itself is innocuous. When installing equipment which includes a large amount of charged refrigerant in a sub-room, it is necessary that the concentration does not the limit even if the refrigerant leaks. If the refrigerant leaks and exceeds the limit concentration, an accident of shortage of oxygen is caused.		
Compulsion	Tighten the flare nut with a torque wrench in the specified manner. Excessive tighten of the flare nut may cause a crack in the flare nut after a long period, which may result in refrigerant leakage.		
	Nitrogen gas must be used for the airtight test.		
	The charge hose must be connected in such a way that it is not slack.		
	For the installation / moving / reinstallation work, follow to the Installation Manual. If an incorrect installation is done, a trouble of the refrigerating cycle, water leak, electric shock or fire is caused.		
	Once the repair work has been completed, check for refrigerant leaks, and check the insulation resistance and water drainage. Then perform a trial run to check that the air conditioner is running properly.		
	After repair work has finished, check there is no trouble. If check is not executed, a fire, electric shock or injury may be caused. For a check, turn off the power breaker.		
Check after repair	After repair work (installation of front panel and cabinet) has finished, execute a test run to check there is no generation of smoke or abnormal sound. If check is not executed, a fire or an electric shock is caused. Before test run, install the front panel and cabinet.		
	Be sure to fix the screws back which have been removed for installation or other purposes.		
Do not operate the unit with the valve closed.	Check the following matters before a test run after repairing piping. • Connect the pipes surely and there is no leak of refrigerant. • The valve is opened. Running the compressor under condition that the valve closes causes an abnormal high pressure resulted in damage of the parts of the compressor and etc. and moreover if there is leak of refrigerant at connecting section of pipes, the air is sucked and causes further abnormal high pressure resulted in burst or injury.		
	Only a qualified installer (*1) or qualified service person (*1) is allowed to relocate the air conditioner. It is dangerous for the air conditioner to be relocated by an unqualified individual since a fire, electric shocks, injury, water leakage, noise and / or vibration may result.		
Check after reinstallation	Check the following items after reinstallation. 1) The earth wire is correctly connected. 2) The power cord is not caught in the product. 3) There is no inclination or unsteadiness and the installation is stable. If check is not executed, a fire, an electric shock or an injury is caused.		
	When carrying out the reclaim work shut down the compressor before disconnecting the refrigerant pipe. Disconnecting the refrigerant pipe with the service valve left open and the compressor still operating will cause air, etc. to be sucked in, raising the pressure inside the refrigeration cycle to an abnormally high level, and possibly resulting in rupture, injury, etc.		

	V
-	

When the service panel of the outdoor unit is to be opened in order for the compressor or the area around this part to be repaired immediately after the air conditioner has been shut down, set the circuit breaker to the OFF position, and then wait at least 10 minutes before opening the service panel.

If you fail to heed this warning, you will run the risk of burning yourself because the compressor pipes and other parts will be very hot to the touch. In addition, before proceeding with the repair work, wear the kind of insulated heat-resistant gloves designed to protect electricians.

Take care not to get burned by compressor pipes or other parts when checking the cooling cycle while running the unit as they get heated while running. Be sure to put on gloves providing protection for heat.



When the service panel of the outdoor unit is to be opened in order for the fan motor, reactor, inverter or the areas around these parts to be repaired immediately after the air conditioner has been shut down, set the circuit breaker to the OFF position, and then wait at least 10 minutes before opening the service panel.

If you fail to heed this warning, you will run the risk of burning yourself because the fan motor, reactor, inverter heat sink and other parts will be very hot to the touch.

In addition, before proceeding with the repair work, wear the kind of insulated heat-resistant gloves designed to protect electricians.

Only a qualified installer or service person is allowed to do installation work. Inappropriate installation may result in water leakage, electric shock or fire.

Before starting to install the air conditioner, read carefully through the Installation Manual, and follow its instructions to install the air conditioner.

Be sure to use the company-specified products for the separately purchased parts. Use of non-specified products may result in fire, electric shock, water leakage or other failure. Have the installation performed by a qualified installer.

Do not supply power from the power terminal block equipped on the outdoor unit to another outdoor unit. Capacity overflow may occur on the terminal block and may result in fire.



Do not install the air conditioner in a location that may be subject to a risk of expire to a combustible gas. If a combustible gas leaks and becomes concentrated around the unit, a fire may occur.

Install the indoor unit at least 2.5 m above the floor level since otherwise the users may injure themselves or receive electric shocks if they poke their fingers or other objects into the indoor unit while the air conditioner is running.

Install a circuit breaker that meets the specifications in the Installation Manual and the stipulations in the local regulations and laws.

Install the circuit breaker where it can be easily accessed by the agent.

If you install the unit in a small room, take appropriate measures to prevent the refrigerant from exceeding the limit concentration even if it leaks. Consult the dealer from whom you purchased the air conditioner when you implement the measures. Accumulation of highly concentrated refrigerant may cause an oxygen deficiency accident.

Do not place any combustion appliance in a place where it is directly exposed to the wind of air conditioner, otherwise it may cause imperfect combustion.

Explanations given to user

If you have discovered that the fan grille is damaged, do not approach the outdoor unit but set the circuit breaker to the OFF position, and contact a qualified service person to have the repairs done. Do not set the circuit breaker to the ON position until the repairs are completed.

Relocation

- Only a qualified installer (*1) or qualified service person (*1) is allowed to relocate the air conditioner. It is dangerous for the air conditioner to be relocated by an unqualified individual since a fire, electric shocks, injury, water leakage, noise and / or vibration may result.
- When carrying out the reclaim work shut down the compressor before disconnecting the refrigerant pipe.
 Disconnecting the refrigerant pipe with the service valve left open and the compressor still operating will cause air, etc. to be sucked in, raising the pressure inside the refrigeration cycle to an abnormally high level, and possibly resulting in rupture, injury, etc.
- (*1) Refer to the "Definition of Qualified Installer or Qualified Service Person"

Precautions for using R32 refrigerant

The basic installation work procedures are the same as conventional refrigerant (R410A, R22) models.

However, Please read through this manual after understanding the contents below;

These safety cautions describe important matters concerning safety to prevent injury to users or other people and damages to property. Please read through this manual after understanding the contents below (meanings of indications), and be sure to follow the description;

Meanings of symbols displayed on the unit

	MA DAUNG	This mark is for R32 refrigerant only. Refrigerant type is written on nameplate of outdoor unit.
	WARNING (Risk of fire)	uses a flammable refrigerant. If refrigerant leaks and comes in contact with fire or heating part, it will create harmful gas and there is risk of fire.
	Read the OWNER'S MANUAL carefully before operation.	
	Service personnel are required to carefully read the OWNER'S MANUAL and INSTALLATION MANUAL before operation.	
[]i	Further information is available in the OWNER'S MANUAL, INSTALLATION MANUAL, and the like.	

MARNING

- Models that use refrigerant R32 and R410A have a different charging port thread diameter to prevent erroneous charging with refrigerant R22 and for safety.
- Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.
- The appliance shall be stored in a room without continuously operating ignition sources. (For example: open flames, an operating gas appliance or an operating electric heater.)
- Do not pierce or burn.
- · Be aware that refrigerants may not contain an odor.
- The manufacturer may provide other suitable examples or may provide additional information about the refrigerant odor.

CAUTION

When a flammable refrigerant is used, all appliances shall be charged with refrigerant at the manufacturing location or charged on site as recommended by the manufacturer.

A part of an appliance that is charged on site, which requires brazing or welding in the installation shall not be shipped with a flammable refrigerant charge. Joints made in the installation between parts of the refrigerating system, with at least one part charged, shall be made in accordance with the following.

- A brazed, welded, or mechanical connection shall be made before opening the valves to permit refrigerant to flow between the refrigerating system parts. A vacuum valve shall be provided to evacuate the interconnecting pipe and/or any uncharged refrigerating system part.
- Mechanical connectors used indoors shall comply with ISO 14903.

When mechanical connectors are reused indoors, sealing parts shall be renewed. When flared joints are reused indoors, the flare part shall be re-fabricated.

- Refrigerant tubing shall be protected or enclosed to avoid damage.

Flexible refrigerant connectors (such as connecting lines between the indoor and outdoor unit) that may be displaced during normal operations shall be protected against mechanical damage.

General (Installation space / area)

- The installation of pipe-work shall be kept to a minimum.
- Pipe-work shall be protected from physical damage.
- The compliance with national gas regulations shall be observed.
- The mechanical connections shall be accessible for maintenance purposes.
- · In cases that require mechanical ventilation, ventilation openings shall be kept clear of obstruction.
- · When disposing of the product is used, be based on national regulations with properly processed.

- The servicing shall be performed only as recommended by the manufacturer.
- · Where the appliance using flammable refrigerants is installed, Be aware that;
 - The appliance shall be stored in a well-ventilated area where the room size corresponds to the room area as specified for operation.
 - The appliance shall be stored in a room without continuously operating open flames (for example an operating gas appliance) and ignition sources (for example an operating electric heater).
 - The appliance shall be stored so as to prevent mechanical damage from occurring.
- Equipment piping in the occupied space shall be installed in such a way to protect against accidental damage in operation and service.
- · Precautions shall be taken to avoid excessive vibration or pulsation to refrigerating piping.
- Protection devices, piping and fittings shall be protected as far as possible against adverse environmental effects, for example, the danger of water collecting and freezing in relief pipes or the accumulation of dirt and debris.
- · Provision shall be made for expansion and contraction of long runs of piping.
- Piping in refrigerating systems shall be so designed and installed to minimize the likelihood hydraulic shock damaging the system.
- Solenoid valves shall be correctly positioned in the piping to avoid hydraulic shock.
- Solenoid valves shall not block in liquid refrigerant unless adequate relief is provided to the refrigerant system low pressure side.
- Steel pipes and components shall be protected against corrosion with a rustproof coating before applying any insulation.
- Flexible pipe elements shall be protected against mechanical damage, excessive stress by torsion, or other forces. They should be checked for mechanical damage annually.
- The indoor equipment and pipes shall be securely mounted and guarded such that accidental rupture of equipment cannot occur from such events as moving furniture or reconstruction activities.
- Where safety shut off valves are specified, the minimum room area may be determined based on the maximum amount of refrigerant that can be leaked as determined in Installation Manual.
- Where safety shut off valves are specified, the location of the valve in the refrigerating system relative to the occupied spaces shall be as described in Installation Manual.
- Field-made refrigerant joints indoors shall be tightness tested. The test method shall have a sensitivity of 5 grams per year of refrigerant or better under a pressure of at least 0.25 times the maximum allowable pressure. No leak shall be detected.
- The total refrigerant charge in the system cannot exceed the requirements for minimum floor area of the smallest room that is served. For minimum floor area requirements for indoor units, see the Installation and Owner's Manual of the outdoor unit.
- When connecting to an outdoor unit of R32 refrigerant and using a Leak Detector, always turn on the power of the indoor unit after installation except during service in order to detect refrigerant leakage and take safety measures.

Unventilated area

• The appliance shall be stored so as to prevent mechanical damage from occurring.

Information on servicing

1.Check to the area

• Prior to beginning work on systems containing flammable refrigerants, safety checks are necessary to ensure that the risk of ignition is minimized. For repair to the refrigerating system, the precautions in item 2 to 6 shall be complied with prior to conducting work on the system.

2.Work procedure

- Work shall be undertaken under a controlled procedure so as to minimize the risk of a flammable gas or vapour being present while the work is being performed.
- When connecting to an outdoor unit of R32 refrigerant and using a Leak Detector, the fan may automatically operate even if the air conditioner is stopped when a refrigerant leak is detected. Be careful not to get injured by the fan.

3.General work area

- · All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out.
- · Work in confined spaces shall be avoided.
- The area around the workspace shall be sectioned off.
- Ensure that the conditions within the area have been made safe by control of flammable material.

4. Checking for presence of refrigerant

- The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially flammable atmospheres.
- Ensure that the leak detection equipment being used is suitable for use with all applicable refrigerants, i.e. non sparking, adequately sealed or intrinsically safe.

5.Presence of fire extinguisher

- If any hot work is to be conducted on the refrigeration equipment or any associated parts, appropriate fire extinguishing equipment shall be available on hand.
- Have a dry powder or CO2 fire extinguisher adjacent to the charging area.

6.No ignition sources

- No person carrying out work in relation to a refrigeration system which involves exposing any pipe work shall use
 any sources of ignition in such a manner that it may lead to the risk of fire or explosion.
- All possible ignition sources including cigarette smoking, should be kept sufficiently far away from the site of
 installation, repairing, removing and disposal, during which refrigerant can possibly be released to the surrounding
 space.
- Prior to work taking place, the area around the equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks. "No Smoking" signs shall be displayed.

7. Ventilated area

- Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work.
- · A degree of ventilation shall continue during the period that the work is carried out.
- The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.

8. Checks to the refrigeration equipment

- Where electrical components are being changed, installer shall be fit for the purpose and to the correct specification.
- At all times the manufacturer's maintenance and service guidelines shall be followed. If in doubt consult the manufacturer's technical department for assistance.
- The following checks shall be applied to installations using flammable refrigerants.
 - The charge size is in accordance with the room size within which the refrigerant containing parts are installed.
- The ventilation machinery and outlets are operating adequately and are not obstructed.
- If an indirect refrigerating circuit is being used, the secondary circuit shall be checked for the presence of refrigerant.
- Marking to the equipment continues to be visible and legible.

 Markings and signs that are illegible shall be corrected.
- Refrigeration pipe or components are installed in a position where hey are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials which are inherently resistant to being corroded or are suitably protected against being so corroded.

9.Checks to electrical devices

- Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures.
- If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with.
- If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used.

This shall be reported to the owner of the equipment so all parties are advised.

- · Initial safety checks shall include:
 - That capacitors are discharged to avoid possibility of sparking.
 - That there no live electrical components and wiring are exposed while charging, recovering or purging the system.
 - That there is continuity of earth bonding.

10.Repairs to sealed components

- During repairs to sealed components, all electrical supplies shall be disconnected from the equipment being worked upon prior to any removal of sealed covers, etc.
- If it is absolutely necessary to have an electrical supply to equipment during servicing, then a permanently operating form of leak detection shall be located at the most critical point to warn of a potentially hazardous situation.
- Particular attention shall be paid to the following to ensure that by working on electrical components, the casing is not altered in such a way that the level of protection is affected.
- This shall include damage to cables, excessive number of connections, terminals not made to original specification, damage to seals, incorrect fitting of glands, etc.
- Ensure that apparatus is mounted securely.
- Ensure that seals or sealing materials have not degraded to the point that they no longer serve the purpose of preventing the ingress of flammable atmospheres.
- Replacement parts shall be in accordance with the manufacturer's specifications.

NOTE

The use of silicon sealant may inhibit the effectiveness of some types of leak detection equipment. Intrinsically safe components do not have to be isolated prior to working on them.

11.Repair to intrinsically safe components

- Do not apply any permanent inductive or capacitance loads to the circuit without ensuring that this will not exceed the permissible voltage and current permitted for the equipment in use.
- Intrinsically safe components are the only types that can be worked on while live in the presence of a flammable atmosphere.
- · The test apparatus shall be at the correct rating.
- Replace components only with parts specified by the manufacturer.
- Other parts may result in the ignition of refrigerant in the atmosphere from a leak.

12.Cabling

- Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects.
- · Check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.

13. Detection of flammable refrigerants

- Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks.
- A halide torch (or any other detector using a naked flame) shall not be used.
- Electronic Leak Detectorss may be used to detect refrigerant leaks but, in the case of flammable refrigerants, the sensitivity may not be adequate, or may need re-calibration. (Detection equipment shall be calibrated in a refrigerantfree area.)
- Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used.
- Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed, and the appropriate percentage of gas (25% maximum) is confirmed.
- Leak detection fluids are also suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode containing chlorine.
- If a leak is suspected, all naked flames shall be removed/ extinguished.
- If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak.

14.Leak detection methods

- Electronic Leak Detectorss shall be used to detect flammable refrigerants leak, but the sensitivity may not be adequate, or may need re-calibration. (Detection equipment shall be calibrated in a refrigerant-free area.)
- Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used.
- Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed and the appropriate percentage of gas (25% maximum) is confirmed.
- Leak detection fluids are suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipework.
- If a leak is suspected, all naked flames shall be removed / extinguished.
- If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak.
- · Oxygen free nitrogen (OFN) shall then be purged through the system both before and during the brazing process.

15.Removal and evacuation

- When breaking into the refrigerant circuit to make repairs or for any other purpose, Conventional procedures shall be used. However, it is important that best practice is followed since flammability is a consideration.
 The following procedure shall be adhered to:
- remove refrigerant;
- purge the circuit with inert gas:
- evacuate;
- purge again with inert gas;
- open the circuit by cutting or brazing;
- The refrigerant charge shall be recovered into the correct recovery cylinders.
- The system shall be "Flushed" with OFN to render the unit safe.
- This process may need to be repeated several times.
- · Compressed air or oxygen shall not be used for purging refrigerant systems.
- Flushing shall be achieved by breaking the vacuum in the system with OFN and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum.
- This process shall be repeated until no refrigerant is within the system.
- When the final OFN charge is used, the system shall be vented down to atmospheric pressure to enable work to take place.
- This operation is absolutely vital if brazing operations on the pipework are to take place.
- Ensure that the outlet for the vacuum pump is not close to any ignition sources and that ventilation available.

16.Charging procedures

- In addition to conventional charging procedures, the following requirements shall be followed.
 - Ensure that contamination of different refrigerants does not occur when using charging equipment.
 - Hoses or lines shall be as short as possible to minimize the amount of refrigerant contained in them.
 - Cylinders shall be kept upright.
 - Ensure that the refrigeration system is earthed prior to charging the system with refrigerant.
 - Label the system when charging is complete (if not already).
 - Extreme care shall be taken not to overfill the refrigeration system.
- · Prior to recharging the system, it shall be pressure-tested with the appropriate purging gas.
- The system shall be leak tested on completion of charging but prior to commissioning.
- · A follow up leak test shall be carried out prior to leaving the site.

17.Decommissioning

- Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its details.
- · It is recommended good practice that all refrigerants are recovered safely.
- Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required to reuse of reclaimed refrigerant.
- It is essential that electrical power is available before the task is commenced.
 - a) Become familiar with the equipment and its operation.
 - b) Isolate system electrically.
 - c) Before attempting the procedure ensure that:
 - Mechanical handling equipment is available, if required, for handling refrigerant cylinders;
 - All personal protective equipment is available and being used correctly;
 - The recovery process is supervised at all times by a competent person;
 - Recovery equipment and cylinders conform to the appropriate standards.
 - d) Pump down refrigerant system, if possible.
 - e) If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.
- f) Make sure that cylinder is situated on the scales before recovery takes place.
- g) Start the recovery machine and operate in accordance with manufacturer's instructions.
- h) Do not overfill cylinders. (No more than 80% volume liquid charge.)
- i) Do not exceed the maximum working pressure of the cylinder, even temporarily.
- j) When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
- k) Recovered refrigerant shall not be charged into another refrigeration system unless it has been cleaned and checked.

18.Labelling

- · Equipment shall be labelled stating that it has been decommissioned and emptied of refrigerant.
- · The label shall be dated and signed.
- · Ensure that there are labels on the equipment stating the equipment contains flammable refrigerant.

19.Recovery

- When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.
- When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed.
- Ensure that the correct number of cylinders for holding the total system charge are available.
- All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i.e. special cylinders for the recovery of refrigerant).
- Cylinders shall be complete with pressure-relief valve and associated shut-off valves in good working order.
- Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.
- The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of all appropriated refrigerants.
- In addition, a set of calibrated weighing scales shall be available and in good working order.
- Hoses shall be complete with leak-free disconnect couplings and in good condition.
- Before using the recovery machine, check that it is in satisfactory working order, has been properly maintained and that any associated electrical components are sealed to prevent ignition in the event of a refrigerant release.
- Consult manufacturer if in doubt.
- The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant waste transfer note arranged.
- Do not mix refrigerants in recovery units and especially not in cylinders.
- If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant.
- The evacuation process shall be carried out prior to returning the compressor to the suppliers.
- · Only electric heating to the compressor body shall be employed to accelerate this process.
- · When oil is drained from a system, it shall be carried out safely.

Declaration of Conformity

Manufacturer: TOSHIBA CARRIER CORPORATION

336 Tadehara, Fuji-shi, Shizuoka-ken 416-8521 JAPAN

TCF holder: TOSHIBA CARRIER EUROPE S.A.S

Route de Thil

01120 Montluel FRANCE

Hereby declares that the machinery described below:

Generic Denomination: Air Conditioner

Model / type: <4-way cassette type>

MMU-UP0091H-E(TR), MMU-UP0121H-E(TR), MMU-UP0151H-E(TR) MMU-UP0181H-E(TR), MMU-UP0241H-E(TR), MMU-UP0271H-E(TR) MMU-UP0301H-E(TR), MMU-UP0361H-E(TR), MMU-UP0481H-E(TR)

MMU-UP0561H-E(TR)

<Compact 4-way cassette type>

MMU-UP0051MH-E(TR), MMU-UP0071MH-E(TR), MMU-UP0091MH-E(TR) MMU-UP0121MH-E(TR), MMU-UP0151MH-E(TR), MMU-UP0181MH-E(TR)

<2-way cassette type>

MMU-UP0071WH-E(TR), MMU-UP0091WH-E(TR), MMU-UP0121WH-E(TR) MMU-UP0151WH-E(TR), MMU-UP0181WH-E(TR), MMU-UP0241WH-E(TR) MMU-UP0271WH-E(TR), MMU-UP0301WH-E(TR), MMU-UP0361WH-E(TR)

MMU-UP0481WH-E(TR), MMU-UP0561WH-E(TR)

<1-way cassette type>

MMU-UP0151SH-E(TR), MMU-UP0181SH-E(TR), MMU-UP0241SH-E(TR)

Commercial name: Super Modular Multi System Air Conditioner

Super Heat Recovery Multi System Air Conditioner

Mini-Super Modular Multi System Air Conditioner (MiNi-SMMS series)

Complies with the provisions of the Machinery Directive (Directive 2006/42/EC) and the regulations transposing into national law

Name: Sato Kazuhisa
Position: Senior Manager

Quality Assurance & Service Engineering Dept.

Date: 01 March, 2022

Place Issued: Japan

NOTE

This declaration becomes invalid if technical or operational modifications are introduced without the manufacturer's consent.

Declaration of Conformity

Manufacturer: TOSHIBA CARRIER CORPORATION

336 Tadehara, Fuji-shi, Shizuoka-ken 416-8521 JAPAN

TCF holder: TOSHIBA CARRIER EUROPE S.A.S

Route de Thil

01120 Montluel FRANCE

Hereby declares that the machinery described below:

Generic Denomination: Air Conditioner

Model / type: <Floor standing cabinet type>

MML-UP0071H-E(TR), MML-UP0091H-E(TR), MML-UP0121H-E(TR) MML-UP0151H-E(TR), MML-UP0181H-E(TR), MML-UP0241H-E(TR)

<Floor standing concealed type>

MML-UP0071BH-E(TR), MML-UP0091BH-E(TR), MML-UP0121BH-E(TR) MML-UP0151BH-E(TR), MML-UP0181BH-E(TR), MML-UP0241BH-E(TR)

<Floor standing type>

MMF-UP0151H-E(TR), MMF-UP0181H-E(TR), MMF-UP0241H-E(TR) MMF-UP0271H-E(TR), MMF-UP0361H-E(TR), MMF-UP0481H-E(TR)

MMF-UP0561H-E(TR)

Commercial name: Super Modular Multi System Air Conditioner

Super Heat Recovery Multi System Air Conditioner

Mini-Super Modular Multi System Air Conditioner (MiNi-SMMS series)

Complies with the provisions of the Machinery Directive (Directive 2006/42/EC) and the regulations transposing into national law

Name: Sato Kazuhisa
Position: Senior Manager

Quality Assurance & Service Engineering Dept.

Date: 10 December, 2020

Place Issued: Japan

NOTE

This declaration becomes invalid if technical or operational modifi cations are introduced without the manufacturer's consent.

1. SPECIFICATIONS

The refrigerant system that can be used depends on the type of indoor unit. R410A-only models cannot be used in systems using R32 refrigerant.

Refrigerant type	Indoor unit
R32 or R410A	Compact 4-way cassette type 2-way cassette type 1-way cassette type 4-way cassette type
R410A only	Floor standing cabinet type Floor standing concealed type Floor standing type

1-1. Compact 4-way cassette type

R32 or R410A



Model name				MMU-UP0051MH-E(TR)	MMU-UP0071MH-E(TR)	MMU-UP0091MH-E(TR)	MMU-UP0121MH-E(TR)				
Cooling Capacity		(*1)	kW	1.7	2.2	2.8	3.6				
Heating Capacity		(*1)	kW	1.9	2.5	3.2	4.0				
Electrical Power su	ıpply				220-240 ~, 50Hz / 208-230 ~, 60Hz						
characteristics Running	curren	t	Α	0.16 / 0.15	0.23 / 0.21	0.24 / 0.22	0.25 / 0.23				
Power co	nsum	ption	kW	0.016 / 0.016	0.023 / 0.023	0.025 / 0.025	0.027 / 0.027				
Starting of	current	i	Α	0.28 / 0.27	0.41 / 0.38	0.43 / 0.39	0.44 / 0.41				
Appearance Main Uni	t			Zinc ho	ot dipping steel plate * Heat-insula	ating material attached to only up	per plate				
Ceiling P	anel	Model Name			RBC-UM2	1PG(W)-E					
	(*2)	Panel Color			Gran White (M	lunsell 5PB9/1)					
Outer Main Uni	t	Height (*3)	mm		25	56					
dimension		Width	mm		57	75					
		Depth (*4)	mm		57	75					
Ceiling P	anel	Height (*3)	mm	12							
		Width	mm	620							
		Depth	mm	620							
Total weight Main Uni	t		kg	15							
Ceiling P	anel		kg	2.5							
Heat exchanger				Finned tube							
Soundproof/Heat-insulating	mater	ial		Non-flammable insulation							
Fan					Turb	o fan					
Fan unit Standard	air flo	w (M+ / M / L+ / L)	m ³ /h	430(415/400/385/365)	552(500/462/395/378)	570(520/468/395/378)	594(550/504/420/402)				
Motor			W		6	0					
Air filter					Standard filter	(Long life filter)					
Controller			(*2)		Remote	controller					
Connecting Gas side			mm	Dia. 9.5							
pipe Liquid sid	de		mm	Dia. 6.4							
Drain port (Nominal dia. mn	n)			VP20 (Polyvinyl chloride tube)							
Sound pressure level Hig	gh (M	+/M/L+/L)	dB	32 (31 / 30 / 29 / 29)	37 (34 / 33 / 30 / 29)	38 (35 / 33 / 30 / 29)	38 (36 / 34 / 31 / 30)				
Sound power level High	(M+/	M / L+ / L)	dB	47 (46 / 45 / 44 / 44)	52 (49 / 48 / 45 / 44)	53 (50 / 48 / 45 / 44)	53 (51 / 49 / 46 / 45)				
Note											

- Cooling / heating capacity is based on single connection operation with standard piping length under Japanese Industrial Standard B 8615 Condition 1.

 Remote controller and ceiling panel are sold separately (*1)
- (*2)
- Height from the ceiling.
- (*3) (*4) Depth doesn't including the Electric parts box.

Model name				MMU-UP0151MH-E(TR)	MMU-UP0181MH-E(TR)			
Cooling Capacity		(*1)	kW	4.5	5.6			
Heating Capacity		(*1)	kW	5.0 6.3				
Electrical F	Power supply			220-240 ~, 50Hz / 208-230 ~, 60Hz				
characteristics F	Running currer	nt	Α	0.28 / 0.26				
F	Power consum	ption	kW	0.030 / 0.030	0.052 / 0.052			
ı	Starting curren	t	Α	0.50 / 0.47	0.80 / 0.81			
Appearance N	Main Unit		!	Zinc hot dipping steel plate * Heat-insula	ting material attached to only upper plate			
	Ceiling Panel	Model Name		RBC-UM2	1PG(W)-E			
	(*2)	Panel Color		Gran White (M	unsell 5PB9/1)			
Outer N	Main Unit	Height (*3)	mm	2!	56			
dimension		Width	mm	5	75			
		Depth (*4)	mm	575				
C	Ceiling Panel	Height (*3)	mm	12				
		Width	mm	620				
		Depth	mm	62	20			
Total weight N	Main Unit		kg	15				
C	Ceiling Panel		kg	2	.5			
Heat exchanger			•	Finned tube				
Soundproof/Heat-in:	sulating mater	ial		Non-flammable insulation				
F	an			Turb	o fan			
Fan unit S	Standard air flo	ow (M+ / M / L+ / L)	m³/h	660(600/552/480/468)	840(740/642/540/522)			
N	Motor		W	6	0			
Air filter			•	Standard filter	(Long life filter)			
Controller			(*2)	Remote	controller			
Connecting	Gas side		mm	Dia. 12.7				
pipe L	iquid side		mm	Dia. 6.4				
Drain port (Nominal	dia. mm)			VP20 (Polyvinyl chloride tube)				
Sound pressure leve	el High (M	+/M/L+/L)	dB	40 (37 / 35 / 32 / 31)	47 (43 / 39 / 36 / 34)			
Sound power level	High (M+ /	M / L+ / L)	dB	55 (52 / 50 / 47 / 46)	62 (58 / 54 / 51 / 49)			

Note

- Cooling / heating capacity is based on single connection operation with standard piping length under Japanese Industrial Standard B 8615 Condition 1. (*1)
- Remote controller and ceiling panel are sold separately Height from the ceiling.

 Depth doesn't including the Electric parts box.
- (*2) (*3) (*4)

1-2. 2-way cassette type



R32 or R410A

Model name			MMU-	UP0071WH-E(TR)	UP0091WH-E(TR)	UP0121WH-E(TR)	UP0151WH-E(TR)		
Cooling / Heatin	ng capacity (*1)		kW	2.2 / 2.5	2.8 / 3.2	3.6 / 4.0	4.5 / 5.0		
Electrical	Power supply				220-240V ~, 50Hz / 208-230V ~, 60Hz				
characteristics	Running curre	ent	Α		0.21 / 0.22				
	Power consur	nption	kW		0.024 / 0.024		0.026 / 0.026		
	Starting curre	nt	Α		0.31 / 0.32		0.33 / 0.35		
Appearance	Main Unit			Heat-insula	iting material attach	ned Zinc hot dipping	g steel plate		
	Ceiling Panel	Model N	ame		RBC-UW28	33PG(W)-E			
		Panel Co	olor		Moon White (Mun	sell 2.5GY9.0/0.5)			
Outer	Main Unit	Height	mm		29	95			
dimension		Width	mm		8	15			
		Depth	mm		5	70			
	Ceiling Panel	Height	mm	20					
		Width	mm	1050					
		Depth	mm	680					
Total weight	Main Unit		kg	18					
	Ceiling Panel		kg	10					
Heat exchanger	•			Finned tube					
Soundproof / He	eat-insulating m	naterial		Non-flammable insulation					
	Fan			Turbo fan					
Fan unit	Standard a		m ³ /h	558	3 / 516 / 498 / 468 /	600 / 552 / 534 / 480 / 450			
	Motor		W		6	60			
Air filter	1		!		Standard filter	(Long life filter)			
Controller					Remote controller				
Connecting	Gas side		mm		Dia. 12.7				
pipe	Liquid side		mm	Dia. 6.4					
Drain port (Nom	ninal dia. mm)			25 (Polyvinyl chloride tube)					
Sound pressure (H / M+ / M / L+			dB(A)	;	34 / 33 / 32 / 31 / 30	0	35 / 34 / 33 / 31 / 30		

Note

Model name			MMU-	UP0181WH-E(TR)	UP0241WH-E(TR)	UP0271WH-E(TR)	UP0301WH-E(TR)			
Cooling / Heatin	g capacity (*1)		kW	5.6 / 6.3	7.1 / 8.0	8.0 / 9.0	9.0 / 10.0			
Electrical	Power supply				220-240V ~, 50Hz	/ 208-230V ~, 60H	Z			
characteristics	Running curre	ent	Α	0.28 / 0.29	0.37	0.43 / 0.46				
	Power consur	nption	kW	0.034 / 0.034	0.045	/ 0.045	0.055 / 0.055			
	Starting curre	nt	Α	0.42 / 0.44	0.57	/ 0.60	0.65 / 0.68			
Appearance	Main Unit			Heat-insula	iting material attach	ned Zinc hot dippin	g steel plate			
	Ceiling Panel	Model N	ame		RBC-UW80	03PG(W)-E				
		Panel Co	olor		Moon White (Mun	sell 2.5GY9.0/0.5)				
Outer	Main Unit	Height	mm		34	45				
dimension		Width	mm		11	80				
		Depth	mm		570					
	Ceiling Panel	Height	mm	20						
		Width	mm	1415						
		Depth	mm	680						
Total weight	Main Unit		kg		2	16				
	Ceiling Panel		kg	14						
Heat exchanger	•			Finned tube						
Soundproof / He	eat-insulating m	naterial		Non-flammable insulation						
	Fan			Centrifugal fan						
Fan unit	Standard a		m³/h	900 / 810 / 750 / 678 / 618	1050 / 942 / 840 / 780 / 738		1260 / 1062 / 900 / 840 / 780			
	Motor		W	94						
Air filter					Standard filter	(Long life filter)				
Controller				Remote controller						
Connecting	Gas side		mm	Dia. 12.7 Dia. 15.9						
pipe	Liquid side		mm	Dia. 6.4 Dia. 9.5						
Drain port (Nom	inal dia. mm)			25 (Polyvinyl chloride tube)						
Sound pressure (H / M+ / M / L+			dB(A)	35 / 34 / 33 / 31 / 30	38 / 37 / 3	5 / 34 / 33	40 / 38 / 37 / 35 / 34			

Note

(*1) Rated conditions

Model name			MMU-	UP0361WH-E(TR)	UP0481WH-E(TR)	UP0561WH-E(TR)				
Cooling / Heating	ng capacity (*1)		kW	11.2 / 12.5	14.0 / 16.0	16.0 / 18.0				
Electrical	Power supply			220-240	V ~, 50Hz / 208-230V	′ ~, 60Hz				
characteristics	Running curre	ent	Α	0.50 / 0.53	0.57 / 0.59	0.77 / 0.81				
	Power consu		kW	0.081 / 0.081	0.091 / 0.091	0.131 / 0.131				
	Starting curre	nt	Α	0.76 / 0.79	0.85 / 0.89	1.17 / 1.22				
Appearance	Main Unit			Heat-insulating mat	erial attached Zinc ho	t dipping steel plate				
	Ceiling Panel	Model N	ame	F	RBC-UW1403PG(W)-I	E				
		Panel Co	olor	Moon \	White (Munsell 2.5GY	9.0/0.5)				
Outer	Main Unit	Height	mm		345					
dimension		Width	mm		1600					
		Depth	mm		570					
	Ceiling Panel	Height	mm							
		Width	mm	1835						
		Depth	mm	680						
Total weight	Main Unit		kg	35						
	Ceiling Panel		kg	14						
Heat exchanger	•			Finned tube						
Soundproof / He	eat-insulating n	naterial		N	on-flammable insulation	on				
	Fan				Centrifugal fan					
Fan unit	Standard a		m ³ /h	1740 / 1530 / 1434 1260 / 1182	1800 / 1608 / 1482 1320 / 1230	2040 / 1770 / 1578 1410 / 1320				
	Motor		W		139					
Air filter	•		•	Star	ndard filter (Long life f	ilter)				
Controller					Remote controller					
Connecting	Gas side		mm		Dia. 15.9					
pipe	Liquid side		mm	Dia. 9.5						
Drain port (Nom	ninal dia. mm)			25 (Polyvinyl chloride tube)						
Sound pressure (H / M+ / M / L+			dB(A)	42 / 41 / 39 / 37 / 36	43 / 42 / 40 / 38 / 37	46 / 44 / 42 / 40 / 39				

Note

(*1) Rated conditions

1-3. 1-way cassette type



R32 or R410A

Model name			MMU-	UP0151SH-E(TR)	UP0181SH-E(TR)	UP0241SH-E(TR)		
Cooling / Heatir	ng capacity (*1)		kW	4.5 / 5.0	5.6 / 6.3	7.1 / 8.0		
Electrical	Power supply		•	220-240	/ ~ 60Hz			
characteristics	Running curre	ent	Α	0.34 / 0.36	0.36 / 0.37	0.54 / 0.57		
	Power consur	nption	kW	0.039 / 0.039	0.042 / 0.042	0.064 / 0.064		
	Starting curre	nt	Α	0.44 / 0.46	0.47 / 0.49	0.70 / 0.73		
Appearance	Main Unit			Heat-insulating mate	erial attached Zinc ho	ot dipping steel plate		
	Ceiling Panel	Model N	ame		RBC-US21PGE			
		Panel Co	olor	Moon W	Vhite (Munsell 2.5G)	(9.0/0.5)		
Outer	Main Unit	Height	mm		200			
dimension		Width	mm		1000			
		Depth	mm		710			
	Ceiling Panel	Height	mm	20				
		Width	mm	1230				
		Depth	mm		800			
Total weight	Main Unit		kg	20 21				
	Ceiling Panel		kg	5.5				
Heat exchange	r			Finned tube				
Soundproof / H	eat-insulating m	naterial		Polyethylen	polyethylene			
	Fan				Centrifugal fan			
Fan unit	Standard a		m ³ /h	750 / 720 / 690 / 650 / 630	780 / 750 / 720 / 680 / 660	1140 / 1050 / 960 / 840 / 810		
	Motor		W		94			
Air filter	•		!	Stan	dard filter (Long life	filter)		
Controller					Remote controller			
Connecting	Gas side		mm	Dia.	12.7	Dia. 15.9		
pipe	Liquid side		mm	Dia	. 6.4	Dia. 9.5		
Drain port (Non	ninal dia. mm)			25 (Polyvinyl chloride tube)				
Sound pressure (H / M+ / M / L-			dB(A)	37 / 36 / 35 / 34 / 32	38 / 37 / 36 / 35 / 34	45 / 43 / 41 / 39 / 37		

Note

(*1) Rated conditions

1-4. Floor standing cabinet type

R410A

Model name			MML-	UP0071H-E(TR)	UP0091H-E(TR)	UP0121H-E(TR)	UP0151H-E(TR)	UP0181H-E(TR)	UP0241H-E(TR)	
Cooling/Heating	capacity (*1)		kW	2.2 / 2.5	2.8 / 3.2	3.6 / 4.0	4.5 / 5.0	5.6 / 6.3	7.1 / 8.0	
	Power supply					220-240V ~, 50H	z / 220V ~, 60Hz	,		
Electrical	Running curre	nt	А	0.26 / 0.25			/ 0.44	0.47 / 0.53		
characteristics	Power consumption		kW	0.056	/ 0.053	0.092	/ 0.092	0.102	/ 0.113	
	Starting curren	t	А	0.60	/ 0.60	0.80 / 0.80 1.10 / 1.10				
Appearance						Munsell1	Y8.5/0.5			
		Height	mm	630						
Outer dimension	ı	Width	mm	950						
		Depth	mm 230							
Total weight			kg		3	5		3	8	
Heat exchanger				Finned tube						
Soundproof/Hea	t-insulating mat	erial		Non-flammable insulation						
	Fan			Centrifugal fan						
Fan unit	Standard air flo (High/Mid./Low		m³/h	480 / 42	20 / 360	900 / 78	30 / 650	1,080 / 9	930 / 780	
	Motor output		W		4	5		7	0	
Air filter						Standard filter	(Simple filter)	,		
Controller						Remote controller	(Sold separately)			
Gas side			mm		Dia. 9.5		Dia.	12.7	Dia. 15.9	
Connecting pipe Liquid side			mm	Dia. 6.4					Dia. 9.5	
	Drain port (No	minal dia.)	mm			20 (Polyvinyl	chloride tube)		1	
Sound pressure	level (High/Mid.	/Low)	dB(A)	39 / 3	37 / 35	45 / 4	1 / 38	49 / 4	4 / 39	

Note

(*1) Rated conditions

1-5. Floor standing concealed type



R410A

Model name			MML-	UP0071BH-E(TR)	UP0091BH-E(TR)	UP0121BH-E(TR)	UP0151BH-E(TR)	UP0181BH-E(TR)	UP0241BH-E(TR)			
Cooling/Heating	capacity (*1)		kW	2.2 / 2.5	2.8 / 3.2	3.6 / 4.0	4.5 / 5.0	5.6 / 6.3	7.1 / 8.0			
	Power supply				220-240V ~, 50Hz / 220V ~, 60Hz							
Electrical	Running curre	nt	А	0.25 / 0.27			0.45	/ 0.46	0.46 / 0.51			
characteristics	Power consun	nption	kW		0.056 / 0.058		0.090	/ 0.096	0.095 / 0.110			
	Starting currer	nt	А		0.60 / 0.60		0.80 / 0.80 1.00 /					
Appearance						Zinc hot dippi	lipping steel plate					
		Height	mm		600		600					
Outer dimension	n	Width	mm		745		1,045					
		Depth	mm		220			220				
Total weight		•	kg		21			28				
Heat exchanger						Finne	d tube					
Soundproof/Hea	at-insulating mat	erial				Non-flammal	ble insulation					
	Fan			Centrifugal fan								
Fan weit	Standard air flo (High/Mid./Lov		m³/h		460 / 400 / 300		740 / 60	00 / 490	950 / 790 / 640			
Fan unit	Motor output		W		19			70				
	Static pressure	Э	Pa			(0 (*2)					
Air filter	-					Standard filter	(Simple filter)					
Controller						Remote controller	(Sold separately)					
	Gas side			Dia. 9.5			Dia.	12.7	Dia. 15.9			
Connecting pipe	Liquid side	uid side mm Dia. 6.4				Dia. 9.5						
	Drain port (No	minal dia.)	1			20 (polyvinyl	inyl chloride tube)					
Sound pressure	level (High/Mid	./Low)	dB(A)			36 / 34 / 32			42 / 37 / 33			

Note

Cooling : Indoor 27 °C Dry Bulb / 19 °C Wet Bulb, Outdoor 35 °C Dry Bulb. (*1) Rated conditions

Heating: Indoor 20 °C Dry Bulb, Outdoor 7 °C Dry Bulb / 6 °C Wet Bulb.

Based on equivalent piping length of 7.5 m and piping height difference of 0 m.

(*2) This model cannot be used with external static pressure.

1-6. Floor standing type



R410A

Model name			MMF-	UP0151H-E(TR)	UP0181H-E(TR)	UP0241H-E(TR)	UP0271H-E(TR)	UP0361H-E(TR)	UP0481H-E(TR)	UP0561H-E(TR)
Cooling/Heating	capacity (*1)		kW	4.5 / 5.0	5.6 / 6.3	7.1 / 8.0	8.0 / 9.0	11.2 / 12.5	14.0 / 16.0	16.0 / 18.0
	Power supply				220-240V ~ 50Hz / 208-230V ~ 60Hz					
Electical	Running curre	nt	А	0.37 / 0.38		0.55 / 0.58		0.82 / 0.86	0.97	/ 1.02
characteristics Power consun		nption	kW	0.053	/ 0.053	0.087	/ 0.087	0.133 / 0.133	0.158	/ 0.158
	Starting currer	nt	А	0.48	/ 0.50	0.71	/ 0.75	1.06 / 1.11	1.27	/ 1.33
Appearance	1					Silky sha	de (Munsell 1Y	8.5 / 8.0)	-	
		Height	mm		1,7	750			1,750	
Outer dimension	1	Width	mm		6	00			600	
		Depth	mm		2	10	390			
Total weight		1	kg	46 47			7	61		
Heat exchanger				Finned tube						
Soundproof/Hea	t-insulating mat	erial		Non-flammable insulation						
	Fan			Centrifugal fan						
Fan unit	Standard air flo (H/M+/M/L+/L)		m³/h	820/760/70	00/640/600	930/830/77	70/700/640	1660/1550/ 1420/1190/1170	1760/1630/14	80/1370/1350
	Motor output		W		6	62			109	
Air filter						Standa	ard filter (Simple	e filter)		
Controller						Remote c	ontroller (Sold s	eparately)		
Gas side			mm	Dia.	12.7			Dia. 15.9		
Connecting pipe	Liquid side		mm	Dia.	6.4			Dia. 9.5		
Drain port		minal dia.)	mm			20 (po	olyvinyl chloride	de tube)		
Sound pressure	level (H/M+/M/I	L+/L)	dB(A)	46 / 44 / 4	2 / 40 / 38	50 / 47 / 4	5 / 43 / 41	51 / 49 / 46 / 44 / 41	53 / 51 / 4	8 / 46 / 45

Note

(*1) Rated conditions

1-7. 4-way cassette type



R32 or R410A

Model name			MMU-	MMU-UP0091H-E	MMU-UP0121H-E	MMU-UP0151H-E	MMU-UP0181H-E	MMU-UP0241H-E					
Cooling / Heating	g capacity (*1)		kW	2.8 / 3.2	3.6 / 4.0	4.5 / 5.0	5.6 / 6.3	7.1 / 8.0					
Electrical	Power supply		<u>'</u>	220-240V~, 50Hz / 208-230V~, 60Hz									
characteristics	Running currer	ıt	Α	0.17 / 0.18	0.17 / 0.18	0.19 / 0.2	0.25 / 0.26	0.36 / 0.38					
	Power consum	ption	kW	0.02	0.02	0.018	0.026	0.042					
Power factor			%	50	50	41	45	50					
	Starting curren	t	А	0.26 / 0.27	0.55 / 0.57								
Appearance	Main Unit				Heat-insulat	ting material attached Zinc hot dippi	ng steel plate						
	Ceiling Panel	Model Na	ime			RBC-U41PG(W)-E							
		Panel Co	lor			White (2.5GY9.0/0.5)							
Outer	Main Unit	Height	mm	2	56		319						
dimension		Width	mm			840							
		Depth	mm			840							
	Ceiling Panel	Height	mm	30									
		Width	mm	950									
		Depth	mm		950								
Total weight	Main Unit		kg	18 25									
	Ceiling Panel		kg			5							
Heat exchanger				Finned tube									
Soundproof / He	at-insulating mate	rial		Non-flammable insulation									
	Fan			Turbo fan									
Fan unit	Standard a		m³/h	846 / 792 / 768 / 738 / 708	846 / 792 / 768 / 738 / 708	1060 / 960 / 920 / 860 / 800	1260 / 1160 / 1100 / 1040 / 940	1580 / 1440 / 1300 / 1210 / 1120					
	Motor		W	6	60		130						
Air filter				Standard filter (Long life filter)									
Controller						Remote controller							
Connecting	Gas side		mm	Dia	. 9.5	Dia.	12.7	Dia. 15.9					
pipe	Liquid side		mm	Dia. 6.4 Dia. 9.5									
Drain port (Nomi	nal dia. mm)					25 (Polyvinyl chloride tube)							
Sound pressure	level (H / M+ / M	/ L+ / L)	dB(A)	30/29/28/27/26 30/29/28/27/26 32/30/30/29/28 36/34/33/				41 / 39 / 37 / 35 / 35					
Sound power level (H / M+ / M / L+ / L) dB(A)				45 / 44 / 43 / 42 / 42	45 / 44 / 43 / 42 / 42	46 / 45 / 44 / 43 / 42	50 / 48 / 47 / 46 / 45	55 / 53 / 51 / 49 / 48					

Note

(*1) Rated conditions

Model name			MMU-	MMU-UP0271H-E	MMU-UP0301H-E	MMU-UP0361H-E	MMU-UP0481H-E	MMU-UP0561H-E					
Cooling / Heating	capacity (*1)		kW	8.0 / 9.0	9.0 / 10.0	11.2 / 12.5	14.0 / 16.0	16.0 / 18.0					
Electrical	Power supply					220-240V~, 50Hz / 208-230V~, 60Hz							
characteristics	Running currer	nt	А	0.46 / 0.48	0.57 / 0.6	0.9 / 0.94	0.92 / 0.96	0.93 / 0.97					
	Power consum	ption	kW	0.054	0.068	0.125	0.135	0.137					
	Power factor		%	51	52	60	64	64					
	Starting curren	t	Α	0.69 / 0.72	0.69 / 0.72								
Appearance	Main Unit				Heat-ins	ulating material attached Zinc hot dipping st	eel plate						
	Ceiling Panel	Model Na	me			RBC-U41PG(W)-E							
		Panel Col	or			White (2.5GY9.0/0.5)							
Outer	Main Unit	Height	mm			319							
dimension		Width	mm			840							
		Depth	mm			840							
	Ceiling Panel	Height	mm			30							
		Width	mm	950									
		Depth	mm	950									
Total weight	Main Unit	•	kg	25									
	Ceiling Panel		kg	5									
Heat exchanger				Finned tube									
Soundproof / Hea	at-insulating mate	erial		Non-flammable insulation									
	Fan			Turbo fan									
Fan unit	Standard air flo		m³/h	1770 / 1590 / 1380 / 1320 / 1250	1940 / 1770 / 1520 / 1450 / 1400	2184 / 1848 / 1596 / 1356 / 1260 2262 / 1998 / 1740 / 1470 / 1368		2262 / 2034 / 1782 / 1512 / 1404					
	Motor		W	130									
Air filter				Standard filter (Long life filter)									
Controller				Remote controller									
Connecting	Gas side		mm	Dia. 15.9									
pipe	Liquid side		mm	Dia. 9.5									
Drain port (Nomin	nal dia. mm)					25 (Polyvinyl chloride tube)							
Sound pressure I (H / M+ / M / L+			dB(A)	42 / 40 / 37 / 36 / 35	44 / 42 / 39 / 38 / 37	45 / 41 / 38 / 36 / 32	46 / 43 / 39 / 37 / 33	46 / 43 / 40 / 38 / 35					
Sound power leve (H / M+ / M / L+			dB(A)	56 / 54 / 51 / 50 / 49	58 / 56 / 53 / 52 / 51	60 / 56 / 53 / 50 / 48	61 / 57 / 54 / 52 / 49	61 / 58 / 55 / 53 / 51					


Note

(*1) Rated conditions

2. CONSTRUCTION VIEWS (EXTERNAL VIEWS)


2-1. Compact 4-way cassette type

MMU-UP0051MH-E(TR), UP0071MH-E(TR), UP0091MH-E(TR), UP0121MH-E(TR), UP0151MH-E(TR), UP0181MH-E(TR)




2-2. 2-way cassette type


MMU-UP0071WH-E(TR), UP0091WH-E(TR), UP0121WH-E(TR), UP0151WH-E(TR)



MMU-UP0181WH-E(TR), UP0241WH-E(TR), UP0271WH-E(TR), UP0301WH-E(TR)




MMU-UP0361WH-E(TR), UP0481WH-E(TR), UP0561WH-E(TR)




2-3. 1-way cassette (SH) type

MMU-UP0151SH-E(TR), UP0181SH-E(TR), UP0241SH-E(TR)




2-4. Floor standing cabinet type

MML-UP0071H-E(TR), UP0091H-E(TR), UP0121H-E(TR), UP0151H-E(TR), UP0181H-E(TR), UP0241H-E(TR)



2-5. Floor standing concealed type

MML-UP0071BH-E(TR), UP0091BH-E(TR), UP0121BH-E(TR)



(Unit: mm)

The drain filter to prevent drain clogging is attached in this indoor unit.It might become clogging condition with garbages or foreign matters during the installation, due to set it outside of the unit.

So be sure to clean the drain filter before test run.


Moreover be sure to clean it in the regular check.

This model is a concealed type. Therefore conceal other parts than the air outlet and the air filter.

Be sure not to touch the electric parts box, the surrounding lead wires, the refrigerant pipes, etc. directly with the hands. က်

- 36 -

MML-UP0151BH-E(TR), UP0181BH-E(TR), UP0241BH-E(TR)



(Unit: mm)

The drain filter to prevent drain clogging is attached in this indoor unit.It might become clogging condition with garbages or foreign matters during the installation, due to set it outside of the unit.

So be sure to clean the drain filter before test run.


Moreover be sure to clean it in the regular check.

3. This model is a concealed type. Therefore conceal other parts than the air outlet and the air filter.


Be sure not to touch the electric parts box, the surrounding lead wires, the refrigerant pipes, etc. directly with the hands.

2-6. Floor standing type

MMF-UP0151H-E(TR), UP0181H-E(TR), UP0241H-E(TR), UP0271H-E(TR)





MMF-UP0361H-E(TR), UP0481H-E(TR), UP0561H-E(TR)



2-7. 4-way cassette type

MMU-UP0091H-E(TR), UP0121H-E(TR)






3. WIRING DIAGRAMS


3-1. Compact 4-way cassette type

 $\begin{array}{lll} MMU-UP0051MH-E(TR),\, UP0071MH-E(TR),\, UP0091MH-E(TR),\, UP0121MH-E(TR),\\ UP0151MH-E(TR),\, UP0181MH-E(TR) \end{array}$




3-2. 2-way cassette type

MMU-UP0071WH-E(TR), UP0091WH-E(TR), UP0121WH-E(TR), UP0151WH-E(TR), UP0181WH-E(TR), UP0241WH-E(TR), UP0271WH-E(TR), UP0301WH-E(TR), UP0361WH-E(TR), UP0481WH-C, UP0561WH-E(TR)




3-3. 1-way cassette (SH) type

MMU-UP0151SH-E(TR), UP0181SH-E(TR), UP0241SH-E(TR)




3-4. Floor standing cabinet type

MML-UP0071H-E(TR), UP0091H-E(TR), UP0121H-E(TR), UP0151H-E(TR), UP0241H-E(TR)



3-5. Floor standing concealed type

MML- UP0071BH-E(TR), UP0091BH-E(TR), UP0121BH-E(TR), UP0151BH-E(TR), UP0181BH-E(TR), UP0241BH-E(TR)




Terminal Block
Temp sensor
Transformer

TC1,TC2,TCJ

띺


3-6. Floor standing type

 $\begin{array}{l} \text{MMF-UP0151H-E(TR), UP0181H-E(TR), UP0241H-E(TR), UP0271H-E(TR), UP0361H-E(TR), UP0481H-E(TR), UP0561H-E(TR)} \end{array}$



3-7. 4-way cassette type

MMU-UP0091H-E(TR), UP0121H-E(TR), UP0151H-E(TR), UP0181H-E(TR), UP0241H-E(TR), UP0271H-E(TR), UP0301H-E(TR), UP0361H-E(TR), UP0481H-E(TR), UP0561H-E(TR)



4. PARTS RATING

Indoor unit

Compact 4-way cassette type

Model	MMU-UP***MH-E(TR)	005	007	009	012	015	018	
Fan motor				ICF-34	0D60-1			
Drain pump	motor			MDP	-1401			
Float switch	ı			FS-02	18-102			
Pulse moto	r valve		PAM-B2	PAM-B40YGTF-1				
P.C. board		MCC-1643						
TA sensor		Lead wire length: 818 mm Vinyl tube						
TC1 sensor	r	Dia.4 size lead wire length: 400 mm Vinyl tube						
TC2 sensor	r	Dia.6 size lead wire length: 500 mm Vinyl tube (Black)						
TCJ sensor	-	Dia.6 size lead wire length: 400 mm Vinyl tube (Red)						

2-way cassette type

Model MMU-UP***WH-E(TR)	007 009 012	015	018	024	027	030	036	048	056
Fan motor	ICF-340D60-1			ICF-340WD94-9				ICF-340WD139-3	
Drain pump motor	ADP-1409								
Float switch			F	S-0218-1	03				
Pulse motor valve	PAM-B25YGTF-1	PAM-B40YGTF-2					PAM-B60YGTF-1		
P.C. board				MCC-164	3				
TA sensor			Lead wi	re length	: 268 mm				
TC1 sensor	Dia.4 size lead wire length: 1200 mm vinyl tube (Blue)								
TC2 sensor	Dia.6 size lead wire length: 1200 mm vinyl tube (Black)								
TCJ sensor	Dia.6 size lead wire length: 1200 mm vinyl tube (Red)								

1-way cassette type

Model MMU-UP***SH-E(TR)	015	018	024				
Fan motor	ICF-340WD94-9						
Drain pump motor	ADP-1409						
Float switch		FS-0218-103					
Pulse motor valve	PAM-B40YGTF-1						
P.C. board		MCC-1643					
TA sensor	L	ead wire length: 155 mm Vinyl tub	oe e				
TC1 sensor	Dia.4 size	Dia.4 size lead wire length: 1100 mm Vinyl tube (Blue)					
TC2 sensor	Dia.6 size lead wire length: 1100 mm Vinyl tube (Black)						
TCJ sensor	Dia.6 size lead wire length: 1100 mm Vinyl tube (Red)						

Floor standing cabinet type

Model MML-UP***H-E(TR	007	009	012	015	018	024	
Fan motor	SWA-2	200A4A	AF-200)-45-4F	AF200-70-4K		
Running capacitor for fan motor	AC450	V, 1.2 μF	AC400 \	/, 1.8 μF	AC450	V, 2 μF	
Pulse motor valve	PAM-B2	5YGTF-1	PAM-B40YGTF-1				
P.C. board	MCC-1744						
TA sensor		L	ead wire length: 818 mm Vinyl tube				
TC1 sensor		Dia.4 size	e lead wire length: 1200 mm Vinyl tube (Blue)				
TC2 sensor	Dia.6 size lead wire length: 1200 mm Vinyl tube (Black)						
TCJ sensor		Dia.6 size lead wire length: 1200 mm Vinyl tube (Red)					

Floor standing concealed type

Model MML-UP***BH-E(TR)	007	009	012	015	018	024		
Fan motor		SWA-200A4B			AF-200-70-4K			
Running capacitor for fan motor		AC450 V, 1.5 μF		AC450	V, 3 μF	AC450 V, 2 μF		
Pulse motor valve		PAM-B25YGTF-	1	PAM-B40YGTF-1				
P.C. board	MCC-1744							
TA sensor		L	ead wire length:	818 mm Vinyl tube				
TC1 sensor		Dia.4 size	lead wire length:	2000 mm Vinyl tube (Blue)				
TC2 sensor	Dia.6 size lead wire length:			2000 mm Vinyl tube (Black)				
TCJ sensor		Dia.6 size lead wire length: 2000 mm Vinyl tube (Red)						

Floor standing type

Model	MMF-UP***H-E(TR)	015	018	024	027	036	048	056
Fan motor			ICF-340	D62-1		IC	CF-340WD109-	1
Pulse motor	valve	PAM-B40YGTF-1 PAM-B60YGTF-1						1
P.C. board		MCC-1643						
TA sensor				Lead wire l	ength: 1200 mr	m Vinyl tube		
TC1 sensor			Dia.4	size lead wire	length: 1200 n	nm Vinyl tube (Blue)	
TC2 sensor		Dia.6 size lead wire length: 2000 mm Vinyl tube (Black)						
TCJ sensor			Dia.6	size lead wire	length: 1200 r	mm Vinyl tube ((Red)	


4-way cassette type

Model MMU-UP***H-E(TR	009	012	015	018	024		
Fan motor	ICF-34	0D60-1	ICF-340D130-2*				
Drain pump motor			PMD-08D12TF-2				
Float switch		FS-0218-102					
Pulse motor valve	PAM-B2	5YGTF-1	PAM-B40YGTF-2				
P.C. board	MCC-1643						
TA sensor		Lead wire length: 328 mm Vinyl tube					
TC1 sensor		Dia. 4 size lead	wire length : 1200mm Vinyl tube (Blue)				
TC2 sensor	Dia. 6 size lead wire length: 1000mm Vinyl tube (Black)						
TCJ sensor		Dia. 6 size lead wire length: 1000mm Vinyl tube (Red)					

Model	MMU-UP***H-E(TR)	027	030	036	048	056			
Fan motor				ICF-340	D130-2*				
Drain pump n	notor			PMD-08D12TF-2					
Float switch			FS-0218-102						
Pulse motor v	/alve	PAM-B40	0YGTF-2	PAM-B60YGTF-1					
P.C. board		MCC-1643							
TA sensor		Lead wire length: 328 mm Vinyl tube							
TC1 sensor			Dia. 4 size lead v	vire length : 1200mm	Vinyl tube (Blue)				
TC2 sensor		Dia. 6 size lead wire length: 1000mm Vinyl tube (Black)							
TCJ sensor		Dia. 6 size lead wire length: 1000mm Vinyl tube (Red)							

5. REFRIGERANT CYCLE DIAGRAM

Indoor unit



Explanation of functional parts in indoor unit

Functional part	name	Functional outline
Pulse Motor Valve	PMV	(Connector CN82 (6P): Blue) 1) Controls superheat in cooling operation 2) Controls subcool in heating operation 3) Recovers refrigerant oil in cooling operation 4) Recovers refrigerant oil in heating operation
Temp. Sensor	TA	(Connector CN104 (2P): Yellow) 1) Detects indoor suction temperature
	TC1	(Connector CN100 (3P): Brown) 1) Controls PMV superheat in cooling operation
		(Connector CN101 (2P): Black) 1) Controls PMV subcool in heating operation
	TCJ	(Connector CN102 (2P): Red) 1) Controls PMV superheat in cooling operation

6. CONTROL OUTLINE

Control Specifications

No.	Item		cifications	Remarks		
1	When power supply is reset	distinguished a distinguished a distinguished a distinguished a setting of indo adjustment Based on EEF speed and the speed and the trouble, the check code and the setting the trouble and the setting the check code and settinguished as the check code and settinguished a settinguished as the settinguished a	er supply is researed the control is result. or fan speed and PROM data, sele existence of air power supply deck code is once emote controller resumed, if the e is again display	d existence of ct setting of the direction adjuuring occurrer e cleared. After was pushed abnormal state yed on the rer		
2	Operation mode selection	Based on the remote control	operation mode ler, the operation			
		Remote controller command	С	ontrol outline		
		STOP	Operation stop	S.		
		FAN	Fan operation			
		COOL	Cooling operat	ion		
		DRY	Dry operation			
		HEAT	Heating operat	ion		
		AUTO Heat recovery system outdoor unit type	The operation the following f at the first tim (In the range Cooling therm	on mode for op is performed a igure according	TA: Room temp. Ts: Setup temp.	
		+1.0	//// Cooling ////thermostat	ON ///////		
		TA (°C) Ts	Cooling thermo	ostat OFF ne only)		
		_1.0 ├	//// Heating thermostat C	DN ///////		
		automatic mo While a wirele notified by "Pi alternate flash	ess remote control Pi" (two times) re ning of [TIMER © Iternate flashing,			
3	Room temp.	1) Adjustment ran	ge: Remote cont	roller setup ter	mperature (°C)	
	COILLOI		COOL/DRY	HEAT	AUTO*	* Heat recovery system only
		Wired type	18 to 29	18 to 29	18 to 29	Offiny
		Wireless type	17 to 30	17 to 30	17 to 30	

No.	Item		Outline of sp	ecifica	tions			Remarks
3	Room temp.		y setting the CODE No. 06 eating operation can be co			nperati	ure in	Return air temperature shift of heating operation
	(Continued)	Setup data 0 2 4 6 Setup temp. compensation +0°C +2°C +4°C +6°C						
		Se	etup temp. compensation	+6°C	Except while sensor of the remote controller is			
		T	he initial factory default val	ue				controlled
		EI/	Model oor standing cabinet, Floor sta	anding o	onooolo	_	et data	(Code No. [32], "0001")
		Fic	oor standing	anding c	onceale	;u,	0	
		Ot	her models				2	
4	Automatic capacity control	tio	cool SD SB S9 Ts S7 S5 S3 S0	Ts: Setup temp. TA: Room temp.				
5	Automatic cooling/heating control	D CC 10 CC OP	the judgment of selecting Comown below. When TA exception is the eating operation (thermost peration). TA Cooling +1.5	eeds Tsermosta at OFF Heati ses shoes less the thermost OFF) control and No.4. ion of r	h by 1. at OFF) is cha Cooling of the cooling of the character judgment to the cooling of the cooling of the character judgment to the cooling of the cool	5 for 10 then, the	e of for the heating	Heat recovery system only Tsc: Setup temp. in cooling operation Tsh: Setup temp. in heating operation + temp. compensation of room temp. control

No.	Item	Outline of specifications	Remarks
6	Fan speed selection	1) By the command from remote control, fan speed is changed. ((HH), (H+), (H), (L+), (L) or [AUTO]) 2) When the fan speed mode [AUTO] is selected, the fan speed varies by the difference between TA and Ts. COOL> TA (C) +3.0 HH +2.5 +2.0 H+ <hh> D H+ <hh> D H- <hh> D H- <hh> TSC -0.5 L <h> TSC L <h> TSC -0.5 L <h> TSC L <h< td=""><td>HH > H+ > H > L+ > L > UL Depends on fan speed mode selection at the remote controller. (H+) and (L+) cannot be selected. For Floor Standing Concealed Type, or Floor Standing Cabinet Type, (HH), (H), (L) or [AUTO] can be selected regardless of remote controller models.</td></h<></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></h></hh></hh></hh></hh>	HH > H+ > H > L+ > L > UL Depends on fan speed mode selection at the remote controller. (H+) and (L+) cannot be selected. For Floor Standing Concealed Type, or Floor Standing Cabinet Type, (HH), (H), (L) or [AUTO] can be selected regardless of remote controller models.
		 Fan speed mode [AUTO] in case when remote controller sensor works is equal to that in case when indoor unit sensor works. If the fan speed has been changed once, it is not changed for 3 minutes. However when the air volume is changed, the fan speed changes. When cooling operation has started, select a downward slope for the fan speed, that is, the high position. If the temperature is just on the difference boundary, the fan speed is not changed. CHEAT> TA (*C) (+0.5) +1.0 (0) Tsh (-0.5) -1.0 H+ (-1.0) -2.0 HH (-1.5) -3.0 HH (-1.5) -3.0 HH (-2.0) -4.0 HH H+ H H H H H H 	Code No. [32] 0000: Indoor unit sensor (Main unit) 0001: Remote controller sensor

No.	Item	Outline of specifications	Remarks
6	Fan speed selection (Continued):		Setting of height ceiling mode at CODE No. [5D] or at SW501 on P.C. board.

4-way, Compact 4-way (only UP015), 2-way, 1-way (SH)
(Fan speed selection of UP012 or less and UP018 for Compact 4-way are only Standard.)

CODE No.	Factory default		Тур	Type 1		e 3	Type 6 0006	
[5d]	00	00	0001		0003			
SW501 (1)/(2)	OFF	/OFF	ON/	OFF	OFF	/ON	ON	ON
Тар	COOL	HEAT	COOL	HEAT	COOL	HEAT	COOL	HEAT
F1					HH	HH	HH	HH
F2			HH	HH				
F3				H+	H+, H	H+, H	H+, H, L+, L	H+, H, L+, L
F4			H+					
F5		HH		Н				
F6	HH		Н		L+	L+		
F7	H+	H+			L	L		
F8		Н		L+				
F9	Н		L+	L				
FA		L+	L					
FB	L+	Ĺ						
FC	L							
FD	LL	LL	LL	LL	LL	LL	LL	LL

Floor standing

Floor standing			
CODE No.	Factory default		
[5d]	00	00	
SW501 (1)/(2)	OFF	OFF	
Тар	COOL	HEAT	
F1			
F2			
F3			
F4			
F5		HH	
F6	HH		
F7	H+	± ±	
F8		Ι	
F9	Н		
FA		L+	
FB	L+	L	
FC	L		
FD	LL	LL	

- 3) In heating operation, the mode changes to [LL] if thermostat is turned off.
- 4) When the optional R32 Refrigerant Leak Detector is connected and a leak of R32 Refrigerant is detected, the fan may operate at speed [HH]. For details, refer to item No. 26 "Leak detector control".

No.	Item	Outline of specifications	Remarks
I I	vention of cold discharge	 In heating operation, the lowest temperature between TC1 sensor and the highest temperature between TC2 and TCJ sensor is set as the upper bound of the fan speed mode control. When B zone has been continuing for 6 minutes, the operation shifts to C zone. For the defrosting operation, the control point is set to +6°C. (°C) 32 A zone: OFF B zone: Over 26°C, below 28°C, C zone: Over 28°C, below 30°C, D zone: Over 30°C, below 32°C, E zone: HIGH (HH) 	LOW (L)
cont	eze prevention trol (Low temp. ase)	 In all cooling operation, the air conditioner operates as described below based upon temp. detected by TC1, TC2 and TCJ sensors. When "J" zone is detected for 5 minutes, the thermostat is forcedly off. In "K" zone, the timer count is interrupted, and held. When "J"zone is detected, the timer is cleared and the operation returns to the normal operation. If "J" zone continues, operation of the indoor fan in LOW mode continues until it reaches the "J"zone. It is reset when the following conditions are satisfied. Reset conditions TC1 ≥ 12°C and TC2 ≥ 12°C and TCJ ≥ 12°C 20 minutes passed after stop. ("C) P1	() value: When the power supply is turned on, the forced thermostat becomes OFF if the temperature is less than this indicated temperature.

No.	Item	Outline of specifications	Remarks
9	Refrigerant (Oil) recovery control in cooling operation	Indoor units during stop/thermostat OFF or FAN operation perform following controls when a refrigerant (compressor oil) recovery signal is received from outdoor unit at the cooling operation, (1) Opening the indoor unit PMV at constant valve opening. (For a maximum of about 4 minutes) (2) Operating the drain pump for about one minute, during recovery control and after the control finished. Also, indoor unit fan or louvers may operate depending on the indoor unit type.	Control is performed per two hours or when the outdoor unit determines its need.(It varies depending on the indoor units connected.)
10	Refrigerant (Oil) recovery control in heating operation	Indoor units during stop/thermostat OFF or FAN operation perform following controls when a refrigerant (compressor oil) recovery signal is received from outdoor unit at the heating operation, (1) Opening the indoor unit PMV at constant valve opening. (For a maximum of about 20 minutes) (2) TC2 temperature is detected to close its PMV. Also, the fan, louvers, drain pump may operate for about one minute after recovery control finished depending on indoor unit types, until the number of recovery control reaches the predetermined number. NOTE The PMV, indoor fan, or louvers may operate through the outdoor unit instruction. For its detail, refer to the outdoor unit service guide.	Indoor unit during cooling thermostat OFF or FAN operation stops the indoor fan and displays "Operation standby (*)". Control is performed per one hour or when the outdoor unit determines its need.(It varies depending on the indoor units connected.)
11	Compensation control for short intermittent operation	 For 3 minutes after start of operation, the operation is forcedly continued even if the unit enters in Thermostat-OFF condition. However the thermostat is OFF giving prior to COOL/HEAT selection, READY for operation and protective control. 	Usually the priority is given to 5 minutes at outdoor controller side.
12	Drain pump control	 Drain pump operates while in cooling operation. (including DRY operation) While the drain pump is operating, if the float switch is operated, the outdoor unit will stop operating but the drain pump will keep continuously operating. After that, the check code is issued. When the drain pump stops operating, if the float switch is operated, the outdoor unit will stop and the drain pump will start operating. After the float switch is being operating for roughly 5 minutes, the check code will be issued. 	Check Code [P10] • A model with a drain pump: Compact 4-way 2-way cassette 1-way cassette (SH) 4-way cassette
13	Elimination of retained heat	When the unit stopped from [HEAT] operation, the indoor fan operates with [L] for approx. 30 seconds.	
14	HA control	 ON/OFF operation is available by input of HA signal from the remote site when connecting to remote controller or the remote ON/OFF interface. The HA terminal is ON/OFF depending on HA control output. The I/O specifications of HA is in accordance with JEMA standard. 	When using HA terminal (CN61) for the remote ON/OFF, a connector sold separately is necessary. In case of group operation, use the connector to connect HA terminal to either master or follower indoor unit.

No.	Item		Outline of specifications		Remarks
15 Alar setu	rm output up	DN Alarm output of the header indoor unit Setting data			Connector CN61 (Refer to 8-3-1,8-3-2. Optional connector specifications of indoor P.C. board) Be sure to change the setting data while operation stops.
sigr (No	play of filter n [ot provided to wireless e)	 The filter sign is reset signal to time (150H/250 operation time) The integrated received from the life in this time, if the reset and the life 	[IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII		
		Type	2500H Compact 4-way cassette type 1-way cassette type (SH) 2-way cassette type 4-way cassette	Floor standing to Floor standing co Floor standing co	pe oncealed type
[RE	play of EADY] EAT READY]	* This may not be outdoor unit. 1) When the follo • There is an i [P10]. • There is an i [L30]. 2) When the open restricted. (At thermostat-off • [COOL/DRY indoor unit office the other indoor unit office the other indoor the other indoor the indoor fan [Recovery open controller etc.] 3) The indoor fan stowhen heating open controller etc.	operation is unavailable becomerates with [HEAT] mode. ation is unavailable because of the Outdoor I/F P. C. board is poor unit operates with [COOL/Experation mode of the outdoor an optional board for outdoor an optional board for outdoor	ed. ndoor overflow nterlock alarm emporarily ds by in forced ause the other COOL priority ON) is set and DRY] mode. unit is r units, central erforms (Oil)]. roller rge of cool air ng operation.	• < READY (③) > display No display for wireless type remote controller • <heat (※)="" ready=""> display</heat>

No.	Item			Outli	ne of spec	ifications			Rema	rks
18	Selection central co mode			ntroller at t to setting a	ents that ca he indoor u at the centra	nit side is p	ossible			
		Or	peration from		0	peration on re	emote control	ler		
			tral controller	ON/OFF setting	Operation selection	Timer setting	Temp. setting	Fan speed setting	Air direction setting	
			Individual	0	0	0	0	0	0	
		+	[Central 1]	X	0	X	0	0	0	
			[Central 2] [Central 3]	× 0	×	× 0	×	0	0	
			[Central 4]	0	×	0	0	0	0	
			eration possible X						1 0	
			necessa the set The lour range. In cooling In cooling In case formed horizont Swing set Compact 4-way cas Figwing In group collective	arily to down position. If the position of the position of twin/triple ctively or incited that HEAT in STOP stated when the stall when the position of the po	operation, the dividually. The frigerant restricts, the louve operation is the control of the following and the follower persection of the follower persecti	arge position up in the fol In heating the louver position the covery conting resumed. 1-way casse the covery conting disp tions continued.	n once to recommend operations can becomes trol was per becomes tette (SH), play is repeated be set up	ation be set atted.	Compact 4-way cassett -way cassett -way cassett	e e (SH)
			horizoni (Perforn In group collectiv 3) When the automatic 4) When PRI (Heating of heating the is automat * The low louver of automat	tal direction on vertical with coperation, wely or individually set to full table. The comment of the comment o	nd direction the louver p dually. d or the war ıll closed po	adjustment ositions car ning was ou sition. ly) is display st operation aning is perf scharge pos s individually t stops and discharge pos	t manually) In be set up utput, the loved is performed, the lition. y set or the the louver in t	uver is d), ouver locked s 1 PRE-		

No.	Item	Outline of specifications	Remarks
19	Louver control (Continued)	 C-Individual air direction setup>> Pushing Louver Select button enables every discharge port to set up the air direction. (In the case of RBC-AMTU3*) The louver numbers that are displayed on the display part correspond to those in the following figure. In case of no input (key operation) for approx. 5 seconds during setting of individual air direction (during displaying of louver No. on the remote controller screen), the remote controller screen returns to the normal display screen. For the air direction illustration during normal operation, the air direction of the least No. among the louvers which are block-set is displayed. While individual air direction is being set, the remote controller operation (Illustration of air direction) and operation of the real machine are linked. When selecting a case, Louver select button is not pushed or louver No. is not displayed, the air directions of all the louvers are collectively set up. 	Subject model : 4-way cassette Compact 4-way Setup from the remote controller without button is unavailable.
		03 [F3] 04 [F4] 02 [F2] Drain pipe 01 Refrigerant pipe [F1] Compact 4-way cassette type	

No.	Item		Outline of sp	ecifications	Remarks
19	Louver control	< <selection< td=""><td>n of Swing mode></td><td>></td><td>Subject model :</td></selection<>	n of Swing mode>	>	Subject model :
	(Continued)	For the Sware selection of the sele	ving mode, the folk able and settable b on pushed for 4 se (In the case of RB de can be selected se of RBC-ASCU1 I (4 pieces: same p	owing three types of modes by keeping Swing/Direction conds or more on the remote cC-AMTU3*) d by Code No.(DN) setup [F0] 1-*).	Compact 4-way 4-way cassette
		When Swithe horiz Swing op 2) Dual swith When op	ontal discharge poperation at the saming \rightarrow Data: [0002] peration is selected	elected, four louvers align at sition and then start the time. I, the louvers of louver No.	Carry out setting operation during stop of the unit; otherwise the unit stops operation.
		the louve downwar operatior	ers of louver No. [02 rd discharge position at the same time.		
		When op the horiz discharge	ring → Data: [0003 peration is selected ontal discharge po e position, [02] and start the Swing op		
		"Cycle the cer 3 seco [SWIN	swing", the following ter of the remote of the remote of the swing/FIX but the swing/FIX but the following the fol	twing mode, "Dual swing" or ng numerals is displayed at controller screen for approx. utton was pushed to select the standard swing)	
			Alternate lighting	Alternate lighting	
			(0.5 sec.)	(0.5 sec.)	
			ll swing	Cycle swing	
		For the air position ca	in be locked during	each discharge port, the louver the normal operation.	
		 An arbitrary air direction of an arbitrary louver can be registered and set by keeping button pushed for 4 seconds or more on the remote controller. (In the case of RBC-AMTU3*) Louver lock can be selected by Code No.(DN) setup [F1], [F2], [F3] or [F4]. (In the case of RBC-ASCU11-*) 			
		The louver lock can be set by registering the setup data to Code No.(DN) [F1] to [F4] according to the following table.			Carry out setting operation during stop of the unit; otherwise the unit stops operation.
			Objective louver No.	Setup data	opolution.
		F1 F2	01 02	0000: Release (At shipment) 0001: Horizontal discharge position	
		F3	03	~	
		F4	04	0005: Downward discharge position	

No.	Item		Outline of specifications	Remarks				
19	Louver control (Continued)	remote • While	 If there is the locked louver in the unit, [] goes on the remote controller screen. While the following controls are performed, the louvers operate even if executing the louver lock. For the setting operation refer to [How to set lour lock] of Installation Management of Installation Man					
			Control which ignores lock	Object	ive louver No.			
		1	Operation stop	Full-c	close position			
		2	When heating operation started	Horizontal	discharge position			
		3	Heating thermostat OFF	Horizontal	discharge position			
		4	During defrost operation	Horizontal	discharge position			
		(5)	Initialize operation	Full-o	close position			
		on the	al louver corresponding to the louver N remote controller screen during setting perates swinging.		It is position check op and it does not link wi real louver and air dir setup (Illustration on t remote controller scre	ith the ection the		
20	DC motor	starte 2) DC n the ir (Note)	n the fan starts, positioning is performer and the rotor. (Vibrate slightly) notor operates according to the commodoor controller. If the fan rotates by entry of outside a the air conditioner stopped, the indoor operate as the fan motor stops. If the fan lock was detected, the operate of the conditioner and the check code.	Check code [P12] Subject model : Compact 4-way 2-way cassette 1-way cassette (SH) Floor standing)			
21	Power saving mode	1. Push 2. The contr 3. The paper 4. If the are remode The paper • The out	the button on the remote cont the button on the remote cont segment lights up on the wired oller display. requirement capacity ratio is limited to eximately 75 %. power saving operation is enabled, the tained when the operation is stopped is changed, or when the power is repower saving operation will be enabled the operation starts. To operation may differ depending on the door unit. Refer to the Service Manual door unit.					

No.	Item	Outline of specifications	Remarks
22	Occupancy sensor	 During the Occupancy sensor operation (DN code: [B5] [0001] and [B6] [0002 to 0005]), when there is no people the Occupancy sensor range, it is automatically switched the operation for the absence. The Occupancy sensor operation can change by [DN companies and operates according to the operation absent time, if time or absence of the setting contents 	to remote controller RBC-AMSU5*
		continues. However time counting starts after the room temperature is stabilized. (after for 30 minutes operation)	
		DN [B6] Data Setting contents 0000 Invalid 0001 to 0005 30 minutes to 150 minutes (30 minutes each)	
		3) The operation at absent time can be changed by [DN corest].	de:
		DN [B7] Data Operation at absent time 0000 Circulator	
		4) If the operation at absent time stops during group operat or absence is fixed in each system, the operation starts circular operation once, and then the operation stops wh absence was determined on all group. * DN [06] and DN [B7] can be set on the "Occupancy ser menu of the wired remote controller RBC - AMSU5*.	en
23	Soft cooling	 * Wired remote controller: RBC-AMSU5* is required. 1) Sensation of draft can be suppressed by controlling performance and correcting the louver angle during cooli operation. 2) However, it may not cool well because the operation will performed with the cooling capacity suppressed. 3) Perform operations from the remote controller menu to u soft cooling. 	be
24	Dual set point (AUTO mode)	The temperature for heating operations and cooling operations can be set separately in AUTO mode when diset point is valid. The compressor will turn off (thermostat-OFF) when reaching the set temperature for heating operations and cooling operations. Set CODE No. (DN) [77] to enable Dual set point. DN [77] Data Dual set point 0000 Unavailable (Factory default) 0002 Available	This function cannot be used with remote controllers that are not RBC-AMSU5*.

No.	Item	Outline of specifications	Remarks
25	Secondary heating	Secondary heating can be used while heating operations are performed. <control (normal="" mode)="" outline=""> 1) If the difference between the indoor temperature and the outdoor temperature is large while the air conditioner is operating, turn ON the secondary heating. 2) This function is valid when the CODE No. (DN) [DC] is set to "0001" (0.5°C) to "0010" (5.0°C) using the wired remote controller, and the output to the external heating source will turn ON if the room temperature satisfies the condition. 3) The output will always stay ON while defrosting operations are being performed. TA</control>	
		TS OFF a a OFF DN b	TA _H : Temp.set air high (= Ts - a) TA _L : Temp.set air low (= TA _H - b)
		4) The output can be turned on by the outdoor temperature when CODE No. (DN) [C7] is set to "0001" (1°C) to "0010" (10°C) using the wired remote controller.	
		TOL OFF C	TO _H : Temp.set out high TO _L : Temp.set out low (= TO _H - c)
		 <control (flip="" mode)="" outline=""></control> 1) If the difference between the room temperature and the set temperature is large while using secondary heating, run the air conditioner. 2) This function is valid when the CODE No. (DN) [C5] is set to "0001" (Flip mode) or the CODE No. (DN) [C7] is set to "0001" (1°C) to "0010" (10°C) using the wired remote controller, and when the output is switched ON when the room temperature satisfies the conditions. * The outdoor temperature determination is invalid whilst this control is performed. 	
		TA Ts OFF OFF ON TAH TAL ON a	

No.	Item	Outline of specifications	Remarks
25	Secondary heating (Continued)	DN [C5] Data Secondary heating mode	
		DN [C5] Data Secondary heating mode 0000 Normal mode (Factory default)	
		0001 Flip mode	
		DN [C6] Data TOH: Set temp. out (high) [°C]	
		-0015 "-0015": -15°C to "0015": 15°C to "0000": 0°C (Factory default)	
		0015	
		DN [C7] Data c: TOH - TOL [°C]	
		0000 Unavailable (Factory default)	
		0001 0001: 1°C to "0010": 10°C	
		to	
		0010	
		DN [DB] Data b : TAH - TAL [°C]	
		0001 "0001": 0.5°C to "0010": 5.0°C	
		to "0006": 3°C (Factory default)	
		DN [DC] Data a : Ts - TAн (Normal mode)[°C] TAL - Ts (Flip mode)[°C]	
		0000 Unavailable (Factory default)	
		0001 0001: 1°C to "0010": 10°C to	
		0010	
		<wiring> 1) Use ① - ④ pin (Cooling output, DC 12 V) of CN60 on indoor P.C. board for output.</wiring>	
		Relay (DC12V, procured locally) Corresponds to the relay up to one that the rated current of the operation coil is approx. 75mA	
		CN60 Option output (6P WHI) Connect to secondary heating unit	
		Indoor control P.C. board Note) Determine the cable length between the indoor control P.C.board and the relay within 2m.	
		2) If there is no CN60 on the P.C. board (MCC-1643 model), install separately-sold Application control kit (TCB-PCUC2E) and use "OUT1 to OUT3" of the Signal output terminal block (TB1). At this time, select "1" (Cool dry output) for "SW1 to SW3". Following the installation manual of the Application control kit for detailed contents relating to wiring.	
		* The output state can be checked from "Monitor function" on the wired remote controller. See page 82 or the manual for the remote controller for operation methods of "Monitor function".	
		Monitor Secondary heating output CODE No: Unavailable E5 0000: OFF 0001: ON	
		500 f. Oly	

No.	Item	Outline of specifications				Remarks
26	R32 refrigerant Safety measures setting	When connecting the following so system used. * Floor standing cannot be considered to see the CODE For details of each of Service Manual DN[107] * When using the standard content of the	Indoor unit type usable with R32 refrigerant: 4-way cassette type, Compact 4-way cassette type, 2-way cassette type, 1-way cassette type			
27	R32 refrigerant Leak Detector control	1) When the opt and safety me controls to de 2) When the indesignal, check displayed on the signal sturn reference (CN32) is turn reference (CN32)	Refrigerant detection control 1) When the optional R32 refrigerant Leak Detector is connected and safety measures are set (Item No. 26), the indoor unit controls to detect refrigerant leakage. 2) When the indoor unit receives the refrigerant leak detection signal, check code J30 (Refrigerant leak detection) is displayed on the remote controller. 3) When refrigerant leakage is detected, ventilation output (CN32) is turned ON. Refer to "8-3. Indoor Print Circuit Board" for details on ventilation output (CN32). 4) When DN[107] (R32 Safety measures) is "0001" or "0003" and DN[108] (Circulation flow operation mode) is "0000", the fan of the indoor unit is operated to prevent refrigerant from stagnating in the room (Fan speed is HH, louver position is middle). In this case, the fan continues to operate even if the operation is stopped by the remote controller. 5) When the indoor unit receives a refrigerant leak clear signal from the Leak Detector, it stops ventilation output and fan			
28	Battery kit Lifetime Notification	When the indoor unit detects that the battery kit connected to the Flow Selector unit or shutoff valve has reached the end of its service life, it outputs notification code No. 203 (Flow Selector unit battery dead) and displays a notification code icon on the wired remote controller.				R32 refrigerant systems only

7. COMMUNICATION TYPE, MODEL NAMES AND THE MAXIMUM NUMBER OF CONNECTABLE UNITS


7-1. This air conditioning (U series) has new communication specifications, and TU2C-LINK (U series) and TCC-LINK (other than U series) differ in a communication type. For the communication type and the model names such as each unit or remote controllers, refer to the following table.

Communication type	TU2C-LINK (U series and future models)	TCC-LINK (Other than U series)		
Outdoor unit	MMY-M <u>U</u> P***, MMY-S <u>U</u> G***, MCY-M <u>U</u> G*** ↑ This letter indicates U series model.	Other than U series MMY-MAP***, MMY-MAP*** MCY-MHP***		
Indoor unit	MM*- <u>U</u> P*** ↑ This letter indicates U series model.	Other than U series MM*-AP***		
Wired remote controller	RBC-A** <u>U</u> *** ↑ This letter indicates U series model.	Other than U series		
Wireless remote controller kit & receiver unit	RBC-AX <u>U</u> *** ↑ This letter indicates U series model.	Other than U series		
Remote sensor	TCB-TC** <u>U</u> *** ↑ This letter indicates U series model.	Other than U series		

U series outdoor unit : SMMS-u, SMMS∞, SHRM-A, MiNi-SMMS Other than U series outdoor unit : SMMS-i, SMMS-e, SHRM-e, SMMS-7 etc.

7-2. If TU2C-LINK (U series) is combined with TCC-LINK (other than U series), the wiring specifications and the maximum number of connectable indoor units during group control operation will be changed.

- (1) For wiring specifications, carry out the installation, maintenance, or repair according to the attached Installation Manual.
- (2) For a communication type combination and the max. number of connectable indoor units, refer to the following table.
 - Only when all outdoor unit, indoor unit and remote control are a U series, communication method is TU2C-LINK, and the maximum number of connectable units will be 16.



The combination of unit type and the number of the maximum connection of a communication method


Unit type								
Outdoor unit	U series	U series	U series	U series	*	*	*	*
Indoor unit	U series	U series	*	*	U series	U series	*	*
Remote controller Remote sensor	U series	*	U series	*	U series	*	U series	*
Communication type	TU2C-LINK				TCC-LINK			
Maximum number of connectable units	16				8			

^{*} Other than U series


8. APPLIED CONTROL AND FUNCTIONS (INCLUDING CIRCUIT CONFIGURATION)

8-1. Indoor controller block diagram (MCC-1643)


8-1-1. In case of connection of wired remote controller




8-1-2. In case of connection of wireless remote controller



8-1-2. In case of connection of wireless remote controller (Compact 4-way cassette type)




8-1-3. Connection of both wired remote controller and wireless remote controller




8-2. Indoor controller block diagram (MCC-1744)


8-2-1. In case of connection of wired remote controller




8-2-2. In case of connection of wireless remote controller



8-2-3. Connection of both wired remote controller and wireless remote controller



8-3. Indoor Print Circuit Board




Optional connector specifications of indoor P.C. board (MCC-1643)

Connector No.	Color	Function	4-way Cassette	Compact 4-way Cassette	2-way Cassette	1-way Cassette (SH)	Floor	Pin No.	Specifications	Remarks
CN32	White	White Ventilation output	0	0	0	0	0	Θ	DC12V	Setting at shipment: Interlock of ON by indoor unit operation, with OFF by stop operation
								0	Output (Open collector)	* The single operation setting by FAN button on the remote controller is performed on the remote controller (DN=31).
CN34	Red	Input for float SW	•	•	•	•	X (With short- circuit	00	DC12V NC	Normal when between ①-③ short-circuits, but abnormal when open-circuits. (check code "P10" appears)
								<u>⊕</u>	Float SW input	
CN61	Yellow HA	НА	0	0	0	0	0		ON/OFF input	HA ON/OFF input (J01: YES/NO=Pulse (At shipment from factory) /Static input selection)
								0 0	0V (COM) Remote controller prohibited input	Permission/Prohibition of remote controller operation stop is performed by input.
									Operation output (Open collector)	Operation ON (Answer back of HA)
								90	DCIZV (COM) Warning output (Open collector)	Warning output ON
CN71	White	CHK Operation check	0	0	0	0	0	90	Check mode input 0V	This check is used to check indoor operation. (Performs operation of indoor fan "H", Louver horizontal and Drain pump ON without communication with outdoor and remote controller)
CN72	White	DISP Exhibition mode	0	0	0	0	0	⊝⊗	DISP mode input 0V	Communication is available by indoor unit and remote controller only (When the power is turned on). Shortening time of timer (Always)
ON81	Black	Output for Flow selector unit	△	⊲	◁	⊲	△		DC12V EP valve output (Open collector) Balance valve output (Open collector) Suction valve output (Open collector) Discharge valve output (Open collector)	
CN309	Yellow	Yellow Output power supply for option	0	0	0	0	0	90	AC230V AC230V	This can be used as power supply for option devices.
CN521	Red	Connection for option P.C.board	⊲	⊲	⊲	⊲	⊲	00000	DC12V DC5V Send Receive OV	Connected Application control kit (TCB-PCUC2E)
	1) =			

Use in standard, ○: Available, △: Use by connecting parts sold separately, x: Unavailable
 To use the functions operated by CN60, CN70 and CN73, which are provided for other P.C.board, use the Application control kit (TCB-PCUC2E) sold separately.

8-3-2. MCC-1744



Optional connector specifications of indoor P.C. board (MCC-1744)

Connector No.	Color	Function	Floor standing concealed	Floor standing cabinet	No.	Specifications	Remarks
CN032	White	Ventilation	0	0	Θ	DC12V (COM)	Setting at shipment: Interlock of ON by indoor unit operation, with OFF by stop operation
					0	Output (Open collector)	* The single operation setting by FAN button on the remote controller is performed on the remote controller (DN=31).
CN033	White	White Louver output	×	×	00	AC230V AC230V	Output is AC200V when louver is ON.
CN034	Red	Input for float SW	X X (With (With short-circuit connector) connector)	X (With short-circuit connector)	Θ	DC12V	Normal when between ①-③ short-circuits, but abnormal when open-circuits. (check code "P10" appears)
					00	NC Float SW input	
CN060	White	White Option output	0	0	000000	DC12V (COM) Defrost output (Open collector) Thermostat-off output (Open collector) Cooling output (Open collector) Heating output (Open collector) Fan output (Open collector)	ON when outdoor unit is on defrost operation. ON when actual thermostat is ON (Comp. ON). ON when the operation mode is on cooling system (Cool, Dry, Auto (Cooling)). ON when the operation mode is on heating system (Heat, Auto (Heating)). ON when the indoor fan is on, (When an air cleaner is used) OFF when the clean operation is on.
CN061	Yellow HA	/ HA	0	0	1	ON/OFF input	HA ON/OFF input (J01: YES/NO=Pulse (At shipment from factory) /Static input selection)
					3@@@	OV (COM) Operation output (Open collector) DC19V (COM)	Permission/Prohibition of remote controller operation stop is performed by input. Operation ON (Answer back of HA)
						Warning output (Open collector)	Warning output (Open collector)
CN068	Blue	Drain pump output	×	×	90	AC230V AC230V	Output is AC200V in cooling and float SW operation.
CN070	White	White Filter	0	0	Θ Θ	Input 0V	Option abnormal input (Display of protective operation for equipment installed to the outside) * Perform the settings having option abnormal input from the remote controller. (DN [2A] = 0002 → 0001).
CN071	White	CHK Operation check	0	0	90	Check mode input 0V	Use for operation check of indoor unit. (Performs operation of indoor fan "H", Louver horizontal and Drain pump ON without communication with outdoor and remote controller)
CN072	White	DISP Exhibition mode	0	0	90	DISP mode input 0V	Communication is available by indoor unit and remote controller only (When the power is turned on). Shortening time of timer (Always)
CN073	Red	EXCT	0	0	90	Demand input 0V	Forced thermostat OFF operation for indoor unit
CN080	Green	External abnormal input	0	0	000	DC12V NC External abnormal input	Make the check code of "L30" occur (by continuing operation for one min) and perform the forced stop.
CN081	Black	Output for Flow selector unit	⊲	⊲	00000	DC12V EP valve output (Open collector) Balance valve output (Open collector) Suction valve output (Open collector) Discharge valve output (Open collector)	
CN309	Yellow	Output power supply for option	0	0	00	AC230V AC230V	This can be used as power supply for option devices.
o ni aol I ·	standard	● · I Ise in standard ○ · Available	1	connecting	narts	\ Use by connecting parts sold separately × Use by	

ullet : Use in standard, igtriangle : Available, Δ : Use by connecting parts sold separately, x : Unavailable


8-4. Test run of indoor unit

■ Cooling/Heating test run check

The test run for cooling/heating can be performed from either indoor remote controller or outdoor interface P.C. board. Refer to the Installation Manual and Service Manual of outdoor unit for the procedure of the test run from an outdoor interface P.C. board.

♦ In case of wired remote controller






Procedure	Operation contents	
1	Push [TEST] button for 4 seconds or more. [TEST] is displayed at the display part and the mode enters in TEST mode.	TEST
2	Push [ON/OFF] button.	
3	Change the mode from [COOL] to [HEAT] using [MODE] button. • Do not use [MODE] button for other mode except [COOL]/[HEAT] modes. • The temperature cannot be adjusted during test run. • The trouble detection is performed as usual.	** TEST ** :
4	After test run, push [ON/OFF] button to stop the operation. (Display on the display part is same to that in Procedure 1.)	
5	Push [TEST] button to clear the TEST mode. ([TEST] display in the display part disappears and status becomes the normal stop status.)	

Note) The test run returns to the normal operation after 60 minutes.


<RBC-ASCU11-*>

Be sure to stop the air conditioner before making settings.

(Change the setup while the air conditioner is not working.)




1 Push and hold OFF timer button and [\triangle] setting button simultaneously for 10 seconds or more. [TEST] is displayed on the display part and the test run is permitted.



- **2** Push ON/OFF button.
- - Do not run the air conditioner in a mode other than [Cool] or [Heat].
 - The temperature setting function does not work during test run.
 - The check code is displayed as usual.
- 4 After the test run, push OFF timer button to stop a test run.

([TEST] disappears on the display and the air conditioner enters the normal stop mode.)



Note) The test run returns to the normal operation after 60 minutes.

♦ In case of wireless remote controller

1 Turn on the power of the air conditioner.

When power is turned on for the first time after installation, it takes approx. 5 minutes until the remote controller becomes available. In the case of subsequent power-on, it takes approx. 1 minute until the remote controller becomes available.

Execute a test run after the predetermined time has passed.

Push "ON/OFF" button on the remote controller, select [★ Cool] or [- Heat] with "MODE" button, and then select [■■■■ HIGH] with "FAN" button.

3

Cooling test run	Heating test run
Set the temperature to 17 °C with the temp. setup buttons.	Set the temperature to 30 °C with the temp. setup buttons.

4

Cooling test run	Heating test run
After confirming a signal receiving sound "beep" immediately set the temperature to 18 °C with the temp. setup buttons.	After confirming a signal receiving sound "beep" immediately set the temperature to 29 °C with the temp. setup buttons.

5

Cooling test run	Heating test run
After confirming a signal receiving sound "beep" immediately set the temperature to 17 °C with the temp. setup buttons.	After confirming a signal receiving sound "beep" immediately set the temperature to 30 °C with the temp. setup buttons.

6 Repeat procedures $4 \rightarrow 5 \rightarrow 4 \rightarrow 5$.

Indicators "Operation" (green), "Timer" (green), and "Ready" (orange) in the wireless receiver section flash in approx. 10 seconds, and the air conditioner starts operation. If any of these indicators does not flash, repeat procedures 2 to 5.

7 Upon completion of the test run, push "ON/OFF" button to stop operation.

<Overview of test run operations using the wireless remote controller>

▼ Cooling test run:

ON/OFF
$$\rightarrow$$
 17 °C \rightarrow 18 °C \rightarrow 17 °C \rightarrow 18 °C \rightarrow 17 °C \rightarrow 18 °C \rightarrow 17 °C \rightarrow (test run) \rightarrow ON/OFF

▼ Heating test run:

ON/OFF
$$\rightarrow$$
 30 °C \rightarrow 29 °C \rightarrow 30 °C \rightarrow 29 °C \rightarrow 30 °C \rightarrow 29 °C \rightarrow 30 °C \rightarrow (test run) \rightarrow ON/OFF

Note) The test run returns to the normal operation after 60 minutes.

Check function for operation of indoor unit (Functions at indoor unit side)

This function is provided to check the operation of the indoor unit individually without connecting to the remote controller or the outdoor unit. This function can be used regardless of the ON/OFF operation. However, it is recommend to avoid using this function for along time, otherwise the trouble of the equipment may occurred.

[How to operate]

- Short-circuit CHK pin (CN71 on the indoor P.C. board).
 The operation mode may differ according to the indoor unit status at that time.
 Normal time: Both float SW and fan motor are normal.
 Abnormal time: Either one of float SW or fan motor is abnormal.
- 2) During the normal time, the minimum opening degree (30pls) of the indoor PMV can be set only when both CHK pin (CN71) and DISP pin (CN72) on the indoor P.C board are short-circuited. If the short-circuit at DISP pin (CN72) is opened, the indoor PMV will be at the maximum opening degree (1500pls). When open DISP pin, the maximum opening degree (1500 pls) can be obtained again.
 - For the detailed positions of CHK pin (CN71 on indoor P.C. board) and DISP pin (CN72 on indoor P.C. board), refer to the indoor P.C. board.

[How to clear]

Open CHK pin. If the system is on operation, it will temporarily stop then automatically restart after a while.

* The actual indoor PMV opening degree may differ from the described values due to adjustment depending on PMV types.

		Short-circuit of CHK pin	
	Norma	al time	Abnormal time
	DISP pin open	DISP pin short circuit	Abnormal time
Fan motor	(H)	(H)	Stop
Indoor PMV (*)	Max. opening degree (1500 pls)	Min. opening degree (30 pls)	Min. opening degree (30 pls)
Louver	Vertical	Vertical	Immediate stop
Communication	All ignored	All ignored	All ignored
P.C. board LED	Lights	Lights	Flashes

• To exchange the indoor PMV coil, set the indoor PMV to Max. opening degree.

8-5. Method to set indoor unit function DN code

(When performing this task, be sure to use a wired remote controller.)

Procedure

Be sure to stop the air conditioner before making settings

<RBC-AMTU3*>


1 Push the [™] + → + → buttons simultaneously and hold for at least 4 seconds.

The unit No. displayed first is the address of the header indoor unit in group control.


Then the fan and louver of the selected indoor unit move.

- 2 Each time the button (left side of the button) is pressed, one of the indoor unit Nos. under group control is displayed in turn. Then the fan and louver of the selected indoor unit move.
- 3 Use the ⊕ button to select the CODE No. (DN code) of the desired function.
- **4** Use the **▼ △** button to select the desired SET DATA associated with the selected function.
- **5** Push the [™] button. (The display changes from flashing to steady.)
 - To change the selected indoor unit, go back to step 2.
 - To change the selected function, go back to step 3.
- 6 When the ^{SET} button is pushed, the system returns to normal off state.


<RBC-ASCU11-*>




- $m{1}$ Push and hold menu button and [abla] setting button simultaneously for 10 seconds or more.
 - After a while, the display flashes as shown in the figure. "ALL" is displayed as indoor unit numbers during initial communication immediately after the power has been turned on.



- **2** Each time $[\nabla][\triangle]$ setting button is pushed, indoor unit numbers in the group control change cyclically. Select the indoor unit to change settings for.
 - The fan of the selected indoor unit runs . The indoor unit can be confirmed for which to change settings.



3 Push OFF timer button to confirm the selected indoor unit.



- **4** Push the menu button to make Code No. [**] flash. Change Code No. [**] with [∇] [\triangle] setting button.
- **5** Push the menu button to make Set data [****] flash. Change Set data [****] with $[\nabla] [\triangle]$ setting button.
- 6 Push OFF timer button to complete the set up.
 - To change other settings of the selected indoor unit, repeat from Procedure 4.
- When all the settings have been completed, push ON/OFF button to finish the settings. (Return to the normal mode)
 - " SETTING " flashes and then the display content disappears and the air conditioner enters the normal stop mode. (The remote controller is unavailable while " SETTING " is flashing.)
 - To change settings of another indoor unit, repeat from Procedure 1.

Indoor unit function Code No. (DN Code) table (includes functions needed to perform applied control on site)

DN	Item	Desc	cription	At shipment
	Filter display delay timer	0000: None	0001: 150H	Depending on model
01		0002: 2500H	0003: 5000H	type
		0004: 10000H		
02	Dirty state of filter	0000: Standard		0000: Standard
02		0001: High degree of dirt (Half	of standard time)	
	Central control address	0001: No.1 unit to 0064: N	lo.64 unit TCC-LINK	00Un/0099: Unfixed *1
03			lo.128 unit TU2C-LINK	
03		00Un: Unfixed (When using U	•	
		0099: Unfixed (Other than U s		
04	Specific indoor unit	0000: No priority	0001: Priority	0000: No priority
	priority	10000 000	2004 4 20	
00	Heating temp. shift	0000: 0 °C	0001: +1 °C	Depending on model
06		0002: +2 °C to	0010: +10 °C	type
	Dancard control	0000. Damand innet	(Up to +6 recommended)	0000. Damandinaut
	Demand control	0000: Demand input 0002: Card input setup.3	0001: O2 sensor input 0003: Fire alarm input	0000: Demand input
	(CN73 / CN4)	0002. Card input setup.3	(Normal open)	
0b		0005: Fire alarm input	0006: Notice code (202)	
		(Normal close)	,	
		0007: Card input setup.5	0008: Card input setup.1	
		0009: Card input setup.2		
	Existence of [AUTO]	0000: Provided		0001: Not provided
0d	mode	0001: Not provided		
		(Automatic selection fro	om connected outdoor unit)	
0F	Cooling only	0000: Heat pump		0000: Heat pump
UF		0001: Cooling only (No display	of [AUTO] [HEAT])	
10	Туре	Refer to Type DN code "10" I	ist	Depending on model
				type
11	Indoor unit capacity	0000: Unfixed	0001 to 0044	According to capacity
		Refer to Indoor Unit Capacity		type
	Line address		lo.30 unit TCC-LINK	00Un/0099: Unfixed *1
12			No.128 unit TU2C-LINK	
-		00Un: Unfixed (When using U		
	la de en costa e deles es	0099: Unfixed (Other than U s	· · · · · · · · · · · · · · · · · · ·	0011=/0000-11=five d *4
	Indoor unit address		No.64 unit TCC-LINK	00Un/0099: Unfixed *1
13			No.128 unit TU2C-LINK	
		00Un: Unfixed (When using U 0099: Unfixed (Other than U s	The state of the s	
	Group address		eader unit of group	00Un/0099: Unfixed *1
1	Croup address	0002: Follower unit of group	oddor driit or group	Toolingood. Simkod
14		00Un: Unfixed (When using U	series remote controller)	
		0099: Unfixed (Other than U s		
40	Louver type	0000: No louver	0001: Swing only	Depending on model
19	(Air direction adjustment)	0004: (4-way Air Discharge Ca	<u> </u>	type
	Temp difference of	0000: 0 °C to	0010: 10 °C (Ts ± 5°C)	0003: 3 °C
1E	AUTO] mode selection		•	(Ts ±1.5 °C)
'-	COOL → HEAT, HEAT → COOL	Ts:Remote controller setup ter	mn	
	Automatic restart of	0000: None	0001: Restart	0000: None
28	power failure	10000.140116	500 i. Nostait	TOOO. INDIE
	Selection of option/Trouble	0000: Filter input	0001: Alarm input	0002: None
2A	input (TCB-PCUC2E: CN3)	0002: None	(Air washer, etc.)	
	HA terminal (CN61)	0000: Usual	0001: Card input setup.1 (3)	0000: Usual
	select	0002: Fire alarm input	0003: Card input setup.2 (4)	(HA terminal)
2E		(Normal open)	,	
		0004: Notice code (201)	0005: Card input setup.5	
31	Ventilating fan control	0000: Unavailable	0001: Available	0000: Unavailable
	TA sensor selection	0000: Indoor unit TA sensor	0001: Remote controller sensor	0000: Indoor unit TA
32	Consor Solocion	Sensor unit 1A sensor	555 1. Remote controller sensor	sensor
	1	L		T

DN	Item	Desc	ription	At shipment
33	Temperature unit select	0000: °C	0001: °F	0000: °C
5d	External static pressure High-ceiling adjustment (Air flow selection)	Refer to next page.		Depending on model type
60	Timer setting (wired remote controller)	0000: Available (can be performed)	0001: Unavailable (cannot be performed)	0000: Available
77	Dual set point	0000: Unavailable	0002: Available	0000: Unavailable
79	Alarm output setup of the header unit	0000: Not including the state of following unit	0001: Including the state of following unit	0000: Not including the state of following unit
b3	Soft cooling	0000: Unavailable	0001: Available	0001: Available
b5	Occupancy sensor/ Wireless Remote controller Provided / None	0000: None 0002: Wireless remote controll	0001: Occupancy sensor provided er provided	0000: None
b6	Occupancy sensor Enable / Invalid (Absence time judgment time)	0000: Invalid 0002: 60min. 0005: 150min.	0001: 30min. 0004: 120min.	0002: Enable (60 min.)
b7	Occupancy sensor operation at absent time	0000: Stand by	0001: operation stop	0000: Stand by
CF	4-way cassette type model name	0000: Standard Model	0001: Smart cassette	Depending on model type
d0	Whether the power saving mode can be set by the remote controller	0000: Invalid	0001: Valid	0001: Valid
E0	Destination	0000: Japan 0004: Global		0004: Global
E 6	Wireless remote controller A-B selection	0000: A	0001: B	0000: A
F0	Swing mode	0000 : Out of sync swing 0002 : Dual swing	0001 : 4-way sync swing 0003 : Cycle swing	0000: Not including 4-way 0001: 4-way (Compact)
F1	Louver fixed position (Louver No.1)	0000 : Release 0005 : Downward discharge po	0001 : Horizontal discharge position	0000: Not fixed
F2	Louver fixed position (Louver No.2)	0000 : Release 0005 : Downward discharge po	0001: Horizontal discharge position	0000: Not fixed
F3	Louver fixed position (Louver No.3)	0000 : Release 0005 : Downward discharge po	0001: Horizontal discharge position	0000: Not fixed
F4	Louver fixed position (Louver No.4)	0000 : Release 0005 : Downward discharge po	0001: Horizontal discharge position	0000: Not fixed
F6	Presence of Application control kit (TCB-PCUC2E)	0000: None	0001: Exist	0000: None
FC	Communication protocol *2	0000:TCC-LINK	0003:TU2C-LINK	0000: TCC-LINK
Fd	Priority operation mode	0000: Heating	0001: Cooling	0000: Heating
FE	(FS unit : Flow Selector unit) Flow Selector unit address		eries remote controller)	00Un/0099: Unfixed *1
105	Flow Selector unit and Shut- off Valve unit port address	0001: Port No.1 ~	0012: Port No.12	0001: Port No. 1
106	Combining branches mode of Flow Selector unit	0000: NOT combining mode	0001: Combining mode	0000: NOT combining mode
107	Safety measures	0000: No safety measures 0002: Individual shut-off operation	0001: Pump-down operation 0003: Leak Detector only	0001: Pump-down operation
108	Circulation flow operation mode of the indoor unit	0000: ON	0001: OFF	0000: ON

DN	ltem	Description	At shipment
180	Notice code number 01	0000: None 0001 ~ 0255 : Notice code	0000: None
181	Notice code number 02	0129 : Notice code (201) 0130 : Notice code (202) (0001 ~ 0255 : TU2C-LINK only)	0000: None
182	Notice code number 03	(1000) 0200 : 1020 2mm(omy)	0000: None
183	Notice code number 04		0000: None
184	Notice code number 05		0000: None
185	Notice code number 06		0000: None
186	Notice code number 07		0000: None
187	Notice code number 08		0000: None
188	Notice code number 09		0000: None
189	Notice code number 10		0000: None
103	Remote controller	0000: Use 0001: Do not use • Indoor unit production after Jun-2021 does not need this DN setting. The serial number is 1*6*0001 or upper.	0000: Use
1FB	Central device control state	0000: No central device control (Remote controller use is possible) 0001: Central device control (Remote controller use is impossible)	0000: No central device control
1FC	Indoor Unit terminating resistance	0000: OFF 0001: ON	0000: OFF

^{*1} Display order of "00Un" and "0099" varies depending on remote controller models or communication types.

For Central control address (DN [03]), Indoor unit address (DN [13]), Flow Selector unit address (DN [FE])

Remote controller	Communication type	Display order
II corios	TU2C-LINK	··· ⇔ 0128 ⇔ 00Un ⇔ 0001 ⇔ ···
U series	TCC-LINK	··· ⇔ 0064 ⇔ 00Un ⇔ 0001 ⇔ ···
Other than U series	TCC-LINK	··· ⇔ 0064 ⇔ 0099 ⇔ 0001 ⇔ ···

For Line address (DN [12])

Remote controller	Communication type	Display order
U series	TU2C-LINK	··· ⇔ 0128 ⇔ 00Un ⇔ 0001 ⇔ ···
U Series	TCC-LINK	··· ⇔ 0030 ⇔ 00Un ⇔ 0001 ⇔ ···
Other than U series	TCC-LINK	$\cdots \Leftrightarrow 0030 \Leftrightarrow 0099 \Leftrightarrow 0001 \Leftrightarrow \cdots$

For Group address (DN [14])

	/	
Remote controller	Communication type	Display order
U series	TU2C-LINK	··· ⇔ 0002 ⇔ 00Un ⇔ 0000 ⇔ ···
O Selles	TCC-LINK	↔ 0002 ↔ 00011 ↔ 0000 ↔
Other than U series	TCC-LINK	$\cdots \Leftrightarrow 0002 \Leftrightarrow 0099 \Leftrightarrow 0000 \Leftrightarrow \cdots$

^{*2} Communication protocol can be automatically switched with the setup in the outdoor unit during installation.

[5d] External static pressure & High-ceiling adjustment

<4-way Cassette, 2-way Cassette, 1-way Cassette SH Type>

Set data	High-ceiling adjustment
0000	Standard (Factory default)
0001	High ceiling 1
0003	High ceiling 3

<Compact 4-way Cassette>

Set data	High-ceiling adjustment	
0000	Standard (Factory default)	
0001	High ceiling 1 (UP015 only)	
0003	High ceiling 3 (UP015 only)	

Type DN code "10"

Value	Туре	Model
0000	1-way cassette	MMU-UP***SH*
0001	4-way cassette	MMU-UP***H*
0002	2-way cassette	MMU-UP***WH*
0010	Floor standing cabinet	MML-UP***H*
0011	Floor standing concealed	MML-UP***BH*
0013	Floor standing type	MMF-UP***H*
0014	Compact 4-way cassette	MMU-UP***MH*

Indoor Unit Capacity DN code "11"

■ 2-way cassette type

= = way babbbitto typo	
Value	Capacity
0000*	Invalid
0001	007 type
0003	009 type
0005	012 type
0007	015 type
0009	018 type
0011	024 type
0012	027 type
0013	030 type
0015	036 type
0017	048 type
0018	056 type

■ Floor standing cabinet type

Value	Capacity
0000*	Invalid
0001	007 type
0003	009 type
0005	012 type
0007	015 type
0009	018 type
0011	024 type

■ 1-way cassette type

Value	Capacity
0000*	Invalid
0007	015 type
0009	018 type
0011	024 type

■ 4-way cassette type

• 4-way casselle type	
Capacity	
Invalid	
009 type	
012 type	
015 type	
018 type	
024 type	
027 type	
030 type	
036 type	
048 type	
056 type	

■ Floor standing concealed type

- 1 1001 Star	ianing bonioce
Value	Capacity
0000*	Invalid
0001	007 type
0003	009 type
0005	012 type
0007	015 type
0009	018 type
0011	024 type

■ Compact 4-way cassette type

■ Compact 4-way casse	
Value	Capacity
0000*	Invalid
0041	005 type
0001	007 type
0003	009 type
0005	012 type
0007	015 type
0009	018 type

■ Floor standing type	
Value	Capacity
0000*	Invalid
0007	015 type
0009	018 type
0011	024 type
0012	027 type
0015	036 type
0017	048 type
0018	056 type

^{* &}quot;0000" is default value stored in EEPROM mounted on service P.C. board

8-6. Applied control of indoor unit

■ Control system using Remote location ON/OFF control box (TCB-IFCB-4E2)

Wiring and setting

• In the case of group control, the control system functions as long as it is connected to one of the indoor units (control P.C. board) in the group. If it is desired to access the operation and trouble statuses of other units, relevant signals must be brought to it from those units individually.

1. Control items

(1) Start / Stop input signal Start / stop of unit

(2) In-operation signal Output present while unit in normal operation

(3) Check code Output present while alarm (e.g. serial communication trouble or operation of


protective device for indoor / outdoor unit) being activated

2. Wiring diagram of control system using Remote location ON/OFF control box (TCB-IFCB-4E2)

Input IFCB-4E2: No-voltage ON / OFF serial signal

Output No-voltage contact (in-operation and check code indication)

Contact capacity: Max. AC 240 V, 0.5 A



Ventilating fan control from remote controller

[Function]

- The start / stop operation can be operated from the wired remote controller when air to air heat exchanger or ventilating fan is installed in the system.
- The fan can be operated even if the indoor unit is not operating.
- Use a fan which can receive the no-voltage normally-open contact as an outside input signal.
- In a group control, the units are collectively operated and they cannot be individually operated.

1. Operation

Handle a wired remote controller in the following procedure.

- * Use the wired remote controller during stop of the system.
- * Be sure to set up the wired remote controller to the header unit. (Same in group control)
- * In a group control, if the wired remote controller is set up to the header unit, both header and follower units are simultaneously operable.

<RBC-AMTU3*>

1 Push concurrently $\stackrel{\text{SET}}{\bigcirc} + \stackrel{\text{CL}}{\bigcirc} + \stackrel{\text{TEST}}{\cancel{\bigcirc}}$ buttons for 4 seconds or more.

The unit No. displayed firstly indicates the header indoor unit address in the group control. In this time, the fan of the selected indoor unit turns on.

2 Every pushing button (left side of the button), the indoor unit numbers in group control are displayed successively.

In this time, the fan of the selected indoor unit only turns on.

- 3 Using the setup temp vor button, specify the CODE No. 31.
- 4 Using the timer time ▼ or ▲ button, select the SET DATA. (At shipment: 0000)


The setup data are as follows:

SET DATA	Handling of operation of air to air heat exchanger or ventilating fan
0000	Unavailable (At shipment)
000 (Available

- 5 Push

 End button. (OK if display goes on.)
 - To change the selected indoor unit, go to the procedure 2).
 - To change the item to be set up, go to the procedure 3).
- 6 Pushing of returns the status to the usual stop status.
- * The ventilating fan control may be unavailable depending on the remote controllers. (RBC-ASCU11-* does not have this function.)

2. Wiring



Note) Determine the cable length between the indoor control P.C. board and the relay within 2m.

Auto-off feature control


[Function]

- This function controls the indoor units individually. It is used when the start operation from outside is unnecessary but the stop operation is necessary.
- A card switch box or card lock helps protect customers from forgetting to turn off the indoor unit. (not including the following Card Input 3)
- It is connected with connector on the indoor control P.C. board, and switched with the Code No. and jumper wire setup for use.
- Available connectors are CN61 or CN73. For models without CN73, CN4 on the optional Application control kit (TCB-PCUC2E) can be used.
- * Leaving-ON prevention control cannot be set with both CN61 and CN73 (CN4). If both of them are set, CN73 (CN4) setting automatically turns to a factory default.

[Setup method]

(1) Wiring


Connecting to the CN61 connector



Outside contact (Card switch box, etc: Procured locally)

NOTE) Determine the cable length between the indoor control P.C. board and the relay within 3m.

Connecting to the Application control kit (TCB-PCUC2E, connector: CN4)



Outside contact (Card switch box, etc: Procured locally)

 $\textbf{NOTE)} \ \ \textbf{Determine the cable length between the indoor control P.C. board and the relay within 3m.}$

(2) Code (DN) setup

Set Code (DN) according to "8-5. Method to set indoor unit function DN code".

Connector Jumper wire (J01)		Code No. (DN)	Set data	Function
		002E	0000 (Factory default)	"HA normal setup" (pulse)
	Short-circuit (Factory default)		0001	"Card Input 1" setup
			0003	"Card Input 2" setup
CN61			0005	"Card Input 5" setup
	Open-circuit (cut)		0000 (Factory default)	"HA normal setup" (Static)
			0001	"Card Input 3" setup
			0003	"Card Input 4" setup
		000Ь	0000 (Factory default)	"EXCT demand" setup (Forced thermostat-OFF)
	Short-circuit		0002	"Card Input 3" setup
CN73	(Factory default) or Open-circuit (cut)		0004	"Card Input 4" setup
(CN4)			0007	"Card Input 5" setup
			0008	"Card Input 1" setup
			0009	"Card Input 2" setup

^{*} If you set "Card Input 1 to 5" for Code No. of CN61 and CN73, Code No. 000b setup becomes unavailable and the functions of Card Input 1 to 5 in CN73 cannot be used.

[Control items]

Function	External contact terminal							
runction	Close (Status that card is inserted)	Open (Status that card is taken out)						
Card Input 1	Manual prohibition release (Manual operation)	Manual prohibition (Operation stop)						
Card Input 2	Manual prohibition release (Automatic operation)	Manual prohibition (Operation stop)						
Card Input 3	Operation status continues (Do nothing)	Operation status continues and setting temperature changes (COOL/DRY: 29°C, HEAT: 18°C)						
Card Input 4	Manual prohibition release (The status returns to operating condition before removing the card.)	Manual prohibition (Operation stop)						
Card Input 5	1) To change a setting temperature by changing data at DN code No. 172 to 174. 2) The operation mode can be set by changing data (0000, 0001, 0002) at DN code No. 16b. 0000: operation mode is the same at the current mode. (factory setting default) 0001: operation mode returns to the previous mode when card was inserted. (in case of the previous mode is off operation, the operation mode is also off.) 0002: operation mode starts at the same previous mode when the card was inserted. (the operation mode is on operation even the previous mode is off operation.) See contents below for DN settings and detailed operations.	1) To change a setting temperature, fan speed and wind direction by changing data at DN code No. 16C to 171. 2) The operation mode can be set by changing data (0000, 0001) at DN code No. 16A. 0000: operation mode is the same at the current mode. (factory setting default) 0001: operation automatically starts. See contents below for DN settings and detailed operations.						

^{*} For the card switch box that does not involve contact operation described above, convert signals with a relay including a normally-closed contact.

[Card input setup.5 Code (DN)]

DN	ltem	Description	At shipment
16C	Open mode Set temp. (Cool, Dry)	-0015 : -15°C to 0060 : 60°C	0027 : 27°C
16d	Open mode Set temp. (Heat)	-0015 : -15°C to 0060 : 60°C	0020 : 20°C
16E	Open mode Set temp. (Auto)	-0015 : -15°C to 0060 : 60°C	0024 : 24°C
16F	Open mode Fan speed (All operation mode)	0000 : No change	0000 : No change
170	Open mode Wind direction (Cool, Dry, Fan)	0000 : No change	0000 : No change
171	Open mode Wind direction (Heat)	0000 : No change	0000 : No change
16A	Open mode Operation	0000 : No change 0001 : Run operation	0000 : No change
172	Close mode Set temp. (Cool, Dry)	-0015 : -15°C to 0060 : 60°C	0024 : 24°C
173	Close mode Set temp. (Heat)	-0015 : -15°C to 0060 : 60°C	0024 : 24°C
174	Close mode Set temp. (Auto)	-0015 : -15°C to 0060 : 60°C	0024 : 24°C
16b	Close mode Operation	0000 : No change 0001 : Card ON mode operation 0002 : Run operation (Card ON mode setting)	0000 : No change

[The example of Card Input 5 setting]


_	Code No. (DN) setting								External con	tact terminal	
Case.	[16A] data	[16b] data	[16C] data	[16d] data	[16F] data	[170] data	[171] data	[172] data	[173] data	Close (Status that card is inserted)	Open (Status that card is taken n out)
(1)	0000	0000	0027	0020	0000	0000	0000	0024	0024	 The operation mode continues running at the same as the current mode. The setting temperature of cooling/dry and heating mode is changed to 24°C and 24°C respectively due to change in code No. 172, 173. 	The operation mode continues running at the same as the current mode. The setting temperature of cooling/dry and heating mode is changed to 27°C and 20°C respectively due to change in code No. 16C, 16d.
(2)*	0000	0001	0027	0020	0003	0001	0001	0024	0024	 The operation mode is running at the same mode as the last time when the card was inserted due to change in code no. 16b. * The operation mode will be off if the mode at the last time was in off operation. Also, the fan speed will the same as the last time when the card is inserted. • The setting temperature of cooling/dry and heating mode is changed to 24°C and 24°C respectively due to change in code No. 172, 173. 	The operation mode continues running at the same as the current mode. The setting temperature of cooling/dry and heating mode is changed to 27°C and 20°C respectively due to change in code no. 172, 173. The fan speed for all operation modes is changed due to change in code no.16F. The wind direction of Cooling/dry/fan and heating mode are changed due to change in code No. 170, 171 respectively.
(3)*	0000	0002	0027	0020	0003	0001	0001	0024	0024	The operation mode is running at the same mode as the last time when the card was inserted. Also, the operation mode will be on even the mode was in off operation at the last time due to change in code no. 16B. The fan speed will the same as the last time when the card is inserted. The setting temperature of cooling/dry and heating mode is changed to 24°C and 24°C respectively due to change in code No. 172, 173.	Same operation as case (2)
(4)	0001	0000	0027	0020	0003	0001	0001	0024	0024	The operation mode continues running at the same as the current mode. The setting temperature of cooling/dry and heating mode is changed to 24°C and 24°C respectively due to change in code No. 172, 173.	Due to change in code no. 16A, the operation mode will be as below. When the operation is ON, the operation mode will continue running at the same as the current mode. When the operation is OFF, the air conditioner will turn on automatically. The setting temperature of cooling/dry and heating mode is changed to 27°C and 20°C respectively due to change in code No. 172, 173. The fan speed for all operation modes is changed due to change in code no.16F. The wind direction of Cooling/dry/fan and heating mode are changed due to change in code No. 170, 171 respectively.

^{*} The history operation mode is only recorded when the card is inserted even if the operation mode is changed when the card is taken out, there is no related to the history operation mode.

■ Power peak-cut from indoor unit

When the relay is turned on, a forced thermostat OFF operation starts.

• For indoor P.C. boards other than MCC-1643, the "EXCT" is input with connector CN73 on the P.C. board. MCC-1643 requires Application control kit (TCB-PCUC2E) for input of a forced thermostat OFF "EXCT". Please refer to the manual of Application control kit for a detailed setting.



Note) Determine the cable length between the indoor or outdoor control P.C. board and the relay within 2 m.

■ Notice code signal

Notice code is a function dedicated to TU2C-LINK communication.

See service manual for u series outdoor unit for details of Notice code.


[Function]

- Notice Code is issued if there is signal input to connector of outdoor unit P.C. board. This can be used in cases such as when confirming state of outdoor unit (filter clogging, etc.) by air conditioner system.
- Connector that can be used is CN61 or CN73. CN4 of separately-sold "option input/output P.C. board (TCB-PCUC2E)" can be used for models that do not have CN73.
- Used by switching functions with settings of Code No. (DN Code).
- · Notice Code is continuously issued while input signal is ON.

[Setup method]


(1) Wiring

Connecting to the CN61 connector



Note) Determine the cable length between the indoor control P.C. board and the relay within 3m.

Connecting to the Application control kit (TCB-PCUC2E, connector : CN4)



Note) Determine the cable length between the indoor control P.C. board and the relay within 3m.

(2) Code (DN) setup and Notice code

Set Code (DN) according to "8-5. Method to set indoor unit function DN code".

Connector	Code No. (DN)	Set data	Notice code	
CN61	002E	0004	201	
CN73 (CN4)	000B	0006	202	

^{*} Setting of Code No. (DN Code) is necessary to display Notice code mark at remote controller.

Set data corresponding to Notice code to be used to one of Code No. 180 to 189, in accordance with following table.

In case where data other than 0000 is already set, set to other Code No. (DN Code).


Code No. (DN)	Set data	Notice code
0180	0000	OFF (Factory default)
to	0129	201
0400		
0189	0130	202

^{*} It may take up to ten minutes to be displayed on remote controller after Notice code is issued.

Manual address setting using the remote controller


Procedure when setting indoor units' addresses first under the condition that indoor wiring has been completed and outdoor wiring has not been started (manual setting using the remote controller)

▼ Wiring example of 2 refrigerant lines



In the example above, disconnect the remote controller connections between the indoor units and connect a wired remote controller to the target unit directly before address setting.

<RBC-AMTU3*>



Pair the indoor unit to set and the remote controller one-to-one.

Turn on the power.

1 Push and hold the ○ , ○ and ▷ buttons at the same time for more than 4 seconds. LCD starts flashing.

<Line (system) address>

- $oldsymbol{2}$ Push the TEMP. $oldsymbol{oldsymbol{ o}}$ / $oldsymbol{oldsymbol{ o}}$ buttons repeatedly to set the CODE No. to $oldsymbol{oldsymbol{arepsilon}}$.
- **3** Push the TIME \(\textstyle \) / \(\textstyle \) buttons repeatedly to set a system address.

 (Match the address with the address on the interface P.C. board of the header outdoor unit in the same refrigerant line.)
- **4** Push button. (It is OK if the display turns on.)

<Indoor unit address>

- **5** Push the TEMP. \(\to \) / \(\to \) buttons repeatedly to set the CODE No. to \(\frac{1}{3} \) .
- **6** Push the TIME 🛡 / 🕒 buttons repeatedly to set an indoor unit address.
- **7** Push the ^{SET} button. (It is OK if the display turns on.)

<Group address>

- **8** Push the TEMP. 💌 / 🖎 buttons repeatedly to set the CODE No. to 🖽 .
- **9** Push the TIME \bigcirc / \bigcirc buttons repeatedly to set a group address. If the indoor unit is individual, set the address to 0000; header unit, 000 1; follower unit, 0002.

Individual : 0000
Header unit : 0001
Follower unit : 0001 } In case of group control

10 Push the $\stackrel{\text{SET}}{\bigcirc}$ button.


(It is OK if the display turns on.)


11 Push the button.

The address setting is complete.

(SETING flashes. You can control the unit after SETING has disappeared.)

<RBC-ASCU11-*>







- **1** Push and hold the [menu + ∇] buttons at same time for more than 10 seconds.
- **2** Push the [OFF timer] button to confirm the selected indoor unit.

<Line (system) address>

- **3** Push the [menu] button until the CODE No. flashes. And using the [∇ or \triangle] buttons, specify the CODE No.12.
- **4** Push the [menu] button until the SET DATA flashes. And using the [∇ or \triangle] buttons, set a system address.
- **5** Push the [OFF timer] button to confirm the SET DATA.

<Indoor unit address>

- Push the [menu] button until the CODE No. flashes. And using the [∇ or \triangle] buttons, specify the CODE No.13.
- $m{4}$ Push the [menu] button until the SET DATA flashes. And using the [abla or igtriangle] buttons, set an indoor unit address.
- **5** Push the [OFF timer] button to confirm the SET DATA.

<Group address>

- $m{3}$ Push the [menu] button until the CODE No. flashes. And using the [abla or igtriangle] buttons, specify the CODE No.14.
- $m{4}$ Push the [menu] button until the SET DATA flashes. And using the [abla or \triangle] buttons, set a group address.

If the indoor unit is individual, set the address to 0000. (header unit: 0001, follower unit: 0002)

Individual :0000

Header unit :0001 In case of group control

- **5** Push the [OFF timer] button to confirm the SET DATA.
- When all the settings have been completed, push the [ON/OFF] button to return to normal mode.

NOTE

< In the case of combining with outdoor units of U series (SMMS-u etc.)>

- Turn ON DIP switch 1 of SW100 on the header outdoor unit interface P.C. board the lowest system address
- · After finishing all the settings above, set the address of the central control devices. (For the setting of the central control address, refer to the installation manual of the central control devices.)

< In the case of combining with outdoor units other than U series>

- Set a system address for the header outdoor unit of each line with SW13 and 14 of their interface P.C. boards.
- Turn off dip switch 2 of SW30 on the interface P.C. boards of all the header outdoor units connected to the same central control, except the unit that has the lowest address. (For unifying the termination of the wiring for the central control of indoor and outdoor units)
- · Connect the relay connectors between the [U1, U2] and [U3, U4] terminals on the header outdoor unit of each refrigerate line.
- · After finishing all the settings above, set the address of the central control devices. (For the setting of the central control address, refer to the installation manuals of the central control devices.)


■ Confirming the indoor unit addresses and the position of an indoor unit using the remote controller

♦ Confirming the numbers and positions of indoor units

To know the indoor unit addresses though position of the indoor unit is recognized

▼ When the unit is individual (the indoor unit is paired with a wired remote controller one-to-one), or it is a group-controlled one.

<RBC-AMTU3*>



(Execute it while the units are running.)

- **1** Push the $\stackrel{\text{(JON/OFF}}{\longrightarrow}$ button if the units stop.
- 2 Push the button (left side of the button).

A unit numbers • is indicated on the LCD (it will disappear after a few seconds). The indicated number shows the system address and indoor unit address of the unit.

When 2 or more indoor units are connected to the remote controller (group-controlled units), a number of other connected units appears each time you push the UNIT LOUVER button (left side of the button).


<RBC-ASCU11-*>

There is no such function in the remote controller.

♦ To find an indoor unit's position from its address

▼ When checking unit numbers controlled as a group






(Execute it while the units are stopped.)


The indoor unit numbers in a group are indicated one after another. The fan and louvers of the indicated units are activated.

- **1** Push and hold the $\frac{\sqrt{ENT}}{2}$ and $\frac{TEST}{2}$ buttons at the same time for more than 4 seconds.
 - RLL appears on UNIT No. on the LCD display.
 - The fans and louvers of all the indoor units in the group are activated.
- 2 Push the button (left side of the button). Each time you push the button, the indoor unit numbers are indicated one after another.
 - The first-indicated unit number is the address of the header unit.
 - · Only the fan and louvers of the indicated indoor unit are activated.
- **3** Push the button to finish the procedure.

 All the indoor units in the group stop.

<RBC-ASCU11-*>






- 1 Push and hold the [menu + ∇] buttons at same time for more than 10 seconds. e.g.)A unit number 1-1 is indicated on the LCD. The indicated number shows the system address and indoor unit address of the unit.
- **2** When 2 or more indoor units are connected to the remote controller (group-controlled units), a number of other connected units appears each time you push the [∇ or \triangle] buttons.
- **3** Push the [ON/OFF] button, return to the normal mode.

▼ To check all the indoor unit addresses using an arbitrary wired remote controller.

(When communication wirings of 2 or more refrigerant lines are interconnected for central control)

<RBC-AMTU3*>



(Execute it while the units are stopped.)

You can check indoor unit addresses and positions of the indoor units in a single refrigerant line. When an outdoor unit is selected, the indoor unit numbers of the refrigerant line of the selected unit are indicated one after another and the fan and louvers of the indicated indoor units are activated.

- 1 Push and hold the TIME

 and buttons at the same time for more than 4 seconds. At first, the line 1 and CODE No. □ (Address Change) are indicated on the LCD display. (Select an outdoor unit.)
- 2 Push the button (left side of the button) and buttons repeatedly to select a system address.
- **3** Push the $\stackrel{\text{\tiny SET}}{\bigcirc}$ button to confirm the system address selection.
 - The address of an indoor unit connected to the selected refrigerant line is indicated on the LCD display and its fan and louvers are activated.
- 4 Push the button (left side of the button). Each time you push the button, the indoor unit numbers of the selected refrigerant line are indicated one after another.
 - Only the fan and louvers of the indicated indoor unit are activated.
- **♦** To select another system address
- **5** Push the $\overset{\alpha}{\bigcirc}$ button to return to step 2.
 - After returning to step 2, select another system address and check the indoor unit addresses of the line.
- **6** Push the $\overset{\text{TEST}}{\varnothing}$ button to finish the procedure.

<RBC-ASCU11-*>


There is no such function in the remote controller.

♦ Changing the indoor unit address using a remote controller

To change an indoor unit address using a wired remote controller.

▼ The method to change the address of an individual indoor unit (the indoor unit is paired with a wired remote controller one-to-one), or an indoor unit in a group.
(The method is available when the addresses have already been set automatically.)


<RBC-AMTU3*>



(Execute it while the units are stopped.)

- 1 Push and hold the \bigcirc , \bigcirc , and \bigcirc buttons at the same time for more than 4 seconds. (If 2 or more indoor units are controlled in a group, the first indicated UNIT No. is that of the head unit.)
- Push the button (left side of the button) repeatedly to select an indoor unit number to change if 2 or more units are controlled in a group. (The fan and louvers of the selected indoor unit are activated.)

 (The fan of the selected indoor unit is turned on.)
- **3** Push the TEMP. **▼** / **△** buttons repeatedly to select **13** for CODE No.
- **4** Push the TIME / buttons repeatedly to change the value indicated in the SET DATA section to that you want.
- **5** Push the $\stackrel{\text{\tiny SET}}{\bigcirc}$ button.
- **6** Push the button (left side of the button) repeatedly to select another indoor UNIT No. to change.
- Repeat steps 4 to 6 to change the indoor unit addresses so as to make each of them unique.
- 7 Push the only button (left side of the button) to check the changed addresses.
- **8** If the addresses have been changed correctly, push the button to finish the procedure.



- **1** Push and hold the [menu + ∇] buttons at same time for more than 10 seconds.
- **2** Push the [OFF timer] button to confirm the selected indoor unit.
- **3** Push the [menu] button until the CODE No. flashes. And using the [∇ or \triangle] buttons, specify the CODE No.13.
- **4** Push the [menu] button until the SET DATA flashes. And using the [∇ or \triangle] buttons, set an indoor unit address.
- **5** Push the [OFF timer] button to confirm the SET DATA.
- 6 When all the settings have been completed, push the [ON/OFF] button, return to normal mode.

▼ To change all the indoor unit addresses using an arbitrary wired remote controller. (The method is available when the addresses have already been set automatically.)


(When communication wirings of 2 or more refrigerant lines are interconnected for central control)


NOTE

You can change the addresses of indoor units in each refrigerant line using an arbitrary wired remote controller.

* Enter the address check / change mode and change the addresses.

<RBC-AMTU3*>





If no number appears on UNIT No., no outdoor unit exists on the line. Push button and select another line following step 2.

(Execute it while the units are stopped.)

- 1 Push and hold the TIME ▼ / ♠ buttons at the same time for more than 4 seconds. At first, the line 1 and CODE No. RL (Address Change) are indicated on the LCD display.
- 2 Push button (left side of the button) and buttons repeatedly to select a system address.
- **3** Push the $\stackrel{\text{SET}}{\bigcirc}$ button.
 - The address of one of the indoor units connected to the selected refrigerant line is indicated on the LCD display and the fan and louvers of the unit are activated.
 At first, the current indoor unit address is displayed in SET DATA. (No system address is indicated.)
- **4** Push the TIME ▼ / ♠ buttons repeatedly to change the value of the indoor unit address in SET DATA.

Change the value in SET DATA to that of a new address.

- **5** Push the $\overset{\text{to}}{\bigcirc}$ button to confirm the new address on SET DATA.
- **6** Push the button (left side of the button) repeatedly to select another address to change.

Each time you push the button, the indoor unit numbers in a refrigerant line are indicated one after another. Only the fan and louvers of the selected indoor unit are activated.

Repeat steps 4 to 6 to change the indoor unit addresses so as to make each of them unique.

7 Push the $\stackrel{\text{se}}{\bigcirc}$ button.

(All the segments on the LCD display light up.)

8 Push the $\stackrel{\text{\tiny TEST}}{\triangleright}$ button to finish the procedure.

<RBC-ASCU11-*>

There is no such function in the remote controller.

◆ Check code clearing function


How to clear the check code using the wired remote controller

<RBC-AMTU3*>

- ▼ Clearing a check code of the outdoor unit Clear the currently detected outdoor unit for each refrigerant line to which the indoor unit controlled by the remote controller is connected. (The indoor unit check code is not cleared.) Use the service monitoring function of the remote controller.
- Push and hold the [™]O, and [™]O for 4 seconds or longer to enter the service monitoring mode.
- **2** Push the ♥ button to set CODE No. to "FF".
- **3** The display in A of the following figure counts down as follows at 5-second intervals: "0005" \rightarrow "0004" \rightarrow "0003" \rightarrow "0002" \rightarrow "0000".

The check code is cleared when "**DDDD**" appears. However, the display counts down from "**DDD5**" again.

4 Push the $\stackrel{\text{\tiny LESI}}{\bigcirc}$ to return the display to normal.




▼ Clearing a check code of the indoor unit

Push the

(Only the check code of the indoor unit controlled by the remote controller will be cleared.)

<RBC-ASCU11-*>


▼ Clearing a check code of the outdoor unit Clear the currently detected outdoor unit for each refrigerant line to which the indoor unit controlled by the remote controller is connected. (The indoor unit check code is not cleared.) Use the service monitoring function of the remote controller.



- **1** Push the [menu] button for over 10 seconds.
- **2** Every pushing [∇ or \triangle] buttons, the indoor unit numbers in group control are displayed successively.
- 3 Push the [OFF timer] button to confirm the selected indoor unit.
- **4** Every pushing [∇ or \triangle] buttons to set CODE No. to "FF"
- **5** The display in A of the following figure counts down as follows at 5-second intervals: "0005" \rightarrow "0004" \rightarrow "0003" \rightarrow "0002" \rightarrow "0000" The check code is cleared when "000" appears. However, the display counts down from "005" again.
- 6 After you have finished checking, push the [ON/OFF] button to return to normal mode.
- ▼ Clearing a check code of the indoor unit
 Push the ON / OFF button on the remote controller.
 (Only the check code of the indoor unit controlled by the remote controller will be cleared.)

▼ Monitoring function of wired remote controller

<RBC-AMTU3*>




Content

Enter the service monitoring mode using the remote controller to check the sensor temperature or operation status of the remote controller, indoor unit, and outdoor unit.

- 1 Push and hold the [™] , and [™] for 4 seconds or longer to enter the service monitoring mode.
 - The service monitor lights up. The CODE No. 22 appears at first.
- 2 Push the 🕁 button to change to CODE No. of the item to monitor. Refer to the next page for CODE No.
- **3** Push the left part of the button (left side of the button) to change to the item to monitor. Monitor the sensor temperature or operation status of the indoor unit and outdoor unit in the refrigerant line.
- **4** Push the button to return the display to normal.

<RBC-ASCU11-*>



- **1** Push the [menu] button for over 10 seconds. "Monitoring function" is displayed on a screen.
- **2** Every pushing [∇ or \triangle] buttons, the indoor unit numbers in group control are displayed successively.
- 3 Push the [OFF timer] button to confirm the selected indoor unit.
- 4 Every pushing [∇ or \triangle] buttons, CODE No. of the item is changed successively.
- **5** After you have finished checking, push the [ON/OFF] button, return to normal mode.

◆ Indoor service monitor list

	Code No.	Data name	Display format	Unit	Remote controller display example
	00	Room temperature (Use to control)	×1	°C	
	01	Room temperature (Remote controller)	×1	°C	
	02	Indoor suction air temperature (TA)	×1	°C	
	03	Indoor coil temperature (TCJ)	×1	°C	
data *	04	Indoor coil temperature (TC2)	×1	°C	
	05	Indoor coil temperature (TC1)	×1	°C	
r unit	06	Indoor discharge air temperature (TF) **	×1	°C	
Indoor	07	Indoor fan motor number of revolutions**	×1	rpm	[0600] = 600rpm
=	08	Indoor PMV opening	×1/10	pls	[0150]=1500pls
	E5	Secondary heating output	_	_	[0000] = OFF, [0001] = ON
	F3	Filter sign time	×1	h	[2500] = 2500h
	F9	Suction temperature of air to air heat exchanger (TSA) **	×1	°C	[0024] = 24°C
	FA Outside air temperature (TOA) **		×1	°C	

^{*} When the units are connected to a group, data of the header indoor unit only can be displayed.
** There is also a model which cannot be displayed.

[•] Refer to the service manual of an outdoor unit for "outdoor service monitor list".

9. TROUBLESHOOTING

9-1. Overview

- (1) Before engaging in troubleshooting
 - (a) Applicable models
 - All Super Modular Multi System (SMMS-*, SHRM-*) models.
 - (b) Tools and measuring devices required
 - Screwdrivers (Philips, flat head), spanners, long-nose pliers, nipper, pin to push reset switch, etc.
 - Multimeter, thermometer, pressure gauge, etc.
 - (c) Things to check prior to troubleshooting (behaviors listed below are normal)


NO.	Behavior	Possible cause
1	A compressor would not start	The air conditioner is being controlled by the 3-minute protective function. It is in standby status though the room temperature has reached the setup temperature. It is being operated in timer mode or fan mode. It is being in initial communication.
2	An indoor fan would not start	• The air conditioner is being controlled by the cool air discharge preventive function in "heating"?
3	An outdoor fan would not start or would change speed for no reason	The air conditioner is being operated in "cooling" under the low outside air temperature. It is being operated in defrost operation.
4	An indoor fan would not stop	The air conditioner is being controlled by function of residual heat elimination being performed as part of the air conditioner shutdown process after heating operation.
5	The air conditioner would not respond to a start/stop command from a remote controller	The air conditioner is being operated under external or remote controller.

CAUTION

The cooling performance may be declining considerably when total operating capacity of cooling indoor units is less than 4 HP while ambient temperature is below.

(2) Troubleshooting procedure

When a problem occurs, proceed with troubleshooting in accordance with the procedure shown below.



NOTE

Rather than a product trouble (see the List of Check Codes below), the problem could have been caused by a microprocessor malfunction attributable to a poor quality of the power source or an external noise. Check for possible noise sources, and shield the remote controller wiring and signal wires as necessary.

9-2. Troubleshooting method

The remote controllers (main remote controller and central control device) and the interface P.C. board of an outdoor unit are provided with an a 7-segment display (outdoor interface P.C. board) to display operational status. Using this selfdiagnosis feature, the trouble site / trouble part may be identified in the event of a trouble by following the method described below.

The list below summarizes check codes detected by various devices. Analyze the check code according to where it is displayed and work out the nature of the trouble in consultation with the list.

- · When investigating a trouble on the basis of a display provided on the indoor remote controller or central control device - See the "central control device or main remote controller display" section of the list.
- · When investigating a trouble on the basis of a display provided on an outdoor unit See the "Outdoor 7- segment display" section of the list.
- · When investigating a trouble on the basis of a wireless remote controller-controlled indoor unit See the "Indicator light block" section of the list.

List of check codes (indoor unit)

(Check code detected by indoor unit)

IPDU: Compressor / Fan inverter P.C. board

○: Lighting, ⊚: Flashing, ●: Goes off
ALT: Flashing is alternately when there are two flashing LED
SIM: Simultaneous flashing when there are two flashing LED

	Ch	eck code	Display	of rec	ceivino	unit	SIIVI. 3	Simultaneous flashing when there are two flashing LED
_		loor 7-segment display		ator li				
Remote controller display		Sub-code	Operatio			Flash	Typical trouble on site	Description of check code
E03	-	-	0	•	•		Indoor-remote controller periodic communication check code	Communication from remote controller or network adaptor has been lost (so has central control communication).
E04	-	-	•	•	0		Indoor-outdoor periodic communication check code	Signals are not being received from outdoor unit.
E08	E08	Duplicated indoor address	0	•	•		Duplicated indoor address	Indoor unit detects address identical to its own.
E10	_	_	0	•	•		Communication trouble between indoor unit MCU	Communication trouble between main MCU and the motor microcomputer MCU
E11	-	_	0	•	•		Communication check code between Application control kit and indoor unit	Communication check code between Application control kit and indoor unit P.C. board
E17	_	-	0	•	•		Communication trouble between indoor unit(s) and Flow Selector (FS) unit(s)	There is no communication from FS unit(s).
E18	-	_	0	•	•		Check cod in periodic communication between indoor header and follower unit	Periodic communication between indoor header and follower units cannot be maintained.
F01	_	-	0	0	•	ALT	Indoor heat exchanger temperature sensor (TCJ) check code	Heat exchanger temperature sensor (TCJ) has been open / short-circuit.
F02	_	-	0	0	•	ALT	Indoor heat exchanger temperature sensor (TC2) check code	Heat exchanger temperature sensor (TC2) has been open / short-circuit.
F03	_	-	0	0	•	ALT	Indoor heat exchanger temperature sensor (TC1) check code	Heat exchanger temperature sensor (TC1) has been open / short-circuit.
F10	-	=	0	0	•	ALT	Ambient temperature sensor (TA) check code	Ambient temperature sensor (TA) has been open / short-circuit.
F11	_	_	0	0	•	ALT	Discharge temperature sensor (TF) check code	Discharge temperature sensor (TF) has been open / short-circuit.
F29	-	-	0	0	•	SIM	P.C. board or other indoor check code	Indoor EEPROM is abnormal (some other trouble may be detected).
F30	-	-	0	0	0	ALT	Occupancy sensor trouble	There is no signal from Occupancy sensor.
J29	-	-	•	0	0	SIM	Leak Detector Trouble	There is no communication from Leak Detector. Received a malfunction signal from Leak Detector.
J30		Detected indoor unit address * Not displayed depending on the DN code (I.DN) setting	•	0	0	SIM	Refrigerant leak detection.	Leak Detector detects refrigerant leak.
J31	_	_	•	0	0	SIM	Refrigerant leak detection sensor exceeding its life of the product	Energization time of the Leak Detector has reached its useful life.
L03	_	_	0	•	0	SIM	Duplicated indoor group header unit	There is more than one header unit in group.
L07	-	-	0	•	0	SIM	Connection of group control cable to a single indoor unit	There is at least one a single indoor unit to which group control cable is connected.
L08	L08	-	0	•	0	SIM	Indoor group address not set	Address setting has not been performed for one or more indoor units (also detected at outdoor unit end).
L09	_	_	0	•	0	SIM	Indoor capacity not set	Capacity setting has not been performed for indoor unit.
L20	_	_	0	0	0	SIM	Duplicated central control address	There is duplication in central control address setting.
L22	_	_	0	0	0	SIM	DX-kit (heat source capacity command) non-compliant equipment in the group.	There is a DX-kit (heat source capacity command) non-compliant equipment in the group. (DDC control, TA control and TF control are mixed.)
L30	L30	Detected indoor unit No.	0	0	0	SIM	Indoor external check code input (interlock)	Unit shutdown has been caused by external check code input (CN80).
P01	_	-	•	0	0	ALT	Indoor AC fan check code	Indoor AC fan check code is detected (activation of fan motor thermal relay).
P10	P10	Detected indoor unit No.	•	0	0	ALT	Indoor overflow check code	Float switch has been activated.
P12	_	_	•	0	0	ALT	Indoor DC fan check code	Indoor DC fan check code (e.g. overcurrent or lock-up) is detected.
P31	_		0	•	0	ALT	Other indoor unit check code	Follower unit cannot be operated due to header unit alarm (E03 /L03 / L07 / L08).

(Check code detected by remote controller)

Che	ck co	ode	Display	of re	ceiving	j unit		
	Outo	loor 7-segment display	Indica	ator li	ight blo	ock	Typical trouble site	Description of check code
Remote control		Sub-code	Operation	Timer	Ready	Flash		Description of check code
E01	-	-	0	•	•		No master remote control, failure remote control communication (reception)	Signals cannot be received from indoor unit; master remote control has not been set (including two remote control).
E02	-	-	0	•	•		Failure remote control communication (transmission)	Signals cannot be transmitted to indoor unit.
E09	_	-	0	•	•		Duplicated master remote control	Both remote controls have been set as master remote control in two remote control (alarm and shutdown for header unit and continued operation for follower unit)

(Check code detected by central control device)

Ch	eck co	ode	Display of receiving	g unit		
	Outdoor 7-segment display		Indicator light blo	ock	Typical trouble site	Description of check code
Central control		Sub-code	Operation Timer Ready	Flash		Description of check code
C05	-	-	No indication (when main remote contro		Failure central control communication (transmission)	Central control device is unable to transmit signal due to duplication of central control device
C06	-	-	also in use)		Failure central control communication (reception)	Central control device is unable to receive signal.
C12	-	-	-		Bracket alarm for general- purpose device control interface	Device connected to general-purpose device control interface is trouble.
P30 (L20)	_	-	(L20 is displayed.)		Communication Link	Duplication addresses of indoor units in central control device With the combination of air conditioning system, the indoor unit may detect the check code of L20
S01	-	-				Receiving trouble in central control device.

Note: The same trouble, e.g. a communication trouble, may result in the display of different check codes depending on the device that detects it. Moreover, check codes detected by the main remote controller / central control device do not necessarily have a direct impact on air conditioner operation.

Flow selector unit (FS unit) Relation

(Check code detected by indoor unit or outdoor unit)

Che	Check code		Display	of re	ceiving	g unit		
	Outo	loor 7-segment display	Indicator light block				Typical trouble site	Description of trouble
Main remote control		Sub-code	Operation (1)	Timer	Ready	Flash	Typical trouble site	Description of trouble
E17	-	-	0	•	•		Communication trouble between indoor unit (s) and FS unit (s)	There is no communication from FS unit(s)
J01	_	-	•	0	0	SIM	Communication trouble between indoor unit (s) and FS unit (s)	There is no communication from indoor unit (s)
J02	-	-	•	0	0	SIM	Communication trouble between control boards in FS unit	Communication trouble between PC boards of multiport type FS unit.
J03	-	-	•	0	0		Duplicated FS units	More than one FS units have been set up in one refrigerant line.
J10	-	-	•	0	0		FS unit overflow trouble	FS unit has been shutdown in one refrigerant line due to detection of overflow
J11	-	-	•	0	0		FS unit temperature sensor (TCS) trouble	FS unit temperature sensor (TCS) has been open/short-circuited.

List of Check Codes (Outdoor Unit)

(Check code detected by outdoor interface - typical examples)

If "HELLO" is displayed on the oudoor 7-segment for 1 minute or more, turn off the power supply once and then turn on the power supply again after passage of 30 seconds or more. When the same symptom appears, it is considered there is a possibility of I/F board trouble.

○ : Lighting, ⊚ : Flashing, ● : Goes off ALT.: Flashing is alternately when there are two flashing LED SIM: Simultaneous flashing when there are two flashing LED

	Check code		Displa	y of rec	eiving	unit		
	Outdoor 7-segment display	Central	Indic	ator lig	ght blo	ock	Tomical machiam aita	Description of sheet and
	Sub-code	control or main remote controller display	Operation	n Timer	Ready	Flash	Typical problem site	Description of check code
E06	Number of indoor units from which signal is received normally	E06	•	•	0		Signal lack of indoor unit	Indoor unit initially communicating normally fails to return signal (reduction in number of indoor units connected). In TU2C-LINK communication system, if the termination resistance is not set in any of the indoor units. The number of indoor units connected is decreasing. (Detected when power is turned on)
E07	_	(E04)	•	•	0		Indoor-outdoor communication circuit trouble	Signal cannot be transmitted to indoor units (→ indoor units left without communication from outdoor unit).
E08	Duplicated indoor address	(E08)	0	•	•		Duplicated indoor address	More than one indoor unit are assigned same address (also detected at indoor unit end).
E12	01: Indoor-outdoor communication 02: Outdoor-outdoor communication	E12	0	•	•		Automatic address starting trouble	Indoor automatic address setting is started while automatic address setting for equipment in other refrigerant line is in progress. Outdoor automatic address setting is started while automatic address setting for indoor units is in progress.
E15	-	E15	•	•	0		Indoor unit not found during automatic address setting	Indoor unit fails to communicate while automatic address setting for indoor units is in progress.
E16	00: Capacity over 01: Number of units connected	E16	•	•	0		Too many indoor units connected/capacity over	Combined capacity of indoor units is too large. The maximum combined of indoor units shown in the specification table.
E19	00: No header unit 02: Two or more header units	E19	•	•	0		Trouble in number of outdoor header units	There is no or more than one outdoor header unit in one refrigerant line.
E20	01: Connection of outdoor unit from other refrigerant line 02: Connection of indoor unit from other refrigerant line	E20	•	•	0		Connection to other refrigerant line found during automatic address setting	Indoor unit from other refrigerant line is detected while indoor automatic address setting is in progress.
E23	-	E23	•	•	0		Outdoor-outdoor communication transmission trouble	Signal cannot be transmitted to other outdoor units.
E25	-	E25	•	•	0		Duplicated follower outdoor address	There is duplication in outdoor addresses set manually.
E26	Address of outdoor unit from which signal is not received normally	E26	•	•	0		Signal lack of outdoor unit	Follower outdoor unit initially communicating normally fails to do so (reduction in number of follower outdoor units connected).
E28	Detected outdoor unit No.	E28	•	•	0		Outdoor follower unit trouble	Outdoor header unit detects trouble relating to follower outdoor unit (detail displayed on follower outdoor unit).
E31	P.C.board Compressor Fan Motor 1 2	E31	•	•	0		P.C. board communication trouble Sub MCU communication trouble	There is no communication between P.C. boards in inverter box.
F04	-	F04	0	0	0	ALT	Outdoor discharge temperature sensor (TD1) trouble	Outdoor discharge temperature sensor (TD1) has been open/short-circuited.
F05	-	F05	0	0	0	ALT	Outdoor discharge temperature sensor (TD2) trouble	Outdoor discharge temperature sensor (TD2) has been open/short-circuited.
F06	01: TE1 sensor 02: TE2 sensor 03: TE3 sensor	F06	0	0	0	ALT	Outdoor heat exchanger liquid side temperature sensor (TE1, TE2, TE3) trouble	Outdoor heat exchanger liquid side temperature sensors (TE1, TE2, TE3) have been open/ short-circuited.

	Check code		Display	of rec	ceiving	g unit		
	Outdoor 7-segment display	Central control or main	Indic	ator li	ght blo	ock	Typical problem site	Description of check code
	Sub-code	remote controller	Operation (1)	Timer	Ready	Flash	Typical problem site	Description of check code
F07	01: TL1 sensor 02: TL2 sensor 03: TL3 sensor	display	0	0	0	ALT	Outdoor liquid temperature sensor (TL1,TL2,TL3) trouble	Outdoor liquid temperature sensor (TL1,TL2,TL3) has been open/short-circuited.
F08	-	F08	0	0	0	ALT	Outdoor outside air temperature sensor (TO) trouble	Outdoor air temperature sensor (TO) has been open/short-circuited.
F09	01: TG1 sensor 02: TG2 sensor 03: TG3 sensor	F09	0	0	0	ALT	Outdoor heat exchanger gas side temperature sensor (TG1, TG2, TG3) trouble	Outdoor heat exchanger gas side temperature sensors (TG1, TG2, TG3) have been open/ short-circuited.
F12	01: TS1 sensor 02: TS2 sensor 03: TS3 sensor 04: TS3 sensor disconnect	F12	©	©	0	ALT	Outdoor suction temperature sensor (TS1, TS2, TS3) trouble When TS3 detects an unusual temperature during compressor operation and PMV4 operation in cooling mode	Outdoor suction temperature sensor (TS1,TS2, TS3) has been open/short-circuited. When the disconnect of outdoor temperature sensor (TS3) is detected.
F15	-	F15	0	0	0	ALT	Outdoor temperature sensor (TE1,TL1) wiring trouble	Wiring trouble in outdoor temperature sensors (TE1,TL1) has been detected.
F16	-	F16	0	0	0	ALT	Outdoor pressure sensor (Pd, Ps) wiring trouble	Wiring trouble in outdoor pressure sensors (Pd, Ps) has been detected.
F23	_	F23	0	0	0	ALT	Low pressure sensor (Ps) trouble	Output voltage of low pressure sensor (Ps) is zero.
F24	_	F24	0	0	0	ALT	High pressure sensor (Pd) trouble	Output voltage of high pressure sensor (Pd) is zero or provides abnormal readings when compressors have been turned off.
F31	_	F31	0	©	0	SIM	Outdoor EEPROM trouble	Outdoor EEPROM is failure (alarm and shutdown for header unit and continued operation for follower unit)
H05	_	H05	•	©	•		Outdoor discharge temperature sensor (TD1) wiring trouble	Wiring/installation trouble or detachment of outdoor discharge temperature sensor (TD1) has been detected.
H06	_	H06	•	0	•		Activation of low-pressure protection	Low pressure (Ps) sensor detects abnormally low operating pressure.
H07	_	H07	•	0	•		Low oil level protection	Temperature sensor for oil level detection (TK1,TK2) detects abnormally low oil level.
H08	01: TK1 sensor trouble 02: TK2 sensor trouble	H08	•	©	•		Trouble in temperature sensor for oil level detection (TK1,TK2)	Temperature sensor for oil level detection (TK1,TK2) has been open/short-circuited.
H15	_	H15	•	0	•		Outdoor discharge temperature sensor (TD2) wiring trouble	Wiring/installation trouble or detachment of outdoor discharge temperature sensor (TD2) has been detected.
H16	01: TK1 oil circuit trouble 02: TK2 oil circuit trouble	H16	•	0	•		Oil level detection circuit trouble	No temperature change is detected by temperature sensor for oil level detection (TK1,TK2) despite compressor having been started.
L02	Detected indoor unit address	L02	0	0	0	SIM	Indoor unit incompatible with A2L refrigerant	Indoor unit incompatible with TU2C-LINK is connected. Indoor unit incompatible with R32 refrigerant is connected."
L04	_	L04	0	0	0	SIM	Duplicated outdoor refrigerant line address	Identical refrigerant line address has been assigned to outdoor units belonging to different refrigerant piping systems.
	Number of priority indoor units	L05	0	•	0	SIM	Duplicated priority indoor unit (as displayed on priority indoor unit)	More than one indoor unit have been set up as priority indoor unit.
L06	(check code L05 or L06 depending on individual unit)	L06	0	•	0	SIM	Duplicated priority indoor unit (as displayed on indoor unit other than priority indoor unit)	More than one indoor unit have been set up as priority indoor unit.
L08	-	(L08)	0	•	0	SIM	Indoor group address not set	Address setting have not been performed for one or more indoor units (also detected at indoor end).
L10	_	L10	0	0	0	SIM	Outdoor capacity not set	Outdoor unit capacity has not been set (after P.C. board replacement).
L11	Detected indoor unit address	L11	0	0	0	SIM	Flow Selector unit or Shut- off Valve unit installation trouble	Outdoor unit is set to "HR", there is no connection to Flow Selector unit, and indoor unit is not set to "cooling only". Outdoor unit is set to "HP" and the Flow Selector unit is connected.

L13 Detected indoor unit address		Check code		Displa	y of re	ceiving	g unit		
Sub-code Sub-code		Outdoor 7-segment display		Indic	ator li	ght blo	ock	Typical problem site	Description of check code
installation trouble* L13 Defected indoor unit address L13 Defected indoor unit address L14 Defected indoor unit address L15 Defected indoor unit address L16 Defected indoor unit address L17 Defected indoor unit address L18 Defected indoor unit address L19 Defected indoor unit address L19 Defected indoor unit address L19 Defected indoor unit address L10 Defected indoor unit address L11 Defected indoor unit address L12 Defected indoor unit address L13 Defected indoor unit address L14 Defected indoor unit address L15 Defected indoor unit address L16 Defected indoor unit address L17 Defected indoor unit address L18 Defected indoor unit address L19 Defected indo		Sub-code	main remote controller				Flash	Typical problem site	Description of Check Code
L13 Deflected indoor unit address	L12		L12	0	0	0	SIM		FS unit(s) outside the application setting
L14 Detected indoor unit address	L13	Detected indoor unit address	L13	0	0	0	SIM		unit connected to same FS unit (or Shut-off Valve unit) is mismatched. * "No safety measures required" does not apply. * Mixture of "pump down operation" and "Only Leak Detector" is not case. • Indoor unit is not connected to port1 of multiport type FS unit. • The +1 port address of FS unit port with port combining branched is set. * Next to combining branches port (No.+1 side) must not be port addressed. • One port in an FS unit has multiple indoor unit group settings and a group across multiple ports. • Same FS unit address is set for different FS
L18 Detected indoor unit address L18	L14	Detected indoor unit address	L14	©	0	0	SIM		unit is set other than "no safety measures required" and Leak Detector is not connected at the time of power input. • Safety measures CODE No. setting of indoor unit is set to "pump down operation" or "individual shut-off operation" and FS unit or Shut-off Valve unit is not connected. • Safety CODE No. setting of indoor unit connected to multiport type FS unit is set to
Compressor Control of Con	L17	_	L17	0	0	0	SIM		
Description Compressor Core (G): Trouble P.C. board Court Co	L18	Detected indoor unit address	L18	0	0	0	SIM		Cooling/heating cycle trouble resulting from piping trouble is detected
L24 Carbon control of the control	L23	outdoor unit	L23	0	0	0	SIM	SW setting trouble	
L29	L24	L24 FS unit(s) setting trouble 02: Indoor units operation	L24	0	0	0	SIM	FS unit(s) setting trouble	FS unit(s) detects address identical to its own. Duplicated priority indoor units operation mode.
L29	L28	_	L28	0	0	0	SIM		
L30 Detected indoor unit No. (L30)	L29	Compressor Fan Motor 1 2 1	L29	0	0	0	SIM		l
L30 Detected indoor unit No. (L30)		00	L29	0	0	0	SIM		When there is much number of an inverter P.C. board to model setting of an interface P.C. board.
P03	L30	Detected indoor unit No.	(L30)	0	0	0	SIM		trouble input in one refrigerant line (detected by
P04 02: Compressor 2 P04 © ALT SW Power detection trouble P05 01: Open phase 02: Power supply miswiring P06 01: Open phase 02: Power supply miswiring P07 02: Compressor 1 or 2 heat sink trouble P08 01: Compressor 1 or 2 heat sink trouble P09 02: Compressor 1 heat sink trouble P09 02: Compressor 1 heat sink trouble P09 03: Compressor 1 heat sink trouble P09 04: Heat sink dewing P09 05: Compressor 2 heat sink trouble P09 06: Compressor 3 heat sink trouble P09 07: Compressor 4 heat sink trouble P09 08: ALT SW Power detection trouble Popen phase detected when power is turned on Inverter DC voltage is too high (overvoltage) or to low (undervoltage). P10 08: ALT SW Power detection trouble Popen phase is detected when power is turned on Inverter DC voltage is too high (overvoltage) or to low (undervoltage). P10 09: Compressor 1 or 2 heat sink trouble P10 10: Compressor 1 heat sink trouble P10 10: Compressor 2 heat sink trouble P10 10: Compressor 3 heat sink trouble P10 10: Compressor 4 heat sink trouble P10 10: Compressor 5 heat sink trouble P10 10: Compressor 6 heat sink trouble P10 10: Compressor 6 heat sink trouble P10 10: Compressor 7 heat sink trouble P10 10: Compressor 1 heat sink trouble P10 10: Compressor	P03	-	P03	0	•	0	ALT		Outdoor discharge temperature sensor (TD1) has detected abnormally high temperature.
O0: Power detection trouble O1: Open phase O2: Power supply miswiring O0: Compressor 1 or 2 heat sink trouble O1: Compressor 2 heat sink trouble O2: Compressor 2 heat sink trouble O4: Heat sink dewing P07 Indoor unit No. detected OPen phase detection Power supply miswiring detection ALT Open phase detection Power supply miswiring detection F07 ALT F08 OFEN Phase Is detected when power is turned of Inverter DC voltage is too high (overvoltage) or to low (undervoltage). Temperature sensor built into IPM (TH) detects overheating. Temperature sensor built into IPM (TH) detects overheating. Temperature sensor of IL2) has detected abnormally low temperature. F10 Indoor unit No. detected Indoor unit has been shutdown in one refrigerant line due to detection of overflow (detected by	P04		P04	0	•	0	ALT		High-pressure SW is activated.
P07	P05	01: Open phase	P05	0	•	0	ALT	/Open phase detection /Power supply miswiring	Open phase is detected when power is turned on. Inverter DC voltage is too high (overvoltage) or too low (undervoltage).
04: Heat sink dewing 04: Heat sink dewing trouble Outdoor liquid temperature sensor (TL2) has detected abnormally low temperature. P10 Indoor unit No. detected (P10) ALT Indoor unit overflow Outdoor liquid temperature sensor (TL2) has detected abnormally low temperature. Indoor unit has been shutdown in one refrigeran line due to detection of overflow (detected by	P07	01 : Compressor 1 heat sink trouble	P07	0	•	0	ALT		
P10 Indoor unit No. detected (P10)		04: Heat sink dewing						Heat sink dewing trouble	
	P10	Indoor unit No. detected	(P10)	•	0	0	ALT	Indoor unit overflow	

FS unit: Flow Selector unit

	Check code		Display	of rece	eiving	unit		
	Outdoor 7-segment display	Central control or	Indica	ator lig	ht blo	ock	Typical problem site	Description of check code
	Sub-code	main remote controller display	Operation (1)	Timer R	leady	Flash	Typical problem site	Description of check code
P11	_	P11	•	0	0	ALT	Outdoor heat exchanger freeze trouble	Remaining frost on outdoor heat exchanger has been detected repeatedly.
P13	-	P13	•	0	0	ALT	Outdoor liquid backflow detection trouble	State of refrigerant cycle circuit indicates liquid backflow operation.
P14	01: Outdoor unit valve is close	P14	•	0	0	ALT	Another refrigerant cycle protection	Outdoor unit valve is forget to open during test run.
P15	01: TS condition 02: TD condition	P15	0	•	0	ALT	Gas leak detection	Outdoor suction temperature sensor (TS1) detects sustained and repeated high temperatures that exceed standard value.
P16	01: PMV5 02: PMV6 03: Mis installation of PMV5 and PMV6	P16	0	•	0	ALT	Injection circuit trouble	Discharge temperature of either Comp 1 or Comp 2 is within the normal control range, and discharge temperature of the other is very low. Discharge temperature of either Comp 1 or Comp 2 is very high, and discharge temperature of the other is very low.
P17	-	P17	0	•	0	ALT	Outdoor discharge (TD2) temperature trouble	Outdoor discharge temperature sensor (TD2) detects abnormally high temperature.
P19	0#: 4-way valves 1#: 4-way valve1 2#: 4-way valve2 * Put in outdoor unit No. in [#] mark.	P19	0	•	0	ALT	4-way valve reversing trouble	Abnormality in refrigerating cycle is detected during heating operation. Either 4WV1 or 4WV2 cannot be switched.
P20	-	P20	0	•	0	ALT	Activation of high-pressure protection	High pressure (Pd) sensor detects high pressure that exceeds standard value.

(Check code detected by Inverter of Compressor featuring in outdoor unit - typical examples)

	Check code		Display	of re	ceiving	g unit			
	Outdoor 7-segment display	Central control or	Indica	ator li	ight bl	ock	Typical problem site	Description of check code	
	Sub-code	main remote controller display	Operation (1)	Timer	Ready	Flash	Typical problem site		
F13	1*: Compressor 1 2*: Compressor 2	F13	0	0	0	ALT	Trouble in temperature sensor built into indoor IPM (TH)	Temperature sensor built into indoor IPM (TH) has been open/short-circuited.	
H01	1*: Compressor 1 2*: Compressor 2	H01	•	0	•		Compressor breakdown	Inverter current (Idc) detection circuit detects overcurrent.	
H02	1*: Compressor 1 2*: Compressor 2	H02	•	0	•		Compressor trouble (lockup)	Compressor lockup is detected	
H03	1*: Compressor 1 2*: Compressor 2	H03	•	0	•		Current detection circuit trouble	Abnormal current is detected while inverter compressor is turned off.	
H17	1*: Compressor 1 2*: Compressor 2	H17	•	0	•		Compressor trouble (Step-out)	Compressor is in step-out condition.	
H28	1*: Compressor 1 2*: Compressor 2	H28	•	0	•		Compressor motor winding trouble	Compressor motor winding is layer shorted.	
P05	1*: Compressor 1 side 2*: Compressor 2 side	P05	0	•	0	ALT	Compressor Vdc trouble	Inverter DC voltage is too high (overvoltage) or too low (undervoltage).	
P07	1*: Compressor 1 side 2*: Compressor 2 side	P07	0	•	0	ALT	Heat sink overheat trouble	Temperature sensor built into IPM (TH) detects overheating.	
P11	-	P11	•	0	0	ALT	Outdoor heat exchanger freeze trouble	Remaining frost on outdoor heat exchanger has been detected repeatedly.	
P22	1*: Fan P.C. board 1 2*: Fan P.C. board 2	P22	0	•	0	ALT	Outdoor fan P.C. board trouble	Outdoor fan P.C. board detects trouble.	
P25	1*: Compressor 1 2*: Compressor 2	P25	0	•	0	ALT	Compressor P.C. board trouble	IPM for compressor is broken. (Short-circuit etc.)	
P26	1*: Compressor 1 2*: Compressor 2	P26	0	•	0	ALT	Compressor start up trouble	Open phase or IPM over current for compressor is detected.	
P29	1*: Compressor 1 2*: Compressor 2	P29	0	•	0	ALT	Compressor position detection circuit trouble	Compressor motor position detection trouble is detected.	

Note: The above check codes are examples only, and different check codes may be displayed depending on the outdoor unit configuration


9-3. Troubleshooting based on information displayed on remote controller

<RBC-AMTU3*>

(1) Checking and testing

When a trouble occurs to an air conditioner, a check code and indoor unit No. are displayed on the display window of the remote controller. Check codes are only displayed while the air conditioner is in operation.

If the display has already disappeared, access check code history by following the procedure described below.



(2) Trouble history

The trouble history access procedure is described below (up to four check codes stored in memory). Check code history can be accessed regardless of whether the air conditioner is in operation or shut down.

<Pre><Pre>cedure> To be performed when system at rest

1 Invoke the SERVICE CHECK mode by pressing the

□ +


□ buttons simultaneously and holding for at least 4 seconds.

The letters " SERVICE CHECK" light up, and the check code "01" is displayed, indicating the trouble history. This is accompanied by the indoor unit No. to which the trouble history is related and a check code.

2 To check other trouble history items, press the true button to select another check code.

Check code "01" (latest) → Check code "04" (oldest) Note: Trouble history contains four items.

3 When the button is pushed, normal display is restored.



⚠ CA


CAUTION

Do not push the $\stackrel{\alpha}{\frown}$ button as it would erase the whole trouble history of the indoor unit.

<RBC-ASCU11-*>

(1) Confirmation and check

If a problem occurs with the air conditioner, the OFF timer indicator alternately shows the check code and the indoor Unit No. in which the problem occurred.



(2) Troubleshooting history and confirmation

You can check the troubleshooting history with the following procedure if a problem occurs with the air conditioner.

(The troubleshooting history records up to 4 incidents.)

You can check it during operation or when operation is stopped.

· If you check the troubleshooting history during OFF timer operation, the OFF timer will be canceled.

| Procedure | Description of oper | ation |
|-----------|---|--------------|
| 1 | Push the OFF timer button for over 10 seconds and the indicators appear as an image indicating the troubleshooting history mode has been entered. If [| No. F ID |
| 2 | Each time the setting button is pushed, the recorded troubleshooting history is displayed in sequence. The troubleshooting history appears in order from [01] (newest) to [04] (oldest). | TOSHIBA No. |
| | In the troubleshooting history mode, DO NOT push the Menu button for over 10 seconds, doing so deletes the entire troubleshooting history of the indoor unit. | F 10 |
| 3 | After you have finished checking, push the ON/OFF button to return to the regular mode. If the air conditioner is operating, it remains operated even after the ON/OFF button has been pushed. To stop its operation, push the ON/OFF button again. | |

How to read displayed information

<7-segment display symbols>



<Corresponding alphanumerical letters>

0 1 2 3 4 5 6 7 8 9 A b C d E F H J L P

Using indoor unit indicators (receiving unit light block) (wireless type)

To identify the check code, check the 7-segment display on the outdoor unit. To check for check codes not displayed on the 7-segment display, consult the "List of Check Codes (Indoor Unit)" in "9-2. Troubleshooting method".

■: Goes off ○: Lighting -: Blinking (0.5 seconds)

| Light | block | (| Check code | | Cause of trouble | | | | | | | | |
|-----------------|-----------------------|--------------|---|---|--------------------------------------|------------------------------|--|--|--|--|--|--|--|
| Operation All I | Timer lights or | | _ | Power turned off or trouble in wiring between receiving and indoor units | | | | | | | | | |
| Operation | Timer | Ready | E01 | Trouble reception | Receiving unit | Trouble or poor contact in | | | | | | | |
| \\\ | | rioddy | E02 | Trouble transmission | wiring between receiving unit | | | | | | | | |
| -\- | | | E03 | Loss of communication | _ | and indoor units | | | | | | | |
| Blinking | Blinking | | E08 | Duplicated indoor unit No. (add | Duplicated indoor unit No. (address) | | | | | | | | |
| | | E09 | Duplicated master remote controller Setting trouble | | | | | | | | | | |
| | E10 | | | Communication trouble between indoor unit MCU | | | | | | | | | |
| | E11 | | | Communication trouble between | n Application control kit and | d indoor unit P.C. board | | | | | | | |
| | | | E12 | Automatic address starting trou | ible | | | | | | | | |
| | | | E17 | Communication trouble between | n indoor unit(s) and Flow Se | elector unit(s). | | | | | | | |
| | | | E18 | Trouble or poor contact in wiring between indoor units, indoor power turned off | | | | | | | | | |
| Operation | Timer | Ready | E04 | Trouble or poor contact in wiring between indoor and outdoor units (loss of indoor-outdoor communication) | | | | | | | | | |
| | | - <u>Ö</u> - | E06 | Trouble reception in indoor-out | door communication (droppi | ing out of indoor unit) | | | | | | | |
| | | Blinking | E07 | Trouble transmission in indoor- | outdoor communication | | | | | | | | |
| | | Diriikiing | E15 | Indoor unit not found during automatic address setting | | | | | | | | | |
| | | | E16 | Too many indoor units connected / overloading | | | | | | | | | |
| | | | E19 | Trouble in number of outdoor header units | | | | | | | | | |
| | | | E20 | Detection of refrigerant piping of | communication trouble durin | ng automatic address setting | | | | | | | |
| | | | E23 | Trouble transmission in outdoo | r-outdoor communication | | | | | | | | |
| | | | E25 | Duplicated follower outdoor add | dress | | | | | | | | |
| | | | E26 | Trouble reception in outdoor-ou | utdoor communication, drop | ping out of outdoor unit | | | | | | | |
| | | | E28 | Outdoor follower unit trouble | | | | | | | | | |
| | | | E31 | P.C. board communication troul | ble | | | | | | | | |
| Operation | Timer | Ready | P01 | Indoor AC fan trouble | | | | | | | | | |
| | <u>}</u> | _\ | P10 | Indoor overflow trouble | | | | | | | | | |
| | 7 | 74 | P11 | Outdoor heat exchanger freezing | ng trouble | | | | | | | | |
| Alt | LI Alternate blinking | | P12 | Indoor DC fan trouble | | | | | | | | | |
| | | 3 | P13 | Outdoor liquid backflow detection | on trouble | | | | | | | | |
| | | | P14 | Outdoor unit valve is closed | | | | | | | | | |

| Light block | Check code | Cause of trouble | | | | | | | | |
|--|------------|---|--|--|--|--|--|--|--|--|
| Operation Times De l | P03 | Outdoor discharge (TD1) temperature trouble | | | | | | | | |
| Operation Timer Ready | P04 | Activation of outdoor high-pressure SW | | | | | | | | |
| Alternate blinking | P05 | Open phase / power failure
Inverter DC voltage (Vdc) trouble
MG-CTT trouble | | | | | | | | |
| | P07 | Outdoor heat sink overheating trouble - Poor cooling of electrical outdoor unit | component (IGBT) of | | | | | | | |
| | P15 | Gas leak detection - insufficient refrigerant charging | | | | | | | | |
| | P16 | Injection circuit trouble. | | | | | | | | |
| | P17 | Outdoor discharge (TD2) temperature trouble | | | | | | | | |
| | P18 | Outdoor discharge (TD3) temperature trouble | | | | | | | | |
| | P19 | Outdoor 4-way valve reversing trouble | | | | | | | | |
| | P20 | Activation of high-pressure protection | | | | | | | | |
| | P22 | Outdoor fan P.C. board trouble | | | | | | | | |
| | P25 | Compressor P.C. board trouble. | | | | | | | | |
| | P26 | Compressor trouble / Wire connection trouble. Compressor leads trouble. Compressor P.C. board trouble. | | | | | | | | |
| | P29 | Compressor position detection circuit trouble | | | | | | | | |
| P31 | | Shutdown of other indoor unit in group due to trouble (group follower unit trouble) | | | | | | | | |
| Operation Timer Ready | F01 | Heat exchanger temperature sensor (TCJ) trouble | | | | | | | | |
| Timer Ready | F02 | Heat exchanger temperature sensor (TC2) trouble | | | | | | | | |
| -\-\-\-\-\-\-\-\-\-\-\-\-\-\-\-\-\-\-\ | F03 | Heat exchanger temperature sensor (TC1) trouble | Indoor unit temperature sensor trouble | | | | | | | |
| Alternate blinking | F10 | Ambient temperature sensor (TA/TSA) trouble | | | | | | | | |
| · · · · · · · · · · · · · · · · · · · | F11 | Discharge temperature sensor (TF) trouble | | | | | | | | |
| Operation Timer Ready | F04 | Discharge temperature sensor (TD1) trouble | | | | | | | | |
| -\\\-\\\-\\\-\\\\-\\\\-\\\\\-\\\\\\\\\ | F05 | Discharge temperature sensor (TD2) trouble | | | | | | | | |
| ·γ· ·γ· · · | F06 | Heat exchanger temperature sensor (TE1, TE2, TE3) trouble | | | | | | | | |
| Alternate blinking | F07 | Liquid temperature sensor (TL1, TL2, TL3) trouble | Outdoor unit temperature | | | | | | | |
| · · | F08 | Outside air temperature sensor (TO) trouble | sensor trouble | | | | | | | |
| | F09 | Heat exchanger gas side temperature sensor (TG1, TG2, TG3) trouble | | | | | | | | |
| | F12 | Suction temperature sensor (TS1, TS2, TS3) trouble | | | | | | | | |
| | F13 | Heat sink sensor (TH) trouble | | | | | | | | |
| | F15 | Wiring trouble in heat exchanger sensor (TE1) and liquid temper Outdoor unit temperature sensor wiring / installation trouble | rature sensor (TL) | | | | | | | |
| | F16 | Wiring trouble in outdoor high pressure sensor (Pd) and low presoutdoor pressure sensor wiring trouble | ssure sensor (Ps) | | | | | | | |
| | F23 | Low pressure sensor (Ps) trouble | Outdoor unit pressure sensor | | | | | | | |
| | F24 | High pressure sensor (Pd) trouble | trouble | | | | | | | |
| Operation Timer Ready | F29 | Trouble in indoor EEPROM | | | | | | | | |

| Light block | Check code | Cause of trouble | | | | |
|---|------------|---|---|--|--|--|
| Operation Timer Ready | H01 | Compressor breakdown | | | | |
| Operation Times Treaty | H02 | Compressor lockup | Outdoor unit compressor related trouble | | | |
| <u> </u> | H03 | Current detection circuit trouble | | | | |
| Blinking | H05 | Wiring / installation trouble or detachment of outdoor discharge | temperature sensor (TD1) | | | |
| | H06 | Abnormal drop in low-pressure sensor (Ps) reading | Protective shutdown of outdoor | | | |
| | H07 | Abnormal drop in oil level | unit | | | |
| | H08 | Trouble in temperature sensor for oil level detection circuit (TK | 1, TK2) | | | |
| | H15 | Wiring / installation trouble or detachment of outdoor discharge | temperature sensor (TD2) | | | |
| | H16 | Oil level detection circuit trouble - Trouble in outdoor unit TK1, | TK2 circuit | | | |
| | H17 | Compressor trouble (Step-out) | | | | |
| | H28 | Compressor motor winding trouble. | | | | |
| Operation Timer Ready | J29 | Leak Detector trouble | | | | |
| | J30 | Refrigerant leak detection | | | | |
| Ψ - | J31 | Refrigerant leak detection sensor has reached product life | | | | |
| Operation Times Books | L02 | Outdoor unit model mismatched trouble | | | | |
| Operation Timer Ready | L03 | Duplicated indoor group header unit | | | | |
| -Q- • -Q- | L05 | Duplicated priority indoor unit (as displayed on priority indoor u | nit) | | | |
| Synchronized blinking | L06 | Duplicated priority indoor unit (as displayed on indoor unit other than priority indoor unit) | | | | |
| Sylicilionized billiking | L07 | Connection of group control cable to stand-alone indoor unit | | | | |
| | L08 | Indoor group address not set | | | | |
| | L09 | Indoor capacity not set | | | | |
| Operation Timer Ready | L04 | Duplicated outdoor refrigerant line address | | | | |
| Operation filler fleady | L10 | Outdoor capacity not set | | | | |
| \tau \tau \tau \tau \tau \tau \tau \tau | L11 | Flow Selector unit or Shut-off Valve unit installation trouble | | | | |
| Synchronized blinking | L12 | Flow selector unit(s) system trouble. | | | | |
| Synchronized billiking | L13 | Safety measures setting unmatched. | | | | |
| | L14 | Safety measures nonconformity. | | | | |
| | L17 | Outdoor model incompatibility | | | | |
| | L18 | Cooling/heating Flow selector unit trouble. | | | | |
| | L20 | Duplicated central control address | | | | |
| | L23 | SW setting trouble | | | | |
| | L24 | Flow selector unit(s) setting trouble. | | | | |
| | L28 | Too many outdoor units connected | | | | |
| | L29 | Trouble in number of P.C. boards | | | | |
| | L30 | Indoor external interlock trouble | | | | |

| Light block | Check code | Cause of trouble |
|-----------------------|------------|--------------------------|
| Operation Timer Ready | F30 | Occupancy sensor trouble |
| Synchronized blinking | F31 | Outdoor EEPROM trouble |

Other (indications not involving check code)

| Light block | Check code | Cause of trouble |
|-----------------------|------------|--|
| Operation Timer Ready | - | Test run in progress |
| Operation Timer Ready | _ | Setting incompatibility (automatic cooling / heating setting for model incapable of it and heating setting for cooling-only model) |

Flow selector unit (FS unit) Relation

| Light block | Check code | Cause of trouble |
|---------------------------|------------|---|
| Operation Timer Ready | E17 | Communication trouble between indoor unit(s) and FS unit(s) |
| Operation Timer Ready | L12 | FS unit(s) system trouble |
| L J Synchronized blinking | L24 | FS unit(s) setting trouble |
| Operation Timer Ready | J03 | Duplicated FS units |
| • -¤́¤́- | J10 | FS unit overflow trouble |
| Blinking Blinking | J11 | FS unit temperature sensor(TCS) trouble |

9-4. Check Codes

(Displayed on remote controller and 7-segment display of outdoor Unit)

The contents of these check code tables differ depending on the outdoor unit to be connected. Refer to the service manual of the connected outdoor unit. (The table below is for the SMMS-u series.)

| | Check | code | | | | | |
|----------------------|------------|--|----------------------|--|----------------------------------|--|---|
| Main | | 7-segment display | Location of | Description | System status | Check code detection | Check items (locations) |
| remote
controller | Check code | Sub-code | detection | | • | condition(s) | , , |
| E01 | _ | _ | Remote
controller | Indoor-remote controller communication trouble (detected at remote controller end) | Stop of corresponding unit | Communication between indoor P.C. board and remote controller is disrupted. | Check remote controller inter-unit tie cable (A/B). Check for broken wire or connector bad contact. Check indoor power supply. Check for failure in indoor P.C. board. Check remote controller address settings (when two remote controllers are in use). Check remote controller P.C. board. |
| E02 | _ | - | Remote controller | Remote
controller
transmission
trouble | Stop of corresponding unit | Signal cannot be transmitted from remote controller to indoor unit. | Check internal
transmission circuit of
remote controller Replace remote
controller as necessary. |
| E04 | _ | - | Indoor unit | Indoor-outdoor
communication
circuit trouble
(detected at
indoor end) | Stop of corresponding unit | Indoor unit is not receiving signal from outdoor unit. | Check order in which power was turned on for indoor and outdoor units. Check indoor address setting. Check indoor-outdoor tie cable. Check outdoor terminator resistor setting (SW100, Bit 2). |
| E04 | E06 | No. of indoor
units from
which signal is
received
normally | I/F | Dropping out of indoor unit | All stop | Condition 1 All indoor unit initially communicating normally fails to return signal for specified length of time. Condition 2 Outdoor I / F board SW103, Bit4 : OFF (Factory default) | Check power supply to indoor unit. (Is power turned on?) Check connection of indoor-outdoor communication cable. Check connection of communication connectors on indoor P.C. board. Check connection of communication connectors on outdoor P.C. board. Check for failure in indoor P.C. board. Check for failure in outdoor P.C. board. Check for failure in outdoor P.C. board (I/F). |
| | _ | _ | Indoor unit | Indoor-outdoor
communication
circuit trouble | Only specified indoor units stop | Condition 1 Indoor unit initially communicating normally fails to return signal for specified length of time. | Check power supply to indoor unit. (Is power turned on?) Check indoor-outdoor power-on sequence. Check indoor address setting Check wiring of Indoor-outdoor communication wires Check outdoor terminator resistor setting (SW100, Bit 2). |

| | Check | code | | | | | |
|-------------|------------|---|----------------------|--|----------------------------|---|---|
| Main remote | | 7-segment display | Location of | Description | System status | Check code detection condition(s) | Check items (locations) |
| controller | Check code | Sub-code | detection | | | Condition(3) | |
| | | No. of indoor
units from
which signal is
received
normally | Indoor unit | Indoor-outdoor
communication
circuit trouble
(E04) | All stop | Condition 1 One indoor unit or more initially communicating normally fails to return signal for specified length of time. Condition 2 Outdoor I / F board SW103, Bit4 : ON (To switch the check code detection condition.) | Check power supply to indoor unit. (Is power turned on?) Check indoor-outdoor power-on sequence. Check indoor address setting Check wiring of Indoor-outdoor communication wires Check outdoor terminator resistor setting (SW100, Bit 2). |
| E04/E06 | E06 | | I/F | Dropping out of
indoor unit
(E06) | | Display on main remote controller. Indoor units unavailable for indoor / outdoor communication. :E04 Indoor units available for indoor / outdoor communication. : E06 In TU2C-LINK communication system, if the termination resistance is not set in any of the indoor units. | Check power supply to indoor unit. (Is power turned on?) Check connection of indoor-outdoor communication cable. Check connection of communication connectors on indoor P.C. board. Check connection of communication connectors on outdoor P.C. board. Check for failure in indoor P.C. board. Check for failure in outdoor P.C. board. Check for failure in outdoor P.C. board (I/F). |
| _ | E07 | _ | I/F | Indoor-outdoor
communication
circuit trouble
(detected at
outdoor end) | All stop | Signal cannot be transmitted from outdoor to indoor units for 30 seconds continuously. | Check outdoor terminator
resistor setting (SW100,
Bit 2). Check connection of
indoor-outdoor
communication circuit. |
| E08 | E08 | Duplicated indoor address | Indoor unit
I/F | Duplicated indoor address | All stop | More than one indoor unit are assigned same address. | Check indoor addresses. Check for any change
made to remote controller
connection (group/
individual) since indoor
address setting. |
| E09 | _ | _ | Remote
controller | Duplicated
master remote
controller | Stop of corresponding unit | In two remote controller configuration (including wireless), both controllers are set up as master. (Header indoor unit is shut down with alarm, while follower indoor units continue operating.) | Check remote controller
settings. Check remote controller
P.C. boards. |
| E10 | _ | _ | Indoor unit | Indoor inter-
MCU
communication
trouble | Stop of corresponding unit | Communication cannot be established/maintained upon turning on of power or during communication. | Check for failure in
indoor P.C. board |
| E12 | E12 | 01:
Indoor-outdoor
communication
02:
Outdoor-outdoor
communication | I/F | Automatic
address starting
trouble | All stop | Indoor automatic address setting is started while automatic address setting for equipment in other refrigerant line is in progress. Outdoor automatic address setting is started while automatic address setting for indoor units is in progress. | Check whether the outdoor unit of other systems or the indoor unit is connected to Uv (U1/U2) line or Uc (U5/U6) line. Perform automatic address setting again after disconnecting communication cable to that refrigerant line. |
| E15 | E15 | _ | I/F | Indoor unit not
found during
automatic
address setting | All stop | Indoor unit cannot be detected after indoor automatic address setting is started. | Check connection of indoor-outdoor communication line. Check for trouble in indoor power supply system. Check for noise from other devices. Check for power failure. Check for failure in indoor P.C. board. |

| | Check | code | Location | | | | |
|-------------|---------------|---|-------------|---|-----------------------|---|---|
| Main remote | | 7-segment display | Location of | Description | System status | Check code detection condition(s) | Check items (locations) |
| controller | Check
code | Sub-code | detection | | | | |
| E16 | E16 | 00:
Capacity over
01-:
No. of units
connected | VF | Too many indoor units connected | All stop | Combined capacity of indoor units is too large. Note: If this code comes up after backup setting for outdoor unit failure is performed, perform "No capacity over detected" setting. <"No capacity over detected" setting method> Turn on SW103 / Bit 3 on I/F P.C. board of outdoor header unit. For Cooling Only model, this check code is not displayed even if it exceeds the combined capacity of indoor units. • More than 128 indoor units are connected. | Check capacities of indoor units connected. Check combined HP capacities of indoor units. Check HP capacity settings of outdoor units. Check No. of indoor units connected. Check for failure in outdoor P.C. board (I/F). |
| | | | Indoor unit | Trouble in | Stop of | Periodic communication | Check remote controller |
| E18 | _ | _ | | communication
between indoor
header and
follower units | corresponding
unit | between indoor header and follower units cannot be maintained. | wiring. Check indoor power supply wiring. Check P.C. boards of indoor units. |
| E19 | E19 | 00:
No header unit
02:
Two or more
header units | VF | Trouble in
number of
outdoor header
units | All stop | There are more than one outdoor header units in one line. There is no outdoor header unit in one line. | The outdoor unit which turned on SW101 and the bit 1 of the interface P.C. board is set to Header unit. Check SW101 bit 1 of follower outdoor unit. Check connection of indoor-outdoor communication line. Check for failure in outdoor P.C. board (I/F). |
| E20 | E20 | 01:
Connection of
outdoor unit
from other line
02:
Connection of
indoor unit
from other line | l/F | Connection to
other line found
during
automatic
address setting | All stop | Equipment from other line is found to have been connected when indoor automatic address setting is in progress. | Check whether the outdoor unit of other systems or the indoor unit is connected to Uv (U1/U2) line or Uc (U5/U6) line. |
| E23 | E23 | _ | l/F | Outdooroutdoor
communication
transmission
trouble | All stop | Signal cannot be transmitted to other outdoor units for at least 30 seconds continuously. | Check power supply to outdoor units. (Is power turned on?) Check connection of tie cables between outdoor units for bad contact or broken wire. Check communication connectors on outdoor P.C. boards. Check for failure in outdoor P.C. board (I/F). Check termination resistance setting for communication between outdoor units. |
| E25 | E25 | _ | I/F | Duplicated follower outdoor address | All stop | There is duplication in outdoor addresses set manually. | Note:
Do not set outdoor
addresses manually. |
| E26 | E26 | Address of
outdoor unit
from which
signal is not
received
normally | VF | Signal lack of outdoor unit | All stop | Outdoor unit initially communicating normally fails to return signal for specified length of time. | Backup setting is being used for outdoor units. Check power supply to outdoor unit. (Is power turned on?) Check connection of tie cables between outdoor units for bad contact or broken wire. Check communication connectors on outdoor P.C. boards. Check for failure in outdoor P.C. board (I/F). |

| | Check | code | | | | | |
|--|-------|--|-------------|--|----------------------------|---|---|
| Main remote | | 7-segment display | Location of | Description | System status | Check code detection condition(s) | Check items (locations) |
| controller | Check | Sub-code | detection | | | | |
| The check code which occurred follower outdoor unit is displayed | E28 | Detected outdoor unit No. | I/F | Outdoor
follower unit
trouble | All stop | Outdoor header unit receives trouble code from outdoor follower unit. | Check check code displayed on outdoor follower unit. Convenient functions> If SW04 is pressed and held for at least 1 second while [E28] is displayed on the 7-segment display of outdoor header unit, the fan of the outdoor unit that has been shut down due to an trouble comes on. If SW04 and SW05 are pressed simultaneously, the fans of normal outdoor units come on. To stop the fan or fans, press SW05 on its own. |
| E31 | E31 | P.C.board Compressor Fan Motor 1 2 | VF | P.C. board
communication
trouble | All stop | Communication is disrupted between P.C. board in inverter box. | Check wiring and connectors involved in communication between P.C. board I/F P.C. board for bad contact or broken wire. Check for failure in outdoor P.C. board (I/F, comp. P.C. board or Fan P.C. board). Check for external noise. |
| | | 80 | | Communication
trouble between
MCU and Sub
MCU | All stop | Communication between MCU and Sub MCU stopped. | Operation of power supply reset (OFF for 60 seconds or more) Outdoor I/F PC board trouble check |
| F01 | _ | _ | Indoor unit | Indoor TCJ
sensor trouble | Stop of corresponding unit | Sensor resistance is infinity or zero (open/short circuit). | Check connection of TCJ sensor connector and wiring. Check resistance characteristics of TCJ sensor. Check for failure in indoor P.C. board. |
| F02 | _ | _ | Indoor unit | Indoor TC2
sensor trouble | Stop of corresponding unit | Sensor resistance is infinity or zero (open/short circuit). | Check connection of TC2 sensor connector and wiring. Check resistance characteristics of TC2 sensor. Check for failure in indoor P.C. board. |
| F03 | _ | _ | Indoor unit | Indoor TC1
sensor trouble | Stop of corresponding unit | Sensor resistance is infinity or zero (open/short circuit). | Check connection of TC1 sensor connector and wiring. Check resistance characteristics of TC1 sensor. Check for failure in indoor P.C. board. |
| F04 | F04 | _ | I/F | TD1 sensor
trouble | All stop | Sensor resistance is infinity or zero (open/short circuit). | Check connection of TD1 sensor connector. Check resistance characteristics of TD1 sensor. Check for failure in outdoor P.C. board (I/F). |

| | Check | code | Lasatian | | | | |
|-------------|---------------|---|--------------------------|--|----------------------------|--|--|
| Main remote | | 7-segment display | l OI | Description | System status | Check code detection condition(s) | Check items (locations) |
| controller | Check
code | Sub-code | detection | | | (0) | |
| F05 | F05 | _ | l/F | TD2 sensor
trouble | All stop | Sensor resistance is infinity or zero (open/short circuit). | Check connection of TD2 sensor connector. Check resistance characteristics of TD2 sensor. Check for failure in outdoor P.C. board (I/F). |
| F06 | F06 | 01: TE1 sensor
trouble
02: TE2 sensor
trouble
03: TE3 sensor
trouble | l/F | TE1/TE2/TE3
sensor trouble | All stop | Sensor resistance is infinity or zero (open/short circuit). | Check connection of TE1/TE2/TE3 sensor connectors. Check resistance characteristics of TE1/TE2/TE3 sensors. Check for failure in outdoor P.C. board (I/F). |
| F07 | F07 | 01: TL1 sensor
trouble
02: TL2 sensor
trouble
03: TL3 sensor
trouble | I/F | TL1/TL2/TL3
sensor trouble | All stop | Sensor resistance is infinity or zero (open/short circuit). | Check connection of TL1/TL2/TL3 sensor connector. Check resistance characteristics of TL1/TL2/TL3 sensor. Check for failure in outdoor P.C. board (I/F). |
| F08 | F08 | _ | I/F | TO sensor
trouble | All stop | Sensor resistance is infinity or zero (open/short circuit). | Check connection of TO sensor connector. Check resistance characteristics of TO sensor. Check for failure in outdoor P.C. board (I/F). |
| F09 | F09 | 01: TG1 sensor
trouble
02: TG2 sensor
trouble
03: TG3 sensor
trouble | I/F | TG1/TG2/TG3
sensor trouble | All stop | Sensor resistance is infinity or zero (open/short circuit). | Check connection of TG1/TG2/TG3 sensor connectors. Check resistance characteristics of TG1/TG2/TG3 sensors. Check for failure in outdoor P.C. board (I/F). |
| F10 | _ | _ | Indoor unit | Indoor TA
sensor trouble | Stop of corresponding unit | Sensor resistance is infinity or zero (open/short circuit). | Check connection of TA sensor connector and wiring. Check resistance characteristics of TA sensor. Check for failure in indoor P.C. board. |
| F11 | _ | _ | Indoor unit | Indoor TF
sensor trouble | Stop of corresponding unit | Sensor resistance is infinity or zero (open/short circuit). | Check connection of TF sensor connector and wiring. Check resistance characteristics of TF sensor. Check for failure in indoor P.C. board. |
| F12 | F12 | 01: TS1 sensor
trouble
03: TS3 sensor
trouble
04: TS3 sensor
disconnection | VF | TS1/TS3
sensor trouble | All stop | Sensor resistance is infinity or zero (open/short circuit). When TS3 detects an unusual temperature during compressor operation and PMV4 operation in cooling mode. | Check connection of TS1/TS3 sensor connector Check resistance characteristics of TS1/TS3 sensor. The attachment check of TS3 sensor. Check for failure in indoor P.C. board. |
| F13 | F13 | 1*: Compressor
1 side
2*: Compressor
2 side | Compressor
P.C. board | TH sensor trouble | All stop | Sensor resistance is infinity or zero (open/short circuit). | Failure in IPM built-in temperature sensor → Replace Compressor P.C. board. |
| F15 | F15 | _ | l/F | Outdoor
temperature
sensor wiring
trouble (TE1,
TL1) | All stop | During compressor
operation in HEAT mode,
TL1 continuously provides
temperature reading higher
than indicated by TL1 by at
least specified margin for 3
minutes or more. | Check installation of TE1 and TL1 sensors. Check resistance characteristics of TE1 and TL1 sensors. Check for outdoor P.C. board (I/F) trouble |

| | Check | | Location | | | Observation of the sale | |
|-------------|---------|--|--------------------------|--|----------------------------|--|--|
| Main remote | Outdoor | 7-segment display | of | Description | System status | Check code detection condition(s) | Check items (locations) |
| controller | code | Sub-code | detection | | | | |
| F16 | F16 | _ | I/F | Outdoor
pressure
sensor wiring
trouble (Pd, Ps) | All stop | Readings of high-pressure
Pd sensor and low-pressure
Ps sensor are switched.
Output voltages of both
sensors are zero. | Check connection of high-pressure Pd sensor connector. Check connection of low-pressure Ps sensor connector. Check for failure in pressure sensors Pd and Ps. Check for trouble in outdoor P.C. board (I/F). Check for compressor poor compression. |
| F23 | F23 | _ | I/F | Ps sensor
trouble | All stop | Output voltage of Ps sensor is zero. | Check for connection trouble involving Ps sensor and Pd sensor connectors. Check connection of Ps sensor connector. Check for failure in Ps sensor. Check for compressor poor compression. Check for failure in 4-way valve. Check for failure in outdoor P.C. board (I/F). Check for failure in SV4 circuit. |
| F24 | F24 | _ | I/F | Pd sensor
trouble | All stop | Output voltage of Pd sensor is zero (sensor open-circuited). Pd > 4.15MPa despite compressor having been turned off. | Check connection of Pd sensor connector. Check for failure in Pd sensor. Check for failure in outdoor P.C. board (I/F). |
| F29 | _ | _ | Indoor unit | Other indoor trouble | Stop of corresponding unit | Indoor P.C. board does not operate normally. | Check for failure in indoor
P.C. board (failure
EEPROM) |
| F31 | F31 | _ | I/F | Outdoor
EEPROM
trouble | All stop *1 | Outdoor P.C. board (I/F) does not operate normally. | Check power supply voltage. Check power supply noise. Check for failure in outdoor P.C. board (I/F). |
| H01 | H01 | 1*: Compressor
1 side
2*: Compressor
2 side | Compressor
P.C. board | Compressor
breakdown | All stop | Inverter current detection circuit detects overcurrent and shuts system down. | Check power supply voltage. (AC380V ± 10%). Check for failure in compressor. Check for possible cause of abnormal overloading. Check for failure in outdoor P.C. board (Compressor). |
| H02 | H02 | 1*: Compressor
1 side
2*: Compressor
2 side | Compressor
P.C. board | Compressor
trouble (lockup)
MG-CTT trouble | All stop | Overcurrent is detected several seconds after startup of inverter compressor. | Check for failure in compressor. Check power supply voltage. (AC380V ± 10%). Check compressor system wiring, particularly for open phase. Check connection of connectors/terminals on compressor P.C. board. Check conductivity of case heater. (Check for refrigerant problem inside compressor.) Check for failure in outdoor P.C. board (Compressor). |
| H03 | H03 | 1*: Compressor
1 side
2*: Compressor
2 side | Compressor
P.C. board | Current
detection
circuit trouble | All stop | Current flow of at least
specified magnitude is
detected despite inverter
compressor having been
shut turned off. | Check current detection circuit wiring. Check failure in outdoor P.C. board (Compressor). |

^{*1} Total shutdown in case of header unit Continued operation in case of follower unit

| | Check | code | 1 4' | | | | |
|-------------|------------|--|-----------|--|---------------|--|--|
| Main remote | | 7-segment display | OI OI | Description | System status | Check code detection condition(s) | Check items (locations) |
| controller | Check code | Sub-code | detection | | | | |
| H05 | H05 | _ | I/F | TD1 sensor
miswiring
(incomplete
insertion) | All stop | Discharge temperature of compressor 1 (TD1) does not increase despite compressor being in operation. | Check installation of TD1 sensor. Check connection of TD1 sensor connector and wiring. Check resistance characteristics of TD1 sensor. Check for failure in outdoor P.C. board (I/F). |
| H06 | H06 | _ | VF | Activation of low-pressure protection | All stop | Low-pressure Ps sensor detects operating pressure lower than 0.02MPa. | Check service valves to confirm full opening (both gas and liquid sides). Check outdoor PMVs for clogging (PMV1, 2, 3). Check for failure in SV4 circuits. Check for failure in low-pressure Ps sensor. Check indoor filter for clogging. Check valve opening status of indoor PMV. Check refrigerant piping for clogging. Check operation of outdoor fan (during heating). Check for insufficiency in refrigerant quantity. |
| H07 | H07 | _ | I/F | Low oil level protection | All stop | Operating compressor detects continuous state of low oil level for about 2 hours. | <all be="" checked="" corresponding="" in="" line="" outdoor="" to="" units=""> Check connection and installation of TK1 and TK2 sensors. Check resistance characteristics of TK1 and TK2 sensors. Check for gas or oil leak in same line. Check for refrigerant problem inside compressor casing. Check SV3D, SV3F valves for failure. Check oil return circuit of oil separator for clogging. Check oil equalizing circuit for clogging. </all> |
| H08 | H08 | 01: TK1 sensor
trouble
02: TK2 sensor
trouble | l/F | Trouble in
temperature
sensor for oil
level detection | All stop | Sensor resistance is infinity or zero (open/short circuit). | Check connection of TK1 sensor connector. Check resistance characteristics of TK1 sensor. Check for failure in outdoor P.C. board (I/F). |
| | | | | | All stop | Sensor resistance is infinity or zero (open/short circuit). | Check connection of TK2 sensor connector. Check resistance characteristics of TK2 sensor. Check for failure in outdoor P.C. board (I/F). |
| H15 | H15 | _ | VF | TD2 sensor
miswiring
(incomplete
insertion) | All stop | Discharge temperature of (TD2) does not increase despite compressor 2 being in operation. | Check installation of TD2 sensor. Check connection of TD2 sensor connector and wiring. Check resistance characteristics of TD2 sensor. Check for failure in outdoor P.C. board (I/F). |

| | Check | code | 1 4' | | | | |
|-------------|---------------|--|--------------------------|---|----------------------------|---|---|
| Main remote | | 7-segment display | Location of | Description | System status | Check code detection condition(s) | Check items (locations) |
| controller | Check
code | Sub-code | detection | | | oonamon(o) | |
| | | 01: TK1 oil
circuit trouble
02: TK2 oil
circuit trouble | I/F | Oil level
detection
circuit trouble | All stop | No temperature change is detected by TK1 despite compressor 1 having been started. | Check for disconnection of TK1 sensor. Check resistance characteristics of TK1 sensor. Check for connection trouble involving TK1 and TK2 sensors Check for clogging in oil equalizing circuit capillary. Check for refrigerant entrapment inside compressor. |
| H16 | H16 | | | | | No temperature change is detected by TK2 despite compressor 2 having been started. | Check for disconnection of TK2 sensor. Check resistance characteristics of TK2 sensor. Check for connection trouble involving TK1 and TK2 sensors Check SV3F valve malfunction. Check for clogging in oil equalizing circuit capillary. Check for refrigerant entrapment inside compressor. |
| H17 | H17 | 1*: Compressor
1 side
2*: Compressor
2 side | Compressor
P.C. board | Compressor
trouble
(Step-out) | All stop | Compressor is in step-out condition. | Check power supply voltage. (AC380V ± 10%). Check for failure in compressor. Check for possible cause of abnormal overloading. Check for failure in outdoor P.C. board (compressor). |
| L02 | L02 | Detected indoor unit address | Indoor unit | Outdoor units
model
disagreement
trouble | Stop of corresponding unit | In case of different outdoor
unit (Not corresponded to
Air to Air Heat Exchanger
type) | Check outdoor unit model.
(Check whether the
outdoor unit corresponds
to Air to Air Heat
Exchanger type or not.) |
| L03 | _ | _ | Indoor unit | Duplicated indoor header unit | Stop of corresponding unit | There are more than one header units in group. | Check indoor addresses. Check for any change made to remote controller connection (group/individual) since indoor address setting. |
| L04 | L04 | _ | I/F | Duplicated outdoor line address | All stop | There is duplication in line address setting for outdoor units belonging to different refrigerant piping systems. | Check line addresses. |
| L05 | _ | _ | I/F | Duplicated priority indoor unit (as displayed on priority indoor unit) | All stop | More than one indoor units have been set up as priority indoor unit. | Check display on priority indoor unit. |
| L06 | L06 | No. of priority indoor units | I/F | Duplicated
priority indoor
unit (as
displayed on
indoor unit other
than priority
indoor unit) | All stop | More than one indoor units have been set up as priority indoor unit. | Check displays on priority
indoor unit and outdoor
unit. |
| L07 | _ | _ | Indoor unit | Connection of
group control
cable to
standalone
indoor unit | Stop of corresponding unit | There is at least one standalone indoor unit to which group control cable is connected. | Check indoor addresses. |
| L08 | L08 | _ | Indoor unit | Indoor group /
addresses not
set | Stop of corresponding unit | Address setting has not been performed for indoor units. | Check indoor addresses. Note: This code is displayed when power is turned on for the first time after installation. |
| L09 | _ | _ | Indoor unit | Indoor capacity not set | Stop of corresponding unit | Capacity setting has not been performed for indoor unit. | Set indoor capacity. (DN = 11) |

| | Check code | | | | | | | | |
|-------------|---------------|--|-----------------------------------|--|----------------------------|---|---|--|---|
| Main remote | Outdoor Check | 7-segment display | Location
of | Description | System status | Check code detection condition(s) | Check items (locations) | | |
| controller | code | Sub-code | detection | | | , , | | | |
| L10 | L10 | _ | I/F | Outdoor capacity not set | All stop | Initial setting of I/F P.C. board has not been implemented. | Check model setting of
P.C. board for servicing
outdoor I/F P.C. board. | | |
| L17 | L17 | ı | l/F | Outdoor model incompatibility trouble | All stop | Outdoor unit that cannot be connected is connected. | Check the model name of
the outdoor unit. | | |
| L20 | _ | _ | Network
adaptor
Indoor unit | Duplicated central control address | All stop | There is duplication in central control address setting. | Check central control addresses. | | |
| L23 | _ | _ | I/F | SW setting trouble | All stop | Outdoor P.C. board (I/F) does not operate normally. | Check switch setting of
outdoor P.C. board (I/F). | | |
| L28 | L28 | - | l/F | Too many outdoor units connected | All stop | There are more than 5 outdoor units. | Check No. of outdoor units connected (Only up to 5 units per system allowed). Check communication lines between outdoor units. Check for failure in outdoor P.C. board (I/F). | | |
| L29 | L29 | P.C.board Compressor Fan Motor 1 2 1 2 2 0 0 0 0 0 0 0 0 | VF | Trouble in No. of P.C. board | All stop | Insufficient number of P.C. board are detected when power is turned on. | Check model setting of P.C. board for servicing outdoor I/F P.C. board. Check connection of UART communication connector. Check compressor P.C. board, fan P.C. board, and I/F P.C. board for failure. | | |
| | | | | 00 | I/F | The number of inverter P.C. boards is abnormal. | All stop | When there is much number of an inverter P.C. board to model setting of an interface P.C. board. | Check I/F P.C. board exchange has been correctly performed as a procedure. Check for failure in I/F P.C. board. Check for inverter P.C. board for compressors and inverter P.C. board for fan |
| L30 | L30 | Detected indoor address | Indoor unit | Indoor external
interlock
(External
abnormal input) | Stop of corresponding unit | Indoor unit has been shut
down due to external
abnormal input signal. | When external device is connected: 1) Check for trouble in external device. 2) Check for trouble in indoor P.C. board. When external device is not connected: 1) Check for trouble in indoor P.C. board. | | |
| _ | L31 | _ | I/F | Extended IC trouble | Continued operation | There is part failure in P.C. board (I/F). | Check outdoor P.C. board (I/F). | | |
| P01 | _ | _ | Indoor unit | Indoor fan
motor trouble | Stop of corresponding unit | | Check the lock of fan motor (AC fan). Check wiring. | | |
| P03 | P03 | _ | VF | Discharge
temperature
TD1 trouble | All stop | Discharge temperature (TD1) exceeds 115 °C. | Check outdoor service valves (gas side, liquid side) to confirm full opening. Check outdoor PMVs (PMV1, 2, 3, 4) for clogging. Check resistance characteristics of TD1 sensor. Check for insufficiency in refrigerant quantity. Check for failure in 4-way valve. Check for leakage of SV4 circuit. Check SV4 circuit (wiring or installation trouble in SV41 or SV42). | | |

| | Check code | | | | | | |
|-------------|---------------|---|----------------------------|--|---------------|---|---|
| Main remote | | 7-segment display | Location of | Description | System status | Check code detection condition(s) | Check items (locations) |
| controller | Check
code | Sub-code | detection | | | oonamon(o) | |
| P04 | P04 | 01: Compressor
1 side
02: Compressor
2 side | I/F | Activation of high-pressure SW | All stop | High-pressure SW is activated. | Check connection of highpressure SW connector. Check for failure in Pd pressure sensor. Check outdoor service valves (gas side, liquid side) to confirm full opening. Check for failure in outdoor fan. Check for failure in outdoor fan motor. Check outdoor PMVs (PMV1, 2, 3) for clogging. Check indoor/outdoor heat exchangers for clogging. Check for short-circuiting of outdoor suction/discharge air flows. Check for failure in outdoor P.C. board (I/F). Check for trouble in indoor fan system (possible cause of air flow reduction). Check opening status of indoor PMV. Check indoor-outdoor communication line for wiring trouble. Check for failure operation of check valve in discharge pipe convergent section. Check gas balancing SV4 valve circuit. |
| P05 | P05 | 00: Power detection trouble 01: Open phase 02: Power supply miswiring 1*: Compressor 1 side | I/F Compressor P.C. board | Power detection
trouble / Open
phase detection
/ Power supply
miswiring
Compressor
Vdc trouble | All stop | Open phase is detected
when power is turned on. Inverter DC voltage is too
high (overvoltage) or too
low (undervoltage). | Check for failure in outdoor P.C. board (I/F). Check wiring of outdoor power supply. Check power supply voltage. |
| | | 2*: Compressor
2 side | r.o. board | vao nousio | All . | | |
| | | 1*: Compressor
1 side
2*: Compressor
2 side | Compressor
P.C. board | Heat sink
overheating
trouble | All stop | Temperature sensor built into IPM (TH) is overheated. | Check outdoor fan system trouble. Check IPM and heat sink for thermal performance for failure installation. (e.g. mounting screws and thermal conductivity) Check for failure in Compressor P.C. board. (failure IPM built-in temperature sensor (TH)) |
| P07 | P07 | 01: Compressor
1 heat sink
trouble
02: Compressor
2 heat sink
trouble
04: Heat sink
dewing | I/F | Heat sink
overheating
trouble
Heat sink
dewing trouble | All stop | Condensation detection on heat sink has occurred four times or more in operation. Temperature sensor built into IPM (TH) is overheated. | Check outdoor fan system trouble. Check IPM and heat sink for thermal performance for troubled installation. (e. g. mounting screws and thermal conductivity) Check for failure in compressor P.C. board. (failure IPM built-in temperature sensor (TH)) Check shortage of refrigerant. Check outdoor service valves. Check connection of TL2 sensor. Check resistance characteristics of TL2 sensor. Check resistance characteristics of TO sensor. Check malfunctions of Pd and Ps sensors. Check outdoor I/F P.C. board malfunction. Check PMV2 and PMV3 |

| | Check code | | | | | | | |
|-------------|---------------|-------------------------|------------------|--|---|---|--|--|
| Main remote | | 7-segment display | Location of | Description | System status | Check code detection condition(s) | Check items (locations) | |
| controller | Check
code | Sub-code | detection | | | 00114111011(0) | | |
| P10 | P10 | Detected indoor address | Indoor unit | Indoor overflow trouble | All stop | Float switch operates. Float switch circuit is open-circuited or disconnected at connector. | Check float switch connector. Check operation of drain pump. Check drain pump circuit. Check drain pipe for clogging. Check for failure in indoor P.C. board. | |
| P11 | _ | _ | I/F | Outdoor heat
exchanger
freeze trouble | All stop | Outdoor heat exchanger
remaining frost detection
has occurred eight times
or more due to abnormal
frost formation in heating
operation. | Check shortage of refrigerant. Check connection of TE1, TE2 and TE3 sensors. Check resistance characteristics of TE1, TE2, and TE3 sensors. Check disconnection of TS1 sensor. Check resistance characteristics of TS1 sensor. Check outdoor I/F P.C. board malfunction. Check operation of 4 way valve. Check operation of outdoor PMV (1, 2, 3). Check short circuit from outlet air to inlet air. | |
| P12 | _ | _ | Indoor unit | Indoor fan
motor trouble | Stop of
corresponding
unit | Motor speed
measurements
continuously
deviate from target
value. Overcurrent
protection is
activated. | Check connection of fan connector and wiring. Check for failure in fan motor. Check for failure in indoor P.C. board. Check impact of outside air treatment (OA). | |
| P13 | P13 | _ | I/F | Outdoor liquid
backflow
detection
trouble | All stop | <during cooling="" operation="">
When system is in cooling
operation, high pressure is
detected in the unit that
has been turned off. <during heating="" operation="">
When system is in heating
operation, low pressure is
detected to be high in unit
that has been turned off.</during></during> | Check full-close operation of outdoor PMV (1, 2, 3, 4). Check for failure in Pd or Ps sensor. Check failure in outdoor P.C. board (I/F). Check capillary of oil separator oil return circuit for clogging. Check for leakage of check valve in discharge pipe | |
| P15 | P15 | 01: TS condition | I/F | Gas leak
detection
(TS1 condition) | All stop | Protective shutdown due to sustained suction temperature at or above judgment criterion for at least 10 minutes is repeated four times or more. <ts criterion="" judgment="" trouble="">In cooling operation: 60 °C In heating operation: 40 °C</ts> | Check for insufficiency in refrigerant quantity. Check outdoor service valves (gas side, liquid side) to confirm full opening. Check PMVs (PMV1, 2, 3, 4) for clogging. Check resistance characteristics of TS1 sensor. Check for failure in 4-way valve. Check SV4 circuit for leakage | |
| . 10 | | | 02: TD condition | I/F | Gas leak
detection
(TD condition) | All stop | Protective shutdown due to
sustained discharge
temperature (TD1 or TD2)
at or above 108 °C for at
least 10 minutes is repeated
four times or more. | Check for insufficiency in refrigerant quantity. Check PMVs (PMV 1, 2, 3, 4) for clogging. Check resistance characteristics of TD1 and TD2 sensors. Check indoor filter for clogging. Check piping for clogging. Check SV4 circuit (for leakage or coil installation trouble). |


| | Check | code | | | | | |
|----------------------|------------|---------------------------|-------------|---|-----------------|--|---|
| Main | Outdoor | 7-segment display | Location of | Description | System status | Check code detection | Check items (locations) |
| remote
controller | Check code | Sub-code | detection | Docompaion | - Cyclom cultur | condition(s) | Check nome (recallency |
| P17 | P17 | _ | I/F | Discharge
temperature
TD2 trouble | All stop | Discharge temperature (TD2) exceeds 115 °C. | Check outdoor service valves (gas side, liquid side) to confirm full opening. Check outdoor PMVs (PMV1, 2, 3, 4) for clogging. Check resistance characteristics of TD2 sensor. Check for failure in 4-way valve. Check SV4 circuit for leakage. Check SV4 circuit (for wiring or installation trouble involving SV41 and SV42). |
| P19 | P19 | Detected outdoor unit No. | I/F | 4-way valve
reversing
trouble | All stop | Abnormal refrigerating cycle data is collected during heating operation. | Check for failure in main body of 4-way valve. Check for coil failure in 4-way valve and loose connection of its connector. Check resistance characteristics of TS1 and TE1,TE2 sensors. Check output voltage characteristics of Pd and Ps pressure sensors. Check for wiring trouble involving TE1 and TL1 sensors. |
| P20 | P20 | _ | I/F | Activation of high-pressure protection | All stop | <during cooling="" operation="">
Pd sensor detects pressure
equal to or greater than
3.85 MPa. <during heating="" operation="">
Pd sensor detects pressure
equal to or greater than
3.6 MPa.</during></during> | Check for failure in Pd pressure sensor. Check service valves (gas side, liquid side) to confirm full opening. Check for failure in outdoor fan. Check for failure in outdoor fan motor. Check outdoor PMV (PMV1, 2, 3, 4) for clogging. Check indoor/outdoor heat exchangers for clogging. Check for short-circuiting of outdoor suction/ discharge air flows. Check for failure in outdoor P.C. board (I/F). Check for failure in indoor fan system (possible cause of air flow reduction). Check opening status of indoor PMV. Check indoor-outdoor communication line for wiring trouble. Check for troble operation of check valve in discharge pipe convergent section. Check for refrigerant overcharging. |


| | Check | code | | | | | |
|----------------------|---------------------------|--|--------------------------|---|----------------------------|--|--|
| Main | Outdoor 7-segment display | | Location of | Description | System status | Check code detection condition(s) | Check items (locations) |
| remote
controller | Check code | Sub-code | detection | | - | condition(s) | , |
| P22 | P22 | 1*: Fan P.C.
board 1
2*: Fan P.C.
board 2 | Fan INV.
P.C. board | Outdoor fan
P.C. board
trouble | All stop | Protected operation of Fan inverter P.C. board | Check fan motor. Check for failure in fan P.C. board. Check connection of fan motor connector. Check power voltage of the main power supply. |
| P26 | P26 | 1*: Compressor
1 side
2*: Compressor
2 side | Compressor
P.C. board | IPM,
Compressor
shortcircuit
protection
trouble | All stop | Overcurrent is momentarily detected during startup of compressor. | Check connector connection and wiring on compressor P.C. board. Check for failure in compressor (layer shortcircuit). Check for failure in outdoor P.C. board (Compressor). |
| P29 | P29 | 1*: Compressor
1 side
2*: Compressor
2 side | Compressor
P.C. board | Compressor
position
detection circuit
trouble | All stop | Position detection is not going on normally. | Check wiring and connector connection. Check for compressor layer short-circuit. Check for failure in compressor P.C. board. |
| P31 | _ | _ | Indoor unit | Other indoor
trouble
(group follower
unit trouble) | Stop of corresponding unit | There is trouble in other indoor unit in group, resulting in detection of E07/L07/L03/L08. | Check indoor P.C. board. |


Check codes Displayed on Central Control Device


| | Check | code | | | | | |
|----------------------|--|-------------------|--------------------------------------|--|----------------------------|---|---|
| Main | Outdoor | 7-segment display | Location of | Description System statu | System status | Check code detection | Check items (locations) |
| remote
controller | Check code Sub-code | | detection | 2000 | | condition(s) | (|
| E03 | | _ | Indoor unit | Indoor-remote
controller
communication
trouble
(detected at
indoor end) | Stop of corresponding unit | There is no communication from remote controller (including wireless) or network adaptor. | Check remote controller
and network adaptor
wiring. |
| C05 | | | Central
control
device | Central control
device
transmission
trouble | Continued operation | Central control device is unable to transmit signal. | Check for failure in central control device. Check for failure in central control communication line. Check termination resistance setting. |
| C06 | | | Central
control
device | Central control
device reception
trouble | Continued operation | Central control device is unable to receive signal. | Check for failure in central control device. Check for failure in central control communication line. Check terminator resistor setting. Check power supply for devices at other end of central control communication line. Check failure in P.C. boards of devices at other end of central control communication line. |
| C12 | _ | | General-
purpose
device
I/F | Batch alarm
for general-
purpose
device
control interface | Continued operation | Trouble signal is input to control interface for general-purpose devices. | Check trouble input. |
| P30 | Differs according to nature of alarm-causing trouble | | Central
control
device | Group control follower unit trouble | Continued operation | Trouble occurs in follower unit under group control. ([P30] is displayed on central control remote controller.) | Check check code of unit
that has generated alarm. |
| | (L20 displayed.) | | | Duplicated central control address | Continued operation | There is duplication in central control addresses. | Check address settings. |
| S01 | | _ | _ | _ | _ | Receiving trouble in central control device. | Check central control device. |


9-5. Diagnostic Procedure for Each Check Code (Indoor Unit)































| Cause | Indoor unit / Leak Detector communication
connector trouble. Refrigerant sensor trouble. I. Leak Detector P.C. board trouble. | Cause | Refrigerant leak detection | | Refrigerant sensor trouble (Exceeding its life of the product) Leak Detector P.C. board trouble. |
|-------|--|-----------------|--|---|--|
| name | Leak Detector trouble 1. Indo
con
2. Ref
3. Lea | Check code name | Refrigerant leak detection 1. Ref | - | Refrigerant leak detection sensor 1. Ref
exceeding its of the product. (Exceeding its of the product. |
| de | [J29] Lee | Check code | [J30] Re | - | [J31] Re |















9-6. Sensor characteristics

Indoor unit

▼ Temperature sensor characteristics



| Temperature [°C] | Resistance [k Ω] |
|------------------|--------------------------|
| 0 | 33.9 |
| 5 | 26.1 |
| 10 | 20.3 |
| 15 | 15.9 |
| 20 | 12.6 |
| 25 | 10.0 |
| 30 | 8.0 |
| 35 | 6.4 |
| 40 | 5.2 |
| 45 | 4.2 |
| 50 | 3.5 |
| 55 | 2.6 |
| 60 | 2.4 |
| | |

| Indoor TC1 sensor | |
|---|--|
| 200 - | 20 |
| $\begin{array}{c} 150 \\ \text{Resistance } [k\Omega] \\ (10^{\circ}\text{C or below}) \end{array}$ | - 15
Resistance [kΩ]
(10°C or above) |
| 100 | 10 |
| 50 - | - 5 |
| | |
| 0 L |]
00 |
| Temperature [°C] | |

| Temperature [°C] | Resistance [k Ω] |
|------------------|--------------------------|
| -20 | 99.9 |
| -15 | 74.1 |
| -10 | 55.6 |
| - 5 | 42.2 |
| 0 | 32.8 |
| 5 | 25.4 |
| 10 | 19.8 |
| 15 | 15.6 |
| 20 | 12.4 |
| 25 | 10.0 |
| 30 | 8.1 |
| 35 | 6.5 |
| 40 | 5.3 |
| 45 | 4.4 |
| 50 | 3.6 |
| 55 | 3.0 |
| 60 | 2.5 |
| 65 | 2.1 |
| 70 | 1.8 |
| 75 | 1.5 |
| 80 | 1.3 |
| 85 | 1.1 |
| 90 | 1.0 |
| 95 | 0.8 |
| 100 | 0.7 |
| | |

| Indoor TC2 and TCJ sensors | | |
|---|----|---------------------------------------|
| 200 | - | 20 |
| 150 -
Resistance [kΩ]
(10°C or below) | | 15 Resistance [kΩ] (10°C or above) 10 |
| | 01 | 5 |

| Temperature [°C] | Resistance [k Ω] |
|------------------|--------------------------|
| -20 | 115.2 |
| -15 | 84.2 |
| -10 | 62.3 |
| - 5 | 46.6 |
| 0 | 35.2 |
| 5 | 26.9 |
| 10 | 20.7 |
| 15 | 16.1 |
| 20 | 12.6 |
| 25 | 10.0 |
| 30 | 8.0 |
| 35 | 6.4 |
| 40 | 5.2 |
| 45 | 4.2 |
| 50 | 3.5 |
| 55 | 2.8 |
| 60 | 2.4 |
| 65 | 2.0 |
| 70 | 1.6 |
| 75 | 1.4 |
| 80 | 1.2 |
| · | |

▼ Winding resistance of PMV (Pulse Motor Vale) coil

| Measure position | Resistance value |
|--------------------|------------------|
| White - Red (COM) | |
| Yellow - Red (COM) | 180 to 220 O |
| Orange - Red (COM) | |
| Blue - Red (COM) | |

at 20°C

9-7. Maintenance list

Aiming in environmental preservation, it is strictly recommended to clean and maintain the indoor/outdoor units of the operating air conditioning system regularly to secure effective operation of the air conditioner.

It is also recommended to maintain the units once a year regularly when operating the air conditioner for a long time.

Check periodically signs of rust or scratches, etc. on coating of the outdoor units.

Repair the defective position or apply the rust resisting paint if necessary.

If an indoor unit operates for approx. 8 hours or more per day, usually it is necessary to clean the indoor/outdoor units once three months at least.

These cleaning and maintenance should be carried out by a qualified dealer.


Although the customer has to pay the charge for the maintenance, the life of the unit can be prolonged. Failure to clean the indoor/outdoor units regularly will cause shortage of capacity, freezing, water leakage or trouble on the compressor.

<Check list>

| Dort name | Object | | Contents of sheek | Contents of maintenance | |
|------------------------------|----------|----------|--|---|--|
| Part name | Indoor | Outdoor | Contents of check | Contents of maintenance | |
| Heat exchanger | ✓ | ✓ | Blocking with dust, damage check | Clean it when blocking is found. | |
| Fan motor | ✓ | ✓ | Audibility for sound | When abnormal sound is heard | |
| Filter | ✓ | _ | Visual check for dirt and breakage | Clean with water if dirty Replace if any breakage | |
| Fan | √ | √ | Visual check for swing and balance Check adhesion of dust and external appearance. | Replace fan when swinging or
balance is remarkably poor. If a large dust adheres, clean it with
brush or water. | |
| Suction/
Discharge grille | ✓ | _ | Visual check for dirt and scratch | Repair or replace it if deformation or
damage is found. | |
| Drain pan | ✓ | _ | Check blocking by dust and dirt of drain water. | Clean drain pan, Inclination check | |
| Front panel, Louver | ✓ | _ | Check dirt and scratch. | Cleaning/Coating with repair painting | |
| External appearance | _ | √ | Check rust and pealing of insulator Check pealing and floating of coating film | Coating with repair painting | |

9-8. Notice code

- Notice code is a function only in TC2U-LINK communication.
- When the outdoor or indoor unit detects its conditions requiring caution or maintenance, this function notices you to check your units with the spanner mark (Notice code mark) on the wired remote controller or central controller display.
- · Even while the notice code mark is displayed, the air conditioner can operate normally.
- A maximum of 5 notice codes can be issued simultaneously in one system (line).



■ How to check Notice code No.

- 1 Stop the operation of the air conditioner and push the Menu button and OFF timer button at the same time for 10 seconds or more.
- **2** The unit number of the indoor unit is displayed at the bottom left of the screen. Change it with the $[\nabla]$ [\triangle] setting button and push the OFF timer button to confirm.
- 3 The history number is displayed in the center of the screen, and the Notice code No. is displayed in the lower left.
 [√] [△] You can switch the history with the setting button (a maximum of 5 notice codes).
- **4** Push the ON / OFF button to return to the operation stop screen.

■ Notice code list

| Notice code
No. | ltem | Content |
|--------------------|------------------------------------|--|
| 203 | Flow Selector unit battery dead | The battery kit connected to the Flow Selector unit has reached the end of its life. |
| 204 | Leak Detector life advance display | The Leak Detector will soon reach the end of its life. |

10. P.C. BOARD EXCHANGE PROCEDURES

Indoor unit

10-1. Replacement of indoor P.C. boards

CAUTION

For this model, please make all the following settings.

| CODE No.(DN) | Setting data | Description |
|--------------|--------------------|---------------|
| E0 | 0004 | Global model |
| CF | Depending on model | Model setting |

<Note: when replacing the P.C. board for indoor unit servicing>

The nonvolatile memory (hereafter called EEPROM, IC503) on the indoor unit P.C. board before replacement includes the model specific type information and capacity codes as the factory-set value and the important setting data which have been automatically or manually set when the indoor unit is installed, such as system/indoor/group addresses, high ceiling select setting, etc.

When replacing the P.C. board for indoor unit servicing, follow the procedures below.

After replacement completes, confirm whether the settings are correct by checking the indoor unit No., Group header unit/follower unit settings and perform the cooling cycle confirmation through the trial operation.

<Replacement procedures>

CASE 1

Before replacement, the indoor unit can be turned on and the setting data can be read out by wired remote control operation.

EEPROM data read out [1]



Replacement of P.C. board for Indoor unit servicing and power on [2]



Writing the read out EEPROM data [3]



Power reset

(for all indoor units connected to the remote control when the group operation control is performed.)

CASE 2

The EEPROM before replacement is incomplete and the setting data cannot be read out.

Replacement of P.C. board for Indoor unit servicing and power on [2]



Writing the setting data to EEPROM, such as high ceiling installation setting and optional connection setting, etc., based on the customer information. [3]




Power reset

(for all indoor units connected to the remote control when the group operation control is performed.)

[1] Setting data read out from EEPROM

The setting data modified on the site, other than factory-set value, stored in the EEPROM shall be read out. <RBC-ASCU11-*>



- **Step1** Push and hold the [menu + ∇] buttons at same time for more than 10 seconds.
 - *When the group operation control is performed, the unit No. displayed for the first time is the header unit No.

At this time, the Code No. (DN) shows "10". Also, the fan of the indoor unit selected starts its operation and the swing operation also starts if it has the louvers.

- **Step2** Every time when the $[\nabla \text{ or } \Delta]$ button is pushed, the indoor unit No. under the group control is displayed in order. Specify the indoor unit No. to be replaced.
 - 1. Change the Code No. (DN) to $10 \rightarrow 01$ by pushing [∇ or Δ] buttons setting. (this is the setting for the filter sign lighting time.)

 At this time, be sure to write down the setting data displayed.
 - 2. Change the Code No. (DN) by pushing [∇ or Δ] buttons. Similarly, be sure to write down the setting data displayed.
 - 3. Repeat the step 2-2 to set the other settings in the same way and write down the setting data in the manual that comes with the P.C. board. (See pages 85 to 87).

<RBC-AMTU3*>

[1] Setting data read out from EEPROM

The setting data modified on the site, other than factory-set value, stored in the EEPROM shall be read out.

- Step 1 Push \(\tilde{\bigcirc} \), \(\tilde{\bigcirc} \) and \(\tilde{\bigcirc} \) button on the remote controller simultaneously for more than 4 seconds.
 - *When the group operation control is performed, the unit No. displayed for the first time is the header unit No.
 - At this time, the CODE No. (DN) shows " \square ". Also, the fan of the indoor unit selected starts its operation and the swing operation also starts if it has the louvers.
- Step 2 Every time when the (left side button) button is pushed, the indoor unit No. under the group control is displayed in order. Specify the indoor unit No. to be replaced.
 - Change e the CODE No. (DN) to □→□ t by pushing ▼ / ▲ buttons for the temperature setting. (this is the setting for the filter sign lighting time.)
 At this time, be sure to write down the setting data displayed.
 - 2. Change the CODE No. (DN) by pushing \(\textit{\textit{\$\sigma}}\) / \(\textit{\$\textit{\$\sigma}\$}\) buttons for the temperature setting. Similarly, be sure to write down the setting data displayed.
 - 3. Repeat the step 2-2 to set the other settings in the same way and write down the setting data in the manual that comes with the P.C. board. (See pages 85 to 87).

CODE No. required at least

| DN | Contents | |
|----|----------------------|--|
| 10 | Туре | |
| 11 | Indoor unit capacity | |
| 12 | System address | |
| 13 | Indoor unit address | |
| 14 | Group address | |
| CF | Model setting | |
| E0 | Destination | |


- 1. The Code No. for the Indoor unit type and Indoor unit capacity are required to set the rotation number setting of the fan.
- 2. If the system/indoor/group addresses are different from those before replacement, the auto-address setting mode starts and the manual resetting may be required again. (when the multiple units group operation including twin system.)

Step3 After writing down all setting data, push [ON/OFF] button to return to the normal stop status. (It takes approx. 1 min until the remote controller operation is available again.)

[2] P.C. Board for indoor unit servicing replacement procedures (e.g. MCC-1643)


Step1 Replace the P.C. board to the P.C. board for indoor unit servicing.

At this time, perform the same setting of the jumper wire (J01, J08, J09) setting (cut), switch SW501, (short-circuit) connector CN34 as the setting of the P.C. board before replacement.



- **Step2** It is necessary to set indoor unit to be exchanged: Remote controller = 1 : 1

 Based upon the system configuration, turn on power of the indoor unit with one of the following items.
 - 1) Single (Individual) operation. Turn on power of the indoor units and proceed to [3].
 - 2) Group operation
 - A) In case that power of the exchanged indoor unit only can be turned on Turn on power of the exchanger indoor unit only and proceed to [3].
 - B) In case that power of the indoor units cannot be turned on individually (Case 1)
 - a) Remove temporarily the group wire connected to the terminal blocks A and B of the indoor unit.
 - b) After connecting the remote controller wire only to the removed terminal block, turn on power of the indoor units and proceed to [3].
 - * When the above methods cannot be used, follow to the two cases below.
 - C) In case that power of the indoor units cannot be turned in individually (Case 2)
 - a) Remove all CN41 connectors of the indoor units in the same group except those of the exchanged indoor unit.
 - b) Turn on power of the indoor units and proceed to [3].
 - * After [3] operation has finished, be sure to return the temporarily removed group wire or CN41 connector to the original connection.



[3] Writing the setting data to EEPROM

The settings stored in the EEPROM of the P.C. board for indoor unit servicing are the factory-set values.

<RBC-ASCU11-*>

- **Step 1** Push and hold the [menu + ∇] buttons at same time for more than 10 seconds.
 - *When the group operation control is performed, the unit No. displayed for the first time is the header unit No.
 - At this time, the Code No. (DN) shows "10". Also, the fan of the indoor unit selected starts its operation and the swing operation also starts if it has the louvers.
- **Step 2** Every time when the $[\nabla \text{ or } \triangle]$ button is pushed, the indoor unit No. in the group control operation are displayed in order.

(The settings stored in the EEPROM of the P.C. board for indoor unit servicing are the factory-set values.)

Specify the indoor unit No. with its P.C. board replaced to the P.C. board for indoor unit servicing. (You cannot perform this operation if "ALL" is displayed.)

- **Step 3** Select the Code No. (DN) can be selected by pushing the $[\nabla \text{ or } \Delta]$ button.
 - Set the indoor unit type and capacity.
 The factory-set values shall be written to the EEPROM by changing the type and capacity.
 - 1. Push the [menu] button to make Code No. flash. And set the Code No. (DN) to10.
 - 2. Push the [menu] button to make SET DATA flash. And select the type by pushing the [∇ or \triangle] buttons.

(For example, 4-way Cassette Type is set to "0001". Refer to Type DN code "10" on page 88.)

- 3. Push [OFF timer] button. (The changed data is set.)
- 4. Change the Code No. (DN) to "11" by pushing the [∇ or \triangle] buttons.
- 5. Select the capacity by pushing the [∇ or \triangle] buttons. (For example, UP009 Type is set to "0003". Refer to Indoor Unit Capacity DN code "11" on page 88.)
- 6. Push [OFF timer] button. (The changed data is set.)
- **Step 4** Write the on-site setting data to the EEPROM, such as address setting, etc. Perform the steps 1 and 2 above again.
- **Step 5** Change the Code No. (DN) to "01" by pushing the [∇ or Δ] buttons. (this is the setting for the filter sign lighting time.)
- Step 6 Check the setting data displayed at this time with the setting data put down in [1].
 - 1. If the setting data is different, modify the setting data by pushing the $[\nabla \text{ or } \Delta]$ buttons to the data put down in [1].
 - 2. If the data is the same, proceed to next step.
- Step 7 Change the Code No. (DN) by pushing the [∇ or Δ] buttons.

 As described above, check the setting data and modify to the data put down in [1].
- Step 8 Repeat the steps 6 and 7.
- **Step 9** After the setting completes, push the [ON/OFF] button to return to the normal stop status. (It takes approx. 1 min until the remote controller operation is available again.)

<RBC-AMTU3*>


- **Step 1** Push ∅, ७ and ⋓ buttons on the remote controller simultaneously for more than 4 seconds.
 - * In the group control operation, the unit No. displayed for the first time is the header unit No.. At this time, the CODE No. (DN) shows " ". Also, the fan of the indoor unit selected starts its operation and the swing operation starts if it has the louvers. (The unit No. " RLL" is displayed if the auto-address setting mode is interrupted in [2] step 2 a))
- Step 2 Every time when (left side button) button is pushed, the indoor unit No. in the group control operation are displayed in order.

(The settings stored in the EEPROM of the P.C. board for indoor unit servicing are the factory-set values.)

Specify the indoor unit No. with its P.C. board replaced to the P.C. board for indoor unit servicing. (You cannot perform this operation if "FLL" is displayed.)

- Step 3 Select the CODE No. (DN) can be selected by pushing the ▼ / ▲ button for the temperature setting.
 - Set the indoor unit type and capacity.
 The factory-set values shall be written to the EEPROM by changing the type and capacity.
 - 1. Set the CODE No. (DN) to \square . (without change)
 - 2. Select the type by pushing ▼ / ▲ buttons for the timer setting. (For example, 4-way Cassette Type is set to "☐☐☐ I". Refer to Type DN code " ☐ "on page 88.)
 - Push [™] button.
 (The operation completes if the setting data is displayed.)
 - 4. Change the CODE No. (DN) to " ! ! " by pushing / buttons for the temperature setting.
 - 5. Select the capacity by pushing ▼ / ▲ buttons for the timer setting.

 (For example, UP018 Type is set to "□□□□□ ". Refer to Indoor Unit Capacity DN code " { 1" on page 88.)
 - Push [™] button. (The setting completes if the setting data are displayed.)



- **Step 4** Write the on-site setting data to the EEPROM, such as address setting, etc. Perform the steps 1 and 2 above again.
- Step 5 Change the CODE No. (DN) to " \$\frac{1}{2}\$ 1" by pushing \$\top / \top \text{ buttons for the temperature setting.} (this is the setting for the filter sign lighting time.)
- Step 6 Check the setting data displayed at this time with the setting data put down in [1].
 - 1. If the setting data is different, modify the setting data by pushing 🔻 / 📤 buttons for the timer setting to the data put down in [1].

 The operation completes if the setting data is displayed.
 - 2. If the data is the same, proceed to next step.
- **Step 7** Change the CODE No. (DN) by pushing ▼ / ▲ buttons for the temperature setting. As described above, check the setting data and modify to the data put down in [1].
- Step 8 Repeat the steps 6 and 7.
- Step 9 After the setting completes, push button to return to the normal stop status. (It takes approx. 1 min until the remote controller operation is available again.)

 Even after modifying the data wrongly and pushing button, it is possible to return to the data before modification by pushing button if the CODE No. (DN) is not changed.

11. DETACHMENTS

11-1. Compact 4-way cassette

MMU-UP***MH*

MARNING

CAUTION

Be sure to stop operation of the air conditioner before work and then turn off switch of the breaker.

Be sure to put on gloves during working time; otherwise an injury will be caused by a part etc.

| No. Part nam | e Procedure | Remarks |
|-----------------------------------|--|--|
| No. Part nam ① Air intake grille | Procedure 1. Detachment 1) Stop operation of the air conditioner and then turn off switch of the circuit breaker. 2) Loosen the fixing screw. And slide the fixing bracket toward the inside. (M 4 × 8, 1 pcs.) 3) Holding the air intake grille, slide the hook in the direction of the arrow and slowly open the grille. 4) Remove the hook of the fall-preventive strap from the ceiling panel. Remove the hinge section of the air intake grille is opened. 2. Attachment 1) Hook the hinge of the air intake grille to the main panel, and then attach the fall-preventive strap. 2) Close the air intake grille, and then slide the hook. 3) Slide the grille fixing bracket to fix it with the screws. (M 4 × 8, 1pc.) | Remarks Air intake grille Hook Close Open Open Slide direction Close Hook Fixing bracket |
| ② Electric parts cove | 1. Detachment 1) Loosen the fixing screws (2 places) of the electric parts cover. (M 4 × 8, 2 pcs.) 2) Slide the electric parts cover toward upper side to remove it. 2. Attachment 1) Slide the electric parts cover to attach it. (Arrange the boss at the electric parts side just on the boss hole at the cover side.) 2) Tighten the screws of the electric parts cover (2 positions) to fix it. (M 4 × 8, 2 pcs.) | Hinge Electric parts cover Boss part |

| No. | Part name | Procedure | Remarks |
|-----|------------|---|--|
| 3 | Adjust | 1. Detachment | |
| | corner cap | 1) Remove the air intake grille. (Refer to 1 of ①.) | |
| | | Loosen the fixing screws on the adjust corner cap.
(M 4 x 12, 4 pcs.) | Adjust corner |
| | | 3) Slide the adjust corner cap to outside to remove it. | cap
Screw |
| | | 2. Attachment | |
| | | Matching claws (5 positions) of the adjust corner cap
to holes of the panel main unit holes and attach them. | Slide direction (1) Ceiling panel |
| | | Tighten the fixing screws of the adjust corner cap
(M 4 x 12, 4 pcs.). | January Parisi |
| | | NOTE | |
| | | Tighten the screw with a hand screwdriver and do not use a tool such as a electric screwdriver. Tightening torque: 1 N•m or less | |
| 4 | Ceiling | 1. Detachment | Slide direction |
| | panel | 1) Remove the air intake grille and the adjust corner cap. (Refer to 1 of ①and 1 of ③.) | Panel fixed implement (bracket) |
| | | 2) Remove the louver motor connector. | Panel fixed |
| | | By sliding the panel fixing bracket of the corner part,
remove it from the fixing screws. (Total 4 positions) | screw |
| | | 4) Push the tentative hanging hook at the center part of
the ceiling panel main body toward the outside of the
ceiling panel, and then remove the ceiling panel from
the indoor unit. | |
| | | 2. Attachment | |
| | | Match the louver motor connector of the ceiling panel so that it directs to the electric parts side, and then hook the tentative hanging hook at the center part of the ceiling panel main body to the bell mouth. | Louver motor Tentative hanging |
| | | Connect the louver motor connectors at the ceiling panel side and the indoor unit side. | connector hook |
| | | 3) Lift up the panel corner part and put out the screw head of the panel fixed implement. Slide the panel fixed bracket, and then fix the indoor unit and the ceiling panel. (Total 4 positions). * In case of loosening screws of the panel fixed implement so that screw head is out under the panel fixed implement, retighten the screws after work. | Refrigerant piping Electrical control box Drain piping corner |
| | | 4) Following to the works in items ③-2 and ①-2, attach the adjust corner cap and the air intake grille as original. | Hanging section of tentative hanging hook |
| | | NOTE | |
| | | The ceiling panel aligns directionally with the indoor unit. Check that the lead wires of louver motor connector are on the electrical control box side. When a clearance is found between the ceiling surface and the ceiling panel, readjust height of the indoor unit even if the screws have been tightened. | Ceiling panel Tentative hanging Louver motor connector Square hole of an indoor unit |
| | | | Push to remove → Tentative hanging hook Indoor unit No clearance |
| | | | Ceiling surface Ceiling panel |
| | | | |

| No. | Part name | Procedure | Remarks |
|-----|-----------|--|--|
| (5) | Turbo fan | 1. Detachment | Nut cap |
| | | Remove the air intake grille. (Refer to 1 of ①.) Loosen the fix screws (2 positions) of the bell mouth, rotate the bell mouth, and then take off it. (M 4 × 10, 2 pcs.) | Fixing screw of bell mouth |
| | | 3) Remove the screw which is fixing the nut cap and then remove the nut cap. $(M4 \times 10, 2 \text{ pcs.})$ | |
| | | 4) Loosen the flange nut (M8) at the center part of the turbo fan, and then take off (Counter clockwise) * Supporting with hands, take off the turbo fan so that it will not fall down. | Fixing screw of nut cap |
| | | NOTE | |
| | | Use a box wrench for attachment and detachment of the turbo fan. If using adjustable wrench etc., the other parts may be damaged in work. | Lock release direction |
| | | 2. Attachment | |
| | | Match the D-cut of the motor shaft with the boss part
D-cut of the turbo fan, and then insert the turbo fan
into the motor shaft. | |
| | | 2) Tighten M8 nut with flange. (Tightening torque of the turbo fan: 5.4+0.5, -0.2N•m) | Flange nut (M8) |
| | | 3) Attach a nut cap as original. | · lange hat (ine) |
| | | Slide the Bell mouth removed in item 1-2) and attach it
then fix it with screws. (M 4 x 10, 2 pcs.). | Ser Control of the Co |
| | | 5) Following to the work in item ①-2, attach the air intake grille as original. | D-cut |
| | | NOTE | A THE STATE OF THE |
| | | (Tightening torque of the turbo fan: 5.4 (+0.5, -0.2)N•m) | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| No. | Part name | Procedure | Remarks |
|-----|-----------|---|--|
| 7 | Drain pan | 1. Detachment | |
| | | Remove the ceiling panel and the electrical parts covers. | Fixing screws |
| | | (Refer to items 4-1 and 2-1.) | Tixing screws |
| | | Remove the wiring cover. (Fixing screw M 4 x 8,
3pcs.) | |
| | | 3) Remove the wiring fixing plate. (Fixing screw M 4 × 8, 1pc.) | Wiring cover |
| | | 4) Remove the connectors of the fan motor lead wire, louver motor lead wire, and room temperature (TA) sensor from the control P.C. board, and then remove the wiring from the clamp. * Pull out the wires from the hole at the side face of | Wiring fixing plate |
| | | the electric parts. | |
| | | CN210: Fan motor (7P, White) CN510: Louver motor lead wire (20P, White) CN104: TA (Room temperature) sensor (2P, Yellow) | 6 |
| | | Remove the drain plug of the drain pan, and extract the stayed drain water. Be careful that water is extracted at a stretch when | Fixing screw |
| | | taking off the drain plug. * When taking off the drain plug, be sure to prepare a | |
| | | bucket, etc. for spilled water. 6) Remove the fixing screws of the drain pan fixing bracket. | Drain plug |
| | | (M 4 × 8, 4 pcs.) | |
| | | 7) Using the both hands, hold the water-spilling port part of the drain pan and then slowly pull out the foaming parts firstly.* As there is remained water in the drain pan, clear it | |
| | | carefully. | Drain pan fixing bracket |
| | | 2. Attachment 1) Arrange direction of the drain pan directly to the foaming parts and insert it. * Pass the fan motor lead wire through the inner side of the drain pan. | |
| | | Attach the fixing screws of the drain pan fixing bracket
which was taken off in item 1-6).
(M 4 x 12, 4 pcs.) | Fixing screw (4 positions) |
| | | 3) Insert the drain plug. (Put the tool with thin top in the hole of the drain plug, and then push the plug in.) | |
| | | 4) Perform wiring works to original arrangement, wiring
of the fan motor, louver motor lead wires, and the
room temperature (TA) sensor, and then attach the
wiring fixing bracket and the wiring cover. | Drain plug |
| | | 5) Following to works in items 4-2 and 2-2, attach the panel, electric parts cover as original. | |
| | | | Push in the drain plug with the thin tip tool. |
| | | | |
| | | | |
| | | | |
| | | | |

| No. | Part name | Procedure | Remarks |
|-----|------------|---|------------------------------|
| 8 | Drain pump | 1. Detachment 1) Pomove the drain page (Pofer to (2) 1.) | Fixing screw |
| | | Remove the drain pan. (Refer to ⑦-1.) Remove the drain pump connector (CN504: 2P, White) connected to the control P.C. board and remove the lead wires from the clamp. | |
| | | 3) Remove the fixing screws to remove the drain pump. (M 4×10 , 3 pcs.) | |
| | | 4) Move the knob of the hose band which fixes the drain hose a little from pump connecting part to the hose side, and then remove the drain hose from the drain pump. * Be careful that water may be out. | Drain pump Drain hose |
| | | 2. Attachment | Hose band |
| | | 1) Confirm the direction of the drain pump, and then fix it with screws. (M 4×10 , 3 pcs.) | |
| | | 2) Connect the drain hose to the drain pump. * For the drain hose, insert up to the root of the connecting part. * Attach a band to the marked position of the hose, and the knob of a hose band is attached to the deep side of a set. | |
| | | Pass the drain pump wiring through side plate and
clamp, and then connect the connector to the control
P.C. board. | |
| | | Following to work in ⑦-2, attach the drain pan, panel,
and electrical parts covers as original. | |
| 9 | Float | 1. Detachment | Civing covery |
| | switch | 1) Remove the drain pan. (Refer to ⑦-1.) | Fixing screw |
| | | Remove the float switch connector (CN34 3P, Red)
connected to the control P.C. board, and then take off
the lead wires from the clamp. | |
| | | 3) Remove the screws which fix the float switch. (M 4×8 , 1 pc.) | |
| | | Slide the float switch fixed bracket as direction shown
in the right figure, and then take off it from the claw. | |
| | | 2. Attachment | Claw / Float switch |
| | | Insert the float switch fixing plate into the claw, and
tighten the fixing screw. | Fixing plate of float switch |
| | | Pass the float switch lead wires through the side plate
and the clamp, and then connect the connector to the
control P.C. board. | |
| | | Following to work in ⑦-2, attach the covers of the
drain pan, panel, and electric parts box as original. | |
| | | | |
| | | | |

| 10 | Part name | Procedure | Remarks |
|-----|-----------|---|--|
| W | Fan motor | 1. Detachment | Chavilder agrees (Pleate) |
| | | Remove the turbo fan, electric parts cover, wiring
cover and wiring fixing plate.
(Refer to ⑥-1, ②-1, ⑦-1-2, ⑦-1-3.) | Shoulder screws (Black) |
| | | Remove the fan motor connector (CN210, White, 7P)
connected to the control P.C. board, and then take off
the lead wires from the clamp. | Motor lead wire cover |
| | | Remove the shoulder screws (Black, 2pcs.) of the
motor lead wiring cover, and separate the lead wires
and the lead wire cover. | |
| | | 4) Remove the hexagon nuts (M6) which fix the motor, and the washers. (3 pcs. Each).* When taking off them, hold them with a hand so that motor will not fall down. | |
| | | 5) Remove the motor with rubber cushion from the bolt. | <u> </u> |
| | | 2. Attachment | |
| | | Pass rubber cushion of the motor in the bolt, put the
washer and the hexagon nut in this order, and then
tighten to fix them. (Tightening toque: 4.9 ± 0.5N•m) | Bolt |
| | | Pass the lead wire through the motor lead wire fixing
plate removed in 1-3), and then fix it with shoulder
screw. | Hexagon nut |
| | | Perform wiring of the motor lead wires as original,
connect the connector to the control P.C. board, and
then attach the wiring fixing plate and the wiring
cover. | Washer |
| | | 4) Following to works in ⑥-2 and ②-2, attach the turbo fan and the electric parts covers. | cushion |
| 111 | PMV coil | 1. Detachment | |
| | | 1) Remove the drain pan. (Refer to ⑦-1) | The state of the s |
| | | Remove the PMV connectors (CN82, Blue, 6pcs.)
connected to the control P.C. board, and take off the
lead wires from the clamp. | |
| | | A little PMV coil is rotated, pressing down so that a
PMV body may not turn, and it removes in the
direction of an arrow. | |
| | | 2. Attachment | PMV coil PMV body |
| | | 1) Attach the PMV coil as original. | The lead wire of PMV coil is turned in the |
| | | NOTE | top plate direction. |
| | | Be careful of direction of a PMV coil. Check that four projections of the fixed claw of PMV coil and PMV body have fitted in. | |
| | | | |

| No. | Part name | Procedure | Remarks |
|-----|-----------------------------|---|---|
| 12 | TC1
TC2
TCJ
Sensor | Detachment Remove the drain pan. (Refer to ⑦-1.) Pull out the sensor to be exchanged from the sensor holder. Remove the connector connected to the control P.C. board, and take off wires from the clamp. (Refer to ⑤.) Attachment Insert the sensor to be exchanged into the specified sensor. (Refer to the right figure.) Perform wiring of the sensor as original. | TCJ sensor (Red) TC1 sensor (Blue) TC2 sensor (Black) |
| (3) | TA sensor | Detachment Remove the panel, electric parts box cover, wiring cover and wiring fixing plate. (Refer to ④-1, ②-1, ②-1-2, ⑦-1-3.) Disconnect TA sensor connector (CN104 Yellow, 2P) which is connected to the control P.C. board, and take off the lead wire from the clamp. Remove the screw of the TA sensor cover. (M 4 × 10, 1 pc.) Remove TA sensor from the TA sensor fixing bracket. Attachment Fix TA sensor to TA sensor fixing bracket, and fix the TA sensor cover with screw. (M 4 × 10, 1 pc.) Perform wiring of TA sensor as original. | Adjust position of the tube so that the tube of TA sensor will be included in the cover. TA sensor Fixing screw TA sensor cover Groove for wiring of the drain pan Fixing screw Wiring fixing plate |

| No. | Part name | Procedure | Remarks |
|-----|--------------------------|--|--------------------------------|
| | Part name Heat exchanger | Detachment Recover refrigerant gas. Remove the refrigerant pipe at indoor unit side. Remove the drain pan. (Refer ⑦-1.) Disconnect the heat exchanger sensor (TC1, TC2, TCJ), PMV lead wires connectors from the control P.C. board, and then remove their lead wires from the clamp. (Refer to ⑤-1.) Remove the fixing screws of the piping cover and take off the piping cover. (M 4 × 8, 3 pcs.) Remove the shoulder screws of the separate plate (2 positions) and fixing plate (1 position), and then | Remarks Piping cover Screws |
| | | * Supporting with a hand, remove the heat exchanger so that it will not be fallen down. * Take note that you will not get hurt by touching to Aluminum fin. Be sure to put on the protective gloves and the safety working clothing. | Heat exchanger |
| | | Attachment Attach the heat exchanger as original with the separate plate and the fixing plate. Slide the piping cover to the groove, fix it to the side plate, and then use the screws. (M 4 × 8, 3 pcs.) Perform wiring of the sensor and PMV lead wires as | Shoulder screw Separate plate |
| | | original. 4) Connect the refrigerant pipe as before and then apply vacuuming. 5) Following to the work in ⑦-2, attach the parts as original. | Shoulder screw Fixing pate |

NOTE

After assembling, check if that there is no abnormal sound, vibration, or puncture. Check the exchange point when you have a problem.

11-2. 2-way cassette

MMU-UP****WH*



CAUTION

Be sure to stop operation of the air conditioner before work and then turn off switch of the breaker.

Be sure to put on gloves during working time; otherwise an injury will be caused by a part etc.

Ceiling Panel (RBC-UW283PG(W)-E, UW803PG(W)-E, UW1403PG(W)-E))

For detachment, they are expediently expressed as follows:

UP009: MMU-UP0071WH to UP0151WH (Ceiling panel: RBC-UW283PG(W)-E) UP027: MMU-UP0181WH to UP0301WH (Ceiling panel: RBC-UW803PG(W)-E) UP048: MMU-UP0361WH to UP0561WH (Ceiling panel: RBC-UW1403PG(W)-E)

| N. Bartana | |
|---|---|
| No. Part name Procedure Ro | emarks |
| Center panel 1. Detachment 1) Stop operation of the air conditioner and then turn off the breaker switch. 2) Remove the center panel as the following procedure. The direction to open the center panel is beforehand decided. The opening side is the moving side when pushing edge of the center panel upward, and the side which does not practically move is the hanging side. While pushing edge (1) of opening port side of the center panel, pull it to the opening port side (2). When pulling the panel, the hanging side lowers by one step and the hook at opening port side is removed. * Hold the positions near the hook at both sides of the center panel, and remove hooks at opening port sides one by one. • Confirm that hanging sides at both sides lowered by one step, turn it downward slowly (3) and open the center panel. * Open the center panel until there is no slackness on the wire at both sides. 3) Take off the wire from fixing part of wire on the adjust cover. 4) While lifting up the center panel (1) upward, slide it to the hanged direction (2) . The hook is removed. | Center panel Hook Wire fixing part Wire |

| No. | Part name | Procedure | Remarks |
|-----|--------------------------|---|---|
| | Center panel (Continued) | 2. Attachment 1) Insert hook of the center panel into shaft of the adjust cover. (2 positions at left and right sides) Insert hook attached with a panel stopper. Note Be sure to attach a hook with panel stopper at first. If attaching a hook without panel stopper at first, the center panel cannot be attached. 2) Hang S-shape bracket of the wire to the wire fixing part from down side. Note If hanging it from upside, the bracket may come off when opening/closing of the center panel. The wire is provided to prevent falling of the center panel. Be sure to attach it to the wire fixing part. | Adjust cover Wire fixing part Center panel Wire Panel stopper Hook (Condition that inserting into adjust cover shaft) |
| | Wire fixin | 3) Turn the center panel slowly to (1) direction and then condition that opening port side of the center panel closes, lift up the bump at hanged side (2) and then slide it to (3) hanged side to fix it. Hold the positions near the hooks at both sides of the | If hanging it from upside, the bracket may come off when opening/closing of the center panel. |
| | | center panel, and fix it to the unit one by one. | Center panel Hanged side (1) Opening port side Bump Hanged side Opening port side |
| 2 | Air filter | Detachment Perform work Detachment 1 of ①. Hold knob of the air filter, pull it downward while pushing it slantingly upward and then remove claws from frame of the center panel. Attachment Enter the air filter until it hits the back end of the frame of one side. | Air filter Knob Claw |

| No. | Part name | Procedure | Remarks |
|-------|--------------------|--|---|
| No. 3 | Electric parts box | 1. Detachment 1) Perform work Detachment 1 of ②. 2) Take off screws. (M 4 × 8, 2 pcs.) 3) When sliding the box to the arrow direction (1) in the figure, the electric parts box cover opens at the hinge part as the axis. 4) Remove indoor/outdoor connecting wire and remote controller wiring from each terminal block. 5) Remove the connectors connected from the control P.C. board to other parts. Note Before removing the connectors, unlock the lock of housing part. CN510: Louver motor (20P: White) CN34: Float switch (3P: Red) CN41: Remote controller terminal block (3P: Blue) (Terminal block screws: 4P) CN504: Drain pump (2P: White) CN67: Power supply terminal block (5P: Black) (Terminal block screws: 2P) CN82: PMV (6P: Blue) CN100: TC1 sensor (3P: Brown) CN101: TC2 sensor (2P: Black) CN102: TCJ sensor (2P: Red) CN104: Room temp. sensor (2P: Yellow) CN210: Fan motor (7P: White) 6) Remove the binding band which is fixing the fan motor lead. 7) Take off screws in the electric parts box. (M 4 × 8, 2 pcs.) 8) The hanging structure is set at the side of the electric parts box. Remove the electric parts box by sliding it to the arrow mark in the figure. 2. Attachment 1) Attach the electric parts box and then connect with wires as original. Pote For the connectors, check there is no comingoff or connection error. By the code clamp and binding band beside an electric part box, as shown in the left figure, fix fan motor wiring. | Remarks Electric parts box Cover (2) positions Cord clamp Binding band Screws Hook structure |
| | | wires as original. 2) Be sure to perform wiring in the electric parts box as original. Note For the connectors, check there is no comingoff or connection error. By the code clamp and binding band beside an electric part box, as shown in the left figure, fix fan motor wiring. | Screws Hook structure |

Part name No. **Procedure** Remarks (4) Control 1. Detachment Cord clamp Binding band P.C. board 1) Perform work from 1) to 5) Detachment 1 of 3. 2) Unlock the locks of the card edge spacers (at 4 positions) in the electric parts box and then remove the control P.C. board. 2. Attachment 1) Attach the control P.C. board in the electric parts box as original. 2) Be sure to perform wiring in the electric parts box as original. Note For the connectors, check there is no comingoff or connection error. By the code clamp and binding band beside an electric part box, as shown in the left figure, fix fan motor wiring. 3) Attach both air filter and center panel as original. Card edge spacer (5) Fan motor 1. Detachment (In case of UP009) In case of UP009 Turbo fan Screws 1) Perform work Detachment 1 of 3. Bell mouth Take off screws (M 4 × 8, 4 pcs.) and then remove the bell mouth. Nut cap 3) Take off screws (M 4×10 , 2 pcs.) and then remove the nut cap. 4) Take off nut and remove the turbo fan while supporting the turbo fan so that it does not fall. Turbo fan 5) Take off screws (M 4 × 8, 2 pcs.) which fix the holding Bell mouth plate for wiring and then remove the holding plate for wiring. 6) Remove the fan motor wire from the clamp. Fixing slit for Fan motor fan motor wiring wiring 7) Take off nuts (3 positions) and then remove the fan motor. Note Turbo fan Take off nuts while supporting the fan motor so that it does not fall. Nut Drain pan 2. Attachment (In case of UP009) 1) Attach all the fan motor, turbo fan, nut cap, bell mouth Holding plate and electric parts box as original. Fan motor for wiring Be sure to perform wiring in the electric parts box as original. Clamp Note Pass the fan motor wires necessarily through the clamp and the specified fixing slit for the fan motor wiring. Screws 2) Check that the turbo fan does not hit the fan motor wiring by turning lightly the turbo fan with hands. 3) Attach the air filter and the center panel as original.

Part name No. **Procedure** Remarks 1. Detachment (In cases of UP027) Fan motor In case of UP027 Fan Claw 1) Perform work Detachment 1 of 2. Fan case Claw 2) In the works of 1 of 3, perform works to open the electric parts box cover and remove connectors of the fan motor wiring. 3) Remove the fan case (lower) fixing screws. (at both sides of the case). 4) Open the fan case (lower) while pushing claws (at both sides of the case) of the fan case (lower). 5) Remove the hanging rib at opposite side of the claw and then open the fan case (lower). Fan case (lower) Fan case (lower) fixing screw 6) Take off screws of fixing sheet metal (2 pcs.) at side of fixing screw the fan motor. (M 5×16 , 2 pcs.) Note Take off fixing screws while supporting the fan motor so that it does not fall. Hanging rib 7) Loose the hexagon socket screw to remove the fan Fixing crews from the shaft. (For 3mm, 1 pcs.) 2. Attachment (In cases of UP027) 1) Adjust the hexagon socket screw so that it fits groove of the shaft and then insert the fan into the shaft. 2) Screw the fan motor with the fixing sheet metal. $(M 5 \times 16, 2 pcs.)$ Note As the guide of angle Match direction of the fan motor with turning direction of the fan and then fix the fan motor wiring so that it is set at piping side. * Ensure that the fan motor wiring directs at 50°±5° to the cord clamp side. Fan motor 50±5 Cord 3) Using hexagon socket screw, fix the fan by positioning clamp Fan motor so that the fan is set at the center against the fan case wiring direction (upper). **Note** For fixing the fan, use torque wrench and tighten it with 4.9±0.49 N•m. 4) Attach the fan case (lower) as original, and check the fan can turn smoothly without touching with the fan 5) Connect the fan motor wires as original and then Fan case (upper) attach the electric parts box cover. Be sure to perform wiring in the electric parts box as original. 6) Attach the air filter and the center panel as original.

No. Part name **Procedure** Remarks 1. Detachment (In cases of UP048) Fan motor In case of UP048 Claw Fan Perform work Detachment 1 of ②. Fan case Claw Bearing 2) In the works of 1 of 3, perform works to open the electric parts box cover and remove connectors of the fan motor wiring. 3) Remove the fan case (lower) fixing screws. (at both sides of the case). 4) Open the fan case (lower) while pushing claws (at both sides of the case) of the fan case (lower). 5) Remove the hanging rib at opposite side of the claw Fan case (lower) and then open the fan case (lower). Fan case fixing screw Connect the fan motor to the shaft with the coupling and fix them to the cabinet with the bearing. Remove it if necessary. Coupling: Hexagon socket screw (For 3mm, 2 pcs.) 6) Take off screws of fixing sheet metal (2 pcs.) at side of the fan motor. (M 5×16 , 2 pcs.) Hanging rib Fixing crews Coupling Take off fixing screws while supporting the fan motor so that it does not fall. 7) Loose the hexagon socket screw to remove the fan from the shaft. (For 3mm, 1 pcs.) 8) Take off fixing screw for fixing plate to remove the Bearing fixing plate Bearing bearing. Fixing plate 2. Attachment (In cases of UP048) Fixing screw 1) Insert the bearing securely to the bearing fixing plate for fixing plate and push them with the fixing plate to fix them with screw. As the guide of angle 2) Adjust the hexagon socket screw so that it fits groove of the shaft and then insert the fan into the shaft. 3) Screw the fan motor with the fixing sheet metal. $(M 5 \times 16, 2 pcs.)$ Fan motor Note Cord Match direction of the fan motor with turning direction of clamp the fan and then fix the fan motor wiring so that it is set at Fan motor wiring direction * Ensure that the fan motor wiring directs at 50°±5° to the cord clamp side. 4) Using hexagon socket screw, fix the fan by positioning so that the fan is set at the center against the fan case (upper). Note For fixing the fan, use torque wrench and tighten it with Fan case (upper) 4.9 ±0.49N•m. 5) Attach the fan case (lower) as original, and check the fan can turn smoothly without touching with the fan case. 6) Connect the fan motor wires as original and then attach the electric parts box cover. Be sure to perform wiring in the electric parts box as 7) Attach the air filter and the center panel as original.

| 8 Ceiling panel 1. Detachment 1) Perform work Detachment 1 of ②. Tentative hook | |
|--|-------------------------------|
| 2) In the works of 1 Detachment of ③, perform works to open the electric parts box cover and remove connector of the louver motor wiring. 3) In the works of 1 Detachment of 6, perform work to remove the frame cover. 4) Take off the mounting screws (M 5 × 40, 4 pcs. for UP009 and UP027, 6 pcs. for UP049) which fix the indoor unit and the ceiling panel. 5) Lower the tentative hooks (Total 2 psc. at left and right) slowly while pushing them with fingers (1). The position of tentative hook at the left side differs a little from hook at right side. 2. Attachment 1) Put the ceiling panel slantingly. Hang one side of the tentative hook to the indoor unit, lift up the other hook horizontally and hang it. Note When hanging the ceiling panel, match the louver motor wiring side of the ceiling panel with the electric parts box side of the indoor unit. 2) Check that the tentative hooks at the both sides of the ceiling panel are surely hanged and then leave the hands. For the ceiling panel, induped uplor27, 6 psc. for UP009 and UP027, 6 psc. for UP0949 until it stick firmly to the indoor unit. Note When tightening the mounting screws, check there is no catching of wire. Check there is no clearance between indoor unit and ceiling panel, and between ceiling panel and under face of the ceiling. | No clearance
Ceiling panel |

Remarks Part name **Procedure** No. Drain pan 1. Detachment (In case of UP009) Fan motor 1) Perform work Detachment 1 of 3. In case of UP009 Drain pan Perform work Detachment 1 of 3. crew 2) Take off the drain cap and then extract accumulated drain water in the drain pan. When taking off the drain cap, be sure to receive drain water in a bucket, etc. 3) Remove the bell mouth followed to work of Detachment 1 of 5 and release fixing of the fan Drain cap Bell mouth motor. 4) Remove the fan motor wiring from clamp on the partition board. Fan motor wiring fixing slit 5) Take off screw (M 4×8 , 1 pc.) which fixes the Fan motor wire partition board and then remove it as if lifting up it. Take off screws at 4 corners (M 4 × 8, 4 pcs.) which fix the drain pan and then pull out the drain pan Clamp quietly. Screw 2. Attachment (In case of UP009) 1) Attach the drain pan as original while passing the fan motor wiring and the drain pump/ sensor wiring through the specified hole. Partition board Note Be sure to pass the drain pump sensor wiring through the specified fixing slit of the inner foaming. Be sure to pass also the fan motor wiring through the Screw clamp and the fixing slit. 2) Attach all the partition board, bell mouth, electric parts box, ceiling panel, air filter and center panel as original. For wiring in the electric parts box, be sure to wire it as original. Screw Drain pump/sensor wiring fixing slit Drain pump/ sensor wiring Inner foaming

| | Procedure | Remarks |
|--------------------------|---|--|
| Drain pan
(Continued) | 1. Detachment (In cases of UP027/UP048) 1) Perform work Detachment 1 of ③. Perform work Detachment 1 of ⑦. 2) Take off the drain cap and then extract accumulated drain water in the drain pan. | In cases of UP027/UP048 Partition board Screw |
| | When taking off the drain cap, be sure to receive drain water in a bucket, etc. | |
| | 3) Take off screw (M 4 × 8, 1 pc.) which fixes the partition board and then remove it as if lifting up it. • As shown in the right Photo, the drain pan is fixed by the drain pan fixing sheet metal at the both sides of the fan motor. Take off each screw and then remove the drain pan fixing board. (M 4 × 8, 1 pc. each) | Drain cap In case of UP048 Drain pan fixing board |
| | Take off screws at 4 corners (M 4 x 8, 4 pcs.) which
fix the drain pan and then pull out the drain pan
quietly. | Screw |
| | 2. Attachment (In cases of UP027/UP048) | |
| | Attach the drain pan as original while passing the fan motor wiring and the drain pump sensor wiring through the specified hole. | |
| | Note | |
| | Be sure to pass the drain pump sensor wiring through the specified fixing slit of the inner foaming. | Screw Screw |
| | 2) Attach all the partition board, electric parts box, ceiling panel, air filter and center panel as original. For wiring in the electric parts box, be sure to wire it as original. • Be sure pecessarily to attach the drain pan fixing. | |
| | sheet metal for UP048 type. | Drain pump/
sensor wiring |
| | | |
| | | |
| | | 2) Take off the drain cap and then extract accumulated drain water in the drain pan. Note When taking off the drain cap, be sure to receive drain water in a bucket, etc. 3) Take off screw (M 4 × 8, 1 pc.) which fixes the partition board and then remove it as if lifting up it. • As shown in the right Photo, the drain pan is fixed by the drain pan fixing sheet metal at the both sides of the fan motor. Take off each screw and then remove the drain pan fixing board. (M 4 × 8, 1 pc. each) 4) Take off screws at 4 corners (M 4 × 8, 4 pcs.) which fix the drain pan and then pull out the drain pan quietly. 2. Attachment (In cases of UP027/UP048) 1) Attach the drain pan as original while passing the fan motor wiring and the drain pump sensor wiring through the specified hole. Note Be sure to pass the drain pump sensor wiring through the specified fixing slit of the inner foaming. 2) Attach all the partition board, electric parts box, ceiling panel, air filter and center panel as original. For wiring in the electric parts box, be sure to wire it as original. • Be sure necessarily to attach the drain pan fixing |

| Procedure | Remarks |
|--|--|
| 1. Detachment | |
| 1) Perform work Detachment 1 of ^⑨ . | |
| Pick the hose band and shift it from the pump
connecting part and then remove the drain hose. | Alhose band is moved in the direction of an arrow. |
| 3) Take off screw A which fix the drain pump assembly and then remove the drain pump assembly. (M 4×8 , 3 pcs.) | Remove |
| Remove the binding band which is fixing the drain
pump/float switch. | ScrewA |
| 5) Remove the screw B from holding fixture of drain pump, and remove a drain pump. (M 4×10 , 3 pcs.) | Screw/A |
| 2. Attachment | |
| Using screws taken off from the drain pump assembly,
fix the assembly as original. | Drain pump assembly |
| Fix the drain pump wiring to the slit for fixing the drain
pump/sensor wiring. | Holding fixture of drain pump |
| Connect the drain pump as original and then attach
the hose band. | Odisii B |
| Note | |
| Insert the drain hose up to the back of the pump connecting part, and apply a band at the white mark of the hose. | |
| 4) Attach all the drain pan, partition board, electric parts box ceiling panel, air filter and center panel as original. For wiring in the electric parts box, be sure to wire it as original. | |
| Detachment Perform work from 1) to 4) Detachment 1 of ®. Loosen the nut of a float switch and remove a float switch. Attachment Attach the float switch as original. | Float switch fixed nut |
| | Detachment Perform work Detachment 1 of ③. Pick the hose band and shift it from the pump connecting part and then remove the drain hose. Take off screw A which fix the drain pump assembly and then remove the drain pump assembly. (M 4 × 8, 3 pcs.) Remove the binding band which is fixing the drain pump/float switch. Remove the screw B from holding fixture of drain pump, and remove a drain pump. (M 4 × 10, 3 pcs.) Attachment Using screws taken off from the drain pump assembly, fix the assembly as original. Fix the drain pump wiring to the slit for fixing the drain pump/sensor wiring. Connect the drain pump as original and then attach the hose band. Note Insert the drain hose up to the back of the pump connecting part, and apply a band at the white mark of the hose. Attach all the drain pan, partition board, electric parts box ceiling panel, air filter and center panel as original. For wiring in the electric parts box, be sure to wire it as original. Perform work from 1) to 4) Detachment 1 of ⑩. Loosen the nut of a float switch and remove a float switch. Attachment |

| No. Part name | Procedure | Remarks |
|---------------|---|---|
| ② PMV coil | 1. Detachment 1) Perform work Detachment 1 of 8. 2) Remove the relay connector of PMV coil. (Only relay connector of UP048 type is connected in the vinyl tube. Therefore cut off the bundling band which fixes the tube and then remove the relay connector.) 3) A little PMV coil is rotated, pressing down so that a PMV body may not turn, and it removes in the direction of an arrow. | Relay connector: UP048 type only (Inside of vinyl tube (Black)) |
| | 1) Attach PMV coil and relay connector as original. Note Be careful of direction of a PMV coil. Check that four projections of the fixed claw of PMV coil and PMV body have fitted in. | In cases of UP048 PMV coil PMV body PMV coil PMV body PMV coil PMV body PMV coil is turned in the top plate direction. |

Part name No. **Procedure** Remarks 1. Detachment (In case of UP009) Heat In case of UP009 (13) exchanger 1) Recover the refrigerant gas and then remove the End board refrigerant pipe of the indoor unit. 2) Perform work of Detachment 1 of 8. 3) Pull out wires of TC1 sensor, TC2 sensor and TCJ sensor from the holder. 4) Take off screws (M 4 × 8, 2 pcs.) and the piping cover. 5) Take off screw (M 4×8 , 1 pc.) and then remove the heat exchanger fixing board. While pressing the heat exchanger, take off screws fixing (M 4×8 , 1 pc. each) of the end boards (2 pcs.), and then take out the heat exchanger slowly. Heat exchanger Piping cover fixing board 2. Attachment (In case of UP009) : Screw position 1) Set the heat exchanger at the original position and then fix all the end board, heat exchanger fixing board and piping cover with taken-off screws as original. 2) Insert wires for TC1 sensor, TC2 sensor and TCJ sensor into the holder and perform wiring as original. 3) Attach all the drain pan, partition board, bell mouth, electric parts box, ceiling panel, air filter and center panel as original. Be sure to perform drawing of wires as same as original drawing. O: Screw position 1. Detachment In case of UP027 Fan base (In cases of UP027/UP048) Recover the refrigerant gas and then remove the refrigerant piping of the indoor unit. 2) Perform work Detachment 1 of 8. 3) Take off screws and remove the fan base. (For the tentative hanging parts at 2 positions, it is all right Tentative hanging part only to loosen screws.) UP027 type (Hexagon socket screw M 4×10 , 10 pcs.) UP048 type (Hexagon socket screw M 4×10 , 13 pcs.) In case of UP048 Fan base Note The fan or fan motor are attached to the fan base. If the base is heavy, remove each for working. 4) Pull out wires of TC1 sensor, TC2 sensor and TCJ sensor from the holder. Tentative hanging part Take off screws (M 4×10 , 2 pcs.) and then remove the piping cover. In case of UP027 Heat exchanger Take off screw (M 4 × 10, 1 pc. each) and then remove End board fixing board the heat exchanger fixing boards (2 pcs.). 7) While pressing the heat exchanger, take off screws Piping cove fixing (M 4 × 10, 1 pc. each) of the end boards (2 pcs.), and then take out the heat exchanger slowly. 2. Attachment (In case of UP027/UP048) Heat exchanger 1) Set the heat exchanger at the original position and then fix all the end board, heat exchanger fixing board In case of UP048 Heat exchanger and piping cover with taken-off screws as original. fixing board 2) Insert wires for TC1 sensor, TC2 sensor and TCJ sensor into the holder and perform wiring as original. Attach all the drain pan, partition board, bell mouth, electric parts box, ceiling panel, air filter and center panel as original. Be sure to perform drawing of wires as same as original drawing. Piping cover Heat exchanger

11-3. 1-way cassette (SH)

MMU-UP***SH*

№ WARNING

CAUTION

Be sure to stop operation of the air conditioner before work and then turn off switch of the breaker.

Be sure to put on gloves during working time; otherwise an injury will be caused by a part etc.


Ceiling panel: RBC-US21PGE

| No. | Part name | Procedure | Remarks |
|-----|----------------------|---|----------------------|
| 1 | Air intake
grille | 1. Detachment | |
| | | Stop operation of the air conditioner, and then turn off
switch of the breaker. | |
| | | Remove the screws of air intake grille fixing knob on a side of each filter. | Knob |
| | | Open the grilles by sliding knobs toward suction side. (Both 2 pieces at left and right sides) | Rear hinge |
| | | 4) Pull out the grille by pushing claws at rear hinge (2 positions) with (-) screwdriver. (2) | |
| | | 2. Attachment | |
| | | Insert the rear hinge (2 positions) into square holes of the panel. (Insert it surely up to the end.) | |
| | | NOTE | |
| | | After inserting the hinge, check the grille does not fall out even if pulling the grilles. | |
| | | Close the grilles and slide the hooks (2 positions) toward discharge side to fix them. | |
| | | Tighten the screws of air intake grille fixing knob on a side of each filter. | |
| 2 | Electric | 1. Detachment | |
| | parts cover | 1) Perform work of procedure 1. of ①. | |
| | | 2) Loosen fixing screws. (M 4 ×8, 2 pcs) | |
| | | Pull down the cover and shift it to the fan motor side to
remove it. | |
| | | 2. Attachment | |
| | | Insert the cover along edge of the electrical control box and match the projection inside of the fixing screw with hole of the cover. | Screws (2 positions) |
| | | 2) Tighten the fixing screws. (M 4 × 8, 2 pcs) | Projection |

| No. Part name | Procedure | Remarks |
|-----------------|---|---|
| ③ Adjust cap | Detachment Perform work of procedure 1. of ①. Take off fixing screws. (M4 × 12, 2 pcs) Hold handle of the cap, and then slide it toward suction side to remove cap. Attachment Catch on the top claw and slide it toward discharge side for attachment. Fit the fixing screws. (M4 × 12, 2 pcs) | Screw Sliding direction Handle |
| 4 Ceiling panel | Detachment Perform works of procedures 1. of ② and 1. of ③. Remove a louver connector from the relay connector (5P: white) of the control P.C. board, and remove the lead wires of ceiling panel. NOTE When removing the connector, unlock the lock of the housing. Take off screws fixing the ceiling panel. (M 5 x 4 pcs, M 4 x 2 pcs) NOTE Be sure to open the screw cap before taking off the fixing screw (M4) at the center of the discharge port. While pulling down the ceiling panel by pushing the knob of hook (movable) at right side of the panel toward inner side, remove the hook (movable) and also the hook (movable) at left side to pull down the ceiling panel by lifting the left side of the panel and sliding toward outside. Attachment Hook the hooks at both sides of the ceiling panel to the indoor unit. Fit the fixing screws. (M5 x 4 pcs, M 4 x 2 pcs) NOTE Be sure to close the screw cap after screwing the fixing screw (M 4) at the center of the discharge port. Connect a louver connector from the relay connector (5P: white) of a control P.C. board, and fix the lead wire of ceiling panel to a clamp. A clamp. A connect a louver connector from the relay connector (5P: white) of a control P.C. board, and fix the lead wire of ceiling panel to a clamp. A clamp can be a clamp can | Fixing screw M4 Fixing screw M4 for screw cap Hook knob |

| No. Part name | Procedure | Remarks |
|--------------------------|---|---|
| S Electrical control box | 1. Detachment 1) Perform work of procedure 1. of ②. 2) Take off the fixing screws. (M 4 × 8, 4 pcs) 3) Remove the cord clamp on the ceiling surface, pull the electrical control box downward, and then hook the hooking claw at the rear side to square hole for temporary hanging of the panel. 2. Attachment 1) Take off the hook at the rear side of the electrical control box. 2) Return the electrical control box at the original position, and then fit the fixing screws. (M 4 × 8, 4 pcs) 3) Using cord clamp at the ceiling surface, fix the lead wires as before. | Square hole for hooking electrical control box Fixing screw Cord clamp Square hole for temporary hanging |

| No. | Part name | Procedure | Remarks |
|-----|------------|--|---------|
| 6 | Control | 1. Detachment | |
| | P.C. board | 1) Perform work of procedure 1. of ⑤. | |
| | | Remove connectors connected from the control P.C. board to other parts. | |
| | | NOTE | |
| | | Be sure to unlock the lock of the housing before removing the connector. | |
| | | CN510: Louver motor (20P: White) CN34: Float switch (3P: Red) CN41: Remote controller terminal block (3P: Blue) (Screws of terminal block: 4P) CN67: Power supply terminal block (2P: Black) (Screws of terminal block: 2P) CN504: Drain pump (2P: White) CN82: PMV (6P: Blue) CN100: TC1 sensor (3P: Brown) CN101: TC2 sensor (2P: Black) CN102: TCJ sensor (2P: Red) CN104: Room temp. Sensor (2P: Yellow) CN210: Fan motor (5P: White) 3) Unlock the locks of the card edge spacers (4 positions), and then remove the control P.C. board. | |
| | | 2. Attachment | |
| | | Fix the control P.C. board to the card edge spacers (4 positions). | |
| | | Connect the connectors disconnected in item 1 as before. | |
| | | NOTE | |
| | | Check connectors have no missing or contact failure. | |



Card edge spacer

No. Part name **Procedure** Remarks Fan motor 1. Detachment Remove the banding band fan 1) Perform work of procedure 1. of 5. CN210: Fan motor 2) Remove the banding band and clamps of the lead wires which are connected to the following connectors of the control P.C. board. Remove the clamp Be sure to unlock the lock of the housing before removing the connector. CN210: Fan motor (7P: White) 3) Remove the hooking claws at both sides of the fan case (lower) and remove the fan by pulling out it from Hooking claw the partition board. 4) Loosen hexagon socket head screw of the fan. Remove screws of the fixing bracket while holding the fan motor, and then remove the fan and the fan motor. 2. Attachment 1) Insert the fan into the shaft of the motor and screw the fan motor with the fixing bracket. For the boss of the fan, attach hexagon socket head screw to shaft of the motor matching the marked position of the shaft with groove of the fan. **NOTE** Relief groove Match the rotation direction of the motor with that of the fan, and fix the fan motor so that the motor lead section comes to the piping side referring to the right photo. 2) Determine the position so that the fan locates at the center against the fan case (upper), and then fix the fan with hexagon socket head screw. Fixing screw NOTE Fan motor Use a torque wrench and tighten the screw with 4.9 N•m or more to fix the fan. 3) Mount the fan case (lower) as before, and check the Motor fixing bracket fan smoothly rotates without contacting with fan case. Connect the connectors disconnected in procedure Fan case (Upper) 5) Fix parts as before in order of Electric parts box → Electric parts cover → Air intake grille.

| No. | Part name | Procedure | Remarks |
|------------|---------------------|---|---------------------------|
| No. | Part name Drain pan | Procedure 1. Detachment 1) Perform work of procedure 1. of ④. 2) Remove the drain cap, and then drain the drain water accumulated in the drain pan. NOTE When removing the drain cap, be sure to catch drain water using bucket, etc. 3) Take off screws fixing the drain pan. (M 4 × 8, 2 pcs) 4) Remove the drain pan while lowering the discharge side. 2. Attachment 1) Fix parts as before in order of Drain cap → Drain pan → Ceiling panel → Electric parts cover → Adjust cover → Air intake grille. | Fixing screw Drain cap |
| | | | And remove the drain pan. |
| | | | |

| No. | Part name | Procedure | Remarks |
|-----|---------------|---|--|
| 9 | Drain
pump | 1. Detachment 1) Perform work of procedure 1. of ®. 2) Remove clamps of the lead wires connected to the following connectors of the control P.C. board. | CN504 : Drain pump |
| | | Be sure to unlock the lock of the housing before removing the connector. | |
| | | CN504: Drain pump (2P: White) | CN34 : Float switch |
| | | Pick the hose band and shift band from pump connecting part to remove the drain hose. | Shift the band toward hose side. |
| | | 4) Take off screws fixing the drain pump assembly. (M 4 × 8, 3 pcs) | |
| | | Pull out the drain pump assembly toward discharge
side to remove it. | |
| | | 2. Attachment1) Fix the drain pump assembly as before. | Hose band |
| | | Connect the drain hose and attach the hose band. | Drain pump |
| | | NOTE Insert the drain hose completely up to the end of the pump | fixing screw |
| | | connecting part, and then attach band at the white mark position of the hose. | |
| | | Insert the connectors to the control P.C. board as before. | Binding The fixing screw for float switch fixtures |
| | | 4) Fix parts as before in order of Drain cap → Drain pan → Ceiling panel → Electric parts cover → Adjust cover → Air intake grille. | intuics |
| 10 | Float | 1. Detachment | |
| | switch | 1) Perform work of procedure 1. of ®. | Float |
| | | Remove clamps of the lead wires connected to the following connectors on the control P.C. board. | switch |
| | | NOTE | |
| | | Be sure to unlock the lock of the housing before removing the connector. | Loosen
nut |
| | | CN 04 : Floot switch (OD: Dod) | |
| | | CN 34: Float switch (3P: Red) 3) Remove the float switch fixture. (M 4 × 10, 1 pcs) | |
| | | 4) Remove the binding band fixing wires 4) Remove the binding band fixing wires | |
| | | 5) Loosen the nut fixing float switch to remove the float switch. | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| No. | Part name | Procedure | Remarks |
|-----|----------------|---|--|
| 1 | PMV coil | 1. Detachment 1) Perform work of procedure 1. of ⑧. 2) Remove the relay connector of PMV coil. (As the relay connectors are connected in the vinyl tube, cut off the banding band fixing the both ends of the tube and shift the tube to remove relay connector.) 3) A little PMV coil is rotated, pressing down so that a PMV body may not turn, and it removes in the direction of an arrow. 2. Attachment 1) Mount PMV coil and the relay connector as before. NOTE Be careful of direction of a PMV coil. Check that four projections of the fixed claw of PMV coil and PMV body have fitted in. | Relay connector (In vinyl tube (Black)) PMV motor PMV body PMV coil The lead wire of PMV coil is turned in the top plate direction. PMV coil fixed claw |
| (2) | Heat exchanger | Detachment Recover the refrigerant gas. Remove the refrigerant pipe of the indoor unit. Perform work of procedure 1. of ⑤. Remove the pipe cover by taking off fixing screws of the cover. (M 4 × 8, 2 pcs) Remove the clamp which fixes TC1 sensor, TC2 sensor and TCJ sensor, and then pull out the sensors from the holder. Remove the heat exchanger by taking off fixing screws of the partition board while holding the heat exchanger. (M 4 × 8, 4 pcs) Attachment Fix parts as before in order of Heat exchanger → Sensors → Pipe cover → Drain cap → Drain pan → Ceiling panel → Electric parts cover → Adjust cover → Air intake grille. Connect the refrigerant pipe as before, and then perform vacuuming. | Partition board (Pipe drawing port side) Fixing screw Partition board |

11-4. Floor standing cabinet

MML-UP***H*




CAUTION

Be sure to stop operation of the air conditioner before work and then turn off switch of the breaker.

| ① Electric parts 1. Detachment Discharge | ciliai ko |
|--|--|
| (1) Remove the suction grilles (2 pieces). (No screw Kiring) (2) Remove the wire guard. (M4 screw: 4 pieces) (3) Remove the front panel. (M4 x 20L : 2 pieces) (4) Remove the discharge grille. (M4 x 20L : 2 pieces) (5) Remove the fals shore. (M4 screw: 3 pieces) (6) Remove the fan motor lead from the clamp, slide the glass tube, and then remove the relay connector. (7) Remove the TA sensor from the clamp. (8) Remove the connectors of TC1, TC2, and TCJ sensors from PC. board. CN101TC2 (2P: Black) CN102TCJ (2P: Red) "Unlock the lock of the housing part, and then remove the relay connectors. (9) Remove the relay connector of the PMV lead. (10) Remove body of the electric parts assembly. (M4 screw: 1) 2. Attachment Following step 1 of ① and (1) to (10), attach the parts as original in the reverse procedure. Fan motor lead from the clamp, slide the glass tube, and then remove the connectors. (9) Remove the relay connector of the PMV lead. (10) Remove body of the electric parts assembly. **CLIT To TA Sensor** **Electric parts assembly.** **CLIT To TA Sensor** **CLIT TO | wire guard TC2, TCJ Relay connector (PMV lead) M4 screw |

| No. | Spare parts | Work procedure | Remarks |
|-----|----------------------------|--|---|
| 2 | Refrigerant cycle assembly | 1. Detachment (1) Recover the refrigerant gas. (2) Take off the connecting pipe. | Upper panel Reinforcement plate Shield plate for heat exchanger Vertical grille Shield plate for heat exchanger Screws fixing heat exchanger Screws fixing heat exchanger Shield plate Heat exchanger Shield plate Heat exchanger Liquid pipe/Gas pipe Drain pan |
| 3 | Drain pan assembly | Detachment (1) Following step 1 of ② and those in (1) to (11), detach the parts. (2) Remove the drain pan assembly. Attachment Following step 1 in ③ and those in (1) to (2), attach the parts as original in the reverse procedure. | Drain pan assembly |

| No. | Spare parts | Work procedure | Remarks |
|-----|----------------------|--|---|
| 4 | Horizontal
louver | 1. Detachment (1) Following step 1 of ② and those in (3) to (5), detach the parts. (2) Remove the PMV connector: CN082 (6P Blue) from the P.C.board. (3) Turn the PMV coil slightly clockwise while holding the PMV body so that the body does not turn, and remove the PMV coil in the arrow direction. | PMV motor Turing direction |
| | | 2. Attachment (1) Attach the PMV coil as before and check it does not move. NOTE Check the direction of the PMV coil. Check the claw holes in the PMV coil are securely placed into four claws on the PMV body. Check the position of the lock part on the binding band fixing the lead wires. (2) Attach the PMV connector: CN082 (6P Blue) (3) Following step 1 of ④ and (1), attach the parts as original in the reverse procedure. | PMV coil PMV body |
| | | PMV coil protrusio Fit the claw holes the PMV body. PMV body inlet Lead wire | oil to the PMV body so that the on part points to the PMV body inlet. on the PMV coil into four claws on |
| | | binding baild I . Do part or II . Insorroot of III. Ens | on when fixing the lead wire with the g band. not apply tension to the drawing in the coil lead wire. ert the protective tube up to the forward for a drawing part on the lead wire. sure that the PMV pipe does not to contact with the protective tube. binding the figure. |



| No. | Spare parts | Work procedure | Remarks |
|-----|-------------|---|--|
| 7 | Capacitor | 1. Detachment (1) Following step 1 of ⑤ and (1) to (2), detach the parts. (2) Remove the capacitor. (M4 screw: 1 position) | |
| | | 2. Attachment Following step 1 of ⑥ , and (1) to (3), attach the parts as original in the reverse procedure. * Be sure to connect the capacitor lead to the specified position of the capacitor. | Capacitor |
| | | | Capacitor installing leg |
| | | | Capacitor lead capacitor lead wire (Red) wire (White) Connecting position of capacitor lead |

11-5. Floor standing concealed

MML-UP***BH*

⚠ WARNING

CAUTION

Be sure to stop operation of the air conditioner before work and then turn off switch of the breaker.

| No. Part name | Procedure | Remarks |
|---------------------------|---|--|
| ① Electric parts assembly | 1. Detachment (1) Remove the screws (2pcs) electric parts cover. (2) Slide the electric parts cover in the arrow direction to remove it. (3) Remove the power supply wire, remote controller wire, and communication wire between outdoor and indoor unit. (4) Remove following connectors from the control P.C. board. * Remove the connectors by unlocking the locks of the housing part. CN082 PMV (6P: Blue) CN083 Fan motor (9P: White) CN100 TC1 sensor (3P: Brown) CN101 TC2 sensor (2P: Block) CN102 TCJ sensor (2P: Pellow) (5) Cut the binding bands (2 places) fixing the electric parts box and wires to remove the wires from the wire clamps (2 places) (6) Remove the screws (2 places) fixing the electric parts box and slide it upward (Arrow direction) to remove it. 2. Attachment (1) Slide the electric parts assembly upper to lower to insert it into the inserting part and fix it with the screws (2 pcs). (2) Connect the connectors as original. NOTE • Check the connectors are correctly attached. • Be sure to check each wire is matched with each connector. (3) Wire the power supply wire, remote controller wire, and communication wire between outdoor and indoor unit as original. (4) Attach the electric parts cover. | Remarks Electric parts cover CN083 (White) CN082 (Blue) CN100 (Brown) CN101 (Black) Binding band Wire clamp Binding band Inserting part |

| No. Part n | ame | Procedure | Remarks |
|---------------------|------|---|--|
| © Contro
P.C.box | ol 1 | I. Detachment (1) Remove the electric parts cover. (2) Remove following connectors from the control P.C. board. * Remove the connectors by unlocking the locks of the housing part. CN030: Short-circuit pin (3P: Red) CN041: Terminal block for controller (2P: Blue) CN040: Terminal block for communication wire between indoor and outdoor unit (2P:Blue) CN030: Terminal block for power supply (5P: Black) CN074: Power supply trance (3P: White) CN075: Power supply trance (6P: White) (3) Remove locks for spacers (4 pcs) fixing the control P.C. board to remove the control P.C. board. | CN030 (Red) CN041 CN040 CN075 CN067 CN074 (Blue) (Blue) (White) (Black) (White) |
| | | 2. Attachment (1) Attach the control P.C.board into the control P.C board as original and connect each connector (2) Attach the electric parts cover. | Spacer Spacer Spacer Spacer |

| No. | Part name | Procedure | Remarks |
|--------------|--|--|--|
| No. ③ | Part name Refrigerating cycle assembly | | Piping cover Front panel (upper) Front panel (lower) Filter Sensor lead, PMV lead |
| | | (Int screw. 5 pieces) (11) Take off the screws which fix the drain pan, slide it toward right, remove the drain pan from the side plate (Left), and then draw it toward you. (12) Remove the dashboard of the heat exchanger. (M4 screw: 4 pieces) (13) Slide the heat exchanger toward right, remove the end plate of the heat exchanger from the side plate (left), and then draw away the refrigerating cycle assembly toward you. 2. Attachment Following to the works in 1 of ③, and (1) to (13), attach the parts as original in the reverse procedure. | Side plate (left) Refrigerating cycle assembly Heat exchanger dashboard |

| No. | Part name | Procedure | Remarks |
|-----|-----------|---|--|
| (5) | Fan | 1. Detachment | Clama |
| | assembly | (1) Following to the works in 1 of ① of (1) to (3) detach the parts. | Clamp |
| | | (2) Remove CN083 connector from the control P.C. board. | |
| | | (3) Remove the fan motor lead from the clamp. | |
| | | (4) Slide the glass tube fixing the fan motor lead and remove the connector. | |
| | | (5) Take off the fixing screws of the fan assembly and draw the fan assembly toward you. (M4 screw: 2 pieces) | |
| | | 2. Attachment | |
| | | Following to the works in 1 of ①, and (1) to (5), attach the parts as original in the reverse procedure. | Fan motor lead |
| | | | Sliding direction Glass tube Connector |
| | | | |
| | | | Sliding direction Fan assembly |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| [UP007 to UP012] 1. Detachment (1) Following to works of 1 of ② and (1) to (5), detach the Fan assembly parts. (2) Remove the wire clamps which fixes the fan motor lead. (Two positions) (3) Take of the screws at the left of the fan case (4 pieces) to remove the fan case at the left (4) Loosen the Sirocco fan ixing screws from the discharge port to remove the Birocco fan.) (5) Take off two fixing screws of the fan case (Right), and remove the fan case (Right). (6) Take off two fixing screws (2 pieces) for capacitor cover next to the electrical parts assembly to remove the capacitor. (7) Remove the andrease (Right). (8) Take off the screws (2 pieces) fixing the motor band to remove the motor band, fan motor. reinforcement plate, and fan motor. (8) Take off the screws (2 pieces) fixing the motor band to remove the motor band, fan motor. reinforcement plate, and fan motor. Screw Screw Fan motor Sirocco fan fixing screw Capacitor Capacitor Capacitor lead wire (Red) Capacitor Capac | 1. Detachment (1) Following to works of 1 of (§) and (1) to (5), detach the Fan assembly parts. (2) Remove the wire clamps which fixes the fan motor lead. (five positions) (3) Take off the screws at the left of the fan case (4 pieces) to remove the fan case at the left. (4) Loosen the Sirocco fan fixing screws from the discharge port to remove the Sirocco fan. (5) Take off two fixing screws of the fan case (Right), and remove the fan case (Right), and remove the the case (Fight). (6) Take off screws (2) pieces) for capacitor cover next to the electrical parts assembly to remove the capacitor. (7) Remove the capacitor lead wire from the capacitor. (8) Take off screws (2) pieces) for capacitor cover next to the electrical parts assembly to remove the capacitor. (8) Take off screws (2) pieces) for capacitor cover next to the electrical parts assembly to remove the capacitor. (8) Take off screws (2) pieces) for capacitor cover next to the electrical parts assembly to remove the capacitor. (9) Take off screws (2) pieces) for capacitor cover next to the electrical parts assembly to remove the capacitor. (9) Take off screws (2) pieces) for capacitor cover next to the electrical parts assembly to remove the capacitor. (9) Take off screws (2) pieces) for capacitor cover next to the electrical parts assembly to remove the capacitor. (9) Take off screws (2) pieces) for capacitor cover next to the electrical parts assembly to remove the capacitor. (9) Take off the screws (2) pieces for capacitor cover next to the electrical parts assembly to remove the capacitor. (9) Take off the screws (2) pieces for capacitor cover next to the electrical parts assembly to remove the capacitor. (9) Take off the screws (2) pieces for capacitor cover next to the electrical parts assembly to remove the capacitor. (9) Take off the screws (2) pieces for capacitor cover next to the electrical parts assembly to remove the capacitor. (9) Take off the screws (2) pieces for capacitor cover next to the electrical parts assembly to | No. | Part name | Procedure | Remarks |
|--|--|-----|-----------|--|--|
| discharge port to remove the Sirocco fan. (5) Take off two fixing screws of the fan case (Right), and remove the fan case (Right). (6) Take off screws (2 pieces) for capacitor cover next to the electrical parts assembly to remove the capacitor. (7) Remove the capacitor lead wire from the capacitor. (8) Take off the screws (2 pieces) fixing the motor band to remove the motor band, fan motor- reinforcement plate, and fan motor. Sirocco fan fixing screw Capacitor Capacitor lead wire (Red) Capacitor lead wire (Red) Fan motor screw (Capacitor lead wire (Red) Capacitor lead wire (Red) Fan motor screw (Capacitor lead wire (Red) Fan motor screw (Capacitor lead wire (Red) | discharge port to remove the Sirocco fan. (5) Take off two fixing screws of the fan case (Right), and remove the fan case (Right). (6) Take off screws (2 pieces) for capacitor cover next to the electrical parts assembly to remove the capacitor. (7) Remove the capacitor lead wire from the capacitor. (8) Take off the screws (2 pieces) fixing the motor band to remove the motor band, fan motor- reinforcement plate, and fan motor. Sirocco fan fixing screw Sirocco fan fixing screw Capacitor (Capacitor lead wire (Red)) Capacitor (Red) Capacitor Fan motor Screw hole reinforcement plate Fan motor Screw Screw Capacitor lead wire (Red) Capacitor Screw hole reinforcement plate | 6 | Fan motor | 1. Detachment (1) Following to works of 1 of ⑤ and (1) to (5), detach the Fan assembly parts. (2) Remove the wire clamps which fixes the fan motor lead. (Two positions) (3) Take off the screws at the left of the fan case | Wire Fan motor clamp |
| Motor band | | | | (4 pieces) to remove the fan case at the left (4) Loosen the Sirocco fan fixing screws from the discharge port to remove the Sirocco fan. (5) Take off two fixing screws of the fan case (Right), and remove the fan case (Right). (6) Take off screws (2 pieces) for capacitor cover next to the electrical parts assembly to remove the capacitor. (7) Remove the capacitor lead wire from the capacitor. (8) Take off the screws (2 pieces) fixing the motor band to remove the motor band, fan motor- reinforcement | Fan case (Left) Fan motor Sirocco fan fixing screw Sirocco fan fixing screw Capacitor Capacitor lead wire (Red) Capacitor Screw Screw Capacitor Capacitor lead wire (Red) Capacitor Screw hole reinforcement plate Fan motor F |

| No. | Part name | Procedure | Remarks |
|-----|-----------------------|---|--|
| | Fan motor (Continued) | (1) Attach the fan motor, motor band, fan motor reinforcement plate, and fan case as original. * When attaching the fan motor, be sure that the fan motor does not hit the motor base reinforcement plate. * When attaching the fan motor reinforcement plate, fasten it together with the motor band. * When attaching the Sirocco fan, meet the fixing screw for Sirocco fan to the notch position on the shaft of the fan motor. * When fixing the Sirocco fan, ensure that the Sirocco fan does not hit to the fan case. * For the tightening torque of the screw fixing the Silocco fan, control between 5.0 to 5.2 N·m. (2) Following to the works in 1 of ⑤, and (1) to (3), attach the Fan assembly parts as original in the reverse procedure. | Fan motor reinforcement plate Fan motor Motor band Fan base Fixing screw for sirocco fan Shaft meets to the position of the fixing screw for sirocco fan. |

| No. | Part name | Procedure | Remarks |
|-----|--------------------------|---|---|
| 6 | Fan motor
(Continued) | [UP015 to UP024] | Wire clamp Fan motor lead |
| | (| 1. Detachment(1) Following to works of 1 of ⑤ and (1) to (5), detach the Fan assembly parts. | |
| | | (2) Remove the wire clamps which fixes the fan motor lead. (Two positions). | Screw Screw |
| | | (3) Take off the screws (8 pcs) for outer fan case (2pcs) to the fan motor and remove the tape for inner fan case to remove the outer fan case. | Screw Screw |
| | | (4) Take off the screws (4 pcs) for inner fan case to
remove the inner fan case. | |
| | | (5) Take off screws (2 pieces) for capacitor cover to
remove the capacitor cover. | Screw Outer fan case Screw |
| | | (6) Remove the capacitor lead wire from the capacitor. | |
| | | (7) Take off the screws (2 pieces) fixing the motor band to
remove the motor band, fan motor-reinforcement
plate, and fan motor. | Sirocco fan fixing screw Sirocco fan |
| | | 2. Attachment | |
| | | (1) Attach the fan motor, motor band, and fan case as original. | Discharge port |
| | | * When attaching the Sirocco fan, meet the fixing
screw for Sirocco fan to the notch position on the.
shaft of the fan motor. | Таре |
| | | * When fixing the Sirocco fan, ensure that the Sirocco fan does not hit to the fan case. | |
| | | For the tightening torque of the screw fixing the Silocco fan, control between 5.0 to 5.2 N•m. When connecting the capacitor, be careful of its connection position. | |
| | | (2) Following to the works in 1 of ⑤, and (1) to (5), attach the Fan assembly parts as original in the reverse procedure. | Inner fan case Screw Inside the fan case |
| | | | Capacitor cover Capacitor lead wire (Red) |
| | | | Screw Inside the fan case |
| | | | Earth wire Screw |
| | | | |
| | | | |

| No. | Part name | Procedure | Remarks |
|-----|-----------|---|---|
| 7 | Capacitor | [UP007 to UP012] 1. Detachment (1) Following to ,1 of ①, and (1) to (2), detach the parts. (2) Remove the capacitor cover and remove the capacitor lead from the capacitor. (M4 screw: 2 pieces) (3) Remove the capacitor. (M4 screw: 1 position) | Capacitor cover |
| | | Following to 1 of ①, and (1) to (2), attach the parts as original in the reverse procedure. | Capacitor |
| | | [UP015 to UP024] 1. Detachment (1) Following to ,1 of ⑦, and (1) to (2), detach the parts. (M4 screw: 2 pieces) (2) Remove the capacitor. (M4 screw: 1 position) 2. Attachment Following to 1 of ⑦, and (1) to (2), attach the parts as original in the reverse procedure. | Capacitor |
| | | [UP007 to UP024] * Be sure to connect the capacitor lead to the specified position of the capacitor. | Capacitor installing leg Capacitor lead Capacitor lead wire (Red) Capacitor lead wire (White) Connecting position of capacitor lead |

| No. | Part name | Procedure | Remarks |
|-----|-----------|--|---|
| 8 | Drain pan | 1. Detachment (1) Remove the front panel (lower) and electric parts assembly. Refer to the works of 1 of ③ and (6), and the work of 1 of ①. (2) Remove the screws fixing the drain pan (3) Slide the drain pan in the direction of piping side to remove it. | Screw Drain pan |
| | | 2. Attachment (1) Attach the drain pan as original and tighten it with screws. (2) Attach the front panel (lower) and electric parts assembly. Refer to the works of 2 of ② and (6), and the work of 2 of ①. | Electric parts box side Slide direction Electric parts box side |
| | | | |

11-6. Floor standing

MMF-UP***H*

MARNING

CAUTION

Be sure to stop operation of the air conditioner before work and then turn off switch of the breaker.

| No. | Part name | Procedure | Remarks |
|-----|---------------|---|---------------|
| 1 | Intake grille | 1. Detachment 1) Pull the upper part of the intake grille toward you, remove two strings that connect the intake grille with the main unit, and then remove the intake grille while lifting up it. 2. Attachment 1) Attach the intake grille in the reverse way of detachment. | Intake grille |

| No. | Part name | Procedure | Remarks |
|-----|-----------------------|---|---|
| 2 | Electric parts
box | 1. Detachment 1) Carry out the work of item ①-1. 2) Remove the Screw 1 (two screws) from the drip-proof cover on the bottom plate. * This work is unnecessary for Models UP036 to UP056. 3) Remove the Screw 2 (two screws) from the electrical control box cover. 4) Remove the indoor/outdoor communication wires and the remote controller wires from each terminal block. 5) Remove the connectors and others which connected to P.C. board. | Screw 1 Screw 1 Drip-proof cover Electrical control box cover Screw 2 Electrical control box cover |
| | | When removing the connectors, unlock the lock. CN01: Reactor (3P, Blue) CN40: Indoor/Outdoor communication terminal block (2P, Blue) CN41: Remove controller terminal block (2P, Blue) CN67: Power supply terminal block (5P: Black) CN82: PMV output (6P, Blue) CN100: TC1 sensor (3P, Brown) CN101: TC2 sensor (2P: Black) CN102: TCJ sensor (2P, Red) CN104: Room temperature (2P, Yellow) CN210: Fan motor (7P, White) CN510: Louver motor (20P, White) 6) Remove the Screw 3 (two screws) that fix the electric parts box, slide it toward right, and then remove the electric parts box. 7) Unlock the lock of the card edge spacer, and then remove the P.C. board. 2. Attachment 1) Attach the P.C. board and the electric parts box, and then perform wiring as before. 2) Attach the electrical control box cover and the drip-proof cover. NOTE • Check there is no incorrect wiring or no dislocation of connector. • Set the connected part of tube of the fan motor lead wire at a place out of the electric parts box. | Screw 3 P.C. board Card edge spacer Connected part of tube |

| No. | Part name | Procedure | Remarks |
|-----|--------------|--|---|
| 3 | Access panel | 1. Detachment 1) Carry out the work of item ①-1. 2) Remove the two screws of the Access panel, slide the Access panel approx. 30mm upward, and remove the Access panel while drawing it toward you. • The screws are designed to stay on the Access panel. 2. Attachment 1) Attach the Access panel in the reverse way of detachment, and then fix it with two screws. ACAUTION For reason of safety, be sure to fix the Access panel with screws. | 2 ♣ ↑ ↑ ↑ ↑ ↑ ↑ ↑ ↑ ↑ ↑ ↑ ↑ ↑ ↑ ↑ ↑ ↑ ↑ |

| No. | Part name | Procedure | Remarks |
|-----|----------------|--|--|
| 4 | Fan, Fan motor | 1. Detachment 1) Carry out the works of items ①-1 and ③-1. 2) Cut off the banding band that fixes the fan motor lead wire to remove the fan motor connector in the electric parts box. ▼ UP015 ~ UP027 3) Remove the Screw 1 (five screws) that fix the motor base, and then take out the motor base, fan motor, and fan. 4) Loosen the Screw 2 that fixes the fan and then remove the fan. 5) Remove the Screw 3 (three screws) and then remove the fan motor. ▼ UP036 ~ UP056 3) Remove the Screw 4 (three screws) that fix the shield plate assembly, and then remove the shield plate assembly. 4) Remove the Screw 5 (five screws) that fix the ceiling plate of the fan assembly, and then draw out the fan with assembly. 5) Remove the Screw 6 (four screws) that fix the motor fixing plate, and then remove the motor fixing plate. 6) Remove the Screw 7 (four screws for left and right each) that fixes right and left bellmouth, take off left and right fan case fixing Screw 8 (four screws for left and right), and then remove the fan case. 7) Remove the screw that fixes the fan, and then remove the fan from the fan motor. 8) Remove the Screw 9 (the screw for right and left each) of the left and right motor band, and then remove the fan motor. 1) Attachment 1) Attach the fan motor, fan and others in the reverse way of detachment, and then perform wiring as before. NOTE • Mount UP015 to UP027 fans so that bump difference when putting motor shaft end face and fan end face together is within ± 1mm. • For attachment of UP036 to UP056 fans, set so that the fan locates at the center of the fan case. • Tighten the fan screw with 4.9N•m or more with a torque wrench. | Screw 1 Fan motor Motor base Screw 2 Screw 5 Screw 6 Screw 7 Screw 8 Fan ceiling plate Screw 8 Fan motor Motor fixing plate Screw 9 Scre |

| No. | Part name | Procedure | Remarks |
|----------|----------------|---|--|
| S | Heat exchanger | 1. Detachment 1) Carry out the works of items ①-1 and ③-1. ▼ UP015 to UP027 2) Remove the tube of the relay part of PMV, and then remove the relay connector. 3) Remove the Screw 1 (four screws) that fixes the main unit and heat exchanger assembly, and then draw out the heat exchanger assembly toward you. | <up015 to="" up027=""> To PMV coil Upper shield Screw 2 Screw 1 Screw 1</up015> |
| | | 4) Remove the Screw 2 (two screws) of the heat exchanger, and then remove the upper shield plate. 5) Remove the Screw 3 (four screws) of the heat exchanger assembly, and then remove the shield plate. 6) Remove three types of temperature sensors from the heat exchanger assembly. | Relay connector Banding band (2 positions) PMV lead wire for waterproof) Shield plate To circuit board CN082 (Blue) |
| | | ▼ UP036 to UP056 2) Remove the tube of the PMV relay part to remove the relay connector. 3) Remove the Screw 1 (three screws) that fixes the main unit and the heat exchanger assembly, and then draw out the heat exchanger assembly toward you. 4) Remove the Screw 2 (two screws) of the heat exchanger assembly, and then remove the upper shield plate. 5) Remove the Screw 3 (four screws) of the heart exchanger assembly, and then remove the shield plate. 6) Remove three types of the temperature sensors from the heat exchanger assembly. 2. Attachment 1) Attach the temperature sensor, shield plate, and heat exchanger assembly in the reverse way of the detachment, and then perform wiring of PMV relay lead wire as before. | CUP036 to UP056> Upper shield Screw 2 Screw 1 Screw 1 Screw 2 To PMV coil Banding band (2 positions) Screw 3 Tube (for waterproof) Lead wire To circuit board CN082 (Blue) Shield plate |
| | | | |

| No. | Part name | Procedure | Remarks |
|-------------|--------------------|--|---|
| No . | Part name PMV coil | 1. Detachment (1) Carry out the works items ⑤-1. (2) Cut the binding bands (2 places) to remove the tube of the relay part of PMV. (3) Remove the PMV lead from the relay connector (4) Turn the PMV coil slightly clockwise while holding the PMV body so that the body does not turn, and remove it in the arrow direction. 2. Attachment (1) Attach the PMV coil as before and check it does not move. NOTE • Check the direction of the PMV coil. • Check the claw holes in the PMV coil are securely placed into four claws on the PMV body. • Check position of the lock part on the binding band and the lead wires. (2) Connect the PMV lead wire to the relay connector of PMV. (3) Attach the tube as before and fix it with the binding band (2 place). | Remarks View A Binding band (2:places) Relay connector part of PMV Find the PMV coil your hand. Counterclockwise View A Attach the PMV coil to the PMV body so that the PMV coil protrusion part points to the PMV body inlet. Fit the claw holes on the PMV coil into four claws on the PMV body. PMV body inlet Caution when fixing the lead wire with the binding band. I. Do not apply tension to the drawing part on the coil relaed wire. II. Ensure that the PMV pipe does not come to contact with the protective tube. |
| | | Binding band | binding band. I. Do not apply tension to the drawing part on the coil lead wire. II. Insert the protective tube up to the root of drawing part on the lead wire. III. Ensure that the PMV pipe does not come to contact with the protective tube on the binding |

| No. | Part name | Procedure | Remarks |
|-----|----------------------|--|--|
| 7 | Horizontal
louver | 1. Detachment (1) Remove the intake grille and the access panel. (Carry out the works items ①-1 and ③-1.) (2) Remove three screws that fixes the shield plate assembly to remove the shield plate assembly. (3) Remove two screws that fixes the discharge grille assembly. Draw the discharge grille toward you while lifting it upward slightly to remove it. * Be careful not to lose the supporting plate. (4) Turn the horizontal louver in the vertical direction and draw it toward you to remove it from the discharge grille frame (5) Remove the horizontal louver from the center clamp. (five places at the center) * Lift the horizontal louver to diagonally upward. (6) Remove the horizontal louver from the louver joint (five places). | Shield plate assembly Screw 3 pieces Discharge grille assembly Screw 2 pieces Supporting plate |
| | | 2. Attachment (1) Carry out reversing the detachment procedure, attaching the horizontal louver. * Apply the grease to the receptor of axis (five places) when replacing the center clamp. (Recommended grease: Shinetsu Silicone HIVAC-G) | Horizontal louver Horizontal louver Center clamp Louver joint Horizontal louver |

11-7. 4-way cassette

MMU-UP***H*



CAUTION

Be sure to stop operation of the air conditioner before work and then turn off switch of the breaker.

| No. | Part name | Procedure | Remarks |
|-----|----------------------|--|---|
| 1 | Suction grille | Detachment Stop operation of the air conditioner and then turn off switch of the breaker. Slide the 2 hooks of the suction grille inward and then hang down the suction grille while pushing the suction grille. Remove a strap connecting the panel and the suction grille and then remove the suction grille. Attachment Hook the suction grille to the panel. Attach strap of the suction grille to the panel as before. Close the suction grille, slide the knobs outward and then fix the panel. The panel of the pan | Suction grille Ceiling panel Hook of the suction grille Adjust corner cap Hook for falling-preventive strap Hole for ceiling panel hook Hinge |
| 2 | Electric parts cover | Detachment Carry out work of item 1. of ①. Remove the fixing screw A which fixes the electric parts cover and loosen the fixing screw B. Slide the electric parts cover to the arrow direction in order to open. (The electric parts cover remains hung.) Attachment Slide the electric parts cover in the direction opposite to the arrow direction to insert the craw of electric parts box and the claw of electric parts cover into their slits and hook the fixing screw B to the potbelly hole to insert the bell mouth pin to the electric parts box cover. Tighten the fixing screws A and B and then fix the electric parts box cover. Following to work of item 2 of ①, mount the suction grille as before. | Fixing screw B Potbelly hole (Dharma doll hole) Claw of electric parts box Fixing screw A Fixing screw A Fixing screw A Hinge |


| No. | Part name | Procedure | Remarks |
|-----|----------------------|---|---|
| 3 | Adjust
corner cap | 1. Detachment 1) Pull the knob of the adjust corner cap to the arrow direction ①, remove the adjust corner cap. NOTE: The adjust corner cap will remain hung on a falling-preventive strap. | 01 |
| | | | Ceiling panel Adjust corner cap |
| | | 2. Attachment 1) Hook the fall-prevention strap securely to the claw of the ceiling panel if it remains removed. 2) Insert claw of the adjust corner cap with the arrow direction into the square hole of the panel. (2 positions) 3) Insert three claws of the adjust corner cap into the positions indicated with arrow marks so that they fit in three positions. | Claw (Hook here) Strap of adjust corner cap Adjust corner cap |
| | | | Claw A Square hole Insert the claw B |
| | | | into the three positions securely. |
| | | | |

| No. | Part name | Procedure | Remarks |
|------------|-------------------------|--|--|
| No. | Part name Ceiling panel | 1. Detachment 1) Carry out works of item 1 of ② and item 1 of ③. 2) Remove the flap connector (CN510, White, 20P) connected to the control P.C. board and then remove the lead wire from the clamp. NOTE: Unlock the lock of the housing part and then remove the connector. 3) Slide the panel fixing brackets (4 positions) outward. (Loosen the panel fixing 4 screws when the panel fixing brackets do not move.) 4) Push the tentative bracket outward and then remove the ceiling panel. 2. Attachment 1) Insert the tentative brackets (2 positions) of the ceiling panel into square holes of the indoor unit and then hook the panel tentatively. NOTE: The ceiling panel has the direction against the indoor unit. Direct the louver motor wire to the electric parts box | Clamper CN510 Panel fixing implement Panel fixing screw Panel fixing screw Indicate the part of t |
| | | Direct the louver motor wire to the electric parts box side of the indoor unit. 2) Pass the head of the panel fixing screw through hole of the panel fixing bracket and then slide the panel fixing bracket inward. (If loosening the panel fixing screws in removing, tighten them.) 3) Following to work of item 2 of ③, attach the adjust corner cap as before. 4) Connect the louver connector (CN510, White, 20P) as before and then fix the lead wire with clamp. 5) Following to work of item 2 of ②, mount the electric parts box cover and the suction grille as before. | Refrigerant pipe screw Ceiling panel Louver motor wires Tentative hanging hook (Fig. 3) Square hole of an indoor unit |
| | | | Push to remove Tentative hanging hook |

| No. | Part name | Procedure | Remarks |
|-----|--------------------|---|--|
| © | Control P.C. board | 1. Detachment 1) Carry out work of item 1 of ②. 2) Remove connectors which are connected from the control P.C. board to the other parts and then remove wiring from the clamp. CN510: Louver motor (20P, White) CN34: Float switch (3P, Red) CN504: Drain pump (2P, White) CN100: TC1 sensor (3P, Brown) CN101: TC2 sensor (2P, Black) CN102: TGJ sensor (2P, Black) CN104: Room temp. Sensor (2P, Yellow) CN210: Fan motor (7P, White) CN82: PMV (6P, Blue) CN67: Power supply (5P, Black) CN40: Outdoor communication (2P, Blue) CN41: Remote controller (2P, Blue) CN22: Ground (TAB terminal) NOTE: Unlock the lock of the housing part and then remove the connector. 3) Unlock the locks of the card edge spacer (4 positions) and then remove the control P.C. board. 2. Attachment 1) Fix the control P.C. board to the card edge spacer (4 positions). 2) Connect the connector removed in item 1 as before and then fix the wiring with the clamp. 3) Following to work of item 2 of ③, mount the electric parts box cover and the suction grille as before. NOTE: When removing the electric parts box, do not remove the wire box assembly fixing screw. Otherwise, the wire box assembly may come off. | Card edge spacer Clamp Card edge spacer Wire box assembly Fixing screw |

| No. | Part name | Procedure | Remarks | |
|-----|-----------|---|---|--|
| 6 | Drain cap | 1. Detachment 1) Carry out work of item 1 of ①. 2) Loosen screws (2 positions) fixing the drain cap (outside) and then turn the drain cap to the arrow mark direction to remove it. | Drain cap (outside) | |
| | | NOTE: The drain cap (outside) is hung down because a strap is attached to it. | | |
| | | Turn the drain cap (inside) one round into OPEN direction to loosen it and then drain the drain water accumulated in the drain pan. | Drain cap claw part Drain cap fixing screw | |
| | | NOTE: Be sure to catch drain water using a bucket, etc. when loosening the drain cap. The insulating materials are adhered to the drain cap (outside) and opening part of the drain pan; be careful that they do not come off. If the insulating materials have come off, stick them as before using double-faces tape, etc. | Drain cap (inside) | |
| | | 4) Turn the drain cap once again to OPEN → direction to remove it. 2. Attachment | open Drain pan △ mark | |
| | | Insert the drain cap (inside), turn it to CLOSE → direction until the position where "Click sound" is heard and it cannot be turned more over (Position where △ mark of the drain pan matches with △ mark of the drain cap (inside)) and then fix it. | | |
| | | NOTE: When attaching the drain cap (inside), remove dirt attached to the packing. And tighten the cap with care so that it is securely attached. If the cap is attached with dust or dirt on it, or it is not securely attached, water leakage is caused. | Drain cap (outside) | |
| | | | Slide the drain cap (outside) and then hook the claw part to attach it with the fixing screw as original. | |
| | | NOTE: Be sure to hook the claw part when attaching the drain cap (outside). Improper to attach it cause the water leakage. | Drain cap claw part Drain cap fixing screw | |
| | | 3) Following to work of item 2 of ①, mount the suction grille as before. | Drain cap fixing screw | |
| | | | | |
| | | | | |
| | | | | |

| No. | Part name | Procedure | Remarks |
|-----|-----------|--|---|
| 7 | Fan motor | 1. Detachment | |
| | | Carry out work of item 1 of ②. Remove connectors which are connected from the control P.C. board to the other parts and then remove each wiring from the clamp. CN510: Louver motor (20P, White) CN34: Float switch (3P, Red) CN504: Drain pump (2P, White) CN100: TC1 sensor (3P, Brown) | Fixing screw A Cover plate Fixing screw B |
| | | CN101: TC2 sensor (2P, Black) CN102: TCJ sensor (2P, Red) CN104: Room temp. Sensor (2P, Yellow) CN210: Fan motor (7P, White) CN82: PMV (6P, Blue) NOTE: Unlock the lock of the housing part and then remove the connector. | Fixing Clamp filter screw C (Only MMU-UP009*, UP012*) |
| | | 3) When replacing the fan motor, be sure to remove the clamp filter from the fan motor. (Only MMU-UP009*, UP012*) 4) Remove the fixing screw A and then remove the cover | Wire box |
| | | plate. (Only MMU-UP015* to UP056*) (Fixing screw A: M 4 × 10, 2 pcs) 5) Remove the fixing screws B and C, and then remove the electric parts box. (Fixing screw B: M 4 × 10, 3 pcs, Fixing screw C: M 4 × 8, 1 pc.) | Fixing screw PMV lead Clamp |
| | | 6) Remove the fixing screw and then remove the wire box assembly. (Only MMU-UP015* to UP056*) (Fixing screw: M 4 × 10, 1 pcs) 7) Remove the fan motor lead, TC1 sensor, TC2 sensor, | Glamp |
| | | TCJ sensor and PMV lead from clamp of the bell mouth. 8) Remove the fixing screws and then remove the bell mouth. (M 4 × 10, 5 pcs, three claws) A fan guard can be removed in the state attached to a bell mouth. | Fan motor lead TC1, TC2, TCJ sensor |
| | | 9) Remove the fixing screws and then remove the nut cap. (M 4 × 10, 2 pcs.) 10) Remove the fixing nut and then remove the turbo fan. | Claw Bell mouth Nut cap Claw |
| | | (M 8 nut with flange, 1 pc.) 11) Remove the fixing screws and then remove the motor lead holding bracket. (M 4 × 8, 2 pcs.) 12) Cut the binding band and then remove it from the clamp. 13) Remove the fixing nut and then remove the fan motor. (M 6 nut, 3 pcs.) | Fixing screw |
| | | 2. Attachment | |
| | | Fix the parts as before in order of fan motor → motor lead holding bracket → turbo fan → nut cap → bell mouth. | Turbo fan
Loosen |
| | | NOTE: Fix the motor lead to the clamp using binding band as before so that it does not slack. Fix it so that wiring does not come in contact with heat exchanging aluminum fin, turbo fan, or heat exchange plate. When fixing the turbo fan, be sure to match the D-cut of the fan boss with D-cut of the motor shaft. Using a torque wrench, fix the turbo fan and tighten it to 5.4 +0.5 /-0.2 Nm. Using a torque wrench, fix the motor (three | M8 nut with flange Tighten |
| | | positions) and tighten it to 4.9 ±0.5 Nm. | |



| No. | Part name | Procedure | Remarks |
|------------|-----------|---|---|
| No. | | Procedure Detachment Carry out works of item 1 of ② and item 1 of ⑥. Remove the drain pump connector (CN504, White, 2P) connected to the control P.C. board and then remove the lead wire from the clamp. Remove the fixing screws and then remove the drain pump. (M 4 × 10, 3 pcs.) As shown in the right figure, first pull out the connecting part of the drain pump and the drain hose from the drain port and then take out the drain pump. Set direction of the knob of the hose band downward, slide it from the pump connecting part to the hose side and then remove the drain hose from the drain pump. Pass the connector of the drain pump lead wire through the wiring taking-out port and then take out the drain pump. Attachment | Fixing screw Drain mouth Drain pump Hose band |
| | | Put your hand into the drain port and pass the connector of the drain pump lead wire through the wiring taking-out port. NOTE: Insert the drain hose up to the end of the drain pump connecting part, apply band to the white or yellow mark position of the hose and then set the band knob upward. Connect the drain hose to the drain pump as before. Return the drain pump to the indoor unit and then mount it as before using the fixing screws. (M 4 × 10, 3 pcs.) Connect the drain pump connector (CN504, White, 2P) to the control P.C. board and then fix it as before with the clamp. Following to works of item 2 of ⑥ and item 2 of ② mount the drain cap, the electric parts box cove and the suction grille as before. | Wiring outlet Clamp CN504 |
| | | | |

| No. Part na | ne Procedure | Remarks |
|-----------------------|---|---|
| Float switch assemble | Detachment Carry out works from 1) to 7) in item 1 of ⑦. Remove the fixing screw and then remove the float switch assembly. (M 4 × 25, 1 pc.) Attachment Mount the float switch assembly as before with the fixing screw. | Float switch assembly Fixing screw (M 4×25) |
| | NOTE: When mounting the float switch assembly, match hole of the float switch assembly with projection of the drain pan. 2) Mount the bell mouth as before. (M 4 × 10, 5 pcs, three claws) 3) Following to works of item 2 of ⑦ and works from 2) to 7), attach the parts as before. | Hole of float switch assembly Drain pan projection |
| ① Drain pa | 1. Detachment Carry out works of item 1 of ④, (removing the ceiling panel) item 1 of ⑥, (removing the drain cap), item 1 of ⑦ (removing the bell mouth and the electric parts box) and works from 2) to 7). Remove the fixing screws ②. (M 4 ×10, 2 pcs.) Remove two screws ⓒ fixing the holding plate and loosen two screws ⑥ on the side of the hanging hook. Turn the holding plate to the arrow direction as shown in the figure to remove the drain pan. Attachment Fix parts as before in order of drain cap → drain pan → bell mouth → wire box assembly. NOTE: For inserting the drain pan, perform the work while directing the holding plate outward since the holding plate interrupts its work if it directs to inside of the body. Following to works from 2) to 7) in the item 2 of ⑦, attach the parts as before. | Wire box |


| No. | Part name | Procedure | Remarks |
|-----|-----------|--|--|
| 111 | PMV coil | 1. Detachment | Partition plate |
| | | Carry out works from 1) to 7) in item 1 of ⑦. Remove fixing screw for partition plate. Open the partition plate in the arrow direction and remove the claws from square hole for heat exchanger fixing plate to remove the partition plate. (M 4 ×8, 2 pcs.) A little PMV coil is rotated, pressing down so that a PMV body may not turn, and it removes in the direction of an arrow. | Fixing screw Heat exchanger fixing plate Heat exchanger |
| | | 2. Attachment | Fan motor Claw fixing section |
| | | 1) Mount the PMV coil as before. | Fan motor Claw fixing section lead for partition plate |
| | | NOTE: Be careful of direction of a PMV coil. Check that four projections of the fixed claw of PMV coil and PMV body have fitted in. | partition plate |
| | | | Heat exchanger fixing plate Square hole for Heat exchanger fixing plate |
| | | | Claw |
| | | | PMV coil |
| | | | The lead wire of PMV coil is turned in the piping connection direction. |
| | | | PMV coil fixed claw |

| No. | Part name | Procedure | Remarks |
|-----|-----------|---|---|
| 12 | Heat | 1. Detachment | Piping cover assembly Fixing screw |
| | exchanger | 1) Recover the refrigerant gas. | |
| | | 2) Carry out work of item 1 of (10).3) Remove refrigerant pipe at indoor unit side. | |
| | | 4) Remove the fixing screws and then remove the piping cover. (M 4 ×10, 3 pcs.) | |
| | | 5) Carry out work of 2) in the item 1 of ① | |
| | | 6) Remove the drain hose from the drain pump and remove the fixing screws to remove the drain pump stand. (M 4 ×8, 3 pcs.) | Fixing screw Fixing screw |
| | | 7) While pushing the heat exchanger, remove the fixing band, fixing screws and the heat exchanger.
(M 4 ×8, 4 pcs.) | Drain pump stand Fixing screw |
| | | 2. Attachment | hose |
| | | Mount the heat exchanger with the fixing band and the
fixing screws. (M 4 x8, 4 pcs.) | |
| | | Fix the parts as before in order of drain pump stand →
piping cover. | |
| | | 3) Connect the refrigerant pipe as before and then apply vacuuming. 4) Following to work of item 2 of (0) ettech the parts as | Fixing band |
| | | Following to work of item 2 of (10), attach the parts as
before. | |
| | | Heat exchanger fixing band | |
| | | Loosen this screw to remove the fixing bracket | Heat exchanger fixing screw Heat exchanger |


12. EXPLODED VIEWS AND PARTS LIST

12-1. Compact 4-way cassette type

 $\begin{array}{lll} MMU\text{-}UP0051MH\text{-}E(TR),\, UP0071MH\text{-}E(TR),\, UP0091MH\text{-}E(TR),\, UP0121MH\text{-}E(TR),\\ UP0151MH\text{-}E(TR),\, UP0181MH\text{-}E(TR) \end{array}$




| | | | Q'ty/Set MMU-UP | | | | | | |
|-----------------|----------|--|-------------------|-------------------|-------------------|---|---|-------------------|--|
| Location
No. | Part No. | Description | 0051MH
-E (TR) | 0071MH
-E (TR) | 0091MH
-E (TR) | | | 0181MH
-E (TR) | |
| 201 | 43149501 | NUT, FLARE, 12.7 | | | | | 1 | 1 | |
| 202 | 43149498 | SOCKET, 9.52 | 1 | 1 | 1 | 1 | | | |
| 203 | 43079249 | BAND, HOSE | 1 | 1 | 1 | 1 | 1 | 1 | |
| 204 | 43104248 | PLATE ASSY, PARTITION | 1 | 1 | 1 | 1 | 1 | 1 | |
| 205 | 43107215 | HOLDER, SENSOR | 1 | 1 | 1 | 1 | 1 | 1 | |
| 206 | 43119542 | COVER, PIPE | 1 | 1 | 1 | 1 | 1 | 1 | |
| 208 | 43120277 | FAN, ASSY TURBO | 1 | 1 | 1 | 1 | 1 | 1 | |
| 209 | 43122165 | BELL MOUTH | 1 | 1 | 1 | 1 | 1 | 1 | |
| 210 | 4312C193 | MOTOR, FAN, ICF-340D60-1 N | 1 | 1 | 1 | 1 | 1 | 1 | |
| 211 | 43139166 | CAP, NUT | 1 | 1 | 1 | 1 | 1 | 1 | |
| 212 | 43139187 | RUBBER, CUSHION | 3 | 3 | 3 | 3 | 3 | 3 | |
| 213 | 43147195 | BONNET, 12.7 | | | | | 1 | 1 | |
| 214 | 43149497 | SOCKET, 6.35 | 1 | 1 | 1 | 1 | 1 | 1 | |
| 215 | 43149494 | SOCKET, 12.7 | | | | | 1 | 1 | |
| 216 | 43149500 | NUT, FLARE, 9.52 | 1 | 1 | 1 | 1 | | | |
| 217 | 43149533 | BAND, FIX, EVAPORATOR | 1 | 1 | 1 | 1 | 1 | 1 | |
| 218 | 4314J688 | REFRIGERATION CYCLE ASSY | | | | | 1 | 1 | |
| 219 | 4314J687 | REFRIGERATION CYCLE ASSY | | 1 | 1 | 1 | | | |
| 220 | 4314N202 | BODY, PMV, PAM-B40YGTF-1 | | | | | 1 | 1 | |
| 221 | 4314N205 | COIL, PMV, PAM-MD12TF-301 | 1 | 1 | 1 | 1 | 1 | 1 | |
| 222 | 4314N210 | BODY, PMV, PAM-B25YGTF-1 | 1 | 1 | 1 | 1 | | | |
| 223 | 43151323 | SWITCH, FLOAT | 1 | 1 | 1 | 1 | 1 | 1 | |
| 224 | 43160663 | LEAD, RELAY | 1 | 1 | 1 | 1 | 1 | 1 | |
| 225 | 43162087 | COVER, E-BOX | 1 | 1 | 1 | 1 | 1 | 1 | |
| 226 | 43163052 | HOLDER, LEAD, FAN MOTOR | 1 | 1 | 1 | 1 | 1 | 1 | |
| 227 | 43170276 | HOSE, DRAIN | 1 | 1 | 1 | 1 | 1 | 1 | |
| 228 | 43170277 | HOSE, DRAIN | 1 | 1 | 1 | 1 | 1 | 1 | |
| 229 | 43172259 | PAN ASSY, DRAIN | 1 | 1 | 1 | 1 | 1 | 1 | |
| 230 | 43177029 | PUMP, DRAIN | 1 | 1 | 1 | 1 | 1 | 1 | |
| 231 | 43179170 | BAND, HOSE | 2 | 2 | 2 | 2 | 2 | 2 | |
| 234 | 43F19904 | HOLDER, SENSOR (TS) | 2 | 2 | 2 | 2 | 2 | 2 | |
| 235 | 43F47609 | BONNET, 9.52 | 1 | 1 | 1 | 1 | | | |
| 236 | 43149499 | NUT, FLARE, 6.35 | 1 | 1 | 1 | 1 | 1 | 1 | |
| 237 | 43F49697 | BONNET, 6.35 | 1 | 1 | 1 | 1 | 1 | 1 | |
| 238 | 43F97212 | NUT | 1 | 1 | 1 | 1 | 1 | 1 | |
| 239 | 43166041 | REMOTE CONTROLLER, WIRELESS, RBC-AXU31-E | 1 | 1 | 1 | 1 | 1 | 1 | |
| 240 | 43166042 | REMOTE CONTROLLER, WIRED, RBC-AMSU51-EN | 1 | 1 | 1 | 1 | 1 | 1 | |
| 241 | 43166043 | REMOTE CONTROLLER, WIRED, RBC-AMSU51-ES | 1 | 1 | 1 | 1 | 1 | 1 | |
| 242 | 4314J686 | REFRIGERATION CYCLE ASSY | 1 | | | | | | |



| Location | Part No. | Description | Q'ty/Set |
|----------|------------|-----------------------------|--------------------|
| No. | i ait ivo. | Description | MMU-UP0**1MH-E(TR) |
| 401 | 43150394 | SENSOR, TC2 | 1 |
| 402 | 43150395 | SENSOR, TCJ | 1 |
| 403 | 43150417 | SENSOR, TC1 | 1 |
| 404 | 43160694 | TERMINAL, 4P | 1 |
| 405 | 43160626 | TERMINAL BLOCK, 2P, 20A | 1 |
| 406 | 4316W056 | P.C. BOARD ASSY, MCC-1643 | 1 |
| 407 | 43459017 | P.C. BOARD ASSY, TCB-PCUC*E | 1 |
| 408 | 43150423 | SENSOR, TA | 1 |
| 409 | 43163057 | CLAMP, DOWN | 1 |
| 410 | 43163058 | CLAMP, UP | 1 |

♦ Ceiling panel


RBC-UM21PG (W)-E



| Location
No. | Part No. | Description | Q'ty/Set |
|-----------------|----------|---------------------------|----------|
| 301 | 43109441 | GRILLE, AIR INLET | 1 |
| 302 | 43180361 | AIR FILTER | 1 |
| 303 | 4342D001 | MOTOR, LOUVER, MSBPC20F04 | 4 |
| 304 | 43107296 | OUTLET, AIR FORM | 4 |
| 305 | 43107297 | OUTLET, AIR FORM | 4 |
| 306 | 43122166 | LOUVER ASSY | 4 |
| 307 | 4310A142 | COVER, PANEL ASSY | 3 |
| 308 | 4310A143 | COVER, PANEL ASSY | 1 |
| 309 | 43107298 | PLATE, FIX PANEL (A) | 2 |
| 310 | 43107299 | PLATE, FIX PANEL (B) | 2 |
| 311 | 43107300 | HOOK | 2 |
| 312 | 43107301 | CAP, AXIS | 4 |
| 313 | 43107302 | FIX, MOTOR ASSY | 2 |
| 314 | 43107303 | FIX, MOTOR ASSY | 2 |
| 315 | 43160664 | LEAD, MOTOR | 1 |
| 316 | 4310A144 | PANEL, HINS ASSY | 1 |
| 317 | 43419022 | STRING | 1 |
| 318 | 43107304 | HANGER | 2 |
| 319 | 43107305 | FIX, GRILLE | 1 |


12-2. 2-way cassette type

MMU-UP0071WH-E(TR), UP0091WH-E(TR), UP0121WH-E(TR), UP0151WH-E(TR)




| | | | | Q'ty/Set | MMU-U | U-UP | |
|-----------------|----------|--|-------------------|-------------------|-------------------|-------------------|--|
| Location
No. | Part No. | Description | 0071WH
-E (TR) | 0091WH
-E (TR) | 0121WH
-E (TR) | 0151WH
-E (TR) | |
| 201 | 43149501 | NUT, FLARE, 12.7 | | | | 1 | |
| 202 | 43149498 | SOCKET, 9.52 | 1 | 1 | 1 | | |
| 203 | 43079249 | BAND, HOSE | 1 | 1 | 1 | 1 | |
| 204 | 43107215 | HOLDER, SENSOR | 1 | 1 | 1 | 1 | |
| 206 | 43120225 | FAN, ASSY TURBO | 1 | 1 | 1 | 1 | |
| 207 | 43122099 | PLATE, WIND | 3 | 3 | 3 | 3 | |
| 208 | 43122100 | BELL MOUTH | 1 | 1 | 1 | 1 | |
| 209 | 4312C192 | MOTOR, FAN, ICF-340D60-1 | 1 | 1 | 1 | 1 | |
| 210 | 43135022 | CONNECTOR ASSY, PMV | 1 | 1 | 1 | 1 | |
| 211 | 43139166 | CAP, NUT | 1 | 1 | 1 | 1 | |
| 212 | 43147195 | BONNET, 12.7 | | | | 1 | |
| 213 | 43147664 | STRAINER, 9.52 | 1 | 1 | 1 | 1 | |
| 214 | 43149497 | SOCKET, 6.35 | 1 | 1 | 1 | 1 | |
| 215 | 43149494 | SOCKET, 12.7 | | | | 1 | |
| 216 | 43149500 | NUT, FLARE, 9.52 | 1 | 1 | 1 | | |
| 217 | 43149534 | BAND, FIX, EVAPORATOR | 1 | 1 | 1 | 1 | |
| 218 | 4314J689 | REFRIGERATION CYCLE ASSY | 1 | 1 | 1 | | |
| 219 | 4314J690 | REFRIGERATION CYCLE ASSY | | | | 1 | |
| 220 | 4314N205 | COIL, PMV, PAM-MD12TF-301 | 1 | 1 | 1 | 1 | |
| 221 | 4314N209 | BODY, PMV, PAM-B40YGTF-2 | | | | 1 | |
| 222 | 4314N210 | BODY, PMV, PAM-B25YGTF-1 | 1 | 1 | 1 | | |
| 223 | 4314Q051 | STRAINER, 12.7 | 1 | 1 | 1 | | |
| 224 | 43151328 | SWITCH, FLOAT, FS-0218-103 | 1 | 1 | 1 | 1 | |
| 225 | 43160691 | LEAD, CONN | 1 | 1 | 1 | 1 | |
| 226 | 43170244 | HOSE, DRAIN | 1 | 1 | 1 | 1 | |
| 227 | 43170289 | HOSE, DRAIN | 1 | 1 | 1 | 1 | |
| 228 | 43172191 | PAN ASSY, DRAIN | 1 | 1 | 1 | 1 | |
| 229 | 43177028 | PUMP, DRAIN, PMD-08D12TF-2 | 1 | 1 | 1 | 1 | |
| 230 | 43179110 | PLUG | 1 | 1 | 1 | 1 | |
| 231 | 43179163 | BAND, HOSE | 1 | 1 | 1 | 1 | |
| 234 | 43F19904 | HOLDER, SENSOR (TS) | 2 | 2 | 2 | 2 | |
| 235 | 43F47609 | BONNET, 9.52 | 1 | 1 | 1 | | |
| 236 | 43149499 | NUT, FLARE, 6.35 | 1 | 1 | 1 | 1 | |
| 237 | 43F49697 | BONNET, 6.35 | 1 | 1 | 1 | 1 | |
| 238 | 43F97212 | NUT | 1 | 1 | 1 | 1 | |
| 239 | 43166041 | REMOTE CONTROLLER, WIRELESS, RBC-AXU31-E | 1 | 1 | 1 | 1 | |
| 240 | 43166042 | REMOTE CONTROLLER, WIRED, RBC-AMSU51-EN | 1 | 1 | 1 | 1 | |
| 241 | 43166043 | REMOTE CONTROLLER, WIRED, RBC-AMSU51-ES | 1 | 1 | 1 | 1 | |

MMU-UP0181WH-E(TR), UP0241WH-E(TR), UP0271WH-E(TR), UP0301WH-E(TR)




| l acation | | | | Q'ty/Set | MMU-UP | | |
|-----------------|----------|--|-------------------|-------------------|-------------------|-------------------|--|
| Location
No. | Part No. | Description | 0181WH
-E (TR) | 0241WH
-E (TR) | 0271WH
-E (TR) | 0301WH
-E (TR) | |
| 201 | 43149501 | NUT, FLARE, 12.7 | 1 | | | | |
| 202 | 43149498 | SOCKET, 9.52 | | 1 | 1 | 1 | |
| 203 | 43079249 | BAND, HOSE | 1 | 1 | 1 | 1 | |
| 204 | 43107215 | HOLDER, SENSOR | 1 | 1 | 1 | 1 | |
| 206 | 43120239 | FAN, MULTI BLADE | 2 | 2 | 2 | 2 | |
| 207 | 43122097 | CASE, FAN | 2 | 2 | 2 | 2 | |
| 208 | 43122098 | CASE, FAN | 2 | 2 | 2 | 2 | |
| 209 | 43122099 | PLATE, WIND | 4 | 4 | 4 | 4 | |
| 210 | 4312C183 | MOTOR, FAN, ICF-340WD94-9 | 1 | 1 | 1 | 1 | |
| 211 | 43135022 | CONNECTOR ASSY, PMV | 1 | 1 | 1 | 1 | |
| 212 | 43147194 | BONNET, 15.88 | | 1 | 1 | 1 | |
| 213 | 43147195 | BONNET, 12.7 | 1 | | | | |
| 214 | 43147664 | STRAINER, 9.52 | 1 | 1 | 1 | 1 | |
| 215 | 43149497 | SOCKET, 6.35 | 1 | | | | |
| 216 | 43149352 | NUT, FLARE, 15.88 | | 1 | 1 | 1 | |
| 217 | 43149494 | SOCKET, 12.7 | 1 | | | | |
| 218 | 43149496 | SOCKET, 15.88 | | 1 | 1 | 1 | |
| 219 | 43149500 | NUT, FLARE, 9.52 | | 1 | 1 | 1 | |
| 220 | 43149534 | BAND, FIX, EVAPORATOR | 2 | 2 | 2 | 2 | |
| 221 | 4314J691 | REFRIGERATION CYCLE ASSY | 1 | | | | |
| 222 | 4314J692 | REFRIGERATION CYCLE ASSY | | 1 | 1 | 1 | |
| 223 | 4314N205 | COIL, PMV, PAM-MD12TF-301 | 1 | 1 | 1 | 1 | |
| 224 | 4314N209 | BODY, PMV, PAM-B40YGTF-2 | 1 | 1 | 1 | 1 | |
| 225 | 43151328 | SWITCH, FLOAT, FS-0218-103 | 1 | 1 | 1 | 1 | |
| 226 | 43160691 | LEAD, CONN | 1 | 1 | 1 | 1 | |
| 227 | 43170244 | HOSE, DRAIN | 1 | 1 | 1 | 1 | |
| 228 | 43170290 | HOSE, DRAIN | 1 | 1 | 1 | 1 | |
| 229 | 43172192 | PAN ASSY, DRAIN | 1 | | | | |
| 230 | 43172193 | PAN ASSY, DRAIN | | 1 | 1 | 1 | |
| 231 | 43177028 | PUMP, DRAIN, PMD-08D12TF-2 | 1 | 1 | 1 | 1 | |
| 232 | 43179110 | PLUG | 1 | 1 | 1 | 1 | |
| 233 | 43179163 | BAND, HOSE | 1 | 1 | 1 | 1 | |
| 236 | 43F19904 | HOLDER, SENSOR (TS) | 2 | 2 | 2 | 2 | |
| 237 | 43F47609 | BONNET, 9.52 | | 1 | 1 | 1 | |
| 238 | 43149499 | NUT, FLARE, 6.35 | 1 | | | | |
| 239 | 43F49697 | BONNET, 6.35 | 1 | | | | |
| 239 | 43166041 | REMOTE CONTROLLER, WIRELESS, RBC-AXU31-E | 1 | 1 | 1 | 1 | |
| 240 | 43166042 | REMOTE CONTROLLER, WIRED, RBC-AMSU51-EN | 1 | 1 | 1 | 1 | |
| 241 | 43166043 | REMOTE CONTROLLER, WIRED, RBC-AMSU51-ES | 1 | 1 | 1 | 1 | |

MMU-UP0361WH-E(TR), UP0481WH-E(TR), UP0561WH-E(TR)




| Location | Part No. | Description | Q't | y/Set MMU- | -UP |
|----------|----------|--|---------------|---------------|---------------|
| No. | Part NO. | Description | 0361WH-E (TR) | 0481WH-E (TR) | 0561WH-E (TR) |
| 201 | 43149498 | SOCKET, 9.52 | 1 | 1 | 1 |
| 202 | 43079249 | BAND, HOSE | 1 | 1 | 1 |
| 203 | 43107215 | HOLDER, SENSOR | 1 | 1 | 1 |
| 204 | 43119479 | NUT | 2 | 2 | 2 |
| 206 | 43120239 | FAN, MULTI BLADE | 3 | 3 | 3 |
| 207 | 43122097 | CASE, FAN | 3 | 3 | 3 |
| 208 | 43122098 | CASE, FAN | 3 | 3 | 3 |
| 209 | 43122099 | PLATE, WIND | 6 | 6 | 6 |
| 210 | 43125162 | COUPLING | 1 | 1 | 1 |
| 211 | 43125199 | BEARING ASSY, MOLD | 1 | 1 | 1 |
| 212 | 43125203 | SHAFT | 1 | 1 | 1 |
| 213 | 4312C189 | MOTOR, FAN, ICF-340WD139-3 | 1 | 1 | 1 |
| 214 | 43135021 | CONNECTOR ASSY, PMV | 1 | 1 | 1 |
| 215 | 43139152 | BAND, MOTOR | 2 | 2 | 2 |
| 216 | 43147194 | BONNET, 15.88 | 1 | 1 | 1 |
| 217 | 43147664 | STRAINER, 9.52 | 1 | 1 | 1 |
| 218 | 43149495 | NUT, FLARE, 15.88 | 1 | 1 | 1 |
| 219 | 43149496 | SOCKET,15.88 | 1 | 1 | 1 |
| 220 | 43149500 | NUT, FLARE, 9.52 | 1 | 1 | 1 |
| 221 | 43149535 | BAND, FIX, EVAPORATOR | 2 | 2 | 2 |
| 222 | 4314J693 | REFRIGERATION CYCLE ASSY | 1 | 1 | 1 |
| 223 | 4314N203 | BODY, PMV | 1 | 1 | 1 |
| 224 | 4314N205 | COIL, PMV | 1 | 1 | 1 |
| 225 | 43151328 | SWITCH, FLOAT, FS-0218-103 | 1 | 1 | 1 |
| 226 | 43160691 | LEAD, CONN | 1 | 1 | 1 |
| 227 | 43170244 | HOSE, DRAIN | 1 | 1 | 1 |
| 228 | 43170290 | HOSE, DRAIN | 1 | 1 | 1 |
| 229 | 43172194 | PAN ASSY, DRAIN | 1 | 1 | 1 |
| 230 | 43177028 | PUMP, DRAIN, PMD-08D12TF-2 | 1 | 1 | 1 |
| 231 | 43179110 | PLUG | 1 | 1 | 1 |
| 232 | 43179163 | BAND, HOSE | 1 | 1 | 1 |
| 235 | 43F19904 | HOLDER, SENSOR (TS) | 2 | 2 | 2 |
| 236 | 43F47609 | BONNET, 9.52 | 1 | 1 | 1 |
| 237 | 43166041 | REMOTE CONTROLLER, WIRELESS, RBC-AXU31-E | 1 | 1 | 1 |
| 238 | 43166042 | REMOTE CONTROLLER, WIRED, RBC-AMSU51-EN | 1 | 1 | 1 |
| 239 | 43166043 | REMOTE CONTROLLER, WIRED, RBC-AMSU51-ES | 1 | 1 | 1 |



| Location | Part No. | Description | Q'ty/Set |
|----------|----------|-----------------------------|--------------------|
| No. | rait NO. | Description | MMU-UP0**1WH-E(TR) |
| 401 | 43150422 | SENSOR, TC2 | 1 |
| 402 | 43150342 | SENSOR, TCJ | 1 |
| 403 | 43150414 | SENSOR, TC1 | 1 |
| 404 | 43150421 | SENSOR, TA | 1 |
| 405 | 43160626 | TERMINAL BLOCK, 2P, 20A | 1 |
| 406 | 43160694 | TERMINAL, 4P | 1 |
| 407 | 4316W056 | P.C. BOARD ASSY, MCC-1643 | 1 |
| 408 | 43459017 | P.C. BOARD ASSY, TCB-PCUC*E | 1 |

♦ Ceiling panel


RBC-UW283PG (W)-E, RBC-UW803PG (W)-E, RBC-UW1403PG (W)-E




| Location | Part No. | Description | Q'ty/Set RBC-UW | | | | | |
|----------|----------|------------------------|-----------------|-------------|--------------|--|--|--|
| No. | Part NO. | Description | 283PG (W)-E | 803PG (W)-E | 1403PG (W)-E | | | |
| 201 | 43409195 | Panel, 941L | 1 | | | | | |
| 202 | 43409196 | Panel, 1306L | | 1 | | | | |
| 203 | 43409197 | Panel, 1726L | | | 1 | | | |
| 204 | 43407134 | Hook, Inlet | 2 | 2 | 2 | | | |
| 205 | 43407135 | Hook, Inlet | 2 | 2 | 2 | | | |
| 206 | 43403007 | Cover, Spacer | 1 | 1 | 1 | | | |
| 207 | 43403008 | Cover, Spacer | 2 | 2 | 2 | | | |
| 208 | 43403009 | Cover, Spacer | 1 | 1 | 1 | | | |
| 209 | 43408036 | Mark, TOSHIBA | 1 | 1 | 1 | | | |
| 210 | 43407136 | Fix, Louver, Middle | 1 | 2 | 2 | | | |
| 211 | 43407137 | Fix, Louver, Middle | 1 | 2 | 2 | | | |
| 212 | 43460115 | Lead Ass'y, Motor | 1 | 1 | 1 | | | |
| 213 | 43409193 | Filter Ass'y | 1 | 1 | 2 | | | |
| 214 | 43409194 | Filter Ass'y | | 1 | | | | |
| 215 | 43407138 | Spacer, Louver, Middle | | | 2 | | | |
| 216 | 4302C063 | Motor, Louver, MP24Z | 2 | 2 | 2 | | | |
| 217 | 43409189 | Louver | 1 | | 3 | | | |
| 218 | 43409190 | Louver | 1 | | 1 | | | |
| 219 | 43409191 | Louver | | 1 | | | | |
| 220 | 43409192 | Louver | | 1 | | | | |
| 221 | 43400069 | Frame, Outlet | 2 | | | | | |
| 222 | 43400071 | Frame, Outlet | | 2 | | | | |
| 223 | 43400073 | Frame, Outlet | | | 2 | | | |
| 224 | 43400060 | Frame, Inlet | 1 | | | | | |
| 225 | 43400061 | Frame, Inlet | 1 | | | | | |
| 226 | 43400062 | Frame, Inlet | | 1 | | | | |
| 227 | 43400063 | Frame, Inlet | | 1 | | | | |
| 228 | 43400064 | Frame, Inlet | | | 1 | | | |
| 229 | 43400065 | Frame, Inlet | | | 1 | | | |
| 230 | 43400066 | Cover, Body | 2 | 2 | 2 | | | |
| 231 | 43401030 | Spacer | 1 | 1 | 1 | | | |
| 232 | 43401031 | Spacer | 1 | 1 | 1 | | | |
| 233 | 43407140 | Cap, Louver | 2 | 2 | 2 | | | |
| 234 | 43401033 | Spacer, Motor | 1 | 1 | 1 | | | |
| 235 | 43401034 | Base Ass'y, P.C. board | 1 | 1 | 1 | | | |
| 236 | 43401035 | Cover, P.C. board | 1 | 1 | 1 | | | |
| 237 | 43100492 | Cover Ass'y, Frame | 2 | 2 | 2 | | | |
| 238 | 43108025 | Fix, Plate | 4 | 4 | 4 | | | |
| 239 | 43108024 | Fix, Panel | 4 | 4 | 4 | | | |


12-3. 1-way Cassette Type (SH)

MMU-UP0151SH-E(TR), UP0181SH-E(TR), UP0241SH-E(TR)




| Location | Part No. | Description | Q'ty/Set MMU-UP | | | | | |
|----------|----------|--|-----------------|---------------|---------------|--|--|--|
| No. | Fait NO. | реэсприон | 0151SH-E (TR) | 0181SH-E (TR) | 0241SH-E (TR) | | | |
| 201 | 43149501 | NUT, FLARE, 12.7 | 1 | 1 | | | | |
| 202 | 43149498 | SOCKET, 9.52 | | | 1 | | | |
| 203 | 43079249 | BAND, HOSE | 1 | 1 | 1 | | | |
| 204 | 43107215 | HOLDER, SENSOR | 1 | 1 | 1 | | | |
| 205 | 43119481 | NUT, PLATE | 2 | 2 | 2 | | | |
| 207 | 43120257 | FAN, MULTI BLADE | 2 | 2 | 2 | | | |
| 208 | 43122084 | CASE, FAN, LOWER | 2 | 2 | 2 | | | |
| 209 | 43122085 | CASE, FAN, UPPER | 2 | 2 | 2 | | | |
| 210 | 4312C183 | MOTOR, FAN, ICF-340WD94-9 | 1 | 1 | 1 | | | |
| 211 | 43135021 | CONNECTOR ASSY, PMV | 1 | 1 | 1 | | | |
| 212 | 43147194 | BONNET, 15.88 | | | 1 | | | |
| 213 | 43147195 | BONNET, 12.7 | 1 | 1 | | | | |
| 214 | 43149497 | SOCKET, 6.35 | 1 | 1 | | | | |
| 215 | 43149495 | NUT, FLARE, 15.88 | | | 1 | | | |
| 216 | 43149494 | SOCKET, 12.7 | 1 | 1 | | | | |
| 217 | 43149496 | SOCKET, 15.88 | | | 1 | | | |
| 218 | 43149500 | NUT, FLARE, 9.52 | | | 1 | | | |
| 219 | 4314J694 | REFRIGERATION CYCLE ASSY | 1 | 1 | | | | |
| 220 | 4314J695 | REFRIGERATION CYCLE ASSY | | | 1 | | | |
| 221 | 4314N202 | BODY, PMV, PAM-B40YGTF-1 | 1 | 1 | 1 | | | |
| 222 | 4314N205 | COIL, PMV, PAM-MD12TF-301 | 1 | 1 | 1 | | | |
| 223 | 43151329 | SWITCH, FLOAT, FS-0218-103 | 1 | 1 | 1 | | | |
| 224 | 43160691 | LEAD, CONN | 1 | 1 | 1 | | | |
| 225 | 43162051 | BUSHING | 1 | 1 | 1 | | | |
| 226 | 43170244 | HOSE, DRAIN | 1 | 1 | 1 | | | |
| 227 | 43170291 | HOSE, DRAIN | 1 | 1 | 1 | | | |
| 228 | 43172195 | PAN ASSY, DRAIN | 1 | 1 | 1 | | | |
| 229 | 43177027 | PUMP, DRAIN | 1 | 1 | 1 | | | |
| 230 | 43179129 | CAP DRAIN | 1 | 1 | 1 | | | |
| 231 | 43179163 | BAND, HOSE | 1 | 1 | 1 | | | |
| 234 | 43F19904 | HOLDER, SENSOR (TS) | 2 | 2 | 2 | | | |
| 235 | 43F47609 | BONNET, 9.52 | | | 1 | | | |
| 236 | 43149499 | NUT, FLARE, 6.35 | 1 | 1 | | | | |
| 237 | 43F49697 | BONNET, 6.35 | 1 | 1 | | | | |
| 238 | 43166041 | REMOTE CONTROLLER, WIRELESS, RBC-AXU31-E | 1 | 1 | 1 | | | |
| 239 | 43166042 | REMOTE CONTROLLER, WIRED, RBC-AMSU51-EN | 1 | 1 | 1 | | | |
| 240 | 43166043 | REMOTE CONTROLLER, WIRED, RBC-AMSU51-ES | 1 | 1 | 1 | | | |





| Location | Part No. | Description | Q'ty/Set |
|----------|----------|-----------------------------|--------------------|
| No. | Part NO. | Description | MMU-UP0**1SH-E(TR) |
| 401 | 43150361 | SENSOR, TC2 | 1 |
| 402 | 43150362 | SENSOR, TCJ | 1 |
| 403 | 43150421 | SENSOR, TA | 1 |
| 404 | 43150414 | SENSOR, TC1 | 1 |
| 405 | 43160694 | TERMINAL, 4P | 1 |
| 406 | 43160626 | TERMINAL BLOCK, 2P | 1 |
| 407 | 4316W056 | P.C. BOARD ASSY, MCC-1643 | 1 |
| 408 | 43459017 | P.C. BOARD ASSY, TCB-PCUC*E | 1 |


♦ Ceiling panel




| Location | Part No. | Description | Q'ty/Set |
|----------|------------|---------------------------------|-------------|
| No. | i ait ito. | Description | RBC-US21PGE |
| 201 | 43109408 | GRILLE, INLET | 2 |
| 202 | 43121719 | DRIVER A'SSY, HORIZONTAL LOUVER | 1 |
| 203 | 43180315 | AIR FILTER | 2 |
| 204 | 43108014 | BASE, RECEIVER | 1 |
| 205 | 43401025 | COVER ASSY | 1 |
| 206 | 43401026 | COVER ASSY | 1 |
| 207 | 43419011 | COVER, MOTOR | 1 |
| 208 | 43419012 | PANEL, AIR OUTLET | 1 |
| 209 | 43419013 | PANEL, OUTLET | 1 |
| 210 | 43409188 | LOUVER | 1 |
| 211 | 43401027 | PANEL ASSY | 1 |
| 212 | 43497012 | SCREW | 4 |
| 213 | 43460112 | LEAD ASSY, LOUVER, MOTOR | 1 |
| 214 | 43107254 | HINGE, GRILLE INLET | 4 |
| 215 | 43107255 | HOOK, GRILLE INLET | 4 |
| 216 | 43408033 | MARK, TOSHIBA | 1 |
| 217 | 43419015 | SUPPORTER, OUTLET | 1 |
| 218 | 43419016 | SUPPORTER, SHAFT | 3 |
| 219 | 43419017 | SUPPORTER, MOTOR | 2 |
| 220 | 43419018 | PANEL, OUTLET | 1 |
| 221 | 43419019 | SCREW, CAP ASSY | 1 |

12-4. Floor Standing Cabinet Type

MML- UP0071H-E(TR), UP0091H-E(TR), UP0121H-E(TR), UP0151H-E(TR), UP0181H-E(TR), UP0241H-E(TR)




| | | | Q'ty/Set MML-UP | | | | | | |
|-----------------|----------|---|-----------------|---------|--------|---------|---------|---------|--|
| Location
No. | Part No. | Description | 0071H | 0091H | 0121H- | 0151H | 0181H | 0241H | |
| - | 4070000 | OAGE FAN LEFT | -E (TR) | -E (TR) | E (TR) | -E (TR) | -E (TR) | -E (TR) | |
| 201 | | CASE, FAN, LEFT | 2 | 2 | 2 | 2 | 2 | 2 | |
| 202 | | CASE, FAN, RIGHT CASE, FAN, RIGHT | 2 | 2 | 2 | 2 | 2 | 2 | |
| 203 | | GRILL,INLET,WHITE | 2 | 2 | 2 | 2 | 2 | 2 | |
| 205 | | CAPACITOR, 400V 1.8MF | | | 1 | 1 | | | |
| 206 | | CAPACITOR, 400V 1.5MF | | | | ı | 1 | 1 | |
| 207 | | CAPACITOR, 450V 1.2MF | 1 | 1 | | | ' | ' | |
| | | MOTOR, FAN, AF-200-45-4FR | <u>'</u> | ' | 1 | 1 | | | |
| | | MOTOR, FAN, AF-200-70-4KR | | | | | 1 | 1 | |
| | | MOTOR, FAN. AF-200-19-4FR | 1 | 1 | | | | | |
| | | COIL, PMV, PAM-MD12TF-301 | 1 | 1 | 1 | 1 | 1 | 1 | |
| 212 | | BODY, PMV, PAM-B25YGTF-1 | 1 | 1 | · | · | | | |
| | | BODY, PMV, PAM-B40YGTF-2 | · · | | 1 | 1 | 1 | 1 | |
| | | FAN, MULTI BLADE | 2 | 2 | 2 | 2 | | | |
| | | FAN, MULTI BLADE | | | | _ | 2 | 2 | |
| | | AIR FILTER | 2 | 2 | 2 | 2 | 2 | 2 | |
| 217 | | FRAME, WHITE | 1 | 1 | 1 | 1 | 1 | 1 | |
| 218 | | COVER, CONTROL PANEL, WHITE | 1 | 1 | 1 | 1 | 1 | 1 | |
| 219 | | PAN, DRAIN | 1 | 1 | 1 | 1 | 1 | 1 | |
| 220 | | PANEL, FRONT | 1 | 1 | 1 | 1 | 1 | 1 | |
| 221 | | EVAPORATOR ASSY | 1 | 1 | 1 | 1 | | | |
| 222 | 4314J420 | EVAPORATOR ASSY | | | | | 1 | 1 | |
| 223 | 4314Q155 | DISTRIBUTOR ASSY | 1 | 1 | | | | | |
| 224 | 4314Q156 | DISTRIBUTOR ASSY | | | 1 | 1 | | | |
| 225 | 4314Q157 | DISTRIBUTOR ASSY | | | | | | 1 | |
| 226 | 4314Q160 | DISTRIBUTOR ASSY | | | | | 1 | | |
| | | NUT, FLARE, 1/4 IN | 1 | 1 | 1 | 1 | 1 | | |
| 228 | 43149355 | NUT, FLARE, 9.52 | 1 | 1 | 1 | | | 1 | |
| 229 | 43049776 | SOCKET, 9.52 | 1 | 1 | 1 | | | 1 | |
| 230 | 43149351 | SOCKET, 6.35 | 1 | 1 | 1 | 1 | 1 | | |
| 231 | 43047688 | NUT, FLARE, 12.7 | | | | 1 | 1 | | |
| 232 | 43149352 | NUT, FLARE, 15.88 | | | | | | 1 | |
| 233 | 43149353 | SOCKET, 12.7 | | | | 1 | 1 | | |
| 234 | 43149354 | SOCKET, 15.88 | | | | | | 1 | |
| 235 | 43100374 | CABINET, UPPER, WHITE | 1 | 1 | 1 | 1 | 1 | 1 | |
| 236 | 43100228 | OUTLET, WHITE | 1 | 1 | 1 | 1 | 1 | 1 | |
| 237 | 43109459 | GRILLE, WHITE | 3 | 3 | 3 | 3 | 3 | 3 | |
| 238 | 43109240 | GRILLE | 1 | 1 | 1 | 1 | 1 | 1 | |
| 239 | 43170201 | HOSE, DRA1N | 1 | 1 | 1 | 1 | 1 | 1 | |
| 240 | 43107215 | HOLDER, SENSOR | 1 | 1 | 1 | 1 | 1 | 1 | |
| 241 | 43F47609 | BONNET,9.52 | 1 | 1 | 1 | | | 1 | |
| 242 | 43147195 | BONNET, 12.7 | | | | 1 | 1 | | |
| 243 | | BONNET, 15.88 | | | | | | 1 | |
| | | BONNET, 6.35 | 1 | 1 | 1 | 1 | 1 | | |
| | | BUSHING, GRILLE | 6 | 6 | 6 | 6 | 6 | 6 | |
| | | BAND, MOTOR, LEFT | 2 | 2 | 2 | 2 | 2 | 2 | |
| | | BAND, MOTOR, RIGHT | 2 | 2 | 2 | 2 | 2 | 2 | |
| 248 | | BASE, MOTOR | 1 | 1 | 1 | 1 | 1 | 1 | |
| 249 | | HOLDER, SENSOR (TS) | 2 | 2 | 2 | 2 | 2 | 2 | |
| 250 | | STRAINER, ID9.52 | 1 | 1 | 1 | 1 | 1 | 1 | |
| | | STRAINER | 1 | 1 | 1 | | | | |
| | | REMOTE CONTROLLER, WIRELESS,RBC-AXU31-E | 1 | 1 | 1 | 1 | 1 | 1 | |
| 254 | | REFRIGERATION CYCLE ASSY | 1 | 1 | | | | | |
| 255 | | REFRIGERATION CYCLE ASSY | | | 1 | | | | |
| 256 | | REFRIGERATION CYCLE ASSY | | | | 1 | | | |
| 257 | | REFRIGERATION CYCLE ASSY | - | | | | 1 | | |
| 258 | | REFRIGERATION CYCLE ASSY | | | | | | 1 | |
| 259 | | CONNECTOR ASSY, PMV | 1 | 1 | 1 | 1 | 1 | 1 | |
| 261 | | REMOTE CONTROLLER, WIRED, RBC-AMSU51-EN | 1 | 1 | 1 | 1 | 1 | 1 | |
| 262 | 43166043 | REMOTE CONTROLLER, WIRED, RBC-AMSU51-ES | 1 | 1 | 1 | 1 | 1 | 1 | |




| Location | Description Description | | Q'ty/Set |
|----------|-------------------------|---------------------------|-------------------|
| No. | Part NO. | Description | MML-UP0**1H-E(TR) |
| 401 | 43150424 | SENSOR, TC2 | 1 |
| 402 | 43150425 | SENSOR, TCJ | 1 |
| 403 | 4115A123 | SENSOR,TA | 1 |
| 404 | 43150414 | SENSOR, TC1 | 1 |
| 405 | 43158204 | TRANSFORMER, TT-13 | 1 |
| 406 | 43160626 | TERMINAL BLOCK, 2P, 20A | 1 |
| 407 | 43160694 | TERMINAL, 4P | 1 |
| 408 | 4316V734 | P.C. BOARD ASSY, MCC-1744 | 1 |
| 409 | 4316V345 | P.C. BOARD ASSY, MCC-1520 | 1 |

12-5. Floor Standing Concealed Type

MML-UP0071BH-E(TR), UP0091BH-E(TR), UP0121BH-E(TR), UP0151BH-E(TR), UP0181BH-E(TR), UP0241BH-E(TR)




| | | | Q'ty/Set MML-UP | | | | | |
|-----------------|----------|--|-------------------|-------------------|-------------------|-------------------|-------------------|-------------------|
| Location
No. | Part No. | Description | 0071BH
-E (TR) | 0091BH
-E (TR) | 0121BH
-E (TR) | 0151BH
-E (TR) | 0181BH
-E (TR) | 0241BH
-E (TR) |
| 201 | 43723020 | CASE, FAN, LEFT | 1 | 1 | 1 | 2 | 2 | 2 |
| 202 | 43126119 | CASE, FAN, RIGHT | 1 | 1 | 1 | 2 | 2 | 2 |
| 203 | 43155179 | CAPACITOR, 1.5MFD,450V | 1 | 1 | 1 | | | |
| 204 | 43155171 | CAPACITOR, 450V 2.0MF | | | | | | 1 |
| 205 | 43155191 | CAPACITOR, 450V 1MF | | | | 1 | 1 | |
| 206 | 4312C008 | MOTOR, FAN, AF-200-70-4KR | | | | 1 | 1 | 1 |
| 207 | 4312C024 | MOTOR, FAN, AF-200-19-4GR | 1 | 1 | 1 | | | |
| 208 | 4314N205 | COIL, PMV, PAM-MD12TF-301 | 1 | 1 | 1 | 1 | 1 | 1 |
| 209 | 4314N210 | BODY, PMV, PAM-B25YGTF-1 | 1 | 1 | 1 | | | |
| 210 | 4314N209 | BODY, PMV, PAM-B40YGTF-2 | | | | 1 | 1 | 1 |
| 211 | 43120232 | FAN, MULTI BLADE | 1 | 1 | 1 | 2 | 2 | 2 |
| $\overline{}$ | 43180294 | | 1 | 1 | 1 | | | |
| 213 | 43180295 | FILTER | | | | 1 | 1 | 1 |
| $\overline{}$ | | CATCH, DRAIN | 1 | 1 | 1 | 1 | 1 | 1 |
| $\overline{}$ | | EVAPORATOR ASSY | 1 | 1 | 1 | | | |
| | | EVAPORATOR ASSY | - | | | 1 | 1 | |
| $\overline{}$ | | EVAPORATOR ASSY | | | | | | 1 |
| - | | DISTRIBUTOR ASSY | 1 | 1 | 1 | | | |
| | | DISTRIBUTOR ASSY | | | | 1 | 1 | |
| | | DISTRIBUTOR ASSY | | | | | | 1 |
| | | NUT, FLARE, 9.52 | 1 | 1 | 1 | 1 | 1 | ' |
| | | NUT, FLARE, 9.52 | 1 | 1 | 1 | ' | ' | 1 |
| $\overline{}$ | | SOCKET, 9.52 | 1 | 1 | 1 | | | 1 |
| | | SOCKET, 9.32 | 1 | 1 | 1 | 1 | 1 | ı |
| | | NUT, FLARE, 12.7 | 1 | 1 | 1 | 1 | 1 | |
| | | NUT, FLARE, 15.88 | | | | 1 | 1 | 1 |
| $\overline{}$ | | SOCKET,12.7 | | | | 1 | 1 | ı |
| | | | | | | 1 | ı | 4 |
| $\overline{}$ | | SOCKET,15.88 | | 0 | 0 | | | 1 |
| | | PLATE-WIND
HOSE ASSY | 1 | 1 | 2 | 4 | 4 | 4 |
| $\overline{}$ | | | | | | 1 | 1 | 1 |
| $\overline{}$ | | HOLDER, SENSOR | 1 | 1 | 1 | 1 | 1 | 1 |
| | | BONNET, 9.52 | 1 | 1 | 1 | 4 | 4 | 1 |
| | | BONNET, 1/2 IN | | | | 1 | 1 | 4 |
| - | | BONNET,15.88 | | 4 | 4 | 4 | | 1 |
| | | BONNET, 6.35 | 1 | 1 | 1 | 1 | 1 | |
| | | BAND, MOTOR, LEFT | 2 | 2 | 2 | 2 | 2 | 2 |
| | | BAND, MOTOR, RIGHT | 2 | 2 | 2 | 2 | 2 | 2 |
| | | BASE, MOTOR | 1 | 1 | 1 | 1 | 1 | 1 |
| | | HOLDER, SENSOR (TS) | 2 | 2 | 2 | 2 | 2 | 2 |
| $\overline{}$ | | STRAINER | 1 | 1 | 1 | 1 | 1 | 1 |
| | 43111311 | | 1 | 1 | 1 | 1 | 1 | 1 |
| | | STRAINER, ID 9.52 | | | | 1 | 1 | 1 |
| | | STRAINER | 1 | 1 | 1 | | | |
| | | STRAINER | 1 | 1 | 1 | | | |
| | | REMOTE CONTROLLER, WIRELESS, RBC-AXU31-E | 1 | 1 | 1 | 1 | 1 | 1 |
| 247 | | REFRIGERATION CYCLE ASSY | 1 | 1 | 1 | | | |
| 248 | | REFRIGERATION CYCLE ASSY | | | | 1 | 1 | |
| 249 | | REFRIGERATION CYCLE ASSY | | | | | | 1 |
| - | | CONNECTOR ASSY, PMV | 1 | 1 | 1 | 1 | 1 | 1 |
| | | REMOTE CONTROLLER, WIRED, RBC-AMSU51-EN | 1 | 1 | 1 | 1 | 1 | 1 |
| 253 | 43166043 | REMOTE CONTROLLER, WIRED, RBC-AMSU51-ES | 1 | 1 | 1 | 1 | 1 | 1 |



| Location | Part No. | Description | Q'ty/Set |
|----------|----------|---------------------------|--------------------|
| No. | Part No. | Description | MML-UP0**1BH-E(TR) |
| 401 | 43150426 | SENSOR, TC2 | 1 |
| 402 | 43150427 | SENSOR, TCJ | 1 |
| 403 | 4115A123 | SENSOR,TA | 1 |
| 404 | 43150415 | SENSOR, TC1 | 1 |
| 405 | 43158204 | TRANSFORMER, TT-13 | 1 |
| 406 | 43160626 | TERMINAL BLOCK, 2P, 20A | 1 |
| 407 | 43160694 | TERMINAL, 4P | 1 |
| 408 | 4316V734 | P.C. BOARD ASSY, MCC-1744 | 1 |
| 409 | 4316V345 | P.C. BOARD ASSY, MCC-1520 | 1 |


12-6. Floor Standing Type

MMF-UP0151H-E(TR), UP0181H-E(TR), UP0241H-E(TR), UP0271H-E(TR)




| | | Q'ty/Set | MMF-UF | |
|---------------------------|---|------------------|------------------|------------------|
| Description | 0151H
-E (TR) | 0181H
-E (TR) | 0241H
-E (TR) | 0271H
-E (TR) |
| | 2 | 2 | 2 | 2 |
| | 1 | 1 | 1 | 1 |
| | 1 | 1 | 1 | 1 |
| D62-1 | 1 | 1 | 1 | 1 |
| TF-301 | 1 | 1 | 1 | 1 |
| GTF-2 | 1 | 1 | 1 | 1 |
| | 1 | 1 | 1 | 1 |
| | 1 | 1 | 1 | 1 |
| | 2 | 2 | 2 | 2 |
| R | 1 | 1 | 1 | 1 |
| TROLER | 1 | 1 | 1 | 1 |
| ITROLER | 1 | 1 | 1 | 1 |
| | 1 | 1 | | |
| | | | 1 | 1 |
| LE ASSY | 1 | 1 | | |
| LE ASSY | | | 1 | 1 |
| | 1 | 1 | | |
| | | | 1 | 1 |
| | | | 1 | 1 |
| | 1 | 1 | | |
| | 1 | 1 | | |
| | | | 1 | 1 |
| | 1 | 1 | | |
| | | | 1 | 1 |
| | 5 | 5 | 5 | 5 |
| | 1 | 1 | 1 | 1 |
| TICAL | 4 | 4 | 4 | 4 |
| | 1 | 1 | 1 | 1 |
| | 1 | 1 | | |
| | | | 1 | 1 |
| | 1 | 1 | 1 | 1 |
| | ' | ' | 1 | 1 |
| | 1 | 1 | ' | |
| | ' | ' | 1 | 1 |
| | 1 | 1 | ' | ' |
| | 1 | 1 | 1 | 1 |
| | 1 | 1 | 1 | 1 |
| L | 5 | 5 | 5 | 5 |
| <u> </u> | 2 | 2 | | 2 |
| • | | | 2 | |
| MV | 1 | 1 | 1 | 1 |
| TD WIDELESS DDC AVIIO4 E | 1 | 1 | 1 | 1 |
| ER, WIRELESS, RBC-AXU31-E | 1 | 1 | 1 | 1 |
| ITER | 1 | 1 | 1 | 1 |
| D MIDED DDG AMOUST ST | 1 | 1 | 1 | 1 |
| | | | | 1 |
| | WIRED, RBC-AMSU51-EN WIRED, RBC-AMSU51-ES | | | |

MMF-UP0361H-E(TR), UP0481H-E(TR), UP0561H-E(TR)




| Location B | | | Q'ty/S | Q'ty/Set MMF-UP | | | |
|------------|----------|--|------------------|------------------|------------------|--|--|
| No. | Part No. | Description | 0361H
-E (TR) | 0481H
-E (TR) | 0561H
-E (TR) | | |
| 201 | 43109392 | GRILLE, INLET | 2 | 2 | 2 | | |
| 202 | 43102650 | CASE ASSY | 1 | 1 | 1 | | |
| 203 | 43F2C076 | MOTOR, LOUVER | 1 | 1 | 1 | | |
| 204 | 4312C134 | MOTOR, FAN, ICF-340WD109-1 | 1 | 1 | 1 | | |
| 205 | 4314N205 | COIL, PMV, PAM-MD12TF-301 | 1 | 1 | 1 | | |
| 206 | 4314N203 | BODY, PMV, PAM-B60YGTF-1 | 1 | 1 | 1 | | |
| 207 | 43120272 | FAN, MULTI BLADE | 2 | 2 | 2 | | |
| 208 | 43180238 | AIR FILTER | 1 | 1 | 1 | | |
| 209 | 43109455 | CLAMP, LOUVER | 2 | 2 | 2 | | |
| 210 | 4310A219 | CABINET ASSY, UPPER | 1 | 1 | 1 | | |
| 211 | 43101357 | PANEL, REMOTE CONTROLER | 1 | 1 | 1 | | |
| 212 | 43101345 | COVER, REMOTE CONTROLER | 1 | 1 | 1 | | |
| 213 | 4314J412 | EVAPORATOR ASSY | 1 | 1 | 1 | | |
| 214 | 4314J624 | REFRIGERATION CYCLE ASSY | 1 | 1 | 1 | | |
| 215 | 43149355 | NUT, FLARE, 9.52 | 1 | 1 | 1 | | |
| 216 | 43049776 | SOCKET,9.52 | 1 | 1 | 1 | | |
| 217 | 43149352 | NUT, FLARE, 15.88 | 1 | 1 | 1 | | |
| 218 | 43149354 | SOCKET, 15.88 | 1 | 1 | 1 | | |
| 219 | 43139093 | CONNECTION ROD | 5 | 5 | 5 | | |
| 220 | 3759V024 | GRILLE ASSY | 1 | 1 | 1 | | |
| 221 | 43109207 | GRILLE, OUTLET, VERTICAL | 4 | 4 | 4 | | |
| 222 | 43100373 | CABINET, LOWER | 1 | 1 | 1 | | |
| 223 | 4314Q165 | DISTRIBUTOR ASSY | 1 | 1 | 1 | | |
| 224 | 43107215 | HOLDER, SENSOR | 1 | 1 | 1 | | |
| 225 | 43F47609 | BONNET, 9.52 | 1 | 1 | 1 | | |
| 226 | 43194029 | BONNET, 15.88 | 1 | 1 | 1 | | |
| 227 | 43139154 | BAND, MOTOR, LEFT | 2 | 2 | 2 | | |
| 228 | 43139155 | BAND, MOTOR, RIGHT | 2 | 2 | 2 | | |
| 229 | 43172090 | PAN, DRAIN | 1 | 1 | 1 | | |
| 230 | 43197136 | WASHER | 1 | 1 | 1 | | |
| 231 | 43122193 | LOUVER, HORIZONTAL | 5 | 5 | 5 | | |
| 232 | 43F19904 | HOLDER, SENSOR (TS) | 2 | 2 | 2 | | |
| 233 | 43160700 | CONNECTOR ASSY, PMV | 1 | 1 | 1 | | |
| 234 | 43147664 | STRAINER, ID 9.52 | 1 | 1 | 1 | | |
| 235 | 43166041 | REMOTE CONTROLLER, WIRELESS, RBC-AXU31-E | 1 | 1 | 1 | | |
| 238 | 43122194 | CLAMP, LOUVER, CENTER | 1 | 1 | 1 | | |
| 239 | 43122195 | JOINT, LOUVER | 1 | 1 | 1 | | |
| 240 | 43166042 | REMOTE CONTROLLER, WIRED, RBC-AMSU51-EN | 1 | 1 | 1 | | |
| 241 | 43166043 | REMOTE CONTROLLER, WIRED, RBC-AMSU51-ES | 1 | 1 | 1 | | |



| Location | Part No. | Description | Q'ty/Set |
|----------|----------|---------------------------|-------------------|
| No. | Part NO. | Description | MMF-UP0**1H-E(TR) |
| 401 | 44258091 | REACTOR, CH-49-Z-T | 1 |
| 402 | 43150412 | SENSOR, TC2 | 1 |
| 403 | 43150362 | SENSOR, TCJ | 1 |
| 404 | 43150414 | SENSOR, TC1 | 1 |
| 405 | 43459017 | PC BOARD ASSY, TCB-PCUC*E | 1 |
| 406 | 43160626 | TERMINAL BLOCK, 2P, 20A | 1 |
| 407 | 4316V728 | PC BOARD ASSY, MCC-1643 | 1 |
| 408 | 43150418 | SENSOR, TA | 1 |
| 409 | 43160694 | TERMINAL, 4P | 1 |

12-7. 4-way cassette type

MMU-UP0091H-E(TR), UP0121H-E(TR)




| Location | Part No. | Description | Q'ty/Set | MMU-UP | |
|----------|----------|--|-------------|-------------|--|
| No. | rait NU. | Description | 0091H-E(TR) | 0121H-E(TR) | |
| 202 | 43149498 | SOCKET, 9.52 | 1 | 1 | |
| 203 | 43079249 | BAND, HOSE | 1 | 1 | |
| 204 | 43089147 | CLAMP, WIRE | 4 | 4 | |
| 205 | 43104246 | PLATE ASSY, PARTITION | 1 | 1 | |
| 206 | 43107215 | HOLDER, SENSOR | 1 | 1 | |
| 207 | 43119497 | COVER ASSY | 1 | 1 | |
| 208 | 43119499 | GUARD, FAN | 1 | 1 | |
| 210 | 43120248 | FAN, ASSY, TURB | 1 | 1 | |
| 211 | 43122110 | BELL MOUTH | 1 | 1 | |
| 212 | 4312C192 | MOTOR, FAN, ICF-340D60-1 | 1 | 1 | |
| 213 | 43135020 | CONNECTOR ASSY, PMV | 1 | 1 | |
| 214 | 43139137 | RUBBER, CUSHION | 3 | 3 | |
| 215 | 43139166 | CAP, NUT | 1 | 1 | |
| 218 | 43147664 | STRAINER, ID 9.52 | 1 | 1 | |
| 219 | 43149497 | SOCKET, 6.35 | 1 | 1 | |
| 223 | 43149500 | NUT, FLARE, 9.52 | 1 | 1 | |
| 225 | 43149426 | FIX, BAND, EVAPORATOR | 2 | 2 | |
| 226 | 43149427 | FIX, BAND, EVAPORATOR | 1 | 1 | |
| 228 | 4314J682 | REFRIGERATION CYCLE ASSY | 1 | 1 | |
| 231 | 4314N205 | COIL, PMV, PAM-MD12TF-301 | 1 | 1 | |
| 233 | 4314N210 | BODY, PMV, PAM-B25YGTF-1 | 1 | 1 | |
| 234 | 4314Q051 | STRAINER, ID 12.7 | 1 | 1 | |
| 235 | 43151299 | SWITCH ASSY, FLOAT, FS-0218-102 | 1 | 1 | |
| 236 | 43170244 | HOSE, DRAIN | 1 | 1 | |
| 237 | 43170254 | SOCKET, ASSY DRAIN | 1 | 1 | |
| 238 | 43170280 | HOSE, DRAIN | 1 | 1 | |
| 240 | 43172252 | PAN ASSY, DRAIN | 1 | 1 | |
| 242 | 43177024 | PUMP, DRAIN, PMD-08D12TF-2 | 1 | 1 | |
| 243 | 43179149 | BAND, HOSE | 1 | 1 | |
| 244 | 43179152 | GLASS, ASSY | 1 | 1 | |
| 245 | 43179163 | BAND, HOSE | 1 | 1 | |
| 246 | 43179164 | LID, ASSY, OUTSIDE | 1 | 1 | |
| 247 | 43179167 | LID, ASSY, INSIDE | 1 | 1 | |
| 249 | 43197199 | WASHER | 1 | 1 | |
| 250 | 43197206 | SCREW, FIX, PANEL | 4 | 4 | |
| 252 | 43F19904 | HOLDER, SENSOR (TS) | 2 | 2 | |
| 253 | 43F47609 | BONNET, 9.52 | 1 | 1 | |
| 254 | 43149499 | NUT, FLARE, 9.52 | 1 | 1 | |
| 255 | 43F49697 | BONNET, 6.35 | 1 | 1 | |
| 256 | 43F97212 | NUT | 1 | 1 | |
| 257 | 43166041 | REMOTE CONTROLLER, WIRELESS, RBC-AXU31-E | 1 | 1 | |
| 258 | 43166042 | REMOTE CONTROLLER, WIRED, RBC-AMSU51-EN | 1 | 1 | |
| 259 | 43166043 | REMOTE CONTROLLER, WIRED, RBC-AMSU51-ES | 1 | 1 | |

MMU-UP0151H-E(TR), UP0181H-E(TR), UP0241H-E(TR), UP0271H-E(TR), UP0301H-E(TR), UP0361H-E(TR), UP0481H-E(TR), UP0561H-E(TR) 213 (251) 232 241 235 (235) (23 207 204 250 (242) (249) 233 (237)

| Location | | | | Q'ty/S | Set MN | /U-UP | |
|----------|----------|--|-----------------|-----------------|-----------------|-----------------|-----------------|
| No. | Part No. | Description | 0151H-E
(TR) | 0181H-E
(TR) | 0241H-E
(TR) | 0271H-E
(TR) | 0301H-E
(TR) |
| 201 | 43149497 | SOCKET, 6.35 | 1 | 1 | | | |
| 202 | 43149498 | SOCKET, 9.52 | | | 1 | 1 | 1 |
| 203 | 43079249 | BAND, HOSE | 1 | 1 | 1 | 1 | 1 |
| 204 | 43089147 | CLAMP, WIRE | 4 | 4 | 4 | 4 | 4 |
| 205 | 43104247 | PLATE ASSY, PARTITION | 1 | 1 | 1 | 1 | 1 |
| 206 | 43107215 | HOLDER, SENSOR | 1 | 1 | 1 | 1 | 1 |
| 207 | 43119500 | COVER ASSY | 1 | 1 | 1 | 1 | 1 |
| 208 | 43119557 | PLATE ASSY, FIX, CONDUIT | 1 | 1 | 1 | 1 | 1 |
| 209 | 43120286 | FAN, ASSY, TURB | 1 | 1 | 1 | 1 | 1 |
| 210 | 43122110 | BELL MOUTH | 1 | 1 | 1 | 1 | 1 |
| 211 | 43122152 | PLATE, WIND | 4 | 4 | 4 | 4 | 4 |
| 212 | 4312C167 | MOTOR, ASSY, FAN, ICF-340D130-2 | 1 | 1 | 1 | 1 | 1 |
| 213 | 43135020 | CONNECTOR ASSY, PMV | 1 | 1 | 1 | 1 | 1 |
| 214 | 43139166 | CAP, NUT | 1 | 1 | 1 | 1 | 1 |
| 215 | 43139186 | RUBBER, CUSHION | 3 | 3 | 3 | 3 | 3 |
| 216 | 43147195 | BONNET, 12.7 | 1 | 1 | | | |
| 217 | 43147194 | BONNET, 15.88 | | | 1 | 1 | 1 |
| 218 | 43147664 | STRAINER, ID 9.52 | 1 | 1 | 1 | 1 | 1 |
| 219 | 43149501 | NUT, FLARE, 12.7 | 1 | 1 | | | |
| 220 | 43149495 | NUT, FLARE, 15.88 | | | 1 | 1 | 1 |
| 221 | 43149494 | SOCKET, 12.7 | 1 | 1 | | | |
| 222 | 43149496 | SOCKET, 15.88 | | | 1 | 1 | 1 |
| 223 | 43149499 | NUT, FLARE, 6.35 | 1 | 1 | | | |
| 224 | 43149500 | NUT, FLARE, 9.52 | | | 1 | 1 | 1 |
| 225 | 43149425 | FIX, BAND, EVAPORATOR | 1 | 1 | 1 | 1 | 1 |
| 226 | 43149503 | FIX, BAND, EVAPORATOR | 2 | 2 | 2 | 2 | 2 |
| 227 | 4314J683 | REFRIGERATION CYCLE ASSY | 1 | 1 | | | |
| 228 | 4314J684 | REFRIGERATION CYCLE ASSY | | | 1 | 1 | 1 |
| 231 | 4314N209 | BODY, PMV, PAM-B40YGTF-2 | 1 | 1 | 1 | 1 | 1 |
| 232 | 4314N205 | COIL, PMV, PAM-MD12TF-301 | 1 | 1 | 1 | 1 | 1 |
| 233 | 43151299 | SWITCH ASSY, FLOAT, FS-0218-102 | 1 | 1 | 1 | 1 | 1 |
| 234 | 43170244 | HOSE, DRAIN | 1 | 1 | 1 | 1 | 1 |
| 235 | 43170254 | SOCKET, ASSY, DRAIN | 1 | 1 | 1 | 1 | 1 |
| 236 | 43170282 | HOSE, DRAIN | 1 | 1 | 1 | 1 | 1 |
| 237 | 43172279 | PAN, ASSY, DRAIN | 1 | 1 | 1 | 1 | 1 |
| 238 | 43177024 | PUMP, DRAIN, PMD-08D12TF-2 | 1 | 1 | 1 | 1 | 1 |
| 239 | 43179149 | BAND, HOSE | 1 | 1 | 1 | 1 | 1 |
| 240 | 43179152 | GLASS, ASSY | 1 | 1 | 1 | 1 | 1 |
| 241 | 43179163 | BAND, HOSE | 1 | 1 | 1 | 1 | 1 |
| 242 | 43179164 | LID, ASSY, OUTSIDE | 1 | 1 | 1 | 1 | 1 |
| 243 | 43179167 | LID, ASSY, INSIDE | 1 | 1 | 1 | 1 | 1 |
| 244 | 43197199 | WASHER | 1 | 1 | 1 | 1 | 1 |
| 245 | 43197206 | SCREW, FIX, PANEL | 4 | 4 | 4 | 4 | 4 |
| 246 | 43F19904 | HOLDER, SENSOR (TS) | 2 | 2 | 2 | 2 | 2 |
| 247 | 43F49697 | BONNET, 6.35 | 1 | 1 | _ | _ | |
| 248 | 43F47609 | BONNET, 9.52 | · | | 1 | 1 | 1 |
| 249 | 43F97212 | NUT | 1 | 1 | 1 | 1 | 1 |
| 250 | 43119499 | GUARD, FAN | 1 | 1 | 1 | 1 | 1 |
| 251 | 43166041 | REMOTE CONTROLLER, WIRELESS, RBC-AXU31-E | 1 | 1 | 1 | 1 | 1 |
| 252 | 43166042 | REMOTE CONTROLLER, WIRED, RBC-AMSU51-EN | 1 | 1 | 1 | 1 | 1 |
| | 43166043 | | | 1 | 1 | 1 | |
| 253 | 40100043 | REMOTE CONTROLLER, WIRED, RBC-AMSU51-ES | 1 | | | ' | 1 |


| Location | -ocation Bort No | Book 1985 | Q'ty/Set MMU-UP | | | |
|----------|------------------|--|-----------------|-----------------|-----------------|--|
| No. | Part No. | Description | 0361H-E
(TR) | 0481H-E
(TR) | 0561H-E
(TR) | |
| 202 | 43149498 | SOCKET, 9.52 | 1 | 1 | 1 | |
| 203 | 43079249 | BAND, HOSE | 1 | 1 | 1 | |
| 204 | 43089147 | CLAMP, WIRE | 4 | 4 | 4 | |
| 205 | 43104247 | PLATE ASSY, PARTITION | 1 | 1 | 1 | |
| 206 | 43107215 | HOLDER, SENSOR | 1 | 1 | 1 | |
| 207 | 43119500 | COVER ASSY | 1 | 1 | 1 | |
| 208 | 43119557 | PLATE ASSY, FIX, CONDUIT | 1 | 1 | 1 | |
| 209 | 43120286 | FAN, ASSY, TURB | 1 | 1 | 1 | |
| 210 | 43122110 | BELL MOUTH | 1 | 1 | 1 | |
| 211 | 43122152 | PLATE, WIND | 4 | 4 | 4 | |
| 212 | 4312C167 | MOTOR, ASSY, FAN, ICF-340D130-2 | 1 | 1 | 1 | |
| 213 | 43135020 | CONNECTOR ASSY, PMV | 1 | 1 | 1 | |
| 214 | 43139166 | CAP, NUT | 1 | 1 | 1 | |
| 215 | 43139186 | RUBBER, CUSHION | 3 | 3 | 3 | |
| 217 | 43147194 | BONNET, 15.99 | 1 | 1 | 1 | |
| 218 | 43147664 | STRAINER, ID 9.52 | 1 | 1 | 1 | |
| 220 | 43149495 | NUT, FLARE, 15.88 | 1 | 1 | 1 | |
| 222 | 43149496 | SOCKET,15.88 | 1 | 1 | 1 | |
| 224 | 43149500 | NUT, FLARE, 9.52 | 1 | 1 | 1 | |
| 225 | 43149425 | FIX, BAND, EVAPORATOR | 1 | 1 | 1 | |
| 226 | 43149503 | FIX, BAND, EVAPORATOR | 2 | 2 | 2 | |
| 229 | 4314J685 | REFRIGERATION CYCLE ASSY | 1 | 1 | 1 | |
| 230 | 4314N203 | BODY, PMV, PAM-B60YGTF-1 | 1 | 1 | 1 | |
| 232 | 4314N205 | COIL, PMV, PAM-MD12TF-301 | 1 | 1 | 1 | |
| 233 | 43151299 | SWITCH ASSY, FLOAT, FS-0218-102 | 1 | 1 | 1 | |
| 234 | 43170244 | HOSE, DRAIN | 1 | 1 | 1 | |
| 235 | 43170254 | SOCKET, ASSY, DRAIN | 1 | 1 | 1 | |
| 236 | 43170282 | HOSE, DRAIN | 1 | 1 | 1 | |
| 237 | 43172279 | PAN ASSY, DRAIN | 1 | 1 | 1 | |
| 238 | 43177024 | PUMP, DRAIN, PMD-08D12TF-2 | 1 | 1 | 1 | |
| 239 | 43179149 | BAND, HOSE | 1 | 1 | 1 | |
| 240 | 43179152 | GLASS, ASSY | 1 | 1 | 1 | |
| 241 | 43179163 | BAND, HOSE | 1 | 1 | 1 | |
| 242 | 43179164 | LID, ASSY, OUTSIDE | 1 | 1 | 1 | |
| 243 | 43179167 | LID, ASSY, INSIDE | 1 | 1 | 1 | |
| 244 | 43197199 | WASHER | 1 | 1 | 1 | |
| 245 | 43197206 | SCREW, FIX, PANEL | 4 | 4 | 4 | |
| 246 | 43F19904 | HOLDER, SENSOR (TS) | 2 | 2 | 2 | |
| 248 | 43F47609 | BONNET, 9.52 | 1 | 1 | 1 | |
| 249 | 43F97212 | NUT | 1 | 1 | 1 | |
| 250 | 43119499 | GUARD, FAN | 1 | 1 | 1 | |
| 251 | 43166041 | REMOTE CONTROLLER, WIRELESS, RBC-AXU31-E | 1 | 1 | 1 | |
| 252 | 43166042 | REMOTE CONTROLLER, WIRED, RBC-AMSU51-EN | 1 | 1 | 1 | |
| 253 | 43166043 | REMOTE CONTROLLER, WIRED, RBC-AMSU51-ES | 1 | 1 | 1 | |



| Location | Part No. | Description | Q'ty/Set |
|----------|----------|---------------------------|-------------------|
| No. | Part No. | Description | MMU-UP0**1H-E(TR) |
| 401 | 43150422 | SENSOR, TC2 | 1 |
| 402 | 43150342 | SENSOR, TCJ | 1 |
| 403 | 43150414 | SENSOR, TC1 | 1 |
| 404 | 43160694 | TERMINAL, 4P | 1 |
| 405 | 43160626 | TERMINAL BLOCK, 2P, 20A | 1 |
| 406 | 4316W056 | PC BOARD ASSY, MCC-1643 | 1 |
| 407 | 43459017 | PC BOARD ASSY, TCB-PCUC*E | 1 |
| 408 | 43150396 | SENSOR, TA | 1 |
| 409 | 43163057 | CLAMP, DOWN | 1 |
| 410 | 43163058 | CLAMP, UP | 1 |

♦ Ceiling panel


RBC-U41PG(W)-E



| Location
No. | Part No. | Description | Q'ty/Set |
|-----------------|----------|-----------------------|----------|
| 350 | 43400085 | PANEL, INSULATOR ASSY | 1 |
| 351 | 43401049 | PANEL, COVER ASSY | 3 |
| 352 | 43401054 | PANEL, COVER ASSY | 1 |
| 353 | 43407167 | FIX,HANGER | 2 |
| 354 | 43407168 | PLATE, FIX PANEL | 2 |
| 355 | 43407169 | PLATE, FIX PANEL | 2 |
| 356 | 43407170 | HOOK | 1 |
| 357 | 43407174 | HOOK | 1 |
| 358 | 43407178 | CAP, AXIS | 4 |
| 359 | 43407179 | COVER, AXIS | 4 |
| 360 | 43407180 | FIX, MOTOR | 2 |
| 361 | 43407181 | FIX, MOTOR | 2 |
| 362 | 43409236 | GRILLE, AIR INLET | 1 |
| 363 | 43409232 | LOUVER ASSY | 4 |
| 364 | 43419022 | STRING | 1 |
| 365 | 4342D001 | MOTOR, LOUVER | 4 |
| 366 | 43460130 | LEAD, MOTOR | 1 |
| 367 | 43480017 | AIR FILTER | 1 |


♦ Wireless remote controller kit

RBC-AXU41U-E(TR)




| Location
No. | Part No. | Description | Q'ty/Set |
|-----------------|----------|-----------------------------|----------|
| 301 | 43108039 | COVER, INSULATOR ASSY | 1 |
| 302 | 43108041 | COVER, WIRELESS | 1 |
| 303 | 43166041 | REMOTE CONTROLLER, WIRELESS | 1 |
| 304 | 43183036 | HOLDER, REMOTE, CONTROLLER | 1 |
| 305 | 43459022 | P.C. BOARD ASSY | 1 |
| 306 | 43460132 | LEAD ASSY | 1 |

RBC-AXU31U-E(TR)




| Location
No. | Part No. | Description | Q'ty/Set |
|-----------------|----------|-----------------------------|----------|
| 301 | 43166041 | REMOTE CONTROLLER, WIRELESS | 1 |
| 302 | 4316W013 | PC BOARD ASSY | 1 |
| 303 | 43183036 | HOLDER, REMOTE, CONTROLLER | 1 |
| 304 | 43108018 | COVER, PANEL WRS | 1 |

RBC-AXU31UM-E(TR)




| Location
No. | Part No. | Description | Q'ty/Set |
|-----------------|----------|----------------------------------|----------|
| 351 | 4316V616 | P.C. BOARD ASSY, REMOTE RECIEVER | 1 |
| 352 | 43162103 | COVER, WRS | 1 |
| 353 | 43108036 | COVER, PANEL WRS | 1 |
| 354 | 43160665 | LEAD | 1 |
| 355 | 43108041 | COVER, WIRELESS | 1 |
| 356 | 43166041 | REMOTE CONTROLLER, WIRELESS | 1 |
| 357 | 43183036 | HOLDER, REMOTE, CONTROLLER | 1 |

RBC-AXU31UW-E(TR)




| Location
No. | Part No. | Description | Q'ty/Set |
|-----------------|----------|-----------------------------|----------|
| 301 | 43166041 | REMOTE CONTROLLER, WIRELESS | 1 |
| 302 | 4316W014 | P.C. BOARD ASSY | 1 |
| 303 | 43183036 | HOLDER, REMOTE, CONTROLLER | 1 |
| 304 | 43108035 | BASE, WIRELESS | 1 |

RBC-AXU31C-E(TR)



| Location
No. | Part No. | Description | Q'ty/Set |
|-----------------|----------|-----------------------------|----------|
| 301 | 43166041 | REMOTE CONTROLLER, WIRELESS | 1 |
| 302 | 4316W014 | P.C. BOARD ASSY | 1 |
| 303 | 43183036 | HOLDER, REMOTE, CONTROLLER | 1 |
| 304 | 43108033 | BASE ASSY | 1 |

RBC-AXU31-E(TR)



| Location
No. | Part No. | Description | Q'ty/Set |
|-----------------|----------|-----------------------------|----------|
| 301 | 43166041 | REMOTE CONTROLLER, WIRELESS | 1 |
| 302 | 43183036 | HOLDER, REMOTE, CONTROLLER | 1 |
| 303 | 4316W015 | RECIEVER, UNIT | 1 |

Toshiba Carrier Corporation

72-34 Horikawa-cho, Saiwai-ku, Kawasaki-shi, Kanagawa 212-8585, JAPAN Copyright © 2022 TOSHIBA CARRIER CORPORATION, ALL Rights Reserved.

Revision record

| Number | The contents of modification | Page | Date |
|-------------|---|--|------------|
| First issue | _ | _ | Dec., 2020 |
| Revision 1 | The 4-way cassette type is added. | 28, 29, 40, 41, 48, 50
205 to 215, 244 to 250 | Mar., 2021 |
| Revision 2 | The service parts list was corrected. | 251 | Apr., 2021 |
| Revision 3 | Contents change of check code E03 relation. | 87, 134, 135 | Jun., 2021 |
| Revision 4 | Deleted the word. | 209 | Nov., 2021 |
| Revision 5 | Added the contents related to R32 refrigerant by adding the connection with SHRM-A. | All pages | Aug., 2022 |