

TOSHIBA

AIR CONDITIONER (MULTI TYPE)

SERVICE MANUAL


< Super Modular Multi System-u SMMS-u >

Outdoor

MMY-MUP0801HT8(J)P
MMY-MUP1001HT8(J)P
MMY-MUP1201HT8(J)P
MMY-MUP1401HT8(J)P
MMY-MUP14A1HT8(J)P
MMY-MUP1601HT8(J)P
MMY-MUP1801HT8(J)P
MMY-MUP2001HT8(J)P
MMY-MUP2201HT8(J)P
MMY-MUP2401HT8(J)P

MMY-MUP0801HT7(J)P
MMY-MUP1001HT7(J)P
MMY-MUP1201HT7(J)P
MMY-MUP1401HT7(J)P
MMY-MUP14A1HT7(J)P
MMY-MUP1601HT7(J)P
MMY-MUP1801HT7(J)P
MMY-MUP2001HT7(J)P
MMY-MUP2201HT7(J)P
MMY-MUP2401HT7(J)P

MMY-MUP0801HT8P-A
MMY-MUP1001HT8P-A
MMY-MUP1201HT8P-A
MMY-MUP1401HT8P-A
MMY-MUP14A1HT8P-A
MMY-MUP1601HT8P-A
MMY-MUP1801HT8P-A
MMY-MUP2001HT8P-A
MMY-MUP2201HT8P-A
MMY-MUP2401HT8P-A



CONTENTS

SAFETY CAUTION	6
REFRIGERANT (R410A)	13
1. WIRING DIAGRAMS	16
2. PARTS RATING	19
2-1. Outdoor Unit (50Hz model: MMY-MUP***1HT8(J)P*)	19
2-2. Outdoor Unit (60Hz model: MMY-MUP***1HT7(J)P*)	20
2-3. Outdoor Unit (50Hz model: MMY-MUP***1HT8P-A)	21
2-4. Winding resistance of outdoor unit main parts	22
2-5. Inverter Assembly	23
2-6. Parts Layout in Outdoor Unit	24
2-7. Parts Layout in Inverter Assembly	25
2-8. Outdoor (Inverter) Print Circuit Board	28
2-8-1. Interface P.C. board (MCC-1747)	28
2-8-2. Noise Filter P.C. board (MCC-1748)	29
2-8-3. Inverter P.C. board for compressor (MCC-1729)	30
2-8-4. Inverter P.C. board for fan (MCC-1734)	31
2-8-5. USB isolate P.C. board (MCC-1754)	32
3. REFRIGERANT PIPING SCHEMATIC DRAWING	33
4. COMBINED REFRIGERANT PIPING SYSTEM SCHEMATIC DIAGRAMS	38
4-1. Refrigerant Flow (Cooling)	38
4-2. Refrigerant Flow (Single Defrost)	39
4-3. Refrigerant Flow (Heating)	40
4-4. Refrigerant Flow (Individual Defrost)	41
4-5-1. (1) Refrigerant Flow (Automatic emergency cooling)	42
4-5-2. (1) Refrigerant Flow (Automatic emergency heating)	44
4-6. Refrigerant Flow (Reclaim)	46
5. CONTROL OUTLINE	47
5-1. Outdoor Unit	47
5-2. Indoor Unit	56
6. APPLIED CONTROL AND FUNCTIONS	67
6-1. Optional Connector Specifications of Indoor P.C.Board.....	67
6-2. Test Operation of Indoor Unit	69
6-3. Method to Set Indoor Unit Function DN Code (I.DN)	70
6-4. Method to Set Outdoor Unit Function Code No. (O.DN)	77
6-5. Applied Control of Indoor Unit	82
6-6. Applied Control of Outdoor Unit	86
6-6-1. Outdoor Fan High Static Pressure Shift	86
6-6-2. Priority Operation Mode Setting	87
6-6-3. Applied Control of Outdoor Unit	90
6-7. Notice Code	101
6-8. System Cooperation Defrosting	103
6-9. Night operation (Sound reduction control)	106
7. TEST OPERATION	108
7-1. Procedure and Summary of Test Operation	108
7-2. Check Items before Test Operation (before powering-on)	109
7-3. Check at Main Power-on	116
7-4. Address Setup	118
7-4-1. Precautions	118
7-4-2. Address Setup and Check Procedure	118
7-4-3. Address Setup Procedure	119
7-4-4. Check after Address Setup when Central Control System Is Connected	145

7-5. Troubleshooting in Test Operation	146
7-5-1. A Check Code is Displayed on the Remote Controller	146
7-5-2. No Remote Controller Response with Check Code	147
7-5-3. No Remote Controller Response without Check Code	147
7-5-4. Connected Indoor/Outdoor Unit Quantity Check	148
7-6. Test Operation Check	150
7-6-1. Fan Check	150
7-6-2. Cooling/Heating Test Operation Check	151
7-7. Service Support Function	155
7-7-1. Check Function for Connecting of Refrigerant and Control Lines	155
7-7-2. Function to Start/Stop (ON/OFF) Indoor Unit from Outdoor Unit	157
7-7-3. Check Code Clearing Function	164
7-7-4. Remote Controller Distinction Function	167
7-7-5. Pulse Motor Valve (PMV) Forced Open/Close Function in Indoor Unit	168
7-7-6. Pulse Motor Valve (PMV) Forced Open/Close Function and Solenoid valve Forced ON Function in Outdoor Unit	169
7-7-7. Fan Operation Check in Outdoor Unit	171
7-7-8. Abnormal Outdoor Unit Discrimination Method By Fan Operating Function ..	172
7-7-9. Manual Adjustment Function of Outside Temperature (TO) Sensor	173
7-7-10. Refrigerant leakage detection	174
7-7-11. Monitor Function of Remote Controller Switch	175
7-8. Wave Tool Advance for SMMS-u Series	177
7-8-1. Before the Use of Wave Tool Advance	177
7-8-2. About Wave Tool Advance	177
7-8-3. Valid/Prohibition/Permission setting for Test operation from WTA App.	177
7-8-4. Confirmation for NFC tag Communication	178
8. TROUBLESHOOTING	179
8-1. Overview	179
8-2. Troubleshooting method	180
8-3. Troubleshooting based on information displayed on remote controller	186
8-4. Check Codes list	190
8-5. Diagnosis procedure for each check code	204
8-6. 7-Segment Display Function	235
8-7. Oil Level Judgment Display	242
8-8. SMMS-u Outdoor Interface P.C. Board Function Setting Change Table	243
8-9. Leakage/Clogging of Refrigerating Cycle Circuit	245
8-10. Sensor Characteristics	251
8-11. Pressure Sensor Output Check	254
9. BACKUP OPERATION (EMERGENCY OPERATION)	256
9-1. Note for Backup Operation	256
9-2. Compressor Backup Operation Setting	257
9-3. Outdoor Unit Backup Operation Setting	259
9-3-1. Follower outdoor unit backup operation setting (failure of follower outdoor unit)	259
9-3-2. Header outdoor unit backup operation setting (failure of header outdoor unit)	262
9-4. Cooling-Season Outdoor Unit Backup Operation Setting	264
9-5. Outdoor Unit Automatic Backup Operation Outline	265
10. OUTDOOR UNIT REFRIGERANT RECOVERY METHOD	266
10-1. Refrigerant Recovery from Troubled Outdoor Unit (Reclaim)	266
10-1-1. Note for refrigerant recovery operation	266
10-1-2. Refrigerant recovery procedure A (Case that the troubled outdoor unit turn on)	266
10-1-3. Refrigerant recovery procedure B (Case that the troubled outdoor unit does not turn on)	268
10-2. How to Operate System While Troubled Outdoor Unit Being Repaired	269
10-3. Work procedure after Repair	270

11. REPLACING COMPRESSORS	271
11-1. Compressor Replacement Procedure (Outline)	271
11-2. Replacement of Compressors	272
11-3. Check Procedure to Search Cause of Compressor Oil Shortage	276
12. OUTDOOR UNIT PARTS REPLACEMENT METHODS	280
13. P.C. BOARD REPLACEMENT PROCEDURES	294
13-1. Replacement of outdoor P.C. board & Inverter Parts	294
13-1-1. List of service parts (Inverter)	294
13-1-2. Configuration of inverter assembly	295
13-1-3. Interface P.C. Board (MCC-1747) Replacement Procedure	298
13-1-4. Compressor P.C. Board (MCC-1729) Replacement Procedure	299
13-1-5. Fan-Motor P.C. Board (MCC-1734) Replacement Procedure	303
13-1-6. Noise Filter P.C. Board 1 (MCC-1748) Replacement Procedure	304
13-1-7. Noise Filter P.C. Board 2 (MCC-1748) Replacement Procedure	305
14. EXPLODED DIAGRAM/PARTS LIST	306
14-1. Outdoor unit (8, 10, 12, 14HP)	306
14-2. Outdoor unit (14A, 16, 18, 20HP)	309
14-3. Outdoor unit (22, 24HP)	312

**This service manual provides relevant explanations about new outdoor unit (SMMS-u).
Please refer to the following service manuals for each indoor units.**

Model name	SVM File No.
<4-Way Cassette Type>	
MMU-UP***1HP-E/-TR (Made in Thailand model)	SVM-20095
MMU-UP***1H-E/-TR (Made in Japan model)	A10-2004
MMU-AP***4HP1-E/-TR (Made in Thailand model)	SVM-16041
<Compact 4-Way Cassette Type>	
MMU-UP***1MH-E/-TR (Made in Japan model)	A10-2004
MMU-AP***7MH-E/-TR (Made in Japan model)	A10-1615-1
<2-Way Cassette Type>	
MMU-UP***1WH-E/-TR (Made in Japan model)	A10-2004
MMU-AP***2WH1/-TR (Made in Japan model)	A10-007
<1-Way Cassette Type>	
MMU-UP***1SH-E/-TR (Made in Japan model)	A10-2004
MMU-UP***1YHP-E/-TR (Made in Thailand model)	SVM-20107
MMU-AP***4YH1-E/-TR (Made in Japan model)	A10-033
MMU-AP***4SH1-E/-TR (Made in Japan model)	A10-033
<Concealed Duct Standard Type>	
MMD-UP***1BHP-E/-TR (Made in Thailand model)	SVM-20095
MMD-AP***6BHP1-E/-TR (Made in Thailand model)	SVM-16043
MMD-AP***6BHP1-E1 (Made in Thailand model)	SVM-19065
<Concealed Duct High Static Pressure Type>	
MMD-UP***1HP-E/-TR (Made in Thailand model)	SVM-20095
MMD-AP***6HP1-E/-TR (Made in Thailand model)	SVM-16044
<Slim Duct Type>	
MMD-UP***1SPHY-E (Made in China model)	A10-2006
MMD-AP***4SPH1-E/-TR (Made in Japan model)	A10-033
MMD-AP***6SPH1-E/-TR (Made in Japan model)	A10-033
<Under Ceiling Type>	
MMC-UP***1HP-E/-TR (Made in Thailand model)	SVM-20095
MMC-AP***8HP-E (Made in Thailand model)	SVM-17015
<Floor Standing Cabinet Type>	
MML-UP***1H-E/-TR (Made in Japan model)	A10-2004
MML-AP***4H1-E/-TR (Made in Japan model)	A10-033
<Floor Standing Concealed Type>	
MML-UP***1BH-E/-TR (Made in Japan model)	A10-2004
MML-AP***4BH1-E/-TR (Made in Japan model)	A10-033
<Floor Standing Type>	
MMF-UP***1H-E/-TR (Made in Japan model)	A10-2004
MMF-AP***6H1-E/-TR (Made in Japan model)	A10-1420
<Large Capacity Floor Standing Type>	
MMF-AP***4DH-V/**4H-V* (Made in Japan model)	KA19-001
MMF-AP***5DHP-V/**5HP-V* (Made in Japan model)	KA18-001
<Fresh Air Intake Indoor Unit>	
MMD-UP***1HFP-E/-TR (Made in Thailand model)	SVM-20095
MMD-AP***1HFE (Made in Japan model)	A06-016
<Air to Air Heat Exchanger with DX Coil Unit>	
MMD-VN***2HEX* (Made in Japan model)	A10-022
<High Wall Type>	
MMK-UP***1HP-E/-TR (Made in Thailand model)	SVM-20095
MMK-UP***1HPL-E (Made in Thailand model)	SVM-20095
MMK-AP***7HP-E (Made in Thailand model)	SVM-17045
MMK-AP***7HP-E1 (Made in Thailand model)	SVM-17046
<Console Type>	
MML-UP***1NHP-E/-TR (Made in Thailand model)	SVM-20095
MML-AP***4NH1-E/-TR (Made in Thailand model)	SVM-16048
<Hot Water Module Mid Temperature Type>	
MMW-UP***1LQ-E/-TR (Made in Japan model)	A10-2005
MMW-AP***1LQ-E/-TR (Made in Japan model)	A10-1412

SAFETY CAUTION

Please read carefully through these instructions that contain important information and ensure that you understand them.

Generic Denomination: Air Conditioner

Definition of Qualified Installer or Qualified Service Person

The air conditioner must be installed, maintained, repaired and removed by a qualified installer or qualified service person. When any of these jobs is to be done, ask a qualified installer or qualified service person to do them.

A qualified installer or qualified service person is an agent who has the qualifications and knowledge described in the table below.

Agent	Qualifications and knowledge which the agent must have
Qualified installer (*1)	<ul style="list-style-type: none">• The qualified installer is a person who installs, maintains, relocates and removes the air conditioners. He or she has been trained to install, maintain, relocate and remove the air conditioners he or she has been instructed in such operations by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to these operations.• The qualified installer who is allowed to do the electrical work involved in installation, relocation and removal has the qualifications pertaining to this electrical work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to electrical work on the air conditioners he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work.• The qualified installer who is allowed to do the refrigerant handling and piping work involved in installation, relocation and removal has the qualifications pertaining to this refrigerant handling and piping work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to refrigerant handling and piping work on the air conditioners he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work.• The qualified installer who is allowed to work at heights has been trained in matters relating to working at heights with the air conditioners he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work.
Qualified service person (*1)	<ul style="list-style-type: none">• The qualified service person is a person who installs, repairs, maintains, relocates and removes the air conditioners. He or she has been trained to install, repair, maintain, relocate and remove the air conditioners he or she has been instructed in such operations by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to these operations.• The qualified service person who is allowed to do the electrical work involved in installation, repair, relocation and removal has the qualifications pertaining to this electrical work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to electrical work on the air conditioners he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work.• The qualified service person who is allowed to do the refrigerant handling and piping work involved in installation, repair, relocation and removal has the qualifications pertaining to this refrigerant handling and piping work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to refrigerant handling and piping work on the air conditioners he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work.• The qualified service person who is allowed to work at heights has been trained in matters relating to working at heights with the air conditioners he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work.

Definition of Protective Gear

When the air conditioner is to be transported, installed, maintained, repaired or removed, wear protective gloves and 'safety' work clothing.

In addition to such normal protective gear, wear the protective gear described below when undertaking the special work detailed in the table below.




Failure to wear the proper protective gear is dangerous because you will be more susceptible to injury, burns, electric shocks and other injuries.

Work undertaken	Protective gear worn
All types of work	Protective gloves 'Safety' working clothing
Electrical-related work	Gloves to provide protection for electricians Insulating shoes Clothing to provide protection from electric shock
Work done at heights (50 cm or more)	Helmets for use in industry
Transportation of heavy objects	Shoes with additional protective toecap
Repair of outdoor unit	Gloves to provide protection for electricians

The important contents concerned to the safety are described on the product itself and on this Service Manual.




Please read this Service Manual after understanding the described items thoroughly in the following contents (Indications / Illustrated marks), and keep them.

[Explanation of indications]

Indication	Explanation
 DANGER	Indicates contents assumed that an imminent danger causing a death or serious injury of the repair engineers and the third parties when an incorrect work has been executed.
 WARNING	Indicates possibilities assumed that a danger causing a death or serious injury of the repair engineers, the third parties, and the users due to troubles of the product after work when an incorrect work has been executed.
 CAUTION	Indicates contents assumed that an injury or property damage (*) may be caused on the repair engineers, the third parties, and the users due to troubles of the product after work when an incorrect work has been executed.

* Property damage: Enlarged damage concerned to property, furniture, and domestic animal / pet





[Explanation of illustrated marks]

Indication	Explanation
	Indicates prohibited items (Forbidden items to do) The sentences near an illustrated mark describe the concrete prohibited contents.
	Indicates mandatory items (Compulsory items to do) The sentences near an illustrated mark describe the concrete mandatory contents.
	Indicates cautions (Including danger / warning) The sentences or illustration near or in an illustrated mark describe the concrete cautious contents.

PRECAUTIONS FOR SAFETY



The manufacturer shall not assume any liability for the damage caused by not observing the description of this manual.

DANGER







 Turn off breaker	Before carrying out the installation, maintenance, repair or removal work, be sure to set the circuit breaker for both the indoor and outdoor units to the OFF position. Otherwise, electric shocks may result.
	Before opening the intake grille of the indoor unit or service panel of the outdoor unit, set the circuit breaker to the OFF position. Failure to set the circuit breaker to the OFF position may result in electric shocks through contact with the interior parts. Only a qualified installer (*1) or qualified service person (*1) is allowed to remove the intake grille of the indoor unit or service panel of the outdoor unit and do the work required.
	Before opening the electric box cover set the circuit breaker to the OFF position. Failure to set the circuit breaker to the OFF position may result in injury through contact with the rotation parts. Only a qualified installer (*1) or qualified service person (*1) is allowed to remove the electric box cover and do the work required.
	Before starting to repair the outdoor unit fan or fan guard, be absolutely sure to set the circuit breaker to the OFF position, and place a "Work in progress" sign on the circuit breaker.
	When cleaning the filter or other parts of the indoor unit, set the circuit breaker to OFF without fail, and place a "Work in progress" sign near the circuit breaker before proceeding with the work.
	When you have noticed that some kind of trouble (such as when a check code display has appeared, there is a smell of burning, abnormal sounds are heard, the air conditioner fails to cool or heat or water is leaking) has occurred in the air conditioner, do not touch the air conditioner yourself but set the circuit breaker to the OFF position, and contact a qualified service person. Take steps to ensure that the power will not be turned on (by marking "out of service" near the circuit breaker, for instance) until qualified service person arrives. Continuing to use the air conditioner in the trouble status may cause mechanical problems to escalate or result in electric shocks or other failure.
 Electric shock hazard	When you access inside of the electric cover to repair electric parts, wait for about five minutes after turning off the breaker. Do not start repairing immediately. Otherwise you may get electric shock by touching terminals of high-voltage capacitors. Natural discharge of the capacitor takes about five minutes.
	When checking the electric parts, removing the cover of the electric parts box of indoor unit and/or service panel of outdoor unit inevitably to determine the failure, use gloves to provide protection for electricians, insulating shoes, clothing to provide protection from electric shock and insulating tools. Be careful not to touch the live part. Electric shock may result. Only "Qualified service person" is allowed to do this work.
 Prohibition	Place a "Work in progress" sign near the circuit breaker while the installation, maintenance, repair or removal work is being carried out. There is a danger of electric shocks if the circuit breaker is set to ON by mistake.
	When checking the electric parts, removing the cover of the electric parts box of Indoor Unit and/or front panel of outdoor unit inevitably to determine the failure, put a sign "Do not enter" around the site before the work. Failure to do this may result in third person getting electric shock.
	Before operating the air conditioner after having completed the work, check that the electrical parts box cover of the indoor unit and service panel of the outdoor unit are closed, and set the circuit breaker to the ON position. You may receive an electric shock if the power is turned on without first conducting these checks.
 Stay on protection	If, in the course of carrying out repairs, it becomes absolutely necessary to check out the electrical parts with the electrical parts box cover of one or more of the indoor units and the service panel of the outdoor unit removed in order to find out exactly where the trouble lies, wear insulated heat-resistant gloves, insulated boots and insulated work overalls, and take care to avoid touching any live parts. You may receive an electric shock if you fail to heed this warning. Only qualified service person (*1) is allowed to do this kind of work.








(*1) Refer to the "Definition of Qualified Installer or Qualified Service Person"

WARNIG



 General	Before starting to repair the air conditioner, read carefully through the Service Manual, and repair the air conditioner by following its instructions.
	Only qualified service person (*1) is allowed to repair the air conditioner. Repair of the air conditioner by unqualified person may give rise to a fire, electric shocks, injury, water leaks and / or other problems.
	Do not use any refrigerant different from the one specified for complement or replacement. Otherwise, abnormally high pressure may be generated in the refrigeration cycle, which may result in a failure or explosion of the product or an injury to your body.
	Only a qualified installer (*1) or qualified service person (*1) is allowed to carry out the electrical work of the air conditioner. Under no circumstances must this work be done by an unqualified individual since failure to carry out the work properly may result in electric shocks and / or electrical leaks.
	When the air conditioner is to be transported, installed, maintained, repaired or removed, wear protective gloves and 'safety' work clothing.
	To connect the electrical wires, repair the electrical parts or undertake other electrical jobs, wear gloves to provide protection for electricians, insulating shoes and clothing to provide protection from electric shocks. Failure to wear this protective gear may result in electric shocks.
	Electrical wiring work shall be conducted according to law and regulation in the community and Installation Manual. Failure to do so may result in electrocution or short circuit.
	Use wiring that meets the specifications in the Installation Manual and the stipulations in the local regulations and laws. Use of wiring which does not meet the specifications may give rise to electric shocks, electrical leakage, smoking and/or a fire.
	Only a qualified installer (*1) or qualified service person (*1) is allowed to undertake work at heights using a stand of 50 cm or more or to remove the intake grille of the indoor unit to undertake work.
	When working at heights, use a ladder which complies with the ISO 14122 standard, and follow the procedure in the ladder's instructions. Also wear a helmet for use in industry as protective gear to undertake the work.
	Before working at heights, put a sign in place so that no-one will approach the work location, before proceeding with the work. Parts and other objects may fall from above, possibly injuring a person below. While carrying out the work, wear a helmet for protection from falling objects.
	When executing address setting, test run, or troubleshooting through the checking window on the electric parts box, put on insulated gloves to provide protection from electric shock. Otherwise you may receive an electric shock.
	Do not touch the aluminum fin of the unit. You may injure yourself if you do so. If the fin must be touched for some reason, first put on protective gloves and safety work clothing, and then proceed.
	Do not climb onto or place objects on top of the outdoor unit. You may fall or the objects may fall off the outdoor unit and result in injury.
	Use forklift truck to carry in the air conditioner units and use winch or hoist at installation of them.
 Check earth wires.	When transporting the air conditioner, wear shoes with protective toecap.
	When transporting the air conditioner, do not take hold of the bands around the packing carton. You may injure yourself if the bands break.
	Be sure that a heavy unit (10 kg or heavier) such as a compressor is carried by four persons.
	Before troubleshooting or repair work, check the earth wire is connected to the earth terminals of the main unit, otherwise an electric shock is caused when a leak occurs. If the earth wire is not correctly connected, contact an electric engineer for rework.
	After completing the repair or relocation work, check that the earth wires are connected properly.
	Connect earth wire. (Grounding work) Incomplete earthing causes an electric shock. Do not connect earth wires to gas pipes, water pipes, and lightning rods or earth wires for telephone wires.

(*1) Refer to the "Definition of Qualified Installer or Qualified Service Person"

 Prohibition of modification.	Do not modify the products. Do not also disassemble or modify the parts. It may cause a fire, electric shock or injury.
 Use specified parts.	When any of the electrical parts are to be replaced, ensure that the replacement parts satisfy the specifications given in the Service Manual (or use the parts contained on the parts list in the Service Manual). Use of any parts which do not satisfy the required specifications may give rise to electric shocks, smoking and / or a fire.
 Do not bring a child close to the equipment.	If, in the course of carrying out repairs, it becomes absolutely necessary to check out the electrical parts with the electrical parts box cover of one or more of the indoor units and the service panel of the outdoor unit removed in order to find out exactly where the trouble lies, put a sign in place so that no-one will approach the work location before proceeding with the work. Third-party individuals may enter the work site and receive electric shocks if this warning is not heeded.
 Insulating measures	Connect the cut-off lead wires with crimp contact, etc., put the closed end side upward and then apply a water cut method, otherwise a leak or production of fire is caused at the users' side.
 No fire	When performing repairs using a gas burner, replace the refrigerant with nitrogen gas because the oil that coats the pipes may otherwise burn. When repairing the refrigerating cycle, take the following measures. 1) Be attentive to fire around the cycle. When using a gas stove, etc., be sure to put out fire before work; otherwise the oil mixed with refrigerant gas may catch fire. 2) Do not use a brazing in the closed room. When using it without ventilation, carbon monoxide poisoning may be caused. 3) Do not bring inflammables close to the refrigerant cycle, otherwise fire of the brazing may catch the inflammables.
 Refrigerant	The refrigerant used by this air conditioner is the R410A.
	Check the used refrigerant name and use tools and materials of the parts which match with it. For the products which use R410A refrigerant, the refrigerant name is indicated at a position on the outdoor unit where is easy to see. To prevent miss charging, the route of the service port is changed from one of the former R22.
	Do not use any refrigerant different from the one specified for complement or replacement. Otherwise, abnormally high pressure may be generated in the refrigeration cycle, which may result in a failure or explosion of the product or an injury to your body.
	For an air conditioner which uses R410A, never use other refrigerant than R410A. For an air conditioner which uses other refrigerant (R22, etc.), never use R410A. If different types of refrigerant are mixed, abnormal high pressure generates in the refrigerating cycle and an injury due to breakage may be caused.
	When the air conditioner has been installed or relocated, follow the instructions in the Installation Manual and purge the air completely so that no gases other than the refrigerant will be mixed in the refrigerating cycle. Failure to purge the air completely may cause the air conditioner to malfunction.
	Do not charge refrigerant additionally. If charging refrigerant additionally when refrigerant gas leaks, the refrigerant composition in the refrigerating cycle changes resulted in change of air conditioner characteristics or refrigerant over the specified standard amount is charged and an abnormal high pressure is applied to the inside of the refrigerating cycle resulted in cause of breakage or injury. Therefore if the refrigerant gas leaks, recover the refrigerant in the air conditioner, execute vacuuming, and then newly recharge the specified amount of liquid refrigerant. In this time, never charge the refrigerant over the specified amount.
	When recharging the refrigerant in the refrigerating cycle, do not mix the refrigerant or air other than R410A into the specified refrigerant. If air or others is mixed with the refrigerant, abnormal high pressure generates in the refrigerating cycle resulted in cause of injury due to breakage.
	After installation work, check the refrigerant gas does not leak. If the refrigerant gas leaks in the room, poisonous gas generates when gas touches to fire such as fan heater, stove or cooking stove though the refrigerant gas itself is innocuous.
	Never recover the refrigerant into the outdoor unit. When the equipment is moved or repaired, be sure to recover the refrigerant with recovering device. The refrigerant cannot be recovered in the outdoor unit; otherwise a serious accident such as breakage or injury is caused.

 Assembly / Wiring	<p>After repair work, surely assemble the disassembled parts, and connect and lead the removed wires as before. Perform the work so that the cabinet or panel does not catch the inner wires.</p> <p>If incorrect assembly or incorrect wire connection was done, a disaster such as a leak or fire is caused at user's side.</p>
 Insulator check	<p>After the work has finished, be sure to use an insulation tester set (500VMΩ) to check the resistance is 1 MΩ or more between the charge section and the non-charge metal section (Earth position).</p> <p>If the resistance value is low, a disaster such as a leak or electric shock is caused at user's side.</p>
 Ventilation	<p>When the refrigerant gas leaks during work, execute ventilation.</p> <p>If the refrigerant gas touches to a fire, poisonous gas generates. A case of leakage of the refrigerant and the closed room full with gas is dangerous because a shortage of oxygen occurs. Be sure to execute ventilation.</p>
	<p>If refrigerant gas has leaked during the installation work, ventilate the room immediately.</p> <p>If the leaked refrigerant gas comes in contact with fire, noxious gas may generate.</p>
	<p>After installation work, check the refrigerant gas does not leak. If the refrigerant gas leaks in the room, poisonous gas generates when gas touches to fire such as fan heater, stove or cooking stove though the refrigerant gas itself is innocuous.</p>
 Compulsion	<p>When the refrigerant gas leaks, find out the leaked position and repair it surely.</p> <p>If the leaked position cannot be found out and the repair work is interrupted, reclaim and tighten the service valve, otherwise the refrigerant gas may leak into the room.</p> <p>The poisonous gas generates when gas touches to fire such as fan heater, stove or cooking stove though the refrigerant gas itself is innocuous.</p> <p>When installing equipment which includes a large amount of charged refrigerant in a sub-room, it is necessary that the concentration does not the limit even if the refrigerant leaks.</p> <p>If the refrigerant leaks and exceeds the limit concentration, an accident of shortage of oxygen is caused.</p>
	<p>Tighten the flare nut with a torque wrench in the specified manner.</p> <p>Excessive tighten of the flare nut may cause a crack in the flare nut after a long period, which may result in refrigerant leakage.</p>
	<p>Nitrogen gas must be used for the airtight test.</p>
	<p>The charge hose must be connected in such a way that it is not slack.</p>
	<p>For the installation / moving / reinstallation work, follow to the Installation Manual.</p> <p>If an incorrect installation is done, a trouble of the refrigerating cycle, water leak, electric shock or fire is caused.</p>
 Check after repair	<p>Once the repair work has been completed, check for refrigerant leaks, and check the insulation resistance and water drainage.</p> <p>Then perform a trial run to check that the air conditioner is running properly.</p>
	<p>After repair work has finished, check there is no trouble. If check is not executed, a fire, electric shock or injury may be caused. For a check, turn off the power breaker.</p>
	<p>After repair work (installation of front panel and cabinet) has finished, execute a test run to check there is no generation of smoke or abnormal sound.</p> <p>If check is not executed, a fire or an electric shock is caused. Before test run, install the front panel and cabinet.</p>
	<p>Be sure to fix the screws back which have been removed for installation or other purposes.</p>
 Do not operate the unit with the valve closed.	<p>Check the following matters before a test run after repairing piping.</p> <ul style="list-style-type: none"> • Connect the pipes surely and there is no leak of refrigerant. • The valve is opened. <p>Running the compressor under condition that the valve closes causes an abnormal high pressure resulted in damage of the parts of the compressor and etc. and moreover if there is leak of refrigerant at connecting section of pipes, the air is sucked and causes further abnormal high pressure resulted in burst or injury.</p>
 Check after reinstallation	<p>Only a qualified installer (*1) or qualified service person (*1) is allowed to relocate the air conditioner. It is dangerous for the air conditioner to be relocated by an unqualified individual since a fire, electric shocks, injury, water leakage, noise and / or vibration may result.</p>
	<p>Check the following items after reinstallation.</p> <ol style="list-style-type: none"> 1) The earth wire is correctly connected. 2) The power cord is not caught in the product. 3) There is no inclination or unsteadiness and the installation is stable. <p>If check is not executed, a fire, an electric shock or an injury is caused.</p>
	<p>When carrying out the reclaim work shut down the compressor before disconnecting the refrigerant pipe.</p> <p>Disconnecting the refrigerant pipe with the service valve left open and the compressor still operating will cause air, etc. to be sucked in, raising the pressure inside the refrigeration cycle to an abnormally high level, and possibly resulting in rupture, injury, etc.</p>

(*1) Refer to the "Definition of Qualified Installer or Qualified Service Person"

 Cooling check	<p>When the service panel of the outdoor unit is to be opened in order for the compressor or the area around this part to be repaired immediately after the air conditioner has been shut down, set the circuit breaker to the OFF position, and then wait at least 10 minutes before opening the service panel. If you fail to heed this warning, you will run the risk of burning yourself because the compressor pipes and other parts will be very hot to the touch. In addition, before proceeding with the repair work, wear the kind of insulated heat-resistant gloves designed to protect electricians.</p>
	<p>Take care not to get burned by compressor pipes or other parts when checking the cooling cycle while running the unit as they get heated while running. Be sure to put on gloves providing protection for heat.</p>
 Installation	<p>When the service panel of the outdoor unit is to be opened in order for the fan motor, inverter or the areas around these parts to be repaired immediately after the air conditioner has been shut down, set the circuit breaker to the OFF position, and then wait at least 10 minutes before opening the service panel. If you fail to heed this warning, you will run the risk of burning yourself because the fan motor, reactor, inverter heat sink and other parts will be very hot to the touch. In addition, before proceeding with the repair work, wear the kind of insulated heat-resistant gloves designed to protect electricians.</p>
	<p>Only a qualified installer or service person is allowed to do installation work. Inappropriate installation may result in water leakage, electric shock or fire.</p>
	<p>Before starting to install the air conditioner, read carefully through the Installation Manual, and follow its instructions to install the air conditioner.</p>
	<p>Be sure to use the company-specified products for the separately purchased parts. Use of non-specified products may result in fire, electric shock, water leakage or other failure. Have the installation performed by a qualified installer.</p>
	<p>Do not supply power from the power terminal block equipped on the outdoor unit to another outdoor unit. Capacity overflow may occur on the terminal block and may result in fire.</p>
	<p>Do not install the air conditioner in a location that may be subject to a risk of exposure to a combustible gas. If a combustible gas leaks and becomes concentrated around the unit, a fire may occur.</p>
	<p>Install the indoor unit at least 2.5 m above the floor level since otherwise the users may injure themselves or receive electric shocks if they poke their fingers or other objects into the indoor unit while the air conditioner is running.</p>
	<p>Install a circuit breaker that meets the specifications in the Installation Manual and the stipulations in the local regulations and laws.</p>
	<p>Install the circuit breaker where it can be easily accessed by the agent.</p>
	<p>If you install the unit in a small room, take appropriate measures to prevent the refrigerant from exceeding the limit concentration even if it leaks. Consult the dealer from whom you purchased the air conditioner when you implement the measures. Accumulation of highly concentrated refrigerant may cause an oxygen deficiency accident.</p>
	<p>Do not place any combustion appliance in a place where it is directly exposed to the wind of air conditioner, otherwise it may cause imperfect combustion.</p>

Explanations given to user

If you have discovered that the fan grille is damaged, do not approach the outdoor unit but set the circuit breaker to the OFF position, and contact a qualified service person to have the repairs done. Do not set the circuit breaker to the ON position until the repairs are completed.

Relocation

- Only a qualified installer (*1) or qualified service person (*1) is allowed to relocate the air conditioner. It is dangerous for the air conditioner to be relocated by an unqualified individual since a fire, electric shocks, injury, water leakage, noise and / or vibration may result.
- When carrying out the reclaim work shut down the compressor before disconnecting the refrigerant pipe. Disconnecting the refrigerant pipe with the service valve left open and the compressor still operating will cause air, etc. to be sucked in, raising the pressure inside the refrigeration cycle to an abnormally high level, and possibly resulting in rupture, injury, etc.

(*1) Refer to the "Definition of Qualified Installer or Qualified Service Person"

Refrigerant (R410A)

This air conditioner adopts a HFC type refrigerant (R410A) which does not deplete the ozone layer.

1. Safety Caution Concerned to refrigerant (R410A)

The pressure of R410A is 1.6 times higher than that of the former refrigerant (R22). Accompanied with change of refrigerant, the refrigerating oil has been also changed. Therefore, be sure that water, dust, the former refrigerant or the former refrigerating oil is not mixed into the refrigerating cycle of the air conditioner with new refrigerant during installation work or service work. If an incorrect work or incorrect service is performed, there is a possibility to cause a serious accident. Use the tools and materials exclusive to R410A to purpose a safe work.

2. Cautions on Installation/Service

- (1) Do not mix the other refrigerant or refrigerating oil.
For the tools exclusive to R410A, shapes of all the joints including the service port differ from those of the former refrigerant in order to prevent mixture of them.
- (2) As the use pressure of the refrigerant (R410A) is high, use material thickness of the pipe and tools which are specified for R410A.
- (3) In the installation time, use clean pipe materials and work with great attention so that water and others do not mix in because pipes are affected by impurities such as water, oxide scales, oil, etc. Use the clean pipes.
Be sure to braze with flowing nitrogen gas. (Never use gas other than nitrogen gas.)
- (4) For the earth protection, use a vacuum pump for air purge.
- (5) R410A refrigerant is a zeotropic mixture type refrigerant. Therefore use liquid type to charge the refrigerant.

3. Pipe Materials

For the refrigerant pipes, copper pipe and joints are mainly used. It is necessary to select the most appropriate pipes to conform to the standard. Use clean material in which impurities adhere inside of pipe or joint to a minimum.

- (1) Copper pipe

<Piping>

The pipe thickness, flare-finishing size, flare nut and others differ according to a refrigerant type. When using a long copper pipe for R410A, it is recommended to select "Copper or copper-base pipe without seam" and one with bonded oil amount 40mg/10m or less. Also do not use crushed, deformed, discolored (especially inside) pipes. (Impurities cause clogging of expansion valves and capillary tubes.)

<Flare nut>

Use the flare nuts which are attached to the air conditioner unit.

- (2) Joint

The flare joint and socket joint are used for joints of the copper pipe. The joints are rarely used for installation of the air conditioner. However clear impurities when using them.

Tools

(1) Required Tools for R410A

Mixing of different types of oil may cause a trouble such as generation of sludge, clogging of capillary, etc. Accordingly, the tools to be used are classified into the following three types.

- 1) Tools exclusive for R410A (Those which cannot be used for conventional refrigerant (R22))
- 2) Tools exclusive for R410A, but can be also used for conventional refrigerant (R22)
- 3) Tools commonly used for R410A and for conventional refrigerant (R22)

The table below shows the tools exclusive for R410A and their interchangeability.

Tools exclusive for R410A (The following tools for R410A are required.)

Explanation of symbols

△ : Newly prepared (It is necessary to use it exclusively with R410A, separately from those for R22

⊙ or R407C.) : Former tool is available.

Used tools	Usage	Proper use of tools/parts
Gauge manifold	Vacuuming, charging refrigerant and operation check	△ Exclusive to R410A
Charging hose		△ Exclusive to R410A
Charging cylinder	Charging refrigerant	Unusable (Use the Refrigerant charging balance.)
Gas leak detector	Checking gas leak	△ Exclusive to R410A
Vacuum pump	Vacuum drying	Usable if a counter-flow preventive adapter is attached
Vacuum pump with counter flow	Vacuum drying	⊙ R22 (Existing article)
Flare tool	Flare processing of pipes	⊙ Usable by adjusting size
Bender	Bending processing of pipes	⊙ R22 (Existing article)
Refrigerant recovery device	Recovering refrigerant	△ Exclusive to R410A
Torque wrench	Tightening flare nut	△ Exclusive to Ø12.7mm and Ø15.9mm
Pipe cutter	Cutting pipes	⊙ R22 (Existing article)
Refrigerant canister	Charging refrigerant	△ Exclusive to R410A Enter the refrigerate name for identification
Brazing machine/ Nitrogen gas cylinder	Brazing of pipes	⊙ R22 (Existing article)
Refrigerant charging balance	Charging refrigerant	⊙ R22 (Existing article)

(Note 1) When flaring is carried out for R410A using the conventional flare tools, adjustment of projection margin is necessary. For this adjustment, a copper pipe gauge, etc. are necessary.

(Note 2) Charging cylinder for R410A is being currently developed.

General tools (Conventional tools can be used.)

In addition to the above exclusive tools, the following equipment which serve also for R22 are necessary as the general tools.

- | | |
|---|---|
| (1) Vacuum pump | (7) Screwdriver (+, -) |
| Use vacuum pump by attaching vacuum pump adapter. | (8) Spanner or Adjustable wrench |
| (2) Torque wrench | (9) Hole core drill |
| (3) Pipe cutter | (10) Hexagon wrench (Opposite side 4mm) |
| (4) Reamer | (11) Tape measure |
| (5) Pipe bender | (12) Metal saw |
| (6) Level vial | |

Also prepare the following equipment for other installation method and run check.

- | | |
|-----------------|----------------------------------|
| (1) Clamp meter | (3) Insulation resistance tester |
| (2) Thermometer | (4) Electroscopic |

Communication type, model names and the maximum number of connectable units

- ◆ This air conditioning (U series) has new communication specifications, and TU2C-Link (U series) and TCC-Link (other than U series) differ in a communication type. For the communication type and the model names such as each unit or remote controllers, refer to the following table.


Communication type	TU2C-Link (U series and future models)	TCC-Link (Other than U series)
Outdoor unit	MMY-MUP*** ↑ This letter indicates U series model.	Other than U series MMY-MAP*** MCY-MHP***
Indoor unit	MM*-UP*** ↑ This letter indicates U series model.	Other than U series MM*-AP***
Wired remote controller	RBC-A**U*** ↑ This letter indicates U series model.	Other than U series
Wireless remote controller kit & receiver unit	RBC-AXU*** ↑ This letter indicates U series model.	Other than U series
Remote sensor	TCB-TC**U*** ↑ This letter indicates U series model.	Other than U series

U series outdoor unit : SMMS-u (MMY-MUP***)

Other than U series outdoor unit : SMMS-i, SMMS-e etc. (MMY-MAP***)

- ◆ If TU2C-Link (U series) is combined with TCC-Link (other than U series), the wiring specifications and the maximum number of connectable indoor units during group control operation will be changed.

- (1) For wiring specifications, carry out the installation, maintenance, or repair according to the attached Installation Manual.
- (2) For a communication type combination and the max. number of connectable indoor units, refer to the following table.
 - Only when all outdoor unit, indoor unit and remote control are a U series, communication method is TU2C-LINK, and the maximum number of connectable units will be 16.



The combination of unit type and the number of the maximum connection of a communication method


	Unit type							
	U series	U series	U series	U series	*	*	*	*
Outdoor unit	U series	U series	U series	U series	*	*	*	*
Indoor unit	U series	U series	*	*	U series	U series	*	*
Remote controller	U series	*	U series	*	U series	*	U series	*
Remote sensor	U series	*	U series	*	U series	*	U series	*
Communication type	TU2C-Link	TCC-Link						
Maximum number of connectable units	16	8						

* Other than U series


8, 10, 12, 14HP Model: MMY-MUP0801*, MUP1001*, MUP1201*, MUP1401*









14A, 16, 18, 20HP Model: MMY-MUP14A1*, MUP1601*, MUP1801*, MUP2001*



*1 The installation of the optional board is up to four pieces.




	Field wiring
	Protective earth
	Terminal block
	Terminal
	Connector
	P.C. Board

Color indication -
RED:RED
WHI:WHITE
YEL:YELLOW
BLU:BLUE
BLK:BLACK
GRY:GRAY
ORN:ORANGE
GRN:GREEN

P.C.Board	
Symbol	Parts name
MCC-1729	Inverter P.C.Board (Compressor)
MCC-1734	Inverter P.C.Board (Fan)
MCC-1747	Interface Control P.C.Board
MCC-1748	Noise filter P.C.Board
MCC-1754	USB isolate P.C.Board

Symbol	Parts name
4WV1	4-way valve coil
63H1	High pressure switch
CM	Compressor
CN***	Connector
CN01.CN02	Terminal block(control wiring)
(MCC-1734) F01	Fuse (Fan) 6.3A 750VDC
(MCC-1729) F01.F02	Fuse (Compressor) 63A 600VAC
(MCC-1747) F01.F02	Fuse (Interface) T6.3A 250VAC
(MCC-1748) F01.F02.F03	Fuse (Noise filter) T6.3A 250VAC
FM1.FM2	Fan motor
HEATER1	Compressor case heater
L-CM	Reactor for compressor
Mg-CTT	Magnet contactor
NFC	NFC tag
PD	Pressure sensor (High)
PMV1	Pulse motor valve (Main)
PMV2	Pulse motor valve (Sub/L)
PMV3	Pulse motor valve (Sub/R)
PMV4	Pulse motor valve (Sub cool)
PS	Pressure sensor (Low)
RB	Rush current protect resistor
SV3D.SV3F.SV41	2-way valve coil
SW01.SW02.SW03	Rotary switch
SW04.SW05.SW06	Push button switch
SW100.SW101.SW102.SW103 SW104.SW105.SW106	Dip switch
TB1	Terminal block(Power supply)
TD1	Discharge temp. sensor
TE1.TE2.TE3	Heat exchanger temp. sensor
TG1.TG2.TG3	Gas temp. sensor
TK1	Oil temp. sensor
TL1.TL2.TL3	Liquid temp. sensor
TO	Air temp. sensor
TS1.TS3	Suction temp. sensor

22, 24HP Model: MMY-MUP2201*, MUP2401*



2. PARTS RATING

2-1. Outdoor Unit (50Hz model: MMY-MUP***1HT8(J)P)

No	Name	Model	Specification	MMY-MUP0801HT8(J)P	MMY-MUP1001HT8(J)P	MMY-MUP1201HT8(J)P	MMY-MUP1401HT8(J)P	MMY-MUP14A1HT8(J)P	MMY-MUP1601HT8(J)P	MMY-MUP1801HT8(J)P	MMY-MUP2001HT8(J)P	MMY-MUP2201HT8(J)P	MMY-MUP2401HT8(J)P
1	Compressor	LA771A3TB-20M	Output:4.0kW × 1	○									
1	Compressor	LA771A3TB-20M	Output:5.8kW × 1		○								
1	Compressor	LA771A3TB-20M	Output:7.3kW × 1			○							
1	Compressor	LA771A3TB-20M	Output:10.0kW × 1				○						
1	Compressor	LA1201K4FB-10UC	Output:8.0kW × 1					○					
1	Compressor	LA1201K4FB-10UC	Output:9.7kW × 1						○				
1	Compressor	LA1201K4FB-10UC	Output:11.5kW × 1							○			
1	Compressor	LA1201K4FB-10UC	Output:13.0kW × 1								○		
1	Compressor	LA771A3TB-20M	Output:7.9kW × 2									○	
1	Compressor	LA771A3TB-20M	Output:9.5kW × 2										○
2	4-way valve coil	SHF	AC220-240V 50Hz	○	○	○	○	○	○	○	○	○	○
3	2-way valve coil	FDF	AC220-240V 50Hz SV3D, SV41, SV42	○	○	○	○	○	○	○	○	○	○
3	2-way valve coil	TEV	AC220-240V 50Hz SV3F	○	○	○	○	○	○	○	○	○	○
4	Pulse motor valve coil	PAM	PMV1	○	○	○	○	○	○	○	○	○	○
4	Pulse motor valve coil	HAM	PMV2, 3	○	○	○	○	○	○	○	○	○	○
4	Pulse motor valve coil	UKV	PMV4	○	○	○	○	○	○	○	○	○	○
5	High-pressure SW	ACB-4UB237W	OFF:4.15MPa ON:3.2MPa	○	○	○	○	○	○	○	○	○	○
6	Pressure sensor(For high pressure)	NSK-BH038F-823	0.5~4.5V/0~3.92MPa	○	○	○	○	○	○	○	○	○	○
7	Pressure sensor(For low pressure)	NSK-BH020F-822	0.5~3.5V/0~2.0MPa	○	○	○	○	○	○	○	○	○	○
8	Fan motor	ICF-620A1000-1	DC530 - 620	○	○	○	○	○	○	○	○	○	○
9	Case heater(For comp.)	—	AC240V/29W	○	○	○	○	○	○	○	○	○	○

2-2. Outdoor Unit (60Hz model: MMY-MUP***1HT7(J)P)

No	Name	Model	Specification	MMY-MUP0801HT7(J)P	MMY-MUP1001HT7(J)P	MMY-MUP1201HT7(J)P	MMY-MUP1401HT7(J)P	MMY-MUP14A1HT7(J)P	MMY-MUP1601HT7(J)P	MMY-MUP1801HT7(J)P	MMY-MUP2001HT7(J)P	MMY-MUP2201HT7(J)P	MMY-MUP2401HT7(J)P
1	Compressor	LA771A3TB-20M	Output:4.0kW × 1	○									
1	Compressor	LA771A3TB-20M	Output:5.8kW × 1		○								
1	Compressor	LA771A3TB-20M	Output:7.3kW × 1			○							
1	Compressor	LA771A3TB-20M	Output:10.0kW × 1				○						
1	Compressor	LA1201K4FB-10UC	Output:8.0kW × 1					○					
1	Compressor	LA1201K4FB-10UC	Output:9.7kW × 1						○				
1	Compressor	LA1201K4FB-10UC	Output:11.5kW × 1							○			
1	Compressor	LA1201K4FB-10UC	Output:13.0kW × 1								○		
1	Compressor	LA771A3TB-20M	Output:7.9kW × 2									○	
1	Compressor	LA771A3TB-20M	Output:9.5kW × 2										○
2	4-way valve coil	SHF	AC208-230V 60Hz	○	○	○	○	○	○	○	○	○	○
3	2-way valve coil	FDF	AC208-230V 60Hz SV3D, SV41, SV42	○	○	○	○	○	○	○	○	○	○
3	2-way valve coil	TEV	AC208-230V 60Hz SV3F	○	○	○	○	○	○	○	○	○	○
4	Pulse motor valve coil	PAM	PMV1	○	○	○	○	○	○	○	○	○	○
4	Pulse motor valve coil	TS1	PMV2, 3	○	○	○	○	○	○	○	○	○	○
4	Pulse motor valve coil	UKV	PMV4	○	○	○	○	○	○	○	○	○	○
5	High-pressure SW	ACB-4UB237W	OFF:4.15MPa ON:3.2MPa	○	○	○	○	○	○	○	○	○	○
6	Pressure sensor(For high pressure)	NSK-BH038F-823	0.5~4.5V/0~3.92MPa	○	○	○	○	○	○	○	○	○	○
7	Pressure sensor(For low pressure)	NSK-BH020F-822	0.5~3.5V/0~2.0MPa	○	○	○	○	○	○	○	○	○	○
8	Fan motor	ICF-620A1000-1	DC530 - 620	○	○	○	○	○	○	○	○	○	○
9	Case heater(For comp.)	—	AC240V/29W	○	○	○	○	○	○	○	○	○	○

2-3. Outdoor Unit (50Hz model: MMY-MUP***1HT8P-A)

No	Name	Model	Specification	MMY-MUP0801HT8P-A	MMY-MUP1001HT8P-A	MMY-MUP1201HT8P-A	MMY-MUP1401HT8P-A	MMY-MUP14A1HT8P-A	MMY-MUP1601HT8P-A	MMY-MUP1801HT8P-A	MMY-MUP2001HT8P-A	MMY-MUP2201HT8P-A	MMY-MUP2401HT8P-A
1	Compressor	LA771A3TB-20M	Output:4.4kW × 1	○									
1	Compressor	LA771A3TB-20M	Output:6.5kW × 1		○								
1	Compressor	LA771A3TB-20M	Output:8.1kW × 1			○							
1	Compressor	LA771A3TB-20M	Output:10.9kW × 1				○						
1	Compressor	LA1201K4FB-10UC	Output:9.3kW × 1					○					
1	Compressor	LA1201K4FB-10UC	Output:11.4kW × 1						○				
1	Compressor	LA1201K4FB-10UC	Output:13.2kW × 1							○			
1	Compressor	LA1201K4FB-10UC	Output:14.9kW × 1								○		
1	Compressor	LA771A3TB-20M	Output:9.0kW × 2									○	
1	Compressor	LA771A3TB-20M	Output:10.7kW × 2										○
2	4-way valve coil	SHF	AC220-240V 50Hz	○	○	○	○	○	○	○	○	○	○
3	2-way valve coil	FDF	AC220-240V 50Hz SV3D, SV41, SV42	○	○	○	○	○	○	○	○	○	○
3	2-way valve coil	TEV	AC220-240V 50Hz SV3F	○	○	○	○	○	○	○	○	○	○
4	Pulse motor valve coil	PAM	PMV1	○	○	○	○	○	○	○	○	○	○
4	Pulse motor valve coil	HAM	PMV2, 3	○	○	○	○	○	○	○	○	○	○
4	Pulse motor valve coil	UKV	PMV4	○	○	○	○	○	○	○	○	○	○
5	High-pressure SW	ACB-4UB237W	OFF:4.15MPa ON:3.2MPa	○	○	○	○	○	○	○	○	○	○
6	Pressure sensor(For high pressure)	NSK-BH038F-823	0.5~4.5V/0~3.92MPa	○	○	○	○	○	○	○	○	○	○
7	Pressure sensor(For low pressure)	NSK-BH020F-822	0.5~3.5V/0~2.0MPa	○	○	○	○	○	○	○	○	○	○
8	Fan motor	ICF-620A1000-1	DC530 - 620	○	○	○	○	○	○	○	○	○	○
9	Case heater(For comp.)	—	AC240V/29W	○	○	○	○	○	○	○	○	○	○

2-4. Winding resistance of outdoor unit main parts


No.	Part name	Checking procedure							
1	Compressor (Model : LA771A3TB-20M)	Measure and compare each winding resistance by digital tester. <table><tr><th>Position</th><th>Resistance value</th></tr><tr><td>Red – White</td><td rowspan="3">0.242 Ω ±0.1</td></tr><tr><td>White – Black</td></tr><tr><td>Black – Red</td></tr></table> (all same resistance is ok.) at 20°C	Position	Resistance value	Red – White	0.242 Ω ±0.1	White – Black	Black – Red	
Position	Resistance value								
Red – White	0.242 Ω ±0.1								
White – Black									
Black – Red									
2	Compressor (Model : LA1201K4FB-10UC)	Measure and compare each winding resistance by digital tester. <table><tr><th>Position</th><th>Resistance value</th></tr><tr><td>Red – White</td><td rowspan="3">0.204 Ω ±0.1</td></tr><tr><td>White – Black</td></tr><tr><td>Black – Red</td></tr></table> (all same resistance is ok.) at 20°C	Position	Resistance value	Red – White	0.204 Ω ±0.1	White – Black	Black – Red	
Position	Resistance value								
Red – White	0.204 Ω ±0.1								
White – Black									
Black – Red									
3	Fan motor (Model : ICF-620A1000-1)	Measure and compare each winding resistance by digital tester. <table><tr><th>Position</th><th>Resistance value</th></tr><tr><td>Red – White</td><td rowspan="3">10.38Ω ±1.04</td></tr><tr><td>White – Black</td></tr><tr><td>Black – Red</td></tr></table> (all same resistance is ok.) at 20°C	Position	Resistance value	Red – White	10.38Ω ±1.04	White – Black	Black – Red	
Position	Resistance value								
Red – White	10.38Ω ±1.04								
White – Black									
Black – Red									
4	PMV (Pulse Motor Valve) coil (Model : HAM-MD12TF*) (Model : UKV-A376)	Measure each winding resistance by digital tester. <table><tr><th>Position</th><th>Resistance value</th></tr><tr><td>White - Red (COM)</td><td rowspan="4">46 Ω ±4</td></tr><tr><td>Yellow - Red (COM)</td></tr><tr><td>Orange - Red (COM)</td></tr><tr><td>Blue - Red (COM)</td></tr></table> at 20°C	Position	Resistance value	White - Red (COM)	46 Ω ±4	Yellow - Red (COM)	Orange - Red (COM)	Blue - Red (COM)
Position	Resistance value								
White - Red (COM)	46 Ω ±4								
Yellow - Red (COM)									
Orange - Red (COM)									
Blue - Red (COM)									
5	PMV (Pulse Motor Valve) coil (Model : PAM-MD12TF*)	Measure each winding resistance by digital tester. <table><tr><th>Position</th><th>Resistance value</th></tr><tr><td>White - Red (COM)</td><td rowspan="4">100 Ω ±10</td></tr><tr><td>Yellow - Red (COM)</td></tr><tr><td>Orange - Red (COM)</td></tr><tr><td>Blue - Red (COM)</td></tr></table> at 20°C	Position	Resistance value	White - Red (COM)	100 Ω ±10	Yellow - Red (COM)	Orange - Red (COM)	Blue - Red (COM)
Position	Resistance value								
White - Red (COM)	100 Ω ±10								
Yellow - Red (COM)									
Orange - Red (COM)									
Blue - Red (COM)									
6	4-way valve coil (Model : SQ-A2522G*)	Measure each winding resistance by digital tester. <table><tr><th>Resistance value</th></tr><tr><td>2085 Ω ±10%</td></tr></table> at 20°C	Resistance value	2085 Ω ±10%					
Resistance value									
2085 Ω ±10%									
7	2-way valve coil (Model : FQ-A0522G*)	Measure each winding resistance by digital tester. <table><tr><th>Resistance value</th></tr><tr><td>2085 Ω ±10%</td></tr></table> at 20°C	Resistance value	2085 Ω ±10%					
Resistance value									
2085 Ω ±10%									
8	2-way valve coil (Model :TEV-SMOAJ2170B)	Measure each winding resistance by digital tester. <table><tr><th>Resistance value</th></tr><tr><td>2163 Ω ±7%</td></tr></table> at 20°C	Resistance value	2163 Ω ±7%					
Resistance value									
2163 Ω ±7%									

2-5. Inverter Assembly


No	Name	Model	Specifications	MMY-MUP0801*	MMY-MUP1001*	MMY-MUP1201*	MMY-MUP1401*	MMY-MUP14A1*	MMY-MUP1601*	MMY-MUP1801*	MMY-MUP2001*	MMY-MUP2201*	MMY-MUP2401*
1	Power supply terminal block	JXO-6004	AC600V/75A, 4P	○	○	○	○	○	○	○	○	○	○
2	Noise Filter P.C. board (1)	MCC-1748	-	○	○	○	○	-	-	-	-	-	-
3	Noise Filter P.C. board (2)	MCC-1748	-	-	-	-	-	○	○	○	○	○	○
4	Line filter	-	0.9mH/AC460V/50A	-	-	-	-	○	○	○	○	○	○
5	Interface P.C. board	MCC-1747	-	○	○	○	○	○	○	○	○	○	○
6	Inverter P.C. board for Compressor (1)	MCC-1729	50A	○	○	○	○	-	-	-	-	○	○
7	Inverter P.C. board for Compressor (2)	MCC-1729	75A	-	-	-	-	○	○	○	○	-	-
8	Inverter P.C. board for fan	MCC-1734	-	○	○	○	○	○	○	○	○	○	○
9	Magnet Contactor	FC-1S	-	○	○	○	○	-	-	-	-	○	○
10	Magnet Contactor	FC-2S	-	-	-	-	-	○	○	○	○	-	-
11	PTC Thermistor	MZ32-101R	13A/AC500V	○	○	○	○	○	○	○	○	○	○

2-6. Parts Layout in Outdoor Unit


8,10,12,14HP
Model:
MMY-MUP0801*
MMY-MUP1001*
MMY-MUP1201*
MMY-MUP1401*



14A,16,18,20HP
Model:
MMY-MUP14A1*
MMY-MUP1601*
MMY-MUP1801*
MMY-MUP2001*




22,24HP
Model:
MMY-MUP2201*
MMY-MUP2401*




2-7. Parts Layout in Inverter Assembly

8, 10, 12, 14HP


Model: MMY-MUP0801*, MUP1001*, MUP1201*, MUP1401*



14A,16, 18, 20HP
Model: MMY-MUP14A1*, MUP1601*, MUP1801*, MUP2001*




22, 24HP
 Model: MMY-MUP2201*, MUP2401*



2-8. Outdoor (Inverter) Print Circuit Board



2-8-1. Interface P.C. board (MCC-1747)





2-8-2. Noise Filter P.C. board (MCC-1748)

990W 1Comp 1Fan model (A3 Compressor)
(8, 10, 12, 14HP)


1290W 1Comp 2Fan model (K4 Compressor)
(14A/16/18/20HP)
1290W 2Comp 2Fan model (A3 Compressor)
(22/24HP)




**1290W 1Comp 2Fan model (K4 Compressor)
(14A/16/18/20HP)**



2-8-4. Inverter P.C. board for fan (MCC-1734)



2-8-5. USB isolate P.C. board (MCC-1754)




3. REFRIGERANT PIPING SCHEMATIC DRAWING

Outdoor unit


8, 10, 12, 14HP








Model: MMY-MUP0801*, MUP1001*, MUP1201*, MUP1401*




Symbol						
Solenoid valve	Capillary tube	Check valve	Check joint	Strainer	Temperature sensor	Distributor

14A, 16, 18, 20HP
Model: MMY-MUP14A1*,MUP1601*, MUP1801*, MUP2001*



Symbol						
						
Solenoid valve	Capillary tube	Check valve	Check joint	Strainer	Temperature sensor	Distributor


22, 24HP
 Model: MMY-MUP2201*, MUP2401*



Functional Part Name

	SV3D	(Connector CN324 : WHI) 1) Reserves oil in the oil separator during OFF time. 2) Returns oil reserved in the oil separator to the compressor during ON time.
	SV3F	(Connector CN324: WHI) 1) Supplies oil in the accumulator to the compressor 2) Shuts off the liquid refrigerant from the accumulator when the compressor dilution
	SV41 SV42	(SV41 ••• Connector CN324 : WHI , SV42 ••• Connector CN327 : BLK) 1) High/Low pressure balance Prevention of subcool oil backflow when compressor stop, start-up compensation when starting up the compressor, reducing refrigerant noise when starting up heating operation 2) High pressure release function 3) Low pressure release function 4) Keeps the compressor reliability when Hot Gas Bypass system (prevent dilution with oil) 5) Releases capacity (Refrigerant mass bypass function in minimum cooling operation)
4-Way valve		(Connector CN317 : ORN) 1) Cooling/Heating change 2) Reverses Defrost
Pulse Motor Valve	PMV1	(Connector CN300 : WHI) 1) Controls superheat and subcool of the main heat exchanger 2) Stored liquid refrigerant reduction control in low ambient cooling operation (recovers stored liquid refrigerant in the main heat exchanger)
	PMV2 PMV3	(PMV2 ••• Connector CN301 : WHI , PMV3 ••• Connector CN302 : BLU) 1) Controls superheat and subcool of the sub heat exchanger 2) Maintains discharge pressure in low ambient cooling operation
	PMV4	(Connector CN303 : RED) 1) Controls superheat and subcool of the sub-cooling heat exchanger 2) Liquid bypass function for discharge temperature releases (cooling bypass function)
Oil Separator		1) Prevention for rapid decreasing oil (Decreases oil flowing to the cycle) 2) Reserve function of excess oil
Temperature Sensor	TD1 TD2	(TD1 ••• Connector CN502 : WHI , TD2 ••• Connector CN380 : BLK) 1) Protection of compressor discharge temperature 2) Used for discharge temperature release
	TG1 TG2 TG3	(TG1 ••• Connector CN381 : WHI , TG2 ••• Connector CN381 : WHI , TG3 ••• Connector CN384 : BLU) 1) Controls superheat of PMV in heating operation
	TE1	(Connector CN381 : WHI) 1) Controls the main heat exchanger defrost in heating operation 2) Controls outdoor fan in heating operation
	TE2 TE3	(TE2 ••• Connector CN381 : WHI , TE3 ••• Connector CN384 : BLU) 1) Controls the main heat exchanger defrost in heating operation 2) Controls outdoor fan in heating operation
	TL1	(Connector CN378 : WHI) 1) Detects the main heat exchanger subcool in cooling operation 2) Use as main complement switching during cooling operation
	TL2	(Connector CN378 : WHI) 1) Detects subcool of the sub-cooling heat exchanger in cooling operation 2) Use as main complement switching in cooling operation [3 way variable heat exchanger]
	TL3	(Connector CN378 : WHI) 1) Controls subcool of the sub-cooling heat exchanger
	TS1	(Connector CN378 : WHI) 1) Controls PMV superheat in heating operation
	TS3	(Connector CN378 : WHI) 1) Controls subcool of the sub-cooling heat exchanger
	TO	(Connector CN507 : YEL) 1) Detects outside temperature
	TK1 TK2	(TK1 ••• Connector CN502 : WHI , TK2 ••• Connector CN380 : BLK) 1) Judges oil level of the compressor
	High pressure sensor	(Connector CN501 : RED) 1) Detects high pressure 2) Controls the fan in low ambient cooling operation 3) Detects subcool of indoor units in heating operation
	Low pressure sensor	(Connector CN500 : WHI) 1) Detects low pressure 2) Controls superheat in heating operation
Heater	Compressor case heater	(Comp1 ••• Connector CN331 : WHI , Comp2 ••• Connector CN332 : BLU) 1) Prevents liquid refrigerant accumulation in the compressor

Indoor unit




U series Indoor Unit Functional Part Explanation

Functional part name		Functional outline
Pulse Motor Valve	PMV	(Connector CN082 (6P): Blue) 1) Controls superheat in cooling operation 2) Controls subcool in heating operation 3) Recovers refrigerant oil in cooling operation 4) Recovers refrigerant oil in heating operation
Temp. Sensor	1.TA	(Connector CN104 (2P): Yellow) 1) Detects indoor return air temperature
	2.TC1	(Connector CN100 (3P): Brown) 1) Controls PMV superheat in cooling operation
	3.TC2	(Connector CN101 (2P): Black) 1) Controls PMV subcool in heating operation
	4.TCJ	(Connector CN102 (2P): Red) 1) Controls PMV superheat in cooling operation

* Please refer to each indoor unit Service Manual for details of each sensor

4. COMBINED REFRIGERANT PIPING SYSTEM SCHEMATIC DIAGRAMS


4-1. Refrigerant Flow (Cooling)



The outdoor unit which communication line between indoor and outdoor is connected is the "Header unit". Other outdoor units are called "Follower units".

4-2. Refrigerant Flow (Single Defrost)

Outdoor Unit (MMY-MUP2401*)




Outdoor Unit			
4-way valve	OFF	SV3D	Control
PMV1	Control	SV3F	Control
PMV2	Control	SV4(n)	Control
PMV3	Control	Outdoor fan	Control
PMV4	Control		

High-pressure gas refrigerant	Evaporative gas refrigerant (Low pressure)
Condensate liquid refrigerant	Low-pressure circuit (Refrigerant recover line)

The outdoor unit which communication line between indoor and outdoor is connected is the "Header unit". Other outdoor units are called "Follower units".

4-3. Refrigerant Flow (Heating)



Outdoor Unit			
4-way valve	ON	SV3D	Control
PMV1	Control	SV3F	Control
PMV2	Control	SV4(n)	Control
PMV3	Control	Outdoor fan	Control
PMV4	Control		


	High-pressure gas refrigerant		Evaporative gas refrigerant (Low pressure)
	Condensate liquid refrigerant		Low-pressure circuit (Refrigerant recover line)

(38 HP system described in the example of (24 HP + 14 HP))



The outdoor unit which communication line between indoor and outdoor is connected is the "Header unit". Other outdoor units are called "Follower units".

4-4. Refrigerant Flow (Individual Defrost)

Header Unit (MMY-MUP2401*) Defrost Unit



Follower Unit (MMY-MUP1401*) Heating Unit



Outdoor Unit (Defrost Unit)			
4-way valve	OFF	SV3D	Control
PMV1	Control	SV3F	Control
PMV2	Control	SV4(n)	Control
PMV3	Control	Outdoor fan	Control
PMV4	Control		


Outdoor Unit (Heating Unit)			
4-way valve	ON	SV3D	Control
PMV1	Control	SV3F	Control
PMV2	Control	SV4(n)	Control
PMV3	Control	Outdoor fan	Control
PMV4	Control		

- High-pressure gas refrigerant
- Condensate liquid refrigerant
- Evaporative gas refrigerant (Low pressure)
- Low-pressure circuit (Refrigerant recover line)

(38 HP system described in the example of (24 HP + 14 HP))

The outdoor unit which communication line between indoor and outdoor is connected is the "Header unit". Other outdoor units are called "Follower units".

4-5-1. (1) Refrigerant Flow (Automatic emergency cooling)



Trouble header outdoor unit			
4-way valve	OFF	SV3D	OFF
PMV1	CLOSE	SV3F	OFF
PMV2	CLOSE	SV4(n)	OFF
PMV3	CLOSE	Outdoor fan	OFF
PMV4	CLOSE		


Temporal header outdoor unit			
4-way valve	OFF	SV3D	Control
PMV1	Control	SV3F	Control
PMV2	Control	SV4(n)	Control
PMV3	Control	Outdoor fan	Control
PMV4	Control		

- High-pressure gas refrigerant
- Evaporative gas refrigerant (Low pressure)
- Condensate liquid refrigerant
- Low-pressure circuit (Refrigerant recover line)

(38 HP system described in the example of (24 HP + 14 HP))

The outdoor unit which communication line between indoor and outdoor is connected is the "Header unit". Other outdoor units are called "Follower units".

(2) Refrigerant Flow (Manual emergency cooling)



Trouble header outdoor unit			
4-way valve	OFF	SV3D	OFF
PMV1	CLOSE	SV3F	OFF
PMV2	CLOSE	SV4(n)	OFF
PMV3	CLOSE	Outdoor fan	OFF
PMV4	CLOSE		


Temporal header outdoor unit			
4-way valve	OFF	SV3D	Control
PMV1	Control	SV3F	Control
PMV2	Control	SV4(n)	Control
PMV3	Control	Outdoor fan	Control
PMV4	Control		

- High-pressure gas refrigerant
- Evaporative gas refrigerant (Low pressure)
- Condensate liquid refrigerant
- Low-pressure circuit (Refrigerant recover line)

(38 HP system described in the example of (24 HP + 14 HP))


The outdoor unit which communication line between indoor and outdoor is connected is the "Header unit". Other outdoor units are called "Follower units".

4-5-2. (1) Refrigerant Flow (Automatic emergency heating)



The outdoor unit which communication line between indoor and outdoor is connected is the "Header unit". Other outdoor units are called "Follower units".


(2) Refrigerant Flow (Manual emergency heating)



The outdoor unit which communication line between indoor and outdoor is connected is the "Header unit". Other outdoor units are called "Follower units".



4-6. Refrigerant Flow (Reclaim)

Header Unit (MMY-MUP2401*)



Follower Unit (MMY-MUP1401*)

Trouble



Outdoor Unit			
4-way valve	OFF	SV3D	Control
PMV1	Control	SV3F	Control
PMV2	Control	SV4(n)	Control
PMV3	Control	Outdoor fan	Control
PMV4	Control		





High-pressure gas refrigerant
 Evaporative gas refrigerant (Low pressure)
 Condensate liquid refrigerant
 Low-pressure circuit (Refrigerant recover line)


(38 HP system described in the example of (24 HP + 14 HP))


The outdoor unit which communication line between indoor and outdoor is connected is the "Header unit". Other outdoor units are called "Follower units".

5. CONTROL OUTLINE

5-1. Outdoor Unit

Item	Description of operation, numerical data, and other information	Remarks
1. Pulse motor valve (PMV) control	<p>1. PMV1, 2, 3 control (PMV 1 and 2, 3)</p> <p>1) During air conditioner operation, the pulse count of a PMV1 (pulse motor valve 1) is controlled between 75 pls and 3000 pls, During air conditioner operation, the pulse count of a PMV2, 3 is controlled between 25 pls and 500 pls.</p> <p>2) During cooling, the PMV opening is controlled on the basis of measurements provided by the TL temperature sensor and the Pd sensor (subcool control).</p> <p>3) During heating, the PMV opening is controlled on the basis of measurements provided by the TS, TD and TG temperature sensor and the Ps sensor (superheat control).</p> <p>4) PMVs are fully closed when the air conditioner is in thermostat OFF state or upon being tuned off normally or shut down due to an abnormality.</p> <div style="display: flex; justify-content: space-around; align-items: flex-end;">   </div> <p>2. PMV 4 control</p> <p>1) During cooling, the pulse count of a PMV 4 (pulse motor valve 4) is controlled between 30 pls and 350 pls. The PMV 4 opening is controlled on the basis of measurements provided by the TL3 temperature sensor and Pd sensor (subcool control). or TS3 temperature sensor and Ps sensor (superheat control).</p> <p>2) During heating, the pulse count of a PMV4 is controlled between 30 pls and 350 pls. The PMV 4 operation is controlled by the pulse count of PMV opening of indoor unit and zone judgment. (Indoor refrigerant excess control)</p> <p>3) PMVs are fully closed when the air conditioner is in thermostat OFF state, upon being turned off normally or shut down due to an abnormality.</p> <div style="display: flex; justify-content: space-around; align-items: flex-end;">   </div>	

Item	Description of operation, numerical data, and other information	Remarks														
2. Outdoor fan control	<div>1. Cooling fan control</div> <div>1) Outdoor fan speed (mode) is controlled on the basis of measurements provided by the Pd sensor.</div> <div>2) For a specified period after the start of cooling operation, the header outdoor unit controls outdoor fan speed (mode) on the basis of measurements provided by the Pd sensor. Follower units, on the other hand, control outdoor fan speed (mode) on the basis of measurements provided by the TE1 temperature sensor.</div> <div></div> <div>* Available control modes are 0 (at rest) to 63.</div> <div>2. Heating fan control</div> <div>1) Outdoor fan speed (mode) is controlled on the basis of the measurements provided by the TE temperature sensor.</div> <div>2) If TE > 25 °C is continuously detected for 8 minutes, the fan maybe turned off. However, this condition is the same as normal thermostat OFF, so that fan operation will be restarted.</div> <div>3) For a specified period after air conditioner start up and during defrosting this control is disabled.</div> <div>4) When refrigerant is extremely short supply, this control may cause the air conditioner to be repeatedly turned on and off.</div> <div><table><tr><th>TE1 temperature (°C)</th><th></th></tr><tr><td>25</td><td>Zone A: Lowest mode, timer count for forced compressor shutdown</td></tr><tr><td>8</td><td>Zone B: -2/15 seconds (down to lowest mode)</td></tr><tr><td>6</td><td>Zone C: -1/15 seconds (down to lowest mode)</td></tr><tr><td>4</td><td>Zone D: Hold (staying at current mode)</td></tr><tr><td>2</td><td>Zone E: +1/15 seconds (up to highest mode)</td></tr><tr><td></td><td>Zone F: Highest mode</td></tr></table><div>Zone A: Lowest mode, timer count for forced compressor shutdown</div><div>Zone B: -2/15 seconds (down to lowest mode)</div><div>Zone C: -1/15 seconds (down to lowest mode)</div><div>Zone D: Hold (staying at current mode)</div><div>Zone E: +1/15 seconds (up to highest mode)</div><div>Zone F: Highest mode</div><div>TE1 temperature (°C)</div></div> <div>3. Upper limit shift correction control in outdoor fan mode while operating in heating mode</div> <div>... This is a control that lowers the upper limit of the outdoor fan speed during heating operation when the air conditioning load is low and the number of indoor units operating is small.</div> <div>1) Lowers the current fan mode upper limit by -1 mode</div> <div>2) After that, while the conditions are met, the mode will be down every 30 seconds.</div> <div>3) The lower limit of the mode down is the fan mode "54".</div> <div>4) When the comp is turned off, this control is canceled and it returns to the initial setting upper limit mode.</div> <div>5) When the number of indoor driving increases, one mode will be up every 30 seconds.</div>	TE1 temperature (°C)		25	Zone A: Lowest mode, timer count for forced compressor shutdown	8	Zone B: -2/15 seconds (down to lowest mode)	6	Zone C: -1/15 seconds (down to lowest mode)	4	Zone D: Hold (staying at current mode)	2	Zone E: +1/15 seconds (up to highest mode)		Zone F: Highest mode	<div>• The fan speed corresponding to the highest mode varies with the HP capacity of the outdoor unit.</div> <div>• Pd control point may change depending on conditions and operation mode</div> <div>• TE sensor temperature is the lowest temperature by comparing TE 1, 2, 3</div> <div>• The fan speed corresponding to the highest mode varies with the HP capacity of the outdoor unit.</div> <div>• Mode down is valid only when TH(x) temperature < 75°C</div> <div>• Mode up is valid only when TH(x) temperature ≥ 80°C</div>
TE1 temperature (°C)																
25	Zone A: Lowest mode, timer count for forced compressor shutdown															
8	Zone B: -2/15 seconds (down to lowest mode)															
6	Zone C: -1/15 seconds (down to lowest mode)															
4	Zone D: Hold (staying at current mode)															
2	Zone E: +1/15 seconds (up to highest mode)															
	Zone F: Highest mode															

Item	Description of operation, numerical data, and other information	Remarks
3. Capacity control	<p>1) The compressors of the header and follower units are controlled on the basis of capacity demand issued by indoor controllers.</p> <p>2) The two compressors featured in an outdoor unit operate on a rotational basis, so that, every time they come to stop, their order of startup changes.</p> <p>3) When one or more follower outdoor units are connected, the system will be started next time between all the outdoor units including the header outdoor unit when the system is stopped (including thermostat-off) or the power is reset while 24 hours or more has passed on the accumulated operating time. Reverse the priority of time.</p>	<ul style="list-style-type: none"> The outdoor rotation control may be performed even when the insufficient refrigerant state is not released even if the indoor refrigerant recovery control is performed.
4. Oil level detection control	<p>1) TK1,2 sensor detection temperature and prediction TK1, 2 sensor temperature is used to judge whether there is an appropriate amount of oil in the compressor case. This control is performed independently by the header outdoor unit and follower outdoor units.</p> <p>2) Based on the relationship between the TK detection temperature of the compressor into and the predicted TK sensor temperature, it is judged whether the oil level in the compressor case is appropriate, and if it is insufficient, the upper limit of the compressor speed and SV3D valve operate.</p> <p>3) If the shortage is not resolves by the operation of 2), shift to the oil recovery operation.</p> <p>4) This control function is performed whenever at least one compressor is in operation.</p> 	<ul style="list-style-type: none"> The predicted TK sensor temperature is the predicted value of the TK sensor temperature when the oil is in proper condition SV3D valve: Solenoid valve for oil return of oil separator Oil level judgment guide <ul style="list-style-type: none"> ① When predicted $TK-TK < 10^{\circ}\text{C}$, the oil level is appropriate ② When predicted $TK-TK \geq 10^{\circ}\text{C}$, the oil level is insufficient Predicted TK1, 2 and TK1, and 2 sensor temperature It can check by "8-6. 7-Segment Display Function".

Item	Description of operation, numerical data, and other information	Remarks
5. Oil recovery control	<p>This is a control for preventing oil shortage in the compressor between the outdoor units, and oil equalization control is performed as follows during cooling operation and heating operation.</p> <p>[1] During cooling operation When the oil level of any compressor in the outdoor unit is determined to be insufficient due to the stagnation of refrigerating machine oil in the gas pipes and the indoor unit during cooling operation, this control recovers the oil from the indoor unit and evens oil levels between the outdoor units by increasing the compression frequency of the outdoor unit that detected drop of the oil level. This control is managed by the header outdoor unit.</p> <p>1) Control start condition</p> <ul style="list-style-type: none"> • The operating time of the compressor in which an insufficient oil level is detected exceeds 15 minutes • The operating time of the compressor in which an insufficient oil level is detected exceeds 30 minutes • The operating time of the compressor in which an insufficient oil level is detected exceeds 45 minutes • When the operating time of the compressor in which an insufficient oil level is detected exceeds 60 minutes, it causes an abnormal stop of the compressor. <p>2) Control content</p> <ul style="list-style-type: none"> • The operating compressor is operated at the target speed, the stopped compressor is started, and the compressor is operated at the target speed. • Switch control mode in the indoor unit to the cooling oil (refrigerant) recovery control mode, and open the PMV opening of the indoor unit by a certain opening. • After the recovery control is performed for a predetermined time, the recovery control ends and the normal cooling operation is resumed. <p>[2] During heating operation This control can recover the stagnated oil in the piping or indoor heat exchanger and return it to the compressor by defrosting operation when the oil level continues to decrease even if the compressor oil level has been detected and the oil return control from the oil separator has functioned.</p> <ul style="list-style-type: none"> • Reverse defrost control is performed every 15 minutes after an insufficient oil level is confirmed during heating operation. • When the operating time of the compressor in which an insufficient oil level is detected exceeds 60 minutes, it causes an abnormal stop of the compressor. 	<ul style="list-style-type: none"> • The shortage is confirmed when the shortage continues even if the recovery operation (SV3D valve is turned on) is performed for each outdoor unit when the shortage is detected. * Depending on the number of indoor units when an insufficient oil level is confirmed, this control determines whether to recover the oil from only the operating indoor units or all the indoor units. • Oil level confirmation timer operates when an insufficient oil level is detected.
6. Heating refrigerant (oil) recovery control	<p>Since the indoor unit that is stopped during heating operation closes the PMV, liquid refrigerant may accumulate in the heat exchanger, resulting in a refrigerant shortage condition. This control is to recover the liquid refrigerant to return it to the outdoor unit when a refrigerant shortage is detected.</p> <p>The PMV opening of the stopped indoor unit is slightly opened to return the refrigerant to the outdoor unit, but if the insufficient refrigerant state is still not resolved, heating refrigerant recovery control is performed.</p> <p>This control also recovers the refrigerant in Indoor/Outdoor unit after defrosting and the oil in the outdoor heat exchanger during heating overload operation. It is managed by the header outdoor unit.</p> <p>[1] Paused heating indoor unit PMV minute opening control</p> <ul style="list-style-type: none"> • Control start condition When all the following conditions are satisfied • There are units with heating thermostat ON and other than thermostat ON (stop/thermostat OFF). • When the outdoor unit determines the refrigerant shortage condition • When the outdoor PMV opening exceeds the specified opening or the TD sensor temperature exceeds the specified value • Control content When the control starts, the PMV in the indoor unit during stop opens by a minute opening. <p>[2] Heating refrigerant recovery control</p> <p>Control start condition</p> <ul style="list-style-type: none"> • At the start of heating operation (when Comp. is turned on from Comp. OFF) • During heating operation transition after defrosting • 40 minutes have passed since the refrigerant shortage state was judged after starting the PMV minute opening control in the paused heating indoor unit. 	<ul style="list-style-type: none"> • The recovery duration varies depending on the load condition, but it usually takes around 5-10 minutes. • The compressor's speed varies depending on the control conditions, indoor capacity, and outdoor unit.

Item	Description of operation, numerical data, and other information	Remarks
7. Defrosting control (Reverse defrosting method)	<ul style="list-style-type: none"> The reverse defrosting method is used for the outdoor unit in a single system, and the individual reverse defrosting method is used for the outdoor units in a connected system. In the individual reverse defrosting, in order to prevent the cold air from dropping during defrosting, the Gr in which the unit that satisfies the defrosting start condition exists is switched to the cooling position of the four-way valve to perform the defrosting operation while It will be the operation method to continue the heating operation. <p>[Defrosting start condition (single and common system common)]</p> <ul style="list-style-type: none"> During the heating operation, if the TE sensor detected temperature falls below the predicted TE sensor temperature by a specified amount, or if the TE sensor detected temperature falls below the frosting temperature for 300 minutes, the defrosting operation starts. (After start-up or when switching from cooling to heating, frost judgment is performed and the defrosting operation is started according to the judgment result.) <p>* In the case of the coupled system, when any of the outdoor units satisfies the defrosting start condition, all the units in the group to which the unit belongs start defrosting operation, and the other Gr units continue heating operation.</p> <p>① <u>Reverse defrosting method (the outdoor unit is a single system)</u></p> <ol style="list-style-type: none"> Defrost control content <ol style="list-style-type: none"> Stop the compressor that is running. After a certain period of time, the four-way valve is turned off and the outdoor fan is stopped. Turn on the compressor that is off and operate it at the target speed for defrost control. Defrost termination condition When the TE sensor temperature detection value exceeds a certain value (standard 12 °C) after a certain time has passed since the defrost control was started, the defrost end condition will be set and the defrost end control will be performed. Defrost end control content <ol style="list-style-type: none"> Stop the compressor again. Turns on the four-way valve after a certain period of time. Control the refrigerant recovery in the heating room. For control details, see "6. Heating refrigerant (oil) recovery control". <p>② <u>Individual defrost method (outdoor unit is combined system)</u></p> <ol style="list-style-type: none"> Outdoor unit grouping method The outdoor unit is divided into Gr1 and Gr2 when the power is turned on. Defrost control content <ol style="list-style-type: none"> If any of the units satisfy the defrosting start conditions, all the stopped outdoor units are started, the operating unit operates the compressor at the minimum speed, and after a certain period of time, only the defrosting unit has a four-way valve. To turn off the outdoor fan. Heating Gr continues heating operation as it is The defrosting Gr unit controls the compressor rotation speed so that the Pd and Ps detection values of each unit become the target values. Defrost termination condition When the TE sensor temperature detection value exceeds a certain value (standard 12 °C) after a certain time has passed since the defrost control was started, the defrost end condition will be set and the defrost end control will be performed. <p>* When the defrosting end conditions are met for all outdoor units, the defrosting end control is performed. If any unit does not meet the defrost termination conditions, the outdoor unit that satisfies the defrost termination conditions continues defrosting operation.</p> <ol style="list-style-type: none"> Defrost end control content <ol style="list-style-type: none"> Defrosting Gr unit <ol style="list-style-type: none"> Operates the compressor at standby speed. After a certain period of time, the four-way valve turns on. Shift to heating start pattern control. Unit of heating Gr <ol style="list-style-type: none"> When all the outdoor units included in the defrosting Gr turn on the four-way valve, the normal heating operation is restored. The outdoor unit to be stopped stops its operation. 	<ul style="list-style-type: none"> TE sensor detection temperature is the lowest temperature of TE1, TE2, TE3 Frosting temperature is -1.5 °C After the power is turned on, for the first time, the defrosting operation is continued for 25 minutes below the frosting temperature only when the heat exchanger is frosted. Fan mode may be controlled during defrosting for cycle protection. The compressor speed during defrost control is controlled below 85.0rps. TE sensor detection temperature is the lowest temperature of TE1, TE2, TE3 Frosting temperature is -1.5 °C Fan mode may be controlled during defrosting for cycle protection. The compressor speed of the defrost unit during individual reverse defrost control is controlled at 60.0rps or less. The compressor speed during standby operation is 15.0 ~ 30.0rps.

Item	Description of operation, numerical data, and other information	Remarks														
8. Release valve control	<p>(1) SV4 gas balance control</p> <p>This control turns on SV4 when the compressor is stopped to balance the gas and reduce the starting load when the compressor is turned on next time. This control is performed independently by the center unit and each terminal unit.</p> <p>① Control condition</p> <ul style="list-style-type: none">• At power on• When the compressor is switched from ON to OFF during cooling operation or heating operation. <p>② Control content</p> <ul style="list-style-type: none">• SV4 (x) is turned on when the power is turned on, and then turned off when ΔP ($= P_d - P_s$) becomes 2.0 or less.• SV4 (x) turns on when the compressor turns off. (Turns on when ΔP ($P_d - P_s$) is 3.0 or more, and turns off when ΔP ($P_d - P_s$) is 2.0 or less.) <p>(2) SV4 high pressure release control</p> <p>This control is a control to suppress the high pressure rise during cooling operation and heating operation. This control is performed independently by the header unit and each follower unit.</p> <p>① Control condition</p> <ul style="list-style-type: none">• Compressor ON <p>② Control content</p> <ul style="list-style-type: none">• When $P_d \geq P1$, SV4 (x) is turned on.• When $P_d \leq P2$, SV4 (x) is turned off. <p>* P1 and P2 of each outdoor unit are as follows</p> <table><tr><th rowspan="2">Pd control point</th><th rowspan="2">Heating</th><th colspan="2">Cooling</th></tr><tr><th>Compressor start-up priority 1</th><th>Compressor start-up priority 2 or later</th></tr><tr><td>P1</td><td>3.38MPa</td><td>3.70MPa</td><td>3.70MPa</td></tr><tr><td>P2</td><td>3.33MPa</td><td>3.68MPa</td><td>3.68MPa</td></tr></table> <p>③ Release condition</p> <ul style="list-style-type: none">• When the system is stopped and the thermostat is off <p>(3) SV4 low pressure release control</p> <ul style="list-style-type: none">• The purpose of this control is to protect the P_s drop during compression ON.• This control is performed independently by the header unit and each follower unit. <p>① Control condition</p> <p>The outdoor unit that is turned on will judge each item individually.</p> <p>② Control content</p> <ul style="list-style-type: none">• When $P_s \leq 0.16$, turn on SV4 (x).• When $P_s \geq 0.20$, SV4 (x) is turned off. <p>③ Release condition</p> <ul style="list-style-type: none">• When the system is stopped and the thermostat is off	Pd control point	Heating	Cooling		Compressor start-up priority 1	Compressor start-up priority 2 or later	P1	3.38MPa	3.70MPa	3.70MPa	P2	3.33MPa	3.68MPa	3.68MPa	
Pd control point	Heating			Cooling												
		Compressor start-up priority 1	Compressor start-up priority 2 or later													
P1	3.38MPa	3.70MPa	3.70MPa													
P2	3.33MPa	3.68MPa	3.68MPa													

Item	Description of operation, numerical data, and other information	Remarks																		
9. Capacity release control	<p>This control is a capacity release control that is performed for the purpose of suppressing the thermostat-OFF due to freezing prevention due to excessive capacity even in Min speed [rps] during cooling small capacity operation.</p> <p>① Control condition</p> <p>Perform when all the following conditions are met.</p> <ul style="list-style-type: none">It is an outdoor unit with startup priority 1.When the compressor speed is less than A [rps] during cooling operation <table><tr><th>Compressor</th><th>A [rps]</th></tr><tr><td>(77cc A3)</td><td>25.0</td></tr><tr><td>(120cc K4)</td><td>20.5</td></tr></table> <ul style="list-style-type: none">When TD(X) ≤ 96 °C <p>② Control content</p> <ul style="list-style-type: none">When any of the indoor units that are thermostat-ON detects TCJ ≤ 3 °C or TC1 ≤ 3 °C while any of the compressors is ON, SV4 (x) is turned ON.When any of the indoor units that are thermostat-ON detects TCJ > 7 °C or TC1 > 7 °C while any compressor is ON, SV4 (x) is turned OFF. <p>③ Release condition</p> <ul style="list-style-type: none">When the system is stopped and the thermostat is offWhen TD (X) > 102 °C is detectedWhen the compressor speed is above A [rps]	Compressor	A [rps]	(77cc A3)	25.0	(120cc K4)	20.5													
Compressor	A [rps]																			
(77cc A3)	25.0																			
(120cc K4)	20.5																			
10. High pressure release compressor shut down	<p>This control function is aimed at automatically shutting down a compressor in an outdoor unit depending on Pd. It is individually performed by the header unit and each follower unit.</p> <p>1) Control details</p> <ul style="list-style-type: none">Compressors are shut down when Pd reaches or exceeds P0The Pd control point P0 is switched according to the start priority of the outdoor unitThe compressor restart prevention timer (2 minutes 30 seconds) is set, and the control terminated. <table><tr><th colspan="2">Pd control point P0</th><th>Cooling</th><th>Heating</th></tr><tr><td rowspan="2">Outdoor unit priority1</td><td>compressor1</td><td>3.77MPa</td><td>3.53MPa</td></tr><tr><td>compressor2</td><td>3.72MPa</td><td>3.49MPa</td></tr><tr><td rowspan="2">Outdoor unit priority 2-5</td><td>compressor1</td><td>3.72MPa</td><td>3.45MPa</td></tr><tr><td>compressor2</td><td>3.72MPa</td><td>3.41MPa</td></tr></table>	Pd control point P0		Cooling	Heating	Outdoor unit priority1	compressor1	3.77MPa	3.53MPa	compressor2	3.72MPa	3.49MPa	Outdoor unit priority 2-5	compressor1	3.72MPa	3.45MPa	compressor2	3.72MPa	3.41MPa	
Pd control point P0		Cooling	Heating																	
Outdoor unit priority1	compressor1	3.77MPa	3.53MPa																	
	compressor2	3.72MPa	3.49MPa																	
Outdoor unit priority 2-5	compressor1	3.72MPa	3.45MPa																	
	compressor2	3.72MPa	3.41MPa																	
11. Case heater control	<p>This control function is aimed at preventing the accumulation of refrigerant in those case, and is performed by all outdoor units.</p> <p>If the power supply has not been turned on for a specified period before a post-installation test run. Compressor failure may occur.</p> <p>Similarly, when starting compressors after a long period of no power supply, it is recommended that the power supply be turned on for a while before operation is resumed, just like a post-installation test run.</p> <p>This control function is sometimes used alongside an electrical changing of the compressor motor windings. In this case, a changing sound may be heard, but this is normal.</p> <p>1) Control details</p> <ul style="list-style-type: none">The heaters are turned on while the compressors are turned off.The heaters are turned off when TO sensor temperature becomes ≥ 28 °C、and are turned back on when TO sensor temperature becomes ≤ 25 °C.When the compressors are turned on, the heaters are kept on for 10 minutes.																			

Item	Description of operation, numerical data, and other information	Remarks																																	
12. Inverter P.C.board control for compressor	<p>(1) Current, power release value control The purpose of this control is to prevent high pressure rise and overheating of electric parts by reducing the compressor speed when the maximum current and maximum power value set for each model are exceeded.</p> <p>The maximum current and power value for each horsepower of each model are as follows</p> <table border="1"> <thead> <tr> <th>HP</th><th>Maximum current</th><th>Maximum power</th></tr> </thead> <tbody> <tr> <td>24*</td><td>27.00A</td><td>17.21kW</td></tr> <tr> <td>22*</td><td>25.50A</td><td>16.25kW</td></tr> <tr> <td>20</td><td>36.00A</td><td>22.94kW</td></tr> <tr> <td>18</td><td>34.00A</td><td>21.67kW</td></tr> <tr> <td>16</td><td>30.50A</td><td>19.44kW</td></tr> <tr> <td>14A</td><td>27.00A</td><td>17.21kW</td></tr> <tr> <td>14</td><td>27.50A</td><td>17.52kW</td></tr> <tr> <td>12</td><td>24.50A</td><td>15.61kW</td></tr> <tr> <td>10</td><td>20.50A</td><td>13.06kW</td></tr> <tr> <td>8</td><td>15.40A</td><td>9.81kW</td></tr> </tbody> </table> <p>*2 For comp models, it is the maximum value per comp.</p> <p>Even when the TH sensor temperature $\geq 81^{\circ}\text{C}$, the compressor speed is reduced, and when the TH sensor temperature $< 73^{\circ}\text{C}$ continues, the rotation speed increase is permitted.</p> <p>(2) Heat sink overheat abnormality ① Stop the compressor operation when the TH sensor temperature exceeds 93°C. ② When the above is stopped, the abnormal count is set to 1, and it restarts after 2 minutes and 30 seconds. If you continue the operation for 10 minutes or more after restarting, the trouble count will be cleared ③ A trouble is confirmed with a trouble count of "4".</p> <p>(3) High pressure SW control ① Inverter compressor stops driving the compressor when the high pressure SW is operating. ② When the above is stopped, the abnormal count is set to 1, and it restarts after 2 minutes and 30 seconds. If you continue the operation for 10 minutes or more after restarting, the trouble count will be cleared. ③ The trouble count becomes "4" and the trouble is confirmed. The above display is "P04".</p>	HP	Maximum current	Maximum power	24*	27.00A	17.21kW	22*	25.50A	16.25kW	20	36.00A	22.94kW	18	34.00A	21.67kW	16	30.50A	19.44kW	14A	27.00A	17.21kW	14	27.50A	17.52kW	12	24.50A	15.61kW	10	20.50A	13.06kW	8	15.40A	9.81kW	
HP	Maximum current	Maximum power																																	
24*	27.00A	17.21kW																																	
22*	25.50A	16.25kW																																	
20	36.00A	22.94kW																																	
18	34.00A	21.67kW																																	
16	30.50A	19.44kW																																	
14A	27.00A	17.21kW																																	
14	27.50A	17.52kW																																	
12	24.50A	15.61kW																																	
10	20.50A	13.06kW																																	
8	15.40A	9.81kW																																	

Item	Description of operation, numerical data, and other information	Remarks
13. Heat sink condensation prevention control	<p>Since the refrigerant cooling heat sink cools the device by the refrigerant temperature of the liquid pipe, if the liquid pipe temperature drops due to a gas shortage cycle, dew condensation on the device may occur. Therefore, the control is for the purpose of preventing dew condensation on the element.</p> <p>1) Control condition</p> <ul style="list-style-type: none"> • Compressor ON • Do not execute this control during startup control • Do not execute this control during defrosting operation <p>2) Control content</p> <p>① During cooling operation, when TO-TL2 \geq 5K is continued for 5 minutes</p> <p>② During heating operation, at the time point when TO supplement-TL2 \geq 5K is continued for 5 minutes</p> <ul style="list-style-type: none"> • The header outdoor unit will be stopped, and the system restart prevention timer will be set. • For the follower outdoor units, the compressor of the unit that detected the abnormality is turned off to prevent the compressor from restarting. Set the timer and send the [compressor start permission: OFF] signal outside the center room. • Abnormality count is [1]. 	

<Other points to note>

1) Cooling Operation at Low Outdoor Temperature

- ① When suction pressure (Ps) decreases, the indoor unit operation may stop due to anti-frost control based on the temperature of the TC sensor of indoor unit.
- ② When suction pressure (Ps) decreases, the compressor speed [rps] may be decreased due to cooling capacity control.
- ③ When discharge temperature (TD) is lower than 60°C, the compressor speed [rps] may be increased due to indoor unit command.




2) PMV (Pulse motor Valve)

- ① When power is turned on, the PMV will initialize and make a knocking sound. If there is no knocking sound, there is possibility of PMV malfunction. However, if the outdoor unit area has high ambient noise, there is possibility PMV knocking sound may not be heard.
- ② Do not remove PMV Coil (head part) during operation. It will affect the control valve opening.
- ③ When transporting the set, do not ever remove the PMV Coil. Valve will close and sealing the liquid refrigerant which may damage the valve.
- ④ When removing and reattaching the PMV Coil, push in the coil firmly until [Click] sound is heard, turn off the power and turn it on again.



3) Fan mode during heating operation on same system line of indoor unit

In the same system line of indoor unit, if there's one indoor unit is on the heating operation, the other indoor units cannot do Fan Mode. The indoor unit for which Fan Mode is selected will be forcibly stopped, and ["operation standby Ⓢ"] will be displayed on the remote controller. Refrigerant will accumulate in the indoor unit that is operating in fan mode. This condition is set to prevent repeated refrigerant recovery.

5-2. Indoor Unit



No.	Item	Outline of specifications	Remarks														
1	When power supply is reset	<div>1) Distinction of outdoor unit When the power supply is reset, the outdoors are distinguished and the control is selected according to the distinguished result.</div> <div>2) Setting of indoor fan speed and existence of air direction adjustment Based on EEPROM data, select setting of the indoor fan speed and the existence of air direction adjustment.</div> <div>3) If resetting the power supply during occurrence of a trouble, the check code is once cleared. After ON/OFF button of the remote controller was pushed and the operation was resumed, if the abnormal status continues, the check code is again displayed on the remote controller.</div>															
2	Operation mode selection	<div>1) Based on the operation mode selecting command from the remote controller, the operation mode is selected.</div> <table><thead><tr><th>Remote controller command</th><th>Control outline</th></tr></thead><tbody><tr><td>STOP</td><td>Operation stops.</td></tr><tr><td>FAN</td><td>Fan operation</td></tr><tr><td>COOL</td><td>Cooling operation</td></tr><tr><td>DRY</td><td>Dry operation</td></tr><tr><td>HEAT</td><td>Heating operation</td></tr><tr><td>AUTO (Heat recovery system outdoor unit type)</td><td><div>• TA and Ts automatically select COOL/HEAT operation mode for operation.</div><div>• The operation is performed as shown in the following figure according to TA value at the first time only. (In the range of $T_s - 1 < TA < T_s + 1$, Cooling thermostat OFF (Fan) / Setup air volume operation continues.)</div><div></div><div>* Heat recover system outdoor unit type can select automatic mode. While a wireless remote controller is used, the mode is notified by “Pi Pi” (two times) receiving sound and the alternate flashing of [TIMER ☹] and [READY ☺]. To clear the alternate flashing, change the mode on the wireless remote controller.</div></td></tr></tbody></table> <div>TA: Room temp. Ts: Setup temp.</div>	Remote controller command	Control outline	STOP	Operation stops.	FAN	Fan operation	COOL	Cooling operation	DRY	Dry operation	HEAT	Heating operation	AUTO (Heat recovery system outdoor unit type)	<div>• TA and Ts automatically select COOL/HEAT operation mode for operation.</div> <div>• The operation is performed as shown in the following figure according to TA value at the first time only. (In the range of $T_s - 1 < TA < T_s + 1$, Cooling thermostat OFF (Fan) / Setup air volume operation continues.)</div> <div></div> <div>* Heat recover system outdoor unit type can select automatic mode. While a wireless remote controller is used, the mode is notified by “Pi Pi” (two times) receiving sound and the alternate flashing of [TIMER ☹] and [READY ☺]. To clear the alternate flashing, change the mode on the wireless remote controller.</div>	
Remote controller command	Control outline																
STOP	Operation stops.																
FAN	Fan operation																
COOL	Cooling operation																
DRY	Dry operation																
HEAT	Heating operation																
AUTO (Heat recovery system outdoor unit type)	<div>• TA and Ts automatically select COOL/HEAT operation mode for operation.</div> <div>• The operation is performed as shown in the following figure according to TA value at the first time only. (In the range of $T_s - 1 < TA < T_s + 1$, Cooling thermostat OFF (Fan) / Setup air volume operation continues.)</div> <div></div> <div>* Heat recover system outdoor unit type can select automatic mode. While a wireless remote controller is used, the mode is notified by “Pi Pi” (two times) receiving sound and the alternate flashing of [TIMER ☹] and [READY ☺]. To clear the alternate flashing, change the mode on the wireless remote controller.</div>																
3	Room temp. control	<div>1) Adjustment range: Remote controller setup temperature (°C)</div> <table><thead><tr><th></th><th>COOL/DRY</th><th>HEAT</th><th>AUTO*</th></tr></thead><tbody><tr><td>Wired type</td><td>18 to 29</td><td>18 to 29</td><td>18 to 29</td></tr><tr><td>Wireless type</td><td>17 to 30</td><td>17 to 30</td><td>17 to 30</td></tr></tbody></table>		COOL/DRY	HEAT	AUTO*	Wired type	18 to 29	18 to 29	18 to 29	Wireless type	17 to 30	17 to 30	17 to 30	<div>* For Heat recovery system outdoor unit type</div>		
	COOL/DRY	HEAT	AUTO*														
Wired type	18 to 29	18 to 29	18 to 29														
Wireless type	17 to 30	17 to 30	17 to 30														







No.	Item	Outline of specifications	Remarks																
3	Room temp. control (Continued)	<div>2) By setting the CODE No. 06, the setup temperature in heating operation can be compensated.</div> <table><tr><th>Setup data</th><td>0</td><td>2</td><td>4</td><td>6</td></tr><tr><th>Setup temp. compensation</th><td>+0°C</td><td>+2°C</td><td>+4°C</td><td>+6°C</td></tr></table> <div>The initial factory default value</div> <table><tr><th>Model</th><th>Set data</th></tr><tr><td>Floor standing cabinet, Floor standing concealed, Floor standing</td><td>0</td></tr><tr><td>Other models</td><td>2</td></tr></table>	Setup data	0	2	4	6	Setup temp. compensation	+0°C	+2°C	+4°C	+6°C	Model	Set data	Floor standing cabinet, Floor standing concealed, Floor standing	0	Other models	2	<div>Return air temperature shift of heating operation</div> <div>Except while sensor of the remote controller is controlled (Code No. [32], “0001”)</div>
Setup data	0	2	4	6															
Setup temp. compensation	+0°C	+2°C	+4°C	+6°C															
Model	Set data																		
Floor standing cabinet, Floor standing concealed, Floor standing	0																		
Other models	2																		
4	Automatic capacity control	<div>1) Based on the difference between TA and Ts, the operation capacity is determined by the outdoor unit.</div> <div><div><div>TA (°C)</div><div><div>COOL</div><div></div></div></div><div><div>TA (°C)</div><div><div>HEAT</div><div></div></div></div></div>	<div>Ts: Setup temp.</div> <div>TA: Room temp.</div>																
5	Automatic cooling/heating control	<div>1) The judgment of selecting COOL/HEAT is carried out as shown below. When TA exceeds Tsh by 1.5 for 10 minutes, the operation is thermostat OFF then, the heating operation (thermostat OFF) is changed to cooling operation.</div> <div><div><div>TA (°C)</div><div><div>Cooling</div><div></div></div></div></div> <div>Description in the parentheses shows an example of cooling ON/OFF.</div> <div>When TA is less than Tsh by 1.5 for 10 minutes, the operation is thermostat OFF then, the cooling operation (thermostat OFF) is changed to heating operation.</div> <div>2) For the automatic capacity control after judgment of cooling/heating, refer to item No.4.</div> <div>3) For temperature compensation of room temp. control in automatic heating, refer to item No.3.</div>	<div>* For Heat recovery system outdoor unit type</div> <div>Tsc: Setup temp. in cooling operation</div> <div>Tsh: Setup temp. in heating operation + temp. compensation of room temp. control</div>																

No.	Item	Outline of specifications	Remarks
6	Air speed selection	<p>1) By the command from remote control, fan speed is changed. ((HH), (H+), (H), (L+), (L) or [AUTO])</p> <p>2) When the air speed mode [AUTO] is selected, the air speed varies by the difference between TA and Ts.</p> <p><COOL></p>  <p style="text-align: center;">< > : Indicate automatic cooling.</p> <ul style="list-style-type: none"> • Air speed mode [AUTO] in case when remote controller sensor works is equal to that in case when indoor unit sensor works. • If the air speed has been changed once, it is not changed for 3 minutes. However when the air volume is changed, the air speed changes. • When cooling operation has started, select a downward slope for the air speed, that is, the high position. • If the temperature is just on the difference boundary, the air speed is not changed. <p><HEAT></p>  <p style="text-align: center;">< > : Indicate automatic heating.</p> <p style="text-align: center;"> () : indicate the value when the remote controller sensor is worked. Indoor unit sensor works. Remote controller sensor works. </p> <ul style="list-style-type: none"> • If the air speed has been changed once, it is not changed for 1 minute. However when the air speed changed, the air speed changes. • When heating operation has started, select an upward slope for the air speed, that is, the high position. • If the temperature is at the difference boundary, the air speed is not changed. • If TC2 $\geq 60^{\circ}\text{C}$, the air speed increases by 1 step. 	<p>HH > H+ > H > L+ > L > UL</p> <p>Fan speed 4-way cassette Compact 4-way 2-way cassette 1-way cassette (SH) Depends on fan speed mode selection at the remote controller. (H+) and (L+) cannot be selected. For Floor Standing Concealed Type, or Floor Standing Cabinet Type, (HH), (H), (L) or [AUTO] can be selected regardless of remote controller models.</p> <p>Code No. 32 0000: Indoor unit sensor (Main unit) 0001: Remote controller sensor</p> <p>TC2: Temperature of indoor heat exchanger sensor</p>







No.	Item	Outline of specifications						Remarks																																																																																																																																																									
6	Air speed selection (Continued):							Setting of height ceiling mode at CODE No. [5D] or at SW501 on P.C.board.																																																																																																																																																									
		4-way, compact 4-way (only UP015), 2-way, 1-way (SH) (Air speed selection of UP012 or less and UP018 for Compact 4-way are only Standard.)																																																																																																																																																															
		<table><tr><th rowspan="2">CODE No. [5d]</th><th colspan="2">Factory default</th><th colspan="2">Type 1</th><th colspan="2">Type 3</th><th colspan="2">Type 6</th></tr><tr><th colspan="2">0000</th><th colspan="2">0001</th><th colspan="2">0003</th><th colspan="2">0006</th></tr><tr><td>SW501 (1)/(2)</td><td colspan="2">OFF/OFF</td><td colspan="2">ON/OFF</td><td colspan="2">OFF/ON</td><td colspan="2">ON/ON</td></tr><tr><td>Tap</td><td>COOL</td><td>HEAT</td><td>COOL</td><td>HEAT</td><td>COOL</td><td>HEAT</td><td>COOL</td><td>HEAT</td></tr><tr><td>F1</td><td></td><td></td><td></td><td></td><td>HH</td><td>HH</td><td>HH</td><td>HH</td></tr><tr><td>F2</td><td></td><td></td><td>HH</td><td>HH</td><td></td><td></td><td></td><td></td></tr><tr><td>F3</td><td></td><td></td><td></td><td>H+</td><td>H+, H</td><td>H+, H</td><td>H+, H, L+, L</td><td>H+, H, L+, L</td></tr><tr><td>F4</td><td></td><td></td><td>H+</td><td></td><td></td><td></td><td></td><td></td></tr><tr><td>F5</td><td></td><td>HH</td><td></td><td>H</td><td></td><td></td><td></td><td></td></tr><tr><td>F6</td><td>HH</td><td></td><td>H+</td><td></td><td>L+</td><td>L+</td><td></td><td></td></tr><tr><td>F7</td><td>H+</td><td>H+</td><td></td><td></td><td>L</td><td>L</td><td></td><td></td></tr><tr><td>F8</td><td></td><td>H</td><td></td><td>L+</td><td></td><td></td><td></td><td></td></tr><tr><td>F9</td><td>H</td><td></td><td>L+</td><td>L</td><td></td><td></td><td></td><td></td></tr><tr><td>FA</td><td></td><td>L+</td><td>L</td><td></td><td></td><td></td><td></td><td></td></tr><tr><td>FB</td><td>L+</td><td>L</td><td></td><td></td><td></td><td></td><td></td><td></td></tr><tr><td>FC</td><td>L</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></tr><tr><td>FD</td><td>LL</td><td>LL</td><td>LL</td><td>LL</td><td>LL</td><td>LL</td><td>LL</td><td>LL</td></tr></table>								CODE No. [5d]	Factory default		Type 1		Type 3		Type 6		0000		0001		0003		0006		SW501 (1)/(2)	OFF/OFF		ON/OFF		OFF/ON		ON/ON		Tap	COOL	HEAT	COOL	HEAT	COOL	HEAT	COOL	HEAT	F1					HH	HH	HH	HH	F2			HH	HH					F3				H+	H+, H	H+, H	H+, H, L+, L	H+, H, L+, L	F4			H+						F5		HH		H					F6	HH		H+		L+	L+			F7	H+	H+			L	L			F8		H		L+					F9	H		L+	L					FA		L+	L						FB	L+	L							FC	L								FD	LL	LL	LL	LL	LL	LL	LL	LL
CODE No. [5d]	Factory default		Type 1		Type 3		Type 6																																																																																																																																																										
	0000		0001		0003		0006																																																																																																																																																										
SW501 (1)/(2)	OFF/OFF		ON/OFF		OFF/ON		ON/ON																																																																																																																																																										
Tap	COOL	HEAT	COOL	HEAT	COOL	HEAT	COOL	HEAT																																																																																																																																																									
F1					HH	HH	HH	HH																																																																																																																																																									
F2			HH	HH																																																																																																																																																													
F3				H+	H+, H	H+, H	H+, H, L+, L	H+, H, L+, L																																																																																																																																																									
F4			H+																																																																																																																																																														
F5		HH		H																																																																																																																																																													
F6	HH		H+		L+	L+																																																																																																																																																											
F7	H+	H+			L	L																																																																																																																																																											
F8		H		L+																																																																																																																																																													
F9	H		L+	L																																																																																																																																																													
FA		L+	L																																																																																																																																																														
FB	L+	L																																																																																																																																																															
FC	L																																																																																																																																																																
FD	LL	LL	LL	LL	LL	LL	LL	LL																																																																																																																																																									
		Floor standing																																																																																																																																																															
		<table><tr><th rowspan="2">CODE No. [5d]</th><th colspan="2">Standard</th></tr><tr><th colspan="2">0000</th></tr><tr><td>SW501 (1)/(2)</td><td colspan="2">OFF/OFF</td></tr><tr><td>Tap</td><td>COOL</td><td>HEAT</td></tr><tr><td>F1</td><td></td><td></td></tr><tr><td>F2</td><td></td><td></td></tr><tr><td>F3</td><td></td><td></td></tr><tr><td>F4</td><td></td><td></td></tr><tr><td>F5</td><td></td><td>HH</td></tr><tr><td>F6</td><td>HH</td><td></td></tr><tr><td>F7</td><td>H+</td><td>H+</td></tr><tr><td>F8</td><td></td><td>H</td></tr><tr><td>F9</td><td>H</td><td></td></tr><tr><td>FA</td><td></td><td>L+</td></tr><tr><td>FB</td><td>L+</td><td>L</td></tr><tr><td>FC</td><td>L</td><td></td></tr><tr><td>FD</td><td>LL</td><td>LL</td></tr></table>								CODE No. [5d]	Standard		0000		SW501 (1)/(2)	OFF/OFF		Tap	COOL	HEAT	F1			F2			F3			F4			F5		HH	F6	HH		F7	H+	H+	F8		H	F9	H		FA		L+	FB	L+	L	FC	L		FD	LL	LL																																																																																																						
CODE No. [5d]	Standard																																																																																																																																																																
	0000																																																																																																																																																																
SW501 (1)/(2)	OFF/OFF																																																																																																																																																																
Tap	COOL	HEAT																																																																																																																																																															
F1																																																																																																																																																																	
F2																																																																																																																																																																	
F3																																																																																																																																																																	
F4																																																																																																																																																																	
F5		HH																																																																																																																																																															
F6	HH																																																																																																																																																																
F7	H+	H+																																																																																																																																																															
F8		H																																																																																																																																																															
F9	H																																																																																																																																																																
FA		L+																																																																																																																																																															
FB	L+	L																																																																																																																																																															
FC	L																																																																																																																																																																
FD	LL	LL																																																																																																																																																															
		3)In heating operation, the mode changes to [LL] if thermostat is turned off.																																																																																																																																																															






No.	Item	Outline of specifications	Remarks
7	Prevention of cold air discharge	<div>1. In heating operation, the lowest temperature between TC1 sensor and the highest temperature between TC2 and TCJ sensor is set as the upper bound of the fan speed mode control.</div> <div><div><div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></</div></div></div></div>	






No.	Item	Outline of specifications	Remarks
9	Refrigerant (Oil) recovery control in cooling operation	<p>The indoor unit which is under STOP/Thermostat-OFF status or which operates in [FAN] mode performs the following controls when it received the refrigerant oil recovery signal from the outdoor unit at the cooling operation.</p> <ol style="list-style-type: none"> 1) Opens PMV of the indoor unit with a constant opening degree. 2) Operates the drain pump for approx. 1 minute during recovery control and after finish of control. Louvers may open depending on indoor unit types. 	<ul style="list-style-type: none"> • Recovery operation normally takes place when it detect that the refrigerant is less. • A model with a drain pump : 4-way cassette Compact 4-way 2-way cassette 1-way cassette (YH) (SH)
10	Refrigerant (Oil) recovery control in heating operation	<p>The indoor unit which is under STOP/Thermostat-OFF status or which operates in [FAN] mode performs the following controls when it received the refrigerant (Oil) recovery signal from the outdoor unit at the heating operation.</p> <ol style="list-style-type: none"> 1) Opens PMV of the indoor unit with a constant opening degree. 2) Detects temperature of TC2 and then closes PMV. 3) Counts No. of recovery controls and operates the indoor fan and the drain pump for approx. 1 minute after finish of recovery control until the control count reaches the specified count. Louvers may open depending on indoor unit types. 	<ul style="list-style-type: none"> • The indoor unit which is under thermostat-OFF (COOL) status or which operates in [FAN] mode stops the indoor fan and displays [READY ]. • Recovery operation normally takes place when it detect that the refrigerant is less. • A model with a drain pump : 4-way cassette Compact 4-way 2-way cassette 1-way cassette (YH) (SH)
11	Compensation control for short intermittent operation	<ol style="list-style-type: none"> 1) For 3 minutes after start of operation, the operation is forcedly continued even if the unit enters in Thermostat-OFF condition. 2) However the thermostat is OFF giving prior to COOL/HEAT selection, READY  for operation and protective control. 	Usually the priority is given to 5 minutes at outdoor controller side.
12	Drain pump control	<ol style="list-style-type: none"> 1) Drain pump operates while in cooling operation. (including DRY operation) 2) While the drain pump is operating, if the float switch is operated, the outdoor unit will stop operating but the drain pump will keep continuously operating. After that, the check code is issued. 3) When the drain pump stops operating, if the float switch is operated, the outdoor unit will stop and the drain pump will start operating. After the float switch is being operating for roughly 5 minutes, the check code will be issued. 	<p>Check Code [P10]</p> <ul style="list-style-type: none"> • A model with a drain pump : 4-way cassette Compact 4-way 2-way cassette 1-way cassette (YH) (SH)
13	Elimination of retained heat	<ol style="list-style-type: none"> 1) When the unit stopped from [HEAT] operation, the indoor fan operates with [L] for approx. 30 seconds. 	
14	HA control	<ol style="list-style-type: none"> 1) ON/OFF operation is available by input of HA signal from the remote site when connecting to remote controller or the remote ON/OFF interface. 2) The HA terminal is ON/OFF depending on HA control output. 3) The I/O specifications of HA is in accordance with JEMA standard. 	<p>When using HA terminal (CN61) for the remote ON/OFF, a connector sold separately is necessary.</p> <p>In case of group operation, use the connector to connect HA terminal to either master or follower indoor unit.</p>




No.	Item	Outline of specifications	Remarks																																																
15	Display of filter sign [] (Not provided to the wireless type)	<div>1) The filter sign is displayed with LC by sending the filter-reset signal to the remote controller when the specified time (150H/2500H) elapsed as a result of integration of the operation time of the indoor fan.</div> <div>2) The integrated timer is cleared when the filter-reset signal is received from the remote controller. In this time, if the specified time elapsed, the counted time is reset and the liquid crystal display is deleted.</div> <table><tr><th>Filter service life</th><th>2500H</th><th>150H</th></tr><tr><td>Type</td><td>4-way cassette type Compact 4-way cassette type 1-way cassette type (SH, YH) 2-way cassette type</td><td>Floor standing type Floor standing concealed type Floor standing cabinet type</td></tr></table>	Filter service life	2500H	150H	Type	4-way cassette type Compact 4-way cassette type 1-way cassette type (SH, YH) 2-way cassette type	Floor standing type Floor standing concealed type Floor standing cabinet type	[ FILTER] goes on. The filter sign is not displayed in RBC-ASCU11*.																																										
Filter service life	2500H	150H																																																	
Type	4-way cassette type Compact 4-way cassette type 1-way cassette type (SH, YH) 2-way cassette type	Floor standing type Floor standing concealed type Floor standing cabinet type																																																	
16	Display of [ Operation standby] [ Heating standby]	<div><Operation standby> Displayed on the remote controller</div> <div>1) When the following check codes are indicated<ul style="list-style-type: none">• Open phase of power supply wiring [P05] was detected.• There is an indoor unit that detected the indoor overflow [P10].• There is an indoor unit that detected the interlock alarm [L30].</div> <div>2) During forced thermostat OFF<ul style="list-style-type: none">• [COOL/DRY] operation is unavailable because the other indoor unit operates with [HEAT] mode.• [HEAT] operation is unavailable because COOL priority (SW11-bit1 of the Outdoor I/F P. C. board is ON) is set and the other indoor unit operates with [COOL/DRY] mode.</div> <div>3) The above indoor units that cannot operate stay in thermostat OFF status.</div> <div>4) The indoor fan stops because the system performs [Recovery operation for heating refrigerant (Oil)].</div> <div><Heating standby> Displayed on the remote controller The indoor fan stops in order to prevent discharge of cool air when heating operation started or during heating operation. (including the defrost operation during thermostat OFF)</div>	<div>• <  Operation standby> display No display for wireless type remote controller</div> <div>• <  Heating standby> display</div>																																																
17	Selection of central control mode	<div>1) Selection of the contents that can be operated by the remote controller at the indoor unit side is possible according to setting at the central controller side.</div> <div>2) Setting contents</div> <table><tr><th rowspan="2">Operation from TCC-LINK central control</th><th colspan="6">Operation on remote controller</th></tr><tr><th>ON/OFF setting</th><th>Operation selection</th><th>Timer setting</th><th>Temp. setting</th><th>Air speed setting</th><th>Air direction setting</th></tr><tr><td>Individual</td><td>○</td><td>○</td><td>○</td><td>○</td><td>○</td><td>○</td></tr><tr><td>[Central 1]</td><td>×</td><td>○</td><td>×</td><td>○</td><td>○</td><td>○</td></tr><tr><td>[Central 2]</td><td>×</td><td>×</td><td>×</td><td>×</td><td>○</td><td>○</td></tr><tr><td>[Central 3]</td><td>○</td><td>×</td><td>○</td><td>×</td><td>○</td><td>○</td></tr><tr><td>[Central 4]</td><td>○</td><td>×</td><td>○</td><td>○</td><td>○</td><td>○</td></tr></table>	Operation from TCC-LINK central control	Operation on remote controller						ON/OFF setting	Operation selection	Timer setting	Temp. setting	Air speed setting	Air direction setting	Individual	○	○	○	○	○	○	[Central 1]	×	○	×	○	○	○	[Central 2]	×	×	×	×	○	○	[Central 3]	○	×	○	×	○	○	[Central 4]	○	×	○	○	○	○	
Operation from TCC-LINK central control	Operation on remote controller																																																		
	ON/OFF setting	Operation selection	Timer setting	Temp. setting	Air speed setting	Air direction setting																																													
Individual	○	○	○	○	○	○																																													
[Central 1]	×	○	×	○	○	○																																													
[Central 2]	×	×	×	×	○	○																																													
[Central 3]	○	×	○	×	○	○																																													
[Central 4]	○	×	○	○	○	○																																													

(○: Operation possible ×: Operation impossible)

No.	Item	Outline of specifications	Remarks
18	Louver control	<p>1) Louver position setup</p> <ul style="list-style-type: none"> When the louver position is changed, the position moves necessarily to downward discharge position once to return to the set position. The louver position can be set up in the following operation range. <p>In cooling/dry operation In heating/fan operation</p> <div style="display: flex; justify-content: space-around; align-items: center;">   </div> <ul style="list-style-type: none"> In group twin/triple operation, the louver positions can be set up collectively or individually. <p>In case that HEAT refrigerant recovery control was performed in STOP status, the louver position becomes horizontal when the operation is resumed.</p> <p>2) Swing setup 4-way cassette, Compact 4-way, 2-way cassette, 1-way cassette (SH), Floor standing :</p> <ul style="list-style-type: none"> [SWING] is displayed and the following display is repeated. <p style="text-align: center;">In all operations</p> <div style="display: flex; align-items: center; justify-content: center;">    </div> <p style="text-align: center;">(Repeats)</p> <ul style="list-style-type: none"> In group operation, the louver positions can be set up collectively or individually. <p>1-way cassette (YH) :</p> <ul style="list-style-type: none"> [SWING] is displayed and the following display is repeated. <p style="text-align: center;">In all operations</p> <div style="text-align: center;">  </div> <ul style="list-style-type: none"> In group operation, the louver positions can be set up collectively or individually. <p>3) When the unit stopped or the warning was output, the louver is automatically set to full closed position.</p> <p>4) When PRE-HEAT (Heating ready) is displayed (Heating operation started or defrost operation is performed), heating thermostat is off or self-cleaning is performed, the louver is automatically set to horizontal discharge position.</p> <p>* The louver which air direction is individually set or the locked louver closes fully when the unit stops and the louver is automatically set to horizontal discharge position when PRE-HEAT (Heating ready) is displayed, heating thermostat is off.</p>	<p>Subject model : 4-way cassette Compact 4-way 2-way cassette 1-way cassette (SH)</p>

No.	Item	Outline of specifications	Remarks
18	Louver control (Continued)	<p><<Individual air direction setup>></p> <ul style="list-style-type: none"> Pushing  Louver select button enables every discharge port to set up the air direction. The louver numbers that are displayed on the display part correspond to those in the following figure. In case of no input (key operation) for approx. 5 seconds during setting of individual air direction (during displaying of louver No. on the remote controller screen), the remote controller screen returns to the normal display screen. For the air direction illustration during normal operation, the air direction of the least No. among the louvers which are block-set is displayed. While individual air direction is being set, the remote controller operation (Illustration of air direction) and operation of the real machine are linked. When selecting a case,  Louver select button is not pushed or louver No. is not displayed, the air directions of all the louvers are collectively set up. <div data-bbox="518 795 1093 1411">  <p>Indoor unit drain pipe</p> <p>Indoor unit refrigerant pipe</p> <p>Electrical control box</p> <p>01 [F1]</p> <p>02 [F2]</p> <p>03 [F3]</p> <p>04 [F4]</p> <p>4-way cassette type</p> </div> <div data-bbox="518 1444 1061 2038">  <p>Drain pipe</p> <p>Refrigerant pipe</p> <p>01 [F1]</p> <p>02 [F2]</p> <p>03 [F3]</p> <p>04 [F4]</p> <p>Compact 4-way cassette type</p> </div>	<p>Subject model : 4-way cassette Compact 4-way</p> <p>Setup from the remote controller without  button is unavailable.</p>

No.	Item	Outline of specifications	Remarks												
18	Louver control (Continued)	<p><<Selection of Swing mode>></p> <ul style="list-style-type: none">For the Swing mode, the following three types of modes are selectable and settable by keeping Swing/Direction  button pushed for 4 seconds or more on the remote controller. (In the case of RBC-AMT*) Swing mode can be selected by Code No.(DN) setup [F0]. <p>1) Standard (4 pieces: same phase) swing → Data: [0001 (At shipment)] When Swing operation is selected, four louvers align at the horizontal discharge position and then start the Swing operation at the same time.</p> <p>2) Dual swing → Data: [0002] When operation is selected, the louvers of louver No. [1] and [03] move to the horizontal discharge position, the louvers of louver No. [02] and [04] move to the downward discharge position and then start the Swing operation at the same time.</p> <p>3) Cycle swing → Data: [0003] When operation is selected, the louver No. [01] moves to the horizontal discharge position, [03] to the downward discharge position, [02] and [04] to the middle position and then start the Swing operation at the same time.</p> <ul style="list-style-type: none">In case of selecting the Swing mode, “Dual swing” or “Cycle swing”, the following numerals is displayed at the center of the remote controller screen for approx. 3 seconds when  button was pushed to select [SWING]. (No display for the standard swing) (In the case of RBC-AMT*) <div><div><p>Alternate lighting (0.5 sec.)</p><p>Dual swing</p></div><div><p>Alternate lighting (0.5 sec.)</p><p>Cycle swing</p></div></div> <p><<Louver lock (Louver fix)>></p> <ul style="list-style-type: none">For the air direction setup for each discharge port, the louver position can be locked during the normal operation.An arbitrary air direction of an arbitrary louver can be registered and set by keeping  button pushed for 4 seconds or more on the remote controller. (In the case of RBC-AMT*) Louver lock can be selected by Code No.(DN) setup [F1], [F2], [F3] or [F4]. (In the case of RBC-ASCU11*)The louver lock can be set by registering the setup data to Code No.(DN) [F1] to [F4] according to the following table. <table><tr><th>Code No.(DN)</th><th>Objective louver No.</th><th>Setup data</th></tr><tr><td>F1</td><td>01</td><td rowspan="4">0000: Release (At shipment) 0001: Horizontal discharge position ~ 0005: Downward discharge position</td></tr><tr><td>F2</td><td>02</td></tr><tr><td>F3</td><td>03</td></tr><tr><td>F4</td><td>04</td></tr></table>	Code No.(DN)	Objective louver No.	Setup data	F1	01	0000: Release (At shipment) 0001: Horizontal discharge position ~ 0005: Downward discharge position	F2	02	F3	03	F4	04	<p>Subject model : 4-way cassette Compact 4-way</p> <p>Carry out setting operation during stop of the unit; otherwise the unit stops operation.</p> <p>Carry out setting operation during stop of the unit; otherwise the unit stops operation.</p>
Code No.(DN)	Objective louver No.	Setup data													
F1	01	0000: Release (At shipment) 0001: Horizontal discharge position ~ 0005: Downward discharge position													
F2	02														
F3	03														
F4	04														

No.	Item	Outline of specifications	Remarks																		
18	Louver control (Continued)	<div><ul style="list-style-type: none">If there is the locked louver in the unit, [] goes on the remote controller screen.While the following controls are performed, the louvers operate even if executing the louver lock.</div> <table><tr><th></th><th>Control which ignores lock</th><th>Objective louver No.</th></tr><tr><td>①</td><td>Operation stop</td><td>Full-close position</td></tr><tr><td>②</td><td>When heating operation started</td><td>Horizontal discharge position</td></tr><tr><td>③</td><td>Heating thermostat OFF</td><td>Horizontal discharge position</td></tr><tr><td>④</td><td>During defrost operation</td><td>Horizontal discharge position</td></tr><tr><td>⑤</td><td>Initialize operation</td><td>Full-close position</td></tr></table> <div><ul style="list-style-type: none">The real louver corresponding to the louver No. displayed on the remote controller screen during setting of louver lock operates swinging.</div>		Control which ignores lock	Objective louver No.	①	Operation stop	Full-close position	②	When heating operation started	Horizontal discharge position	③	Heating thermostat OFF	Horizontal discharge position	④	During defrost operation	Horizontal discharge position	⑤	Initialize operation	Full-close position	<div>For the setting operation, refer to [How to set louver lock] of Installation Manual.</div> <div>It is position check operation and it does not link with the real louver and air direction setup (Illustration on the remote controller screen).</div>
	Control which ignores lock	Objective louver No.																			
①	Operation stop	Full-close position																			
②	When heating operation started	Horizontal discharge position																			
③	Heating thermostat OFF	Horizontal discharge position																			
④	During defrost operation	Horizontal discharge position																			
⑤	Initialize operation	Full-close position																			
19	DC motor	<div><div>1) When the fan starts, positioning is performed for the starter and the rotor. (Vibrate slightly)</div><div>2) DC motor operates according to the command from the indoor controller.</div><div>(Note) If the fan rotates by entry of outside air, etc while the air conditioner stopped, the indoor unit may operate as the fan motor stops.</div><div>(Note) If the fan lock was detected, the operation of the indoor unit stops and the check code is displayed.</div></div>	<div>Check code [P12]</div> <div>Subject model :</div> <div>4-way cassette</div> <div>Compact 4-way</div> <div>2-way cassette</div> <div>1-way cassette (SH)(YH)</div> <div>Floor standing</div>																		
20	Power saving mode	<div>(In the case of RBC-AMT*)</div> <div><div>1. Push the  button on the remote controller</div><div>2. The “” segment lights up on the wired remote controller display.</div><div>3. The requirement capacity ratio is limited to approximately 75 %.</div><div>4. If the power saving operation is enabled, the settings are retained when the operation is stopped, when the mode is changed, or when the power is reset. The power saving operation will be enabled at the next time the operation starts.</div></div> <div><ul style="list-style-type: none">The operation may differ depending on the connected outdoor unit. Refer to the Service Manual of the outdoor unit.</div>																			

6. APPLIED CONTROL AND FUNCTIONS

6-1. Optional connector Specifications of Indoor P.C.Board

(MCC-1643)

Connector No.	Color	Function	4-way Smart Cassette	Compact 4-way Smart Cassette	2-way Cassette	1-way Cassette (SH)	Floor standing	Pin No.	Specifications	Remarks
CN32	White	Ventilation output	○	○	○	○	○	① ②	DC12V Output (Open collector)	Setting at shipment: Interlock of ON by indoor unit operation, with OFF by stop operation * The single operation setting by FAN button on the remote controller is performed on the remote controller (DN=31).
CN34	Red	Input for float SW	●	●	●	●	X (With short-circuit connector)	① ② ③	DC12V NC Float SW input	Normal when between ①-③ short-circuits, but abnormal when open-circuits. (check code "P10" appears)
CN61	Yellow	HA	○	○	○	○	○	① ② ③ ④ ⑤ ⑥	ON/OFF input 0V (COM) Remote controller prohibited input Operation output (Open collector) DC12V (COM) Warning output (Open collector)	HA ON/OFF input (J01: YES/NO=Pulse (At shipment from factory) /Static input selection) Permission/Prohibition of remote controller operation stop is performed by input. Operation ON (Answer back of HA) Warning output ON
CN71	White	CHK Operation check	○	○	○	○	○	① ②	Check mode input 0V	This check is used to check indoor operation. (Performs operation of indoor fan "H", Louver horizontal and Drain pump ON without communication with outdoor and remote controller)
CN72	White	DISP Exhibition mode	○	○	○	○	○	① ②	DISP mode input 0V	Communication is available by indoor unit and remote controller only (When the power is turned on). Shortening time of timer (Always)
CN81	Black	Output for PMV relay	△	△	△	△	△	① ② ③ ④ ⑤	DC12V EP valve output (Open collector) Balance valve output (Open collector) Suction valve output (Open collector) Discharge valve output (Open collector)	
CN309	Yellow	Output power supply for option	○	○	○	○	○	① ③	AC230V AC230V	This can be used as power supply for option devices.
CN501	White	(For service)	x	x	x	x	x	—		
CN521	Red	Connection for option P.C.board	△	△	△	△	△	① ② ③ ④ ⑤	DC12V DC5V Send Receive 0V	Connected Application control kit (TCB-PCUC2E)

● : Use in standard, ○ : Available, △ : Use by connecting parts sold separately, x : Unavailable

* To use the functions operated by CN60, CN80, CN70 and CN73, which are provided for other P.C.board, use the Application control kit (TCB-PCUC2E) sold separately.

(MCC-1744)

Connector No.	Color	Function	Floor standing concealed	Floor standing cabinet	Pin No.	Specifications	Remarks
CN032	White	Ventilation output	○	○	① ②	DC12V (COM) Output (Open collector)	Setting at shipment: Interlock of ON by indoor unit operation, with OFF by stop operation * The single operation setting by FAN button on the remote controller is performed on the remote controller (DN=31).
CN033	White	Louver output	×	×	① ③	AC230V AC230V	Output is AC200V when louver is ON.
CN034	Red	Input for float SW	×	×	① ② ③	DC12V NC Float SW input	Normal when between ①-③ short-circuits, but abnormal when open-circuits. (check code "P10" appears)
CN060	White	Option output	○	○	① ② ③ ④ ⑤ ⑥	DC12V (COM) Defrost output (Open collector) Thermostat-off output (Open collector) Cooling output (Open collector) Heating output (Open collector) Fan output (Open collector)	ON when outdoor unit is on defrost operation. ON when actual thermostat is ON (Comp. ON). ON when the operation mode is on cooling system (Cool, Dry, Auto (Cooling)). ON when the operation mode is on heating system (Heat, Auto (Heating)). ON when the indoor fan is on, (When an air cleaner is used) OFF when the clean operation is on.
CN061	Yellow	HA	○	○	① ② ③ ④ ⑤ ⑥	ON/OFF input 0V (COM) Remote controller prohibited input Operation output (Open collector) DC12V (COM) Warning output (Open collector)	HA ON/OFF input (J01: YES/NO=Pulse (At shipment from factory) /Static input selection) Permission/Prohibition of remote controller operation stop is performed by input. Operation ON (Answer back of HA) Warning output (Open collector)
CN068	Blue	Drain pump output	×	×	① ③	AC230V AC230V	Output is AC200V in cooling and float SW operation.
CN070	White	Filter	○	○	① ②	Input 0V	Option abnormal input (Display of protective operation for equipment installed to the outside) * Perform the settings having option abnormal input from the remote controller. (DN [2A] = 0002 → 0001).
CN071	White	CHK Operation check	○	○	① ②	Check mode input 0V	Use for operation check of indoor unit. (Performs operation of indoor fan "H" , Louver horizontal and Drain pump ON without communication with outdoor and remote controller)
CN072	White	DISP Exhibition mode	○	○	① ②	DISP mode input 0V	Communication is available by indoor unit and remote controller only (When the power is turned on). Shortening time of timer (Always)
CN073	Red	EXCT demand	○	○	① ②	Demand input 0V	Forced thermostat OFF operation for indoor unit
CN080	Green	External abnormal input	○	○	① ② ③	DC12V NC External abnormal input	Make the check code of "L30" occur (by continuing operation for one min) and perform the forced stop.
CN081	Black	Output for PMV relay	△	△	① ② ③ ④ ⑤	DC12V EP valve output (Open collector) Balance valve output (Open collector) Suction valve output (Open collector) Discharge valve output (Open collector)	
CN309	Yellow	Output power supply for option	○	○	① ③	AC230V AC230V	This can be used as power supply for option devices.
CN501	White	(For service)	×	×		AC230V	

● : Use in standard, ○ : Available, △ : Use by connecting parts sold separately, × : Unavailable

6-2. Test Operation of Indoor Unit

▼ Check function for operation of indoor unit (Functions at indoor unit side)

This function is provided to check the operation of the indoor unit individually without connecting to the remote controller or the outdoor unit. This function can be used regardless of the ON/OFF operation.

However, it is recommended to avoid using this function for a long time, otherwise the trouble of the equipment may occur.

[How to operate]

- 1) Short-circuit CHK pin (CN71 on the indoor P.C. board).
The operation mode may differ according to the indoor unit status at that time.
Normal time: Both float SW and fan motor are normal.
Abnormal time: Either one of float SW or fan motor is abnormal.
- 2) During the normal time, the minimum opening degree (30pls) of the indoor PMV can be set only when both CHK pin (CN71) and DISP pin (CN72) on the indoor P.C. board are short-circuited. If the short-circuit at DISP pin (CN72) is opened, the indoor PMV will be at the maximum opening degree (1500pls)

[How to clear]

Open CHK pin, If the system is on operation, it will temporarily stop then automatically restart after a while.

	Short-circuit of CHK pin		
	Normal time		Abnormal time
	DISP pin open	DISP pin short circuit	
Fan motor	(H)	(H)	Stop
Indoor PMV (*)	Max. opening degree (1500 pls)	Min. opening degree (30 pls)	Min. opening degree (30 pls)
Louver	Vertical	Vertical	Immediate stop
Communication	All ignored	All ignored	All ignored
P.C. board LED	Lights	Lights	Flashes

* The actual indoor PMV opening degree may differ from the described values due to adjustment depending on PMV types.

- To exchange the indoor PMV coil, set the indoor PMV to Max. opening degree.

6-3. Method to Set Indoor Unit Function DN Code (I.DN)

(When performing this task, be sure to use a wired remote controller.)

◆ Procedure






Be sure to stop the air conditioner before making settings


<RBC-AMT*>

- 1 Push the  +  +  buttons simultaneously and hold for at least 4 seconds.


The unit No. displayed first is the address of the header indoor unit in group control.

Then the fan and louver of the selected indoor unit move.

- 2 Each time the “Select unit” side of the  button is pressed, one of the indoor unit Nos. under group control is displayed in turn. Then the fan and louver of the selected indoor unit move.
- 3 Use the  button to select the CODE No. (DN code) of the desired function.
- 4 Use the  button to select the desired SET DATA associated with the selected function.
- 5 Push the  button. (The display changes from flashing to steady.)
 - To change the selected indoor unit, go back to step 2.
 - To change the selected function, go back to step 3.
- 6 When the  button is pushed, the system returns to normal off state.




<RBC-ASCU11*>



1 Push and hold menu button and [∇] setting button simultaneously for 10 seconds or more.


- After a while, the display flashes as shown in the figure. “ALL” is displayed as indoor unit numbers during initial communication immediately after the power has been turned on.



2 Each time [∇] [△] setting button is pushed, indoor unit numbers in the group control change cyclically. Select the indoor unit to change settings for.

- The fan of the selected indoor unit runs . The indoor unit can be confirmed for which to change settings.

3 Push OFF timer button to confirm the selected indoor unit.



4 Push the menu button to make Code No. [04] flash. Change Code No. [04] with [∇] [△] setting button.

5 Push the menu button to make Set data [0001] flash. Change Set data [0001] with [∇] [△] setting button.

Priority set 0001 No priority set 0000

6 Push OFF timer button to complete the set up.

- To change other settings of the selected indoor unit, repeat from Procedure 4.

7 When all the settings have been completed, push ON/OFF button to finish the settings. (Return to the normal mode)

“ SETTING ” flashes and then the display content disappears and the air conditioner enters the normal stop mode. (The remote controller is unavailable while “ SETTING ” is flashing.)

- To change settings of another indoor unit, repeat from Procedure 1.

Indoor unit function Code No. (DN Code) table

(includes functions needed to perform applied control on site)

DN	Item	Description	At shipment
01	Filter display delay timer	0000: None 0001: 150H 0002: 2500H 0003: 5000H 0004: 10000H	Depending on model type
02	Dirty state of filter	0000: Standard 0001: High degree of dirt (Half of standard time)	0000: Standard
03	Central control address	0001: No.1 unit to 0064: No.64 unit ... TCC-LINK 0001: No.1 unit to 0128: No.128 unit ... TU2C-LINK 00Un: Unfixed (When using U series remote controller) 0099: Unfixed (Other than U series remote controller)	00Un/0099: Unfixed
04	Specific indoor unit priority	0000: No priority 0001: Priority	0000: No priority
06	Heating temp. shift	0000: 0 °C 0001: +1 °C 0002: +2 °C to 0010: +10 °C (Up to +6 recommended)	Depending on model type
0b	Demand control (CN73 / CN4)	0000: Demand input 0001: O2 sensor input 0002: Card input setup.1 0003: Fire alarm input (Normal open) 0004: Card input setup.2 0005: Fire alarm input (Normal close)	0000: Demand input
0d	Existence of [AUTO] mode	0000: Provided 0001: Not provided (Automatic selection from connected outdoor unit)	0001: Not provided
0F	Cooling only	0000: Heat pump 0001: Cooling only (No display of [AUTO] [HEAT])	0000: Heat pump
10	Type	Refer to Type DN code "10" list	Depending on model type
11	Indoor unit capacity	0000: Unfixed 0001 to 0034 Refer to Indoor Unit Capacity DN code "11" list	According to capacity type
12	Line address	0001: No.1 unit to 0064: No.30 unit ... TCC-LINK 0001: No.1 unit to 0128: No.128 unit ... TU2C-LINK 00Un: Unfixed (When using U series remote controller) 0099: Unfixed (Other than U series remote controller)	00Un/0099: Unfixed
13	Indoor unit address	0001: No.1 unit to 0064: No.64 unit ... TCC-LINK 0001: No.1 unit to 0128: No.128 unit ... TU2C-LINK 00Un: Unfixed (When using U series remote controller) 0099: Unfixed (Other than U series remote controller)	00Un/0099: Unfixed
14	Group address	0000: Individual 0001: Header unit of group 0002: Follower unit of group 00Un: Unfixed (When using U series remote controller) 0099: Unfixed (Other than U series remote controller)	00Un/0099: Unfixed
19	Louver type (Air direction adjustment)	0000: No louver 0001: Swing only 0004: (4-way Air Discharge Cassette type, etc.)	Depending on model type
1E	Temp difference of [AUTO] mode selection COOL → HEAT, HEAT → COOL	0000: 0 °C to 0010: 10 °C (Ts ± 5°C) Ts: Remote controller setup temp.	0003: 3 °C (Ts ± 1.5 °C)
28	Automatic restart of power failure	0000: None 0001: Restart	0000: None
2A	Selection of option/Trouble input (TCB-PCUC2E: CN3)	0000: Filter input 0001: Alarm input 0002: None (Air washer, etc.)	0002: None
2E	HA terminal (CN61) select	0000: Usual 0001: Card input setup.1 0002: Fire alarm input (arbiter contact) 0003: Card input setup.2	0000: Usual (HA terminal)
31	Ventilating fan control	0000: Unavailable 0001: Available	0000: Unavailable
32	TA sensor selection	0000: Indoor unit TA sensor 0001: Remote controller sensor	0000: Indoor unit TA sensor
33	Temperature unit select	0000: °C 0001: °F	0000: °C

DN	Item	Description		At shipment
5d	External static pressure High-ceiling adjustment (Air flow selection)	Refer to next page.		0000: Standard
60	Timer setting (wired remote controller)	0000: Available (can be performed)	0001: Unavailable (cannot be performed)	0000: Available
77	Dual set point	0000: Unavailable	0002: Available	0000: Unavailable
79	Alarm output setup of the header unit	0000: Not including the state of following unit	0001: Including the state of following unit	0000: Not including the state of following unit
b3	Soft cooling	0000: Unavailable	0001: Available	0001: Available
b5	Occupancy sensor/ Wireless A-B selection Provided / None	0000: None 0002: Wireless remote controller provided	0001: Occupancy sensor provided	0000: None
b6	Occupancy sensor Enable / Invalid (Absence time judgment time)	0000: Invalid 0002: 60min. 0005: 150min.	0001: 30min. 0004: 120min.	0002: Enable (60 min.)
b7	Occupancy sensor operation at absent time	0000: Stand by	0001: operation stop	0000: Stand by
CF	Indoor unit case type	0000: Standard Model	0001: larger case model	Depending on model type
d0	Whether the power saving mode can be set by the remote controller	0000: Invalid	0001: Valid	0001: Valid
E6	Wireless remote controller A-B selection	0000: A	0001: B	0000: A
F0	Swing mode	0001 : Standard 0003 : Cycle swing	0002 : Dual swing	0001: Standard
F1	Louver fixed position (Louver No.1)	0000 : Release 0005 : Downward discharge position	0001 : Horizontal discharge position	0000: Not fixed
F2	Louver fixed position (Louver No.2)	0000 : Release 0005 : Downward discharge position	0001 : Horizontal discharge position	0000: Not fixed
F3	Louver fixed position (Louver No.3)	0000 : Release 0005 : Downward discharge position	0001 : Horizontal discharge position	0000: Not fixed
F4	Louver fixed position (Louver No.4)	0000 : Release 0005 : Downward discharge position	0001 : Horizontal discharge position	0000: Not fixed
F6	Presence of Application control kit (TCB-PCUC2E)	0000: None	0001: Exist	0000: None
FC	Communication protocol	0000: TCC-LINK	0003: TU2C-LINK	0000: TCC-LINK
Fd	Priority operation mode (FS unit)	0000: Heating	0001: Cooling	0000: Heating
FE	FS unit address	0001: No.1 unit to 0064: No.64 unit ... TCC-LINK 0001: No.1 unit to 0128: No.128 unit ... TU2C-LINK 00Un: Unfixed (When using U series remote controller) 0099: Unfixed (Other than U series remote controller)		00Un/0099: Unfixed
103	Remote controller	0000: Use	0001: Do not use	0000 : Use

DN	Item	Description	At shipment
180	Notice code number 01	0000: None 0001 ~ 0255 : Notice code 0129 : Notice code (201) 0130 : Notice code (202) (0001 ~ 0255 : TU2C-LINK only)	0000: None
181	Notice code number 02		0000: None
182	Notice code number 03		0000: None
183	Notice code number 04		0000: None
184	Notice code number 05		0000: None
185	Notice code number 06		0000: None
186	Notice code number 07		0000: None
187	Notice code number 08		0000: None
188	Notice code number 09		0000: None
189	Notice code number 10		0000: None
103	Remote controller	0000: Use 0001: Do not use	0000 : Use
1FB	Central device control state	0000: No central device control (Remote controller use is possible) 0001: Central device control (Remote controller use is impossible)	0000: No central device control
1FC	Indoor Unit terminating resistance	0000: OFF 0001: ON	0000: OFF

*1 Display order of "00Un" and "0099" varies depending on remote controller models or communication types.

For Central control address (DN [03]), Indoor unit address (DN [13]), FS unit address (DN [FE])

Remote controller	Communication type	Display order
U series	TU2C-LINK	... ⇔ 0128 ⇔ 00Un ⇔ 0001 ⇔ ...
	TCC-LINK	... ⇔ 0064 ⇔ 00Un ⇔ 0001 ⇔ ...
Other than U series	TCC-LINK	... ⇔ 0064 ⇔ 0099 ⇔ 0001 ⇔ ...

For Line address (DN [12])

Remote controller	Communication type	Display order
U series	TU2C-LINK	... ⇔ 0128 ⇔ 00Un ⇔ 0001 ⇔ ...
	TCC-LINK	... ⇔ 0030 ⇔ 00Un ⇔ 0001 ⇔ ...
Other than U series	TCC-LINK	... ⇔ 0030 ⇔ 0099 ⇔ 0001 ⇔ ...

For Group address (DN [14])

Remote controller	Communication type	Display order
U series	TU2C-LINK	... ⇔ 0002 ⇔ 00Un ⇔ 0000 ⇔ ...
	TCC-LINK	
Other than U series	TCC-LINK	... ⇔ 0002 ⇔ 0099 ⇔ 0000 ⇔ ...

*2 Communication protocol can be automatically switched with the setup in the outdoor unit during installation.

[5d] External static pressure & High-ceiling adjustment

<4-way Cassette, 2-way Cassette, 1-way Cassette SH Type>

Set data	High-ceiling adjustment
0000	Standard (Factory default)
0001	High ceiling 1
0003	High ceiling 3

<Compact 4-way Cassette>

Set data	High-ceiling adjustment
0000	Standard (Factory default)
0001	High ceiling 1 (UP015 only)
0003	High ceiling 3 (UP015 only)

<Under Ceiling type>

Set data	High-ceiling adjustment
0000	Standard (Factory default)
0003	High ceiling 1

<Concealed Duct Type>

Set data	External static pressure	
0000	40 Pa	UP024 to 030 (Factory default)
0001	30 Pa	UP007 to 018 (Factory default)
0002	65 Pa	—
0003	50 Pa	UP036 to 056 (Factory default)
0004	80 Pa	—
0005	100 Pa	—
0006	120 Pa	—

<Slim Duct type>

Set data	External static pressure	
0000	10 Pa	Standard (Factory default)
0001	20 Pa	High static pressure 1
0003	35 Pa	High static pressure 2
0006	50 Pa	High static pressure 3

<Concealed Duct High Static Pressure Type (6 HP or less)>

Set data	External static pressure	
0000	100 Pa	Standard (Factory default)
0001	50 Pa	—
0002	75 Pa	—
0003	150 Pa	—
0004	125 Pa	—
0005	175 Pa	—
0006	200 Pa	—

<Concealed Duct High Static Pressure Type (8, 10 HP)>

Set data	External static pressure	
0000	150 Pa	Standard (Factory default)
0001	50 Pa	—
0002	83 Pa	—
0003	217 Pa	—
0004	117 Pa	—
0005	183 Pa	—
0006	250 Pa	—

Type DN code "10"

Value	Type	Model
0000	1-way cassette	MMU-UP***SH*
0001	4-way cassette	MMU-UP***H*
0002	2-way cassette	MMU-UP***WH*
0003	1-way cassette	MMU-UP***YH*
0006	Concealed Duct / High Static Pressure	MMD-UP***HP*
0007	Under Ceiling	MMC-UP***HP*
0008	High Wall	MMK-UP***HP*
0010	Floor standing cabinet	MML-UP***H*
0011	Floor standing concealed	MML-UP***BH*
0013	Floor standing type	MMF-UP***H
0014	Compact 4-way cassette	MMU-UP***MH*
0016	Fresh Air Intake indoor unit (Duct type)	MMD-UP***HFP*
0018	Bi-flow Console	MML-UP***NHP*
0060	Hot Water Module	MMW-UP***LQ*

Indoor Unit Capacity DN code "11"

Value	Capacity
0000*	Invalid
0001	007 type
0002	008 type
0003	009 type
0004	010 type
0005	012 type
0006	014 type
0007	015 type
0008	017 type
0009	018 type
0010	020 type
0011	024 type
0012	027 type
0013	030 type
0015	036 type
0017	048 type
0018	056 type
0021	072 type 144 type *1
0023	096 type 192 type *1
0024	112 type
0025	128 type

*1 The following indoor unit has 2 P.C.boards mounted in 1 unit. Setting required on all of the P.C.boards.

- MMF-AP1444DH-V
- MMF-AP1924DH-V
- MMF-AP1444H-V*
- MMF-AP1924H-V*
- MMF-AP1445DHP-V*
- MMF-AP1925DHP-V*
- MMF-AP1445HP-V*
- MMF-AP1925HP-V*

* "0000" is default value stored in EEPROM mounted on service P.C. board

6-4. Method to Set Outdoor Unit Function Code No. (O.DN)

The settings can be changed by operating the switches on the interface board.
In the TU2C-Link communication system, it can also be done by operating the wired remote controller.

◆ Applicable controls setup

(settings at the site)


Basic procedure

Be sure to stop the air conditioner before making settings.

(Change the setup while the air conditioner is networking.)

When switching settings from the interface P.C. board of the outdoor unit


1. Set the rotary switch of the interface P.C. board on the outdoor unit to SW01= [9], SW02= [1] and SW03= [1].
2. The 7-segment display shows “d n.S E t”.
3. When SW04 is pressed, the 7-segment display switches to “d n.0 0 1” and the outdoor unit code NO. [001] is displayed.
4. Change outdoor unit code NO. [* * *] with SW05 or SW06.
Press SW05 to advance the code. Press and hold SW05 to advance in 5 steps.
Press SW06 to return the code. Press and hold SW06 to return in 5 steps.
5. When SW04 is pressed, the 7-segment display blinks “d.* * * *” and the setting data [* * * *] being set is displayed.
6. Change setting data [* * * *] with SW05 or SW06.
Press SW05 to advance the data. Press SW06 to return the setting data.
7. Push and hold SW04 for more than 2 seconds.
When the flashing stops and remain lit on the display, the setting is complete.
(To return to the item code setting after completing the setting, or to return to the item code setting without setting, press SW04 once.)
8. Set the rotary switch on the interface P.C. board of the outdoor unit back to SW01= [1], SW02= [1], SW03= [1].
9. Reset the power of the outdoor unit (power off for one minute or more) .



When switching from the wired remote controller (RBC-ASCU11*)


Basic procedure

Be sure to stop the air conditioner before making settings.
(Change the setup while the air conditioner is not working.)



1 Push and hold menu button and [Δ] setting button simultaneously for 10 seconds or more.


- After a while, the display flashes as shown in the figure. "ALL" is displayed as outdoor unit numbers during initial communication immediately after the power has been turned on.



2 Each time [∇] [Δ] setting button is pushed, outdoor unit numbers in the group control change cyclically. Select the outdoor unit to change settings for.

- The fan of the selected outdoor unit runs. The outdoor unit can be confirmed for which to change settings.

3 Push OFF timer button to confirm the selected outdoor unit.



- 4** Push the menu button to make Code No. [**] flash.
Change Code No. [**] with [▽] [△] setting button.
- 5** Push the menu button to make Set data [****] flash.
Change Set data [****] with [▽] [△] setting button.
- 6** Push OFF timer button to complete the set up.
• To change other settings of the selected outdoor unit, repeat from Procedure **4** .
- 7** When all the settings have been completed, push ON/OFF button to finish the settings.
(Return to the normal mode).
“SETTING” flashes and then the display content disappears and the air conditioner enters the normal stop mode. (The remote controller is unavailable while “SETTING” is flashing.)
• To change settings of another outdoor unit, repeat from Procedure **1** .

DN	Item	Description	At shipment																																																												
003	Type Setting	<div>Code range : 0000 to 0255</div> <table border="1"><thead><tr><th>Model name</th><th>O.DN[003]</th><th>Model name</th><th>O.DN[003]</th></tr></thead><tbody><tr><td>Undefined</td><td>0000</td><td>MMY-MUP1601*****</td><td>0006</td></tr><tr><td>MMY-MUP0801*****</td><td>0001</td><td>MMY-MUP1801*****</td><td>0007</td></tr><tr><td>MMY-MUP1001*****</td><td>0002</td><td>MMY-MUP2001*****</td><td>0008</td></tr><tr><td>MMY-MUP1201*****</td><td>0003</td><td>MMY-MUP2201*****</td><td>0009</td></tr><tr><td>MMY-MUP1401*****</td><td>0004</td><td>MMY-MUP2401*****</td><td>0010</td></tr><tr><td>MMY-MUP14A1*****</td><td>0005</td><td></td><td></td></tr></tbody></table> <div>* DN Code [003] = 0000 : Undefined</div>	Model name	O.DN[003]	Model name	O.DN[003]	Undefined	0000	MMY-MUP1601*****	0006	MMY-MUP0801*****	0001	MMY-MUP1801*****	0007	MMY-MUP1001*****	0002	MMY-MUP2001*****	0008	MMY-MUP1201*****	0003	MMY-MUP2201*****	0009	MMY-MUP1401*****	0004	MMY-MUP2401*****	0010	MMY-MUP14A1*****	0005			According to type																																
Model name	O.DN[003]	Model name	O.DN[003]																																																												
Undefined	0000	MMY-MUP1601*****	0006																																																												
MMY-MUP0801*****	0001	MMY-MUP1801*****	0007																																																												
MMY-MUP1001*****	0002	MMY-MUP2001*****	0008																																																												
MMY-MUP1201*****	0003	MMY-MUP2201*****	0009																																																												
MMY-MUP1401*****	0004	MMY-MUP2401*****	0010																																																												
MMY-MUP14A1*****	0005																																																														
004	7-segment Display Contents Control	0000 : Outdoor unit No. 0001 : Start priority number	0000 : Outdoor unit No.																																																												
005	Prohibition/Permission of the NFC Setting	0000 : Until 48 hours elapsed from the outdoor unit Power ON, WTA App can start a test operation. After 48 hours, it cannot. 0001 : Regardless of the elapsed time, WTA cannot start test operation. 0002 : Regardless of the elapsed time, WTA can start test operation.	0000																																																												
007	Compressor Maintenance Period Time	0000 : 0h 0001 to 0063 (1000 h to 63000 h)	0000 : 0h																																																												
008	Operation Mode Selection Control	0000 : Non-selected Indoor units keep stand-by state (thermostat OFF). 0001 : Changing non-selected indoor units the mode selected	0000 : Non-Priority																																																												
009	Capacity / Power Demand Control	0000 : Capacity demand 0001 : Power demand	0000 : Capacity demand																																																												
00A	Power consumption upper limit standard value setting Heating (For power demand)_High	<div>Code range [0A] [0C] : 0000 to 0255 (1 kW to 255 kW) [0B] [0D] : 0000 to 0099 (0.00 kW to 0.99 kW)</div> <table border="1"><thead><tr><th rowspan="3">Power consumption upper limit standard value</th><th colspan="3">DN Code</th></tr><tr><th>Heating</th><th>[00A]</th><th>[00B]</th></tr><tr><th>Cooling</th><th>[00C]</th><th>[00D]</th></tr></thead><tbody><tr><td>No power demand function</td><td>0000</td><td>0000</td><td></td></tr><tr><td>0.01 kW</td><td>0000</td><td>0001</td><td></td></tr><tr><td>0.02 kW</td><td>0000</td><td>0002</td><td></td></tr><tr><td>-</td><td>-</td><td>-</td><td></td></tr><tr><td>-</td><td>-</td><td>-</td><td></td></tr><tr><td>10.00 kW</td><td>0010</td><td>0000</td><td></td></tr><tr><td>-</td><td>-</td><td>-</td><td></td></tr><tr><td>-</td><td>-</td><td>-</td><td></td></tr><tr><td>30.50 kW</td><td>0030</td><td>0050</td><td></td></tr><tr><td>-</td><td>-</td><td>-</td><td></td></tr><tr><td>-</td><td>-</td><td>-</td><td></td></tr></tbody></table>	Power consumption upper limit standard value	DN Code			Heating	[00A]	[00B]	Cooling	[00C]	[00D]	No power demand function	0000	0000		0.01 kW	0000	0001		0.02 kW	0000	0002		-	-	-		-	-	-		10.00 kW	0010	0000		-	-	-		-	-	-		30.50 kW	0030	0050		-	-	-		-	-	-		0000 : 0kW						
Power consumption upper limit standard value	DN Code																																																														
	Heating	[00A]		[00B]																																																											
	Cooling	[00C]	[00D]																																																												
No power demand function	0000	0000																																																													
0.01 kW	0000	0001																																																													
0.02 kW	0000	0002																																																													
-	-	-																																																													
-	-	-																																																													
10.00 kW	0010	0000																																																													
-	-	-																																																													
-	-	-																																																													
30.50 kW	0030	0050																																																													
-	-	-																																																													
-	-	-																																																													
00b	Power consumption upper limit standard value setting Heating (For power demand)_Low		0000 : 0kW																																																												
00c	Power consumption upper limit standard value setting Cooling (For power demand)_High		0000 : 0kW																																																												
00d	Power consumption upper limit standard value setting Cooling (For power demand)_Low		0000 : 0kW																																																												
00E	Setting Value during Demand Control	<div>Setting Value during Demand Control for demand standard specifications can be set with DN code [00E]. Its value for expansion specifications can be set in two steps (DN codes [00F], [010]) during the normal operation and demand control (setting value DN Code [00E]).</div> <table border="1"><thead><tr><th></th><th colspan="3">DN Code</th></tr><tr><th>Demand control</th><th>[00E]</th><th>[00F]</th><th>[010]</th></tr></thead><tbody><tr><td>100%</td><td>0</td><td>0</td><td>0</td></tr><tr><td>95%</td><td>1</td><td>1</td><td>1</td></tr><tr><td>90%</td><td>2</td><td>2</td><td>2</td></tr><tr><td>85%</td><td>3</td><td>3</td><td>3</td></tr><tr><td>80%</td><td>4</td><td>4</td><td>4 (Factory default)</td></tr><tr><td>75%</td><td>5</td><td>5</td><td>5</td></tr><tr><td>70%</td><td>6</td><td>6</td><td>6</td></tr><tr><td>65%</td><td>7</td><td>7</td><td>7</td></tr><tr><td>60%</td><td>8</td><td>8 (Factory default)</td><td>8</td></tr><tr><td>55%</td><td>9</td><td>9</td><td>9</td></tr><tr><td>50%</td><td>10</td><td>10</td><td>10</td></tr><tr><td>-</td><td>11 to 14</td><td>11 to 14</td><td>11 to 14</td></tr><tr><td>0%</td><td>15 (Factory default)</td><td>15</td><td>15</td></tr></tbody></table>		DN Code			Demand control	[00E]	[00F]	[010]	100%	0	0	0	95%	1	1	1	90%	2	2	2	85%	3	3	3	80%	4	4	4 (Factory default)	75%	5	5	5	70%	6	6	6	65%	7	7	7	60%	8	8 (Factory default)	8	55%	9	9	9	50%	10	10	10	-	11 to 14	11 to 14	11 to 14	0%	15 (Factory default)	15	15	0015 : 0% (Forcedly stop)
	DN Code																																																														
Demand control	[00E]	[00F]	[010]																																																												
100%	0	0	0																																																												
95%	1	1	1																																																												
90%	2	2	2																																																												
85%	3	3	3																																																												
80%	4	4	4 (Factory default)																																																												
75%	5	5	5																																																												
70%	6	6	6																																																												
65%	7	7	7																																																												
60%	8	8 (Factory default)	8																																																												
55%	9	9	9																																																												
50%	10	10	10																																																												
-	11 to 14	11 to 14	11 to 14																																																												
0%	15 (Factory default)	15	15																																																												
00F	Setting value during Demand Control (Expansion 1)		0008 : 60%																																																												
010	Setting Value during Demand Control (Expansion 2)		0004 : 80%																																																												
012	Optional Output Setting Control 1 (CN514)	0000 : Compressor Operation Output 0001 : Operating Rate Output	0000 : Compressor Operation Output																																																												
018	Priority Operation Mode Setting	0000 : Priority heating 0002 : Priority operation unit No. 0001 : Priority cooling 0003 : Priority indoor unit	0000 : Priority heating																																																												
019	Outdoor Fan High Static Pressure Shift	0000 : Usual 0001 : High Static Pressure Operation	0000 : Usual																																																												
01A	Operation standby Heating standby	0000 : None 0001 : Standby	0000 : None																																																												

DN	Item	Description	At shipment
01d	System cooperation defrosting settings 1 (number cooperating)	0000 : None (vassal) 0001 : Prohibition 0002 : 2-system cooperation (master unit) 0003 : 3-system cooperation (master unit) * set [01D] = 0002 or 0003 to outdoor unit set to master unit in outdoor DN code [01F]	0000: None (vassal)
01E	System cooperation defrosting settings 2 (zone address)	0000 : None 0001 to 0128: Addresses 0001 when not using central controller for control for system cooperation defrosting, 0001 to 0128 when using central controller	0000: None
01F	System cooperation defrosting settings 3 (cooperation address)	0000: None 0001: Master unit 0002 or 0003: Vassal units 2 or 3	0000 : None
03d	Existence of Automatic Back Up	0000 : Provided 0001 : Not provided	0000 : Provided
03F	Operation Control during Overflow Detection of Indoor Unit	0000 : System abnormal stop 0001 : System continuous operation (Stop the corresponding indoor unit.)	0000 : System abnormal stop
040	Operation Control during Outside Abnormal Input Switching control in receiving [L30][L02] from indoor)	0000 : System continuous operation (Stop the corresponding indoor unit.) 0001 : System abnormal stop	0000 : System continuous operation (Stop the corresponding indoor unit.)
082	Communication setting	0000: TCC-Link 0003 : TU2C-Link	0000: TCC-Link

6-5. Applied Control of Indoor Unit

Control system using Remote location ON/OFF control box (TCB-IFCB-4E2)

Wiring and setting


- In the case of group control, the control system functions as long as it is connected to one of the indoor units (control P.C. board) in the group. If it is desired to access the operation and trouble statuses of other units, relevant signals must be brought to it from those units individually.

▼ Control items

- | | |
|-------------------------------|---|
| (1) Start / Stop input signal | Start / stop of unit |
| (2) In-operation signal | Output present while unit in normal operation |
| (3) Check code Output | present while alarm (e.g. serial communication trouble or operation of protective device for indoor / outdoor unit) being activated |

▼ Wiring diagram of control system using Remote location ON/OFF control box (TCB-IFCB-4E2)

Input IFCB-4E2: No-voltage ON / OFF serial signal
Output No-voltage contact (in-operation and check code indication)
Contact capacity: Max. AC 240 V, 0.5 A



▼ Ventilating fan control from remote controller

[Function]

- The start / stop operation can be operated from the wired remote controller when air to air heat exchanger or ventilating fan is installed in the system.
- The fan can be operated even if the indoor unit is not operating.
- Use a fan which can receive the no-voltage normally-open contact as an outside input signal.
- In a group control, the units are collectively operated and they cannot be individually operated.

1. Operation

Handle a wired remote controller in the following procedure.

- * Use the wired remote controller during stop of the system.
- * Be sure to set up the wired remote controller to the header unit. (Same in group control)
- * In a group control, if the wired remote controller is set up to the header unit, both header and follower units are simultaneously operable.

<RBC-AMT*>

- 1 Push concurrently  +  +  buttons for 4 seconds or more.

The unit No. displayed firstly indicates the header indoor unit address in the group control.
In this time, the fan of the selected indoor unit turns on.

- 2 Every pushing  button (left side of the button), the indoor unit numbers in group control are displayed successively.

In this time, the fan of the selected indoor unit only turns on.

- 3 Using the setup temp  or  button, specify the CODE No. 31.

- 4 Using the timer time  or  button, select the SET DATA. (At shipment: 0000)

The setup data are as follows:

SET DATA	Handling of operation of air to air heat exchanger or ventilating fan
0000	Unavailable (At shipment)
0001	Available


- 5 Push  button. (OK if display goes on.)

- To change the selected indoor unit, go to the procedure 2).
- To change the item to be set up, go to the procedure 3).

- 6 Pushing  returns the status to the usual stop status.

* The ventilating fan control may be unavailable depending on the remote controllers.
(RBC-ASCU11* does not have this function.)

2. Wiring



▼ Auto-off feature control


[Function]

- This function controls the indoor units individually. It is used when the start operation from outside is unnecessary but the stop operation is necessary.
- A card switch box or card lock helps protect customers from forgetting to turn off the indoor unit. (not including the following Card Input 2)
- It is connected with connector on the indoor control P.C. board, and switched with the Code No. and jumper wire setup for use.
- Available connectors are CN61 or CN73. For models without CN73, CN4 on the optional Application control kit (TCB-PCUC2E) can be used.
- * Leaving-ON prevention control cannot be set with both CN61 and CN73 (CN4).
If both of them are set, CN73 (CN4) setting automatically turns to a factory default.

[Setup method]


(1) Wiring

Connecting to the CN61 connector



NOTE) Determine the cable length between the indoor control P.C. board and the relay within 3m.

Connecting to the Application control kit (TCB-PCUC2E, connector : CN4)



NOTE) Determine the cable length between the indoor control P.C. board and the relay within 3m.

(2) Code (DN) setup

Set Code (DN) according to "Indoor unit function Code No. (DN Code) table".

Connector	Jumper wire (J01)	Code No. (DN)	Set data	Function
CN61	Short-circuit (Factory default)	002E	0000 (Factory default)	"HA normal setup" (pulse)
			0001	"Card Input 1" setup
			0003	"Card Input 2" setup
	Open-circuit (cut)		0000 (Factory default)	"HA normal setup" (Static)
			0001	"Card Input 3" setup
			0003	"Card Input 4" setup
CN73 (CN4)	Short-circuit (Factory default) or Open-circuit (cut)	000b	0000 (Factory default)	"EXCT demand" setup (Forced thermostat-OFF)
			0002	"Card Input 3" setup
			0004	"Card Input 4" setup

* If you set "Card Input 1 to 4" for Code No. of CN61 and CN73, Code No. 000b setup becomes unavailable and the functions of Card Input 3 or 4 in CN73 cannot be used.

[Control items]

Code No. (DN)	Code No. (DN)	
	ON (Status that card is inserted)	OFF (Status that card is taken out)
Card Input 1	Manual prohibition release (Manual operation)	Manual prohibition (Operation stop)
Card Input 2	Manual prohibition release (Automatic operation)	Manual prohibition (Operation stop)
Card Input 3	Operation status continues (Do nothing)	Operation status continues and setting temperature changes (COOL/DRY: 29°C, HEAT: 18°C)
Card Input 4	Manual prohibition release (The status returns to operating condition before removing the card.)	Manual prohibition (Operation stop)

* For the card switch box that does not involve contact operation described above, convert signals with a relay including a normally-closed contact.

■ Power peak-cut from indoor unit

When the relay is turned on, a forced thermostat OFF operation starts.

- For indoor P.C. boards other than MCC-1643, the “EXCT” is input with connector CN73 on the P.C. board. MCC-1643 requires Application control kit (TCB-PCUC2E) for input of a forced thermostat OFF “EXCT”. Please refer to the manual of Application control kit for a detailed setting.

6-6. Applied Control of Outdoor Unit

The outdoor fan high static pressure support and priority operation mode setting (cooling / heating / number of units / or priority indoor unit) functions are available by setting relevant switches provided on the interface P.C. board of the outdoor unit.

6-6-1. Outdoor Fan High Static Pressure Shift

Setup

Change the outdoor DN code. (O.DN [19]) into "Outdoor Fan High Static Pressure operation."

This function must be enabled with every discharge duct connected outdoor unit for both of the header and follower units.

Purpose/characteristics

Outdoor DN Code (O.DN) Setting Operation	Operation
O.DN [19] = 0000	Normal operation
O.DN [19] = 0001	Outdoor Fan High Static Pressure operation

Specifications

Increase the speed of the propeller fan units on the outdoor fan to allow the installation of a duct with a maximum external static pressure not greater than specified in the table below. If a discharge duct with a resistance greater than 15 Pa (1.5 mmAq) is to be used, enable this function. The maximum external static pressures of single units are shown below (Table 1). In the case of combined use of multiple outdoor units, set all the units to the same maximum external static pressure as the one with the lowest maximum external static pressure.

Table 1: Maximum External Static Pressures of Single Outdoor Units

Model	MMY-MUP	0801*	1001*	1201*	1401*	14A1*
Maximum external static pressure	(Pa)	80	80	80	80	80
(*) Outdoor unit air flow	(m ³ /min)	165	175	195	198	230
Model	MMY-MUP	1601*	1801*	2001*	2201*	2401*
Maximum external static pressure	(Pa)	80	80	80	80	80
(*) Outdoor unit air flow	(m ³ /min)	255	280	265	275	275

(*) Calculate duct resistance from outdoor unit air flow.

6-6-2. Priority Operation Mode Setting

Purpose/characteristics

This function allows switching between priority cooling and priority heating.

Four patterns of priority operation mode setting are available as shown in the table below. Select a suitable priority mode according to the needs of the customer.

Setup

CAUTION

In the case of the priority indoor unit mode, it is necessary to set up the specific indoor unit chosen for priority operation (a single unit only).

(1) Outdoor unit setup method (header unit)

Outdoor DN Code (O.DN) Setting	Operation
O.DN [18] = 0000	Priority heating (factory default)
O.DN [18] = 0001	Priority cooling
O.DN [18] = 0002	Priority operation based on No. of units in operation (priority given to the operation mode with the largest share of units in operation)
O.DN [18] = 0003	Priority indoor unit (priority given to the operation mode of the specific indoor unit set up for priority operation)



(2) Indoor unit setup method for priority indoor unit mode



The setting can be changed only when the system is at rest. (Be sure to turn off the system prior to this operation.)

<RBC-AMT*>

- 1 Push the  +  +  buttons simultaneously and hold for at least 4 seconds. The display window will start flashing in a little while.


Verify that the displayed CODE No. is 10.




- If the displayed CODE No. is not 10, press the  button to erase the display and repeat the procedure from the beginning.
(Note that the system does not respond to remote controller operation for about 1 minute after the  button is pushed.)
(In the case of group control, the indoor unit No. displayed first indicates the header unit.)



- 2 Each time the  button is pushed, one of the indoor unit Nos. under group control is displayed in turn. Select the indoor unit whose setting is to be changed.


The fan and flap of the selected indoor unit then come on, so that the position of this unit can be confirmed.





- 3 Use the  button to select the CODE No. 04.
- 4 Use the  button to select the SET DATA 0001.
Priority set 0001 No priority set 0000
- 5 Push the  button.

The setup is finished when the display changes from flashing to steady.

- 6 Upon finishing the setup, push the  button. (This finalizes the setting.)

When the  button is pushed, the display goes blank, and the system returns to normal off state.

(Note that the system does not respond to remote controller operation for about 1 minute after the  button is pushed.)



NOTE


Priority can be given to only one indoor unit. If more than one indoor unit is accidentally set to priority, an check code

(L5 or L6: Duplicated indoor unit priority setting) will be displayed.


All units displaying L5 have been set to 0001 (priority). Keep the unit to which priority should be given as it is, and change the value back to 0000 (no priority) for all the rest.

Check code	Description
L5	Duplicated indoor unit priority setting (The unit is set to 0001.)
L6	Duplicated indoor unit priority setting (The unit is set to 0000.)


<RBC-ASCU11*>



- 1 Push and hold menu button and [▽] setting button simultaneously for 10 seconds or more.**
 - After a while, the display flashes as shown in the figure. “ALL” is displayed as indoor unit numbers during initial communication immediately after the power has been turned on.



- 2 Each time [▽] [△] setting button is pushed, indoor unit numbers in the group control change cyclically. Select the indoor unit to change settings for.**
 - The fan of the selected indoor unit runs . The indoor unit can be confirmed for which to change settings.
- 3 Push OFF timer button to confirm the selected indoor unit.**



- 4 Push the menu button to make Code No. [04] flash. Change Code No. [04] with [▽] [△] setting button.**
- 5 Push the menu button to make Set data [0001] flash. Change Set data [0001] with [▽] [△] setting button.**
 - Priority set 0001 No priority set 0000
- 6 Push OFF timer button to complete the set up.**
 - To change other settings of the selected indoor unit, repeat from Procedure 4.
- 7 When all the settings have been completed, push ON/OFF button to finish the settings. (Return to the normal mode)**

“SETTING” flashes and then the display content disappears and the air conditioner enters the normal stop mode. (The remote controller is unavailable while “SETTING” is flashing.)

- To change settings of another indoor unit, repeat from Procedure 1.

6-6-3. Applied Control of Outdoor Unit

Optional control P.C. boards provide access to a range of functions as listed below.

No.	Function	Outdoor unit for control P.C. board Connection	Control P.C. board to be used			Outdoor unit interface P.C. board setting*			
			TCB-PCDM4E	TCB-PCMO4E	TCB-PCIN4E	Connector No.	DIP SW No.	Bit ON	Outdoor unit DN Code (O.DN)
1	Power peak-cut Control (Standard) *Limit a maximum capacity	Header unit	✓	—	—	CN513 (blue)	—	—	[009]=0 (Factory default)
	Power peak-cut Control (Standard) *Limit a maximum power	Header unit	✓	—	—	CN513 (blue)	—	—	[009]=1
	Power peak-cut Control (For one input function) *Limit a maximum capacity	Header unit	✓	—	—	CN513 (blue)	SW105	1	[009]=0 (Factory default)
	Power peak-cut Control (For one input function) *Limit a maximum power	Header unit	✓	—	—	CN513 (blue)	SW105	1	[009]=1
2	Power peak-cut Control (Enhanced Function) *Limit a maximum capacity	Header unit	✓	—	—	CN513 (blue)	SW105	2	[009]=0 (Factory default)
	Power peak-cut Control (Enhanced Function) *Limit a maximum power	Header unit	✓	—	—	CN513 (blue)	SW105	2	[009]=1
3	Snowfall Fan Control	Header unit	—	✓	—	CN509 (black)	—	—	—
4	External master ON/OFF Control	Header unit	—	✓	—	CN512 (blue)	—	—	—
5	Night operation (Sound reduction) Control	Header unit	—	✓	—	CN508 (red)	—	—	—
6	Operation Mode Selection Control	Header unit	—	✓	—	CN510 (white)	—	—	[008]=0 (Factory default)
	Operation Mode Selection Control (forced choice)	Header unit	—	✓	—	CN510 (white)	—	—	[008]=1
7	Trouble/Operation output	Header unit	—	—	✓	CN511 (green)	—	—	—
8	Compressor Operation Output	Individual outdoor unit	—	—	✓	CN514 (green)	—	—	[012]=0 (Factory default)
9	Operating Rate Output	Header unit	—	—	✓	CN514 (green)	—	—	[012]=1

To limit a maximum power, set the outdoor unit O.DN code to [009]=1, and set the criteria value of a maximum power consumption with O.DN code [00A], [00B], [00C] and [00D]. Input the values for both cooling and heating.

Outdoor unit DN Code (O.DN) [00C], [00D]

Criteria value setting for a maximum cooling power

(e.g.) When the maximum standard value of cooling power consumption is set as 19.35 kW = 19.35kW

Outdoor unit DN Code (O.DN)	[00C]	[00D]
Value	19	35

Outdoor unit DN Code (O.DN) [00A], [00B]


Criteria value setting for a maximum heating power

(e.g.) When the maximum standard value of heating power consumption is set as 14.00 kW = 14.00kW

Outdoor unit DN Code (O.DN)	[00A]	[00B]
Value	14	00


Layout of Outdoor Unit Interface P.C. Board

* For Applicable controls, switch the DIP SW on the P.C. board or set the outdoor unit O.DN.



6-6-3-1. Power peak-cut Control (Standard)

(1) Four-core cable support



Operation

The demand request signal from the outside restricts the maximum capability (or maximum electric power) of an outdoor unit.

L1: Power peak-cut control indication lamp SW1: Power peak-cut control ON switch (ON as long as target power peak-cut control has been reached or exceeded, normally OFF)*1

SW2: Power peak-cut control OFF switch (OFF as long as target power peak-cut control has not been reached or exceeded, normally ON)*1

*1 The inputs of SW1 and SW2 can be either pulse (100 msec or longer) or step signals.

Do not turn on SW1 and SW2 simultaneously.

* Be sure to provide a contact for each terminal.

Power peak-cut control settings

[2-stage switching] < SW105 bit1 OFF, bit2 OFF >

Demand: power peak-cut control

Control item	Optional P.C.board			Outdoor unit interface P.C.board			
	Input		Display relay	SW105			
	SW1	SW2	(L1)	Bit1	Bit2	Outdoor unit DN Code [00E]	
Input demand OFF signal to release the demand	OFF	ON	OFF	OFF	OFF	100% (normal operation)	100% (normal operation)
Input demand ON signal to control the demand	ON	OFF	ON	OFF	OFF	0% (forced stop)	Approx. X (50% to 100%) (upper limit regulated)

* The upper limit X% can be regulated with the outdoor DN Code (O.DN) [00E].

Outdoor unit DN Code (O.DN) [00E]	X
0	100%
1	95%
2	90%
3	85%
4	80%
5	75%
6	70%
7	65%
8	60%
9	55%
10	50%
15 (factory default)	0% (forced stop)

Note 1: Specifications of display relay contact

- The terminal for display output ([Operation] terminal) must satisfy the following electrical rating.

<Electrical Rating>

220 to 240 VAC, 10 mA or more, 1 A or less

24 VAC, 10 mA or more, 1 A or less (non-conductive load)


When connecting a conductive load (e.g. relay coil) to the display relay load, insert a surge killer CR (for an AC power supply) or a diode for preventing back electromotive force (for a DC power supply) on the bypass circuit.

Note 2: COM contact specifications

- COM terminals have DC12 V output with a basic insulation. Use a switch, such as a relay or photocoupler, insulated from a controller (locally procured) for CO (Change-Over) contact or NO (normally-open) contact.
- DC12 V has a current-limiting resistor of 3.3 Ω.
- For non-voltage contacts, use a relay with minimum applicable load of DC12V,3mA or less.

(2) Two-core cable support

Setting SW105 bit1 on I/F P.C.board of the header outdoor unit to ON allows ON/OFF power peak-cut control to be switched using [ON] terminal input (SW1) alone.



[2-stage switching] < SW105 bit1 ON, bit2 OFF >

Power peak-cut control turns ON when SW 1 in the wiring example is ON (continuous make).

Demand: power peak-cut control

Control item	Optional P.C.board		Outdoor unit interface P.C.board			
	Input	Display relay	Outdoor unit DN Code [00E]			
	SW1	(L1)	SW105 Bit1	SW105 Bit2	Factory default [00E] = 15	[00E] = 0 to 10
Input demand OFF signal to release the demand	OFF	OFF	ON	OFF	100% (normal operation)	100% (normal operation)
Input demand ON signal to control the demand	ON	ON	ON	OFF	0% (forced stop)	Approx. X (50% to 100%) (upper limit regulated)

* The upper limit X% can be regulated with the outdoor DN Code (O.DN) [00E].

Outdoor unit DN Code (O.DN) [00E]	X
0	100%
1	95%
2	90%
3	85%
4	80%
5	75%
6	70%
7	65%
8	60%
9	55%
10	50%
15 (factory default)	0% (forced stop)

Note 1: Specifications of display relay contact

- The terminal for display output ([Operation] terminal) must satisfy the following electrical rating.


<Electrical Rating>
 220 to 240 VAC, 10 mA or more, 1 A or less
 24 VAC, 10 mA or more, 1 A or less (non-conductive load)

When connecting a conductive load (e.g. relay coil) to the display relay load, insert a surge killer CR (for an AC power supply) or a diode for preventing back electromotive force (for a DC power supply) on the bypass circuit.

Note 2: COM contact specifications

- COM terminals have DC12 V output with a basic insulation. Use a switch, such as a relay or photocoupler, insulated from a controller (locally procured) for CO (Change-Over) contact or NO (normally-open) contact.
- DC12 V has a current-limiting resistor of 3.3 Ω.
- For non-voltage contacts, use a relay with minimum applicable load of DC12V,3mA or less.

The optional P.C. board should be connected to the header outdoor unit (U1).



6-6-3-2. Power peak-cut Control (Extended)

Operation

The demand request signal from the outside restricts the maximum capability (or maximum electric power) of an outdoor unit.

L1: Power peak-cut control indication lamp

SW1: Power peak-cut control ON switch*1

SW2: Power peak-cut control OFF switch*1

*1 The inputs of SW1 and SW2 can be either pulse (100 msec or longer) or step signals.

* Be sure to provide a contact for each terminal.

Extended power peak-cut control settings

[4-stage switching] <SW105 Bit1 ON, Bit2 ON>

Demand: power peak-cut control

Control item	Optional P.C.board			Outdoor unit interface P.C.board			
	Input		Display relay	SW105 Outdoor DN Code [***]			
	SW1	SW2	(L1)	Bit1	Bit2	Factory default [00E] = 15, [00F] = 8, [010] = 4	[00E] = X, [00F] = Y, [010] = Z
Input demand OFF signal to release the demand	OFF	OFF	OFF	OFF	ON	100% (normal operation)	100% (normal operation)
Input demand ON signal to control the demand	ON	OFF	ON			Approx. 80% (upper limit regulated)	Approx. Z% (50% to 100%) (upper limit regulated)
Input demand ON signal to control the demand	OFF	ON	ON			Approx. 60% (upper limit regulated)	Approx. Y% (50% to 100%) (upper limit regulated)
Input demand ON signal to control the demand	ON	ON	ON			0% (forced stop)	Approx. X% (50% to 100%) (upper limit regulated)

*The upper limit X%, Y%, Z% can be regulated with the outdoor DN Code (O.DN) [00E] [00F] [010].

Outdoor unit DN Code (O.DN) [00E]	X
0	100%
1	95%
2	90%
3	85%
4	80%
5	75%
6	70%
7	65%
8	60%
9	55%
10	50%
15 (factory default)	0% (forced stop)

Outdoor unit DN Code (O.DN) [00F]	Y
0	100%
1	95%
2	90%
3	85%
4	80%
5	75%
6	70%
7	65%
8 (factory default)	60%
9	55%
10	50%
15	0% (forced stop)

Outdoor unit DN Code (O.DN) [010]	Z
0	100%
1	95%
2	90%
3	85%
4 (factory default)	80%
5	75%
6	70%
7	65%
8	60%
9	55%
10	50%
15	0% (forced stop)

Note 1: Specifications of display relay contact

- The terminal for display output ([Operation] terminal) must satisfy the following electrical rating.

<Electrical Rating>
 220 to 240 VAC, 10 mA or more, 1 A or less
 24 VAC, 10 mA or more, 1 A or less (non-conductive load)

When connecting a conductive load (e.g. relay coil) to the display relay load, insert a surge killer CR (for an AC power supply) or a diode for preventing back electromotive force (for a DC power supply) on the bypass circuit. The optional P.C. board should be connected to the header outdoor unit (U1).

Note 2: COM contact specifications

- COM terminals have DC12 V output with a basic insulation. Use a switch, such as a relay or photocoupler, insulated from a controller (locally procured) for CO (Change-Over) contact or NO (normally-open) contact.
- DC12 V has a current-limiting resistor of 3.3 Ω .
- For non-voltage contacts, use a relay with minimum applicable load of DC12V,3mA or less.

[Power peak-cut control through electric power]

For the Power peak-cut control, the Power peak-cut control through electric power can be set by Outdoor unit DN code (O.DN) [009].

The Power peak-cut control through electric power regulates outdoor unit output so that power consumption does not exceed the upper limit value set.

(1) To change into the power peak-cut control through power, set the outdoor unit DN code to [009] = 1.

* To return to the power peak-cut control through capacity, set the outdoor unit DN code to [009] = 0.

(2) Check that the criteria value of a maximum power in cooling or heating is set to [00A] to [00D].

For the connected outdoor units system, set the criteria value of a maximum power consumption (the total of each outdoor unit power) to the header outdoor unit.

Outdoor unit DN Code (O.DN) [00C], [00D]

Criteria value setting for a maximum cooling power

(e.g.) When the maximum standard value of cooling power consumption is set as 19.35 kW = 19.35kW

Outdoor unit DN Code (O.DN)	[00C]	[00D]
Value	19	35

Outdoor unit DN Code (O.DN) [00A], [00B]

Criteria value setting for a maximum heating power

(e.g.) When the maximum standard value of heating power consumption is set as 14.00 kW = 14.00kW

Outdoor unit DN Code (O.DN)	[00A]	[00B]
Value	14	00

(3) If ON signal is input from the optional P.C. board, the power peak-cut control through electric power operates.

Input method of ON signal for power peak-cut control is the same as that for normal peak-cut control.

Refer to "Standard", "For one input function", or "Enhanced Function".

The power peak-cut control regulates the outdoor unit capacity so that it does not exceed the upper limit value (X%, Y%, Z% of the criteria value for a maximum power set in (2)) set by [00E] [00F] [010] of (O.DN).

e.g.) If the criteria value of maximum heating power during 80% demand control is set to 14.00kW, the upper limit control becomes 11.2kW (14.00kW×80%=11.20kW), the outdoor unit output is controlled so that the power consumption does not exceed 11.20kW.

NOTE 1: To protect a refrigerant cycle, the power peak-cut may not be operated during the defrost operation, oil recovery operation, or refrigerant recovery operation.

NOTE 2: For demand OFF, the outdoor unit may operate beyond the setting criteria value of a maximum power consumption because the power limit control does not function.

NOTE 3: Power consumption is estimated, causing approx. ±5 % difference from the actual power consumption.


To perform accurate power peak-cut control, use a demand controller and electric power meter.

NOTE 4: The power consumption of the indoor units is not included.

NOTE 5: When power consumption does not decrease or expected effects are not obtained, change the upper limit value of X%, Y%, Z% or the criteria value for a maximum power.

NOTE 6: In the case of Upper limit 100% (normal operation), the operation is without peak-cut control. Peak-cut control is not performed with the value set to O.DN [00A] - [00D].

6-6-3.3. Snowfall Fan Control



SW1: Snowfall detection switch (snowfall sensor)


Operation

An external snowfall signal turns on the outdoor unit fan.

Terminal	Input signal	Operation
COOL (SW1)	ON	Snowfall fan control (Turn on outdoor unit fan)
	OFF	
	ON	Normal operation (Cancels control)
	OFF	

The input signal is recognized during its rising/falling phase.
(After reaching the top/bottom of the rising/falling edge, the signal must remain there for at least 100 ms.)
The optional P.C. board should be connected to the header outdoor unit (U1).
COM terminals have DC12 V output with a basic insulation. Use a switch, such as a relay or photocoupler, insulated from a controller (locally procured) for CO (Change-Over) contact or NO (normally-open) contact. DC12 V has a current-limiting resistor of 3.3 Ω.
For non-voltage contacts, use a relay with minimum applicable load of DC12V,3mA or less.

6-6-3.4. External master ON/OFF Control



SW1: Operation input switch
SW2: Stop input switch

Operation

The system is started/stopped from the outdoor unit.

Terminal	Input signal	Operation
COOL (SW1)	ON (100ms pulse) OFF (100ms pulse) It does not matter whether the state is ON or OFF after 100 msec from the signal input. Batch-operation accepted Turn SW1 OFF before sending	Turns on all indoor units
HEAT (SW2)	ON (100ms pulse) OFF (100ms pulse) Batch-stop accepted	Turns off all indoor units


- Input signal is detected in the rising edge between OFF and ON of SW1/SW2 and the control is accepted in 100 msec from the edge.
- When COOL terminals (SW1 and SW2) are simultaneously turned ON, the control turned ON first is valid, and the control turned ON later is invalid.

CAUTION

- (1) Do not turn on the COOL (SW1) and HEAT (SW2) terminals simultaneously.
- (2) COM terminals have DC12 V output with a basic insulation. Use a switch, such as a relay or photocoupler, insulated from a controller (locally procured) for CO (Change-Over) contact or NO (normally-open) contact. DC12 V has a current-limiting resistor of 3.3 Ω.
For non-voltage contacts, use a relay with minimum applicable load of DC12V,3mA or less.





The optional P.C. board should be connected to the header outdoor unit (U1).

6-6-3-5. Night operation (sound reduction) Control



Operation

This function decreases noise at night or other times as necessary.

Terminal	Input signal	Operation
COOL (SW1)	ON 	Night time control
	OFF 	
	ON 	Normal operation
	OFF 	

The input signal is recognized during its rising/falling phase.

(After reaching the top/bottom of the rising/falling edge, the signal must remain there for at least 100 ms.)

The optional P.C. board should be connected to the header outdoor unit (U1).

The system's capacity is reduced during low-noise operation.


The table below provides a rough guide to this capacity reduction.

Model MMY-	Night operation sound reduction dB(A) (COOL/HEAT)	Capacity	
		COOL	HEAT
MUP0801*	50/50	Approx. 85%	Approx. 80%
MUP1001*	50/50	Approx. 70%	Approx. 65%
MUP1201*	50/50	Approx. 60%	Approx. 55%
MUP1401*	50/50	Approx. 70%	Approx. 65%
MUP14A1*	53/53	Approx. 85%	Approx. 80%
MUP1601*	53/53	Approx. 70%	Approx. 70%
MUP1801*	54/54	Approx. 65%	Approx. 65%
MUP2001*	54/54	Approx. 60%	Approx. 60%
MUP2201*	52/54	Approx. 55%	Approx. 55%
MUP2401*	53/54	Approx. 55%	Approx. 55%

Relative to maximum capacity

- * Position of noise measuring device: 1 m from the front face of the set and 1.5 m above ground (anechoic sound)
- COM terminals have DC12 V output with a basic insulation.
Use a switch, such as a relay or photo coupler, insulated from a controller (locally procured) for CO (Change-Over) contact or NO (normally-open) contact.
- DC12 V has a current-limiting resistor of 3.3 Ω.
- For non-voltage contacts, use a relay with minimum applicable load of DC12V,3mA or less.

6-6-3-6. Operation Mode Selection Control



NOTE


SW1: COOL mode selection switch
SW2: HEAT mode selection switch

Input signal		Operation
COOL (SW1)	HEAT (SW2)	
OFF	OFF	Normal operation
ON	OFF	Only cooling operation allowed
OFF	ON	Only heating operation allowed

Indoor unit operation intervention function


The statuses of indoor units operating in a mode other the selected operation mode can be switched by setting the outdoor DN Code of the header outdoor unit.

The optional P.C. board should be connected to the header outdoor unit (U1).

Outdoor DN Code (O.DN)	Details of Processing				
O.DN [008] = 0 (factory default)	Unallowed indoor units in a mode other than the P.C.board selection modes are not treated as priority (thermostat OFF state).				
	P.C. board selection mode	Input Signal		Remote control	Operation State
		COOL (SW1)	HEAT (SW2)		
	Normal	OFF	OFF	* or Δ	Follow the remote controller.
				✱	
				✂	
	Cooling operation only allowed	ON	OFF	* or Δ	Follow the remote controller (Normal cooling operation).
				✱	Thermostat OFF (Air blow operation at super-slow blow rate)
				✂	Follow the remote controller (Normal air blow operation).
	Heating operation only allowed	OFF	ON	* or Δ	Thermostat OFF (Air blow operation at blow rate set on remote control)
✱				Follow the remote controller (Normal heating operation).	
✂				Follow the remote controller (Normal air blow operation).	
O.DN [008]= 1	Only operation modes and air blow operation selected on the P.C.board can be selected on the remote controller. When the input signal is turned ON, indoor units operated in a mode other than the P.C.board selection mode are forcibly switched to the P.C.board selection modes.				
	P.C. board selection mode	Input Signal		Remote control	
		COOL (SW1)	HEAT (SW2)		
	Normal	OFF	OFF	✱, Δ, ✱ or ✂ can be selected.	
	COOL	ON	OFF	• Only ✱, Δ or ✂ can be selected. • Indoor units in Heat mode are forcibly switched to the Cool mode.	
	HEAT	OFF	ON	• Only ✱ or ✂ can be selected. • Indoor units in Cool or Dry mode are forcibly switched to the Heat mode.	
			When using the remote control,  (mode select control) indicator is displayed.		

- COM terminals have DC12 V output with a basic insulation. Use a switch, such as a relay or photocoupler, insulated from a controller (locally procured) for CO (Change-Over) contact or NO (normally-open) contact.
- DC12 V has a current-limiting resistor of 3.3 Ω.
- For non-voltage contacts, use a relay with minimum applicable load of DC12V,3mA or less.

6-6-3-7. Trouble/Operation Output



Operation

In-operation output: An in-operation indication signal is output as long as at least one indoor unit is in operation in the line.

Trouble output: Trouble indication signal is output if trouble occurs in at least one indoor/outdoor unit in the line.

Note 1: Output Relay (K1, K2) Contact Specifications


- Output terminals (OUTPUT1, 2) must satisfy the following electrical rating.
- When connecting a conductive load (e.g. relay coil) to loads K1 and K2, insert a surge killer CR (for an AC power supply) or a diode for preventing back electromotive force (for a DC power supply) on the bypass circuit.

<Electrical Rating>
220-240 VAC, 10 mA or more, 1A or less
24 VAC, 10 mA or more, 1 A or less (non-conductive load)

C1	Attached connection cable 1 (4wires)
CN511	Connector on interface side (green)
K1, K2	Relays
L1	Trouble indication Lamp
L2	Operation indication Lamp
OUTPUT1	Trouble output
OUTPUT2	Operation output
PJ20	Connector on optional P.C.board side
PS	Power supply unit
TB1	Terminal block

The optional P.C. board should be connected to the header outdoor unit (U1).

6-6-3-8. Compressor Operation Output




Operation

When a compressor is in operation, a relay connected to the output terminal assigned to it is turned on (closed). When it is at rest, the relay is turned off (open). The output terminals are named OUTPUT1 and OUTPUT2 from left to right when facing the front of the outdoor unit, as shown in the diagram.

Note 1: Output Relay (K1, K2) Contact Specifications


- Output terminals (OUTPUT1, 2) must satisfy the following electrical rating.
- When connecting a conductive load (e.g. relay coil) to loads K1 and K2 insert a surge killer CR (for an AC power supply) or a diode for preventing back electromotive force (for a DC power supply) on the bypass circuit.

<Electrical Rating>
 220-240 VAC, 10 mA or more, 1A or less
 24 VAC, 10 mA or more, 1 A or less (non-conductive load)



C2	Connector cable 2 ([2])
CN514	Connector on interface side (green)
CTR1	Elapsed operation counter 1
CTR2	Elapsed operation counter 2
K1, K2	Relays
L1, L2	Operation indication LEDs
OUTPUT1	Compressor 1 operation output terminal
OUTPUT2	Compressor 2 operation output terminal
PJ20	Connector on optional P.C.board side
PS	Power supply unit
TB1	Terminal block

6-6-3-9. Operating Rate Output



Operation

At the output terminals, a signal is present (relay closed) or absent (relay open) in various combinations according to the system operation factor, as shown in the diagram.

The operation rate (FA) is the percentage ratio of the current output of the system to the maximum output (100%).

Function	Outdoor DN Code [O.DN]	OUTPUT1	OUTPUT2	OUTPUT3	Operation rate (FA)
System operation rate output	O.DN [012] = 1	off	off	off	FA=0%
		on	off	off	0% < FA < 20%
		off	on	off	20% ≤ FA < 35%
		on	on	off	35% ≤ FA < 50%
		off	off	on	50% ≤ FA < 65%
		on	off	on	65% ≤ FA < 80%
		off	on	on	80% ≤ FA < 95%
		on	on	on	95% ≤ FA

off = Relay open

on = Relay closed

C2	Connector cable 2 (2)
CN514	Connector on interface side (green)
K1, K2, K3	Relays
MONITOR	Monitoring device
OUTPUT1	Output terminal for each function
OUTPUT2	Output terminal for each function
OUTPUT3	Output terminal for each function
PJ20	Connector on optional P.C.board side
TB1	Terminal block

* Connect the optional P.C. board to the header outdoor unit.

Note 1: Output Relay (K1, K2, K3) Contact Specifications

- Output terminals (OUTPUT1, 2, 3) must satisfy the following electrical rating.
- When connecting a conductive load (e.g. relay coil) to loads K1, K2 and K3, insert a surge killer CR (for an AC power supply) or a diode for preventing back electromotive force (for a DC power supply) on the bypass circuit.

<Electrical Rating>
 220-240 VAC, 10 mA or more, 1A or less
 24 VAC, 10 mA or more, 1 A or less (non-conductive load)

6-7. Notice Code


- Notice Code is a function only in TC2U-Link communication.
- When the outdoor or indoor unit detects its conditions requiring caution or maintenance, this function notices you to check your units with the spanner mark (Notice code mark) on the wired remote controller or central controller display.
- Even while the notice code mark is displayed, the air conditioner can operate normally.
- A maximum of five notice codes can be issued simultaneously in one system (line).

1. Notice Code Mark Display on Wired Remote Controller


Set the notice codes from remote controller so that the notice code mark is displayed on the remote controller display when the outdoor unit issues the notice codes.

Please follow the steps below to set the notice code on the unit.


- (1) Set the notice codes, which will be displayed, on the Indoor unit DN Code (I. DN) "180" to "189" from the remote controller.
Enter one of the notice codes for each DN Code. You can set it on any of "180" to "189".
A maximum 10 types of the notice codes can be set on a single indoor unit.
- (2) A notice code mark will be displayed on the remote controller when any of the 10 notice codes set is received into the remote controller.
If the notice code that is not set is received, a notice code mark is not displayed.
Set the notice code that you want from the remote controller.



e.g. 1. When the U1 outdoor unit detects and issues the notice code "001", the notice code mark is displayed on the remote controller connected to the indoor unit on which the "001" was set.



e.g. 2. When the U2 outdoor unit detects and issues the notice code "001" or "022", the notice code mark is displayed on the remote controller connected to the indoor unit on which the "001" or "022" were set.



2. Notice Code Display (7-segment display) on Outdoor Interface P.C. Board

The notice codes detected or issued from the outdoor unit can be confirmed with 7-segment display on the P.C. board.

(The notice codes detected or issued from the other outdoor unit cannot be displayed.)

(1) Displaying the notice code being issued now

Setting the SW01, SW02, SW03 to 1, 1, 14 respectively displays the notice code being issued from the outdoor unit on the 7-segment display 7-segment display [n. 1. . ***] *** : Notice code

Every time SW04 is pushed for 1-second, the display changes and the second notice code or each subsequent code is displayed (up to fifth code).

[n. 1. ***] (First) to [n. 2. ***] (Second) to ••• to [n. 5. ***] (Fifth) to [n. 1. ***] (First)

(2) Displaying the notice code history

Setting the SW01, SW02, SW03 to 1, 2, 14 respectively displays the notice code history being issued from the outdoor unit on the 7-segment display 7-segment display [h. 1. ***] *** : Notice code

Every time SW04 is pushed for 1-second, the display changes and the second notice code or each subsequent code is displayed (up to tenth code history).

[h. 1. ***] (First) to [h. 2. ***] (Second) ••• to [h. A. ***] (Tenth) to [h. 1. ***] (First)

(3) Clearing the notice code history

To clear the notice code history recorded in the outdoor unit, follow the steps below.

Set the SW01, SW02, SW03 to 2, 15, 8 respectively.

7-segment display [n. c]

When SW04 is pushed and held for 5-second, the notice code histories recorded in the outdoor unit are cleared.

7-segment display [n. c C L]

3. Notice Code List

Notice code No.	Item	Content
001	Compressor maintenance timer over	This notice code is detected or issued from the outdoor unit when the actual operation cumulative time of comp.1 or comp.2 exceeds the compressor maintenance time set. The compressor maintenance time is not set at the factory. To use the notice code, set the compressor maintenance time* on O.DN"007".
022	NFC tag wiring trouble	This notice code is detected or issued from the outdoor unit when NFC tag is removed, failed, or cannot communicate with the outdoor interface P.C. board. The notice code stops when NFC tag communication recovers. (Note) A notice code [022] may be issued when connecting equipment to CN800 of the outdoor interface P.C. board, but this is not a faulty connection or a failure. Issuing of the notice code [022] will stop when the equipment is removed from the CN800 and the power of the outdoor unit is turned off. Determination of NFC tag failure should be performed in a state where no equipment is connected to the CN800.

* Setting the compressor maintenance time to detect the time exceeded

Enter the compressor maintenance time to be detected as time over into Outdoor unit DN Code (O.DN) "007".

Input values $\times 1,000$ = Detection time

e.g. When O.DN [007]=20 is set

$20 \times 1,000 = 20,000$ hours ••• The notice code "001" is detected and issued when the actual operation cumulative time of comp.1 or comp.2 will exceed 20,000 hours.


6-8. System Cooperation Defrosting

Overview

This is a function in which two systems or three systems of SMMS-u are communicably connected, and the timing of defrosting at each system is offset.

Installing an indoor device of a different system in the same room and performing system cooperation defrosting suppresses the room temperature from dropping while defrosting.

*When this setup is carried out, central remote controller cannot be connected.



* In this section, system addresses are indicated by Roman numerals (I, II, III...), to differentiate from system cooperation defrosting setup addresses.


■ Setup method

- (1) Connect the header units of systems to perform system cooperation defrosting to each other by Uh (U3, U4) (Central control).
- (2) SW100-bit1 (termination resistance of Uh line) of master outdoor unit is turned on.
- (3) Do not set the same system addresses for each system that link defrosting.
For the system address, please refer to "7-4-3. Address Setup Procedure 2-2.Line (system) address setting", and set with "automatic address setting "or " address setting by remote controller"
- (4) Set the outdoor DN code (O. DN) [01D], [01E], [01F] to the header unit in each system by the following setup method. (Setting the outdoor DN code (O. DN) to follower unit is not necessary.)
 - 1) Decide a master unit and vassal units from header units of each of the systems, and set the master unit to [01F] = 0001, and the vassal units to [01F] = 0002 or 0003.
 - 2) Set the outdoor DN code [01E] of each header unit to 0001.
When using the central controller for system cooperation defrosting control, set to 0001 through 0128 in accordance with the manual for the central controller.
 - 3) Set the number of systems performing defrosting cooperation (0002 or 0003) in the [01D] of the outdoor unit set to be the master unit.

Outdoor DN code	Item	Description	At shipment
01d	System cooperation defrosting settings 1 (number cooperating)	0000 : None (vassal) 0001 : Prohibition 0002 : 2-system cooperation (master unit) 0003 : 3-system cooperation (master unit) * set [01D] = 0002 or 0003 to outdoor unit set to master unit in outdoor DN code [01F]	0000: None (vassal)
01E	System cooperation defrosting settings 2 (zone address)	0000 : None 0001 to 0128: Addresses 0001 when not using central controller for control for system cooperation defrosting, 0001 to 0128 when using central controller	0000: None
01F	System cooperation defrosting settings 3 (cooperation address)	0000: None 0001: Master unit 0002 or 0003: Vassal units 2 or 3	0000: None

- (5) Reset power supply of outdoor unit, and setup is complete.

<Wiring and setup examples>



■ Operations (contents of control)

- (1) Defrosting conditions for system cooperation defrosting (hereinafter referred to as “cooperation defrosting conditions”) are measured at each system, separately from normal defrosting conditions.
When multiple systems satisfy the cooperation defrosting conditions at the same time, the system that has satisfied the conditions earlier starts defrosting.
- (2) When a system that has started defrosting earlier is still defrosting, other systems do not perform defrosting but continue heating operations.
- (3) When defrosting of the system that started defrosting earlier ends, the system that has satisfied the cooperation defrosting conditions next starts defrosting.
- (4) When only one system satisfies the cooperation defrosting conditions, that system continues heating operations, and performs defrosting at the point that normal defrosting conditions are satisfied.
- (5) A system that has satisfied normal defrosting conditions starts defrosting to avoid the risk of remaining frost, even if system cooperation defrosting is being performed.

<Operation examples of system cooperation defrosting>

(Example 1) 2-system cooperation defrosting

In a case where cooperation defrosting conditions are satisfied in the order of system II and system I, defrosting is performed in the order of system II and system I.

System I	Heating	→	Heating *1	→	Defrosting *2	→	Heating
System II	Heating	→	Defrosting	→	Heating	→	Heating

*1 Continue heating without starting defrosting control while system II is defrosting

*2 Start defrosting after system II ends defrosting

(Example 2) 3-system cooperation defrosting

In a case where cooperation defrosting conditions are satisfied in the order of system II, system I and system III, defrosting is performed in the order satisfying conditions among the three systems.

System I	Heating	→	Heating *1	→	Defrosting *2	→	Heating	→	Heating
System II	Heating	→	Defrosting	→	Heating	→	Heating	→	Heating
System III	Heating	→	Heating *1	→	Heating *1	→	Defrosting *3	→	Heating

*1 Continue heating without starting defrosting control while system II is defrosting

*2 Start defrosting after system II ends defrosting

*3 Start defrosting after system I ends defrosting.

(Example 3) 2-system cooperation defrosting out of three systems

In a case where cooperation defrosting conditions are satisfied in the order of system II and system III, but system I does not satisfy conditions, system cooperation defrosting is performed by system II and system III alone.

System I	Heating	→	Heating	→	Heating	→	Heating
System II	Heating	→	Defrosting	→	Heating	→	Heating
System III	Heating	→	Heating *1	→	Defrosting *2	→	Heating

*1 During system II defrosting, don't start defrosting control but continue heating.

*2 The system II is a defrosting start after the end of defrosting

<Examples of not performing system cooperation defrosting>

(Example 4) Normal defrosting

In a case in where only system II satisfies defrosting conditions (system cooperation defrosting conditions and normal defrosting conditions), only system II performs defrosting.

System I	Heating	→	Heating	→	Heating
System II	Heating	→	Defrosting	→	Heating
System III	Heating	→	Heating	→	Heating
System I	Stop	→	Stop	→	Stop
System II	Heating	→	Defrosting	→	Heating
System III	Stop	→	Stop	→	Stop

(Example 5) Example of not performing system cooperation defrosting

In a case where normal defrosting conditions are satisfied due to sudden increase in frost or the like, defrosting is started to avoid the risk of remaining frost, even if other systems are performing system cooperation defrosting.

System I	Heating	→	Heating *1	→	Defrosting *2	→	Heating
System II	Heating	→	Defrosting	→	Heating	→	Heating

*1 State where heating operations are continuing while system II is performing cooperation defrosting

*2 If normal defrosting conditions are satisfied, defrosting is started without awaiting system II to end defrosting.

6-9. Night operation (Sound reduction control)


Overview

The 'Night operation' function of RBC-AMSU5* remote control can be used with SMMS-u. It reduces the sound of outdoor unit putting priority on quietness during night time operation, etc., and the operation time can be set.

Setup method



To set the Night operation time



1 Push the [MENU] button.

2 Push the [^] / [v] button to select "6.Night operation" on the menu screen, then push the " Set " [F2 F2] button.

3 Push the [^] / [v] button to select "1.Night operation" on the "Night operation" screen.

4 Push the " ← • " [F1 F1] / " • → " [F2 F2] button to select "ON" or "OFF".
→ Select "ON" when the function is used.

5 Push the [MENU] button.

→ Push the [^] / [v] button to select "2.Start time" or "3.End time" for setting the Night operation time

* Adjust the clock before setting the Night operation.

1 Push the [^] / [v] button to select "2.Start time" on the "Night operation" screen.

2 Push the " - " [F1 F1] / " + " [F2 F2] button to set the time.

3 Push the [^] / [v] button to select "3.End time".

4 Push the " - " [F1 F1] / " + " [F2 F2] button to set the time.


5 Push the [MENU] button.

→ The screen returns to the menu screen.


Control outline

- During the 'Outdoor unit sound reduction' control, the outdoor unit operates in the same way as in the 'Night operation Control' with optional control P.C.board. For the operation of outdoor unit during 'Night operation Control', please refer to '6-6-3-5. Night operation (sound reduction) Control'.
- Cooling / heating performance may be reduced a little because the operation priority is put on the quietness for the Night operation.
- " Zz " appears on the detailed display when the Night operation is activated.
- The Night operation cannot be set on the Follower remote controller in the two remote controller system. " No function " is displayed on the screen.
- The 24-hour operation of Night operation is performed when the end time is the same as the start time.
- After setting, the 'Night operation Control' operates according to the start time and the end time, even when the remote control is off.


- The 'Night operation' can be set by a number of remote controls. It operates according to the start time and the end time set by each remote controls.



- If the 'Night operation' time set by a number of remote controls overlaps, it starts at the start time set by any one of the remote controls, and ends when all remote controls reach the end time.




- The 'Night operation' with remote controls, and the 'Night Operation Control' with optional control P.C.board (TCB-PCMO4E) connected to the outdoor unit, can be used together. The outdoor unit operates in 'Night Operation' when either control is effective.



7. TEST OPERATION

7-1. Procedure and Summary of Test Operation

A test operation is carried out with the following procedure. When problems or a trouble occurs at any step, remove the causes of the problem or trouble referring to “8 TROUBLESHOOTING.”



7-2. Check Items before Test Operation (before powering-on)


Prior to the test operation, check the following items to verify there are no problems with the installation work.

Main check items for electric wiring

The communication system differs from previous period model air conditioners.

Check wiring points again carefully.

(1) In the case that a central control system is not connected:




Main check items	Check
(1) Are the indoor and outdoor communication lines of the header unit connected to the U1/U2 (Uv) terminals?	
(2) Is the communication line between outdoor units connected to the U5/U6 (Uc) terminal?	
(3) Is the header unit setting (SW101-bit 1) turned on? Is the terminator resistor (SW100-bit 2) on the interface PC board of the header unit turned on?	
(4) Is the end terminal of the shield wire earthed?	

NOTE

The figure above does not show all the electric wires.

For details, refer to the installation manuals for the outdoor unit, indoor unit, remote controller, or optional devices.

(2) In the case that a central control system is connected (before address setup)



Main check items	Check
(1) Are the indoor and outdoor communication lines of the header unit connected to the U1/U2 (Uv) terminals?	
(2) Is the communication line between outdoor units connected to the U5/U6 (Uc) terminal?	
(3) Is the communication line of the central control system connected to the header unit U3/U4 (Uh) terminals of each refrigerant line? (The communication line of the central control system may be connected to the communication lines of the indoor/outdoor communication lines.)	
(4) Is the header unit setting (SW101-bit 1) turned on? Is the terminator resistor (SW100-bit 2 (termination resistance of Uv line)) on the interface PC board of the header unit turned on? * Does the smallest header unit of a system address turn on SW100-bit 1 (termination resistance of Uh line)? Does the header unit of other refrigerant systems turn off SW100-bit 1? (See "7-4-3. Address Setup Procedure")	
(5) Is the end terminal of the shield wire earthed?	
(6) Is the end terminal of the shield wire earthed at the header unit side?	
(7) When the refrigerant line and the central control system of the DI-SDI series are connected: → Are Network adapter (TCB-PCNT30TLE2) correctly connected? → When the DI-SDI series operates with group, twin, or triple operation, are the adapters connected to the header unit of the indoor unit?	

NOTE

The figure above does not show all the electric wires.
For details, refer to the installation manuals for the outdoor unit, indoor unit, remote controller, or optional devices.

Check list 1

• Using Checklist 1, check that there are no problems with the installation work.

Is the capacity of the circuit breaker (Earth leakage breaker) appropriate?	Outdoor total capacity	<input type="text"/> A	Header unit (A)	<input type="text"/> A	Indoor unit	<input type="text"/> A
			Follower unit (B)	<input type="text"/> A		
			Follower unit (C)	<input type="text"/> A		
			Follower unit (D)	<input type="text"/> A		
			Follower unit (E)	<input type="text"/> A		
Is the gauge of the power cable correct?			Header unit (A)	<input type="text"/> mm ²	Indoor unit	<input type="text"/> mm ²
			Follower unit (B)	<input type="text"/> mm ²		
			Follower unit (C)	<input type="text"/> mm ²		
			Follower unit (D)	<input type="text"/> mm ²		
			Follower unit (E)	<input type="text"/> mm ²		
Is the control communication line correct?	Indoor-outdoor connection terminals (U1, U2)		<input type="text"/>			
	Outdoor-outdoor connection terminals (U5, U6)		<input type="text"/>			
	Central control system connection terminals (U3, U4)		<input type="text"/>			
Is the power of indoor units supplied collectively?						
Is it grounded to earth?						
Is the resistance sufficient? (10 MΩ or higher)			<input type="text"/> MΩ or higher			
Is the main power voltage sufficient? (within 380-415V ±10%)			<input type="text"/> V			
Is the diameter of connecting pipe correct?						
Is the branch kit correct?						
Is the water drain of the indoor unit arranged so that it flows without accumulation?						
Is the heat insulation of pipes sufficient? (connecting pipes, branch kit)						
Is there no short circuit of discharge air in the indoor/outdoor units?						
After an airtightness test of the pipes, are vacuuming and adding of refrigerant executed?						
Are the valves of all the outdoor units fully opened?						
			Gas side	Liquid side		
Header unit (A)			<input type="text"/>	<input type="text"/>		
Follower unit (B)			<input type="text"/>	<input type="text"/>		
Follower unit (C)			<input type="text"/>	<input type="text"/>		
Follower unit (D)			<input type="text"/>	<input type="text"/>		
Follower unit (E)			<input type="text"/>	<input type="text"/>		

- Check the additional amount of refrigerant.

Checklist 2

Calculate total additional amount refrigerant from the compensation amount of refrigerant according to total outdoor unit horsepower (A), the additional amount of refrigerant by the pipe diameter on the liquid side and the pipe length (B), the compensation amount of refrigerant according to indoor unit horsepower (C), and the total compensation amount of refrigerant according to the system diversity (D)

$$\begin{array}{rcl}
 \text{Additional amount of refrigerant} & = & \underbrace{\text{Compensation amount of refrigerant according to total outdoor unit horsepower}}_{(A)} + \underbrace{\text{Actual liquid pipe length} \times \text{Additional amount of refrigerant per 1 m of liquid pipe}}_{(B)} \\
 & + & \underbrace{\text{Compensation amount of refrigerant according to indoor unit horsepower}}_{(C)} + \underbrace{\text{Compensation amount of refrigerant according to the system diversity}}_{(D)}
 \end{array}$$

First, refer to following table below, calculate the the compensation amount of refrigerant according to total outdoor unit horsepower (A)

<Compensation amount of refrigerant according to total outdoor unit horsepower (A)>

Total outdoor unit HP	Combination HP					Compensation by total outdoor unit HP (kg)
8	8	-	-	-	-	1.5 kg
10	10	-	-	-	-	1.7 kg
12	12	-	-	-	-	2.3 kg
14	14	-	-	-	-	2.3 kg
14A	14A	-	-	-	-	0.8 kg
16	16	-	-	-	-	1.0 kg
18	18	-	-	-	-	2.0 kg
20	20	-	-	-	-	4.0 kg
22	22	-	-	-	-	5.0 kg
24	24	-	-	-	-	5.5 kg
26	14	12	-	-	-	4.6 kg
28	14	14	-	-	-	4.6 kg
30	18	12	-	-	-	4.3 kg
32	20	12	-	-	-	6.3 kg
34	20	14	-	-	-	6.3 kg
36	24	12	-	-	-	7.8 kg
38	24	14	-	-	-	7.8 kg
40	20	20	-	-	-	8.0 kg
42	24	18	-	-	-	7.5 kg
44	24	20	-	-	-	9.5 kg
46	24	22	-	-	-	10.5 kg
48	24	24	-	-	-	11.0 kg
50	24	14	12	-	-	10.1 kg
52	24	14	14	-	-	10.1 kg
54	20	20	14	-	-	10.3 kg
56	24	20	12	-	-	11.8 kg
58	24	20	14	-	-	11.8 kg
60	24	24	12	-	-	13.3 kg
62	24	24	14	-	-	13.3 kg
64	24	20	20	-	-	13.5 kg

Total outdoor unit HP	Combination HP					Compensation by total outdoor unit HP (kg)
66	24	22	20	-	-	14.5 kg
68	24	24	20	-	-	15.0 kg
70	24	24	22	-	-	16.0 kg
72	24	24	24	-	-	16.5 kg
74	24	24	14	12	-	15.6 kg
76	24	24	14	14	-	15.6 kg
78	24	20	20	14	-	15.8 kg
80	24	24	20	12	-	17.3 kg
82	24	24	20	14	-	17.3 kg
84	24	24	24	12	-	18.8 kg
86	24	24	24	14	-	18.8 kg
88	24	24	20	20	-	19.0 kg
90	24	24	22	20	-	20.0 kg
92	24	24	24	20	-	20.5 kg
94	24	24	24	22	-	21.5 kg
96	24	24	24	24	-	22.0 kg
98	24	24	24	14	12	21.1 kg
100	24	24	24	14	14	21.1 kg
102	24	24	20	20	14	21.3 kg
104	24	24	24	20	12	22.8 kg
106	24	24	24	20	14	22.8 kg
108	24	24	24	24	12	24.3 kg
110	24	24	24	24	14	24.3 kg
112	24	24	24	20	20	24.5 kg
114	24	24	24	22	20	25.5 kg
116	24	24	24	24	20	26.0 kg
118	24	24	24	24	22	27.0 kg
120	24	24	24	24	24	27.5 kg

Next, enter the total length for each liquid pipe diameter in the following table, and then calculate the additional amount of refrigerant by pipe length.

<Additional amount of refrigerant by pipe length (B)>

Pipe diameter on the liquid side mm	Standard amount of refrigerant kg/m	Total pipe length on each liquid side m	Additional amount of refrigerant pipe diameter on each liquid side kg
6.4	0.025 ×	=	kg
9.5	0.055 ×	=	kg
12.7	0.105 ×	=	kg
15.9	0.160 ×	=	kg
19.1	0.250 ×	=	kg
22.2	0.350 ×	=	kg
25.4	0.470 ×	=	kg

Then refer to following table below, calculate corrective amount of refrigerant according to indoor unit horsepower (C).

<Corrective amount of refrigerant according to indoor unit horsepower (C)>

<According to indoor unit horsepower (Not include "DX coil interface")>

Indoor unit capacity rank	Capacity code (Equivalent to HP) HP	Corrective amount of refrigerant kg	Number of connected indoor units Number	Corrective amount of refrigerant on each indoor unit horsepower kg
007	0.8	0.2 ×	=	kg
008	0.9		=	kg
009	1		=	kg
010	1.1		=	kg
012	1.25		=	kg
014	1.5		=	kg
015	1.7	0.4 ×	=	kg
018	2		=	kg
020	2.25		=	kg
024	2.5		=	kg
027	3		=	kg
030	3.2		=	kg
036	4	0.6 ×	=	kg
048	5		=	kg
056	6		=	kg
072	8	1.0 ×	=	kg
096	10		=	kg
144	16	1.4 ×	=	kg
192	20		=	kg

- If the Fresh Air Intake Indoor Unit (MMD-UP****HFP*) is connected, the corrective amount of refrigerant for Fresh Air Intake Unit is 0 kg.
- If the Large Capacity Floor Standing Type Indoor Unit (MMF-AP072**H*-V*(8HP)) is connected, the corrective amount of refrigerant for Large Capacity Floor Standing Type Indoor Unit (MMF-AP072**H*-V*(8HP)) is 0.4 kg.
- If the Large Capacity Floor Standing Type Indoor Unit (MMF-AP098**H*-V*(10HP) and MMF-AP192**H*-V*(20HP)) is connected, the corrective amount of refrigerant for Large Capacity Floor Standing Type Indoor Unit (MMF-AP098**H*-V*(10HP) and MMF-AP192**H*-V*(20HP)) is 0 kg.

<According to indoor unit horsepower for DX coil interface>

TCB-IFDTA201E, TCB-IFDDC201E

AHU capacity HP	Corrective amount of refrigerant kg	Number of connected indoor units Number	Corrective amount of refrigerant on each indoor unit horsepower kg
8	1.4 ×	=	kg
10	1.8 ×	=	kg
16	2.9 ×	=	kg
18	3.2 ×	=	kg
20	3.6 ×	=	kg
32	5.8 ×	=	kg
36	6.5 ×	=	kg
40	7.2 ×	=	kg
48	8.6 ×	=	kg
54	9.7 ×	=	kg
60	10.8 ×	=	kg

TCB-IFDMR01UP-E,TCB-IFDMX01UP-E (TA,DDC type)

***TF Type : The corrective amount of refrigerant is 0 kg.**

AHU capacity	Corrective amount of refrigerant	Number of connected indoor units	Corrective amount of refrigerant on each indoor unit horsepower
HP	kg	Number	kg
8	1.4	=	kg
10	1.8	=	kg
12	2.1	=	kg
14	2.5	=	kg
16	2.9	=	kg
18	3.2	=	kg
20	3.6	=	kg
22	3.9	=	kg
24	4.3	=	kg
26	4.6	=	kg
28	5.0	=	kg
30	5.3	=	kg
32	5.8	=	kg
34	6.1	=	kg
36	6.5	=	kg
38	6.8	=	kg
40	7.2	=	kg
42	7.5	=	kg
44	7.9	=	kg
46	8.2	=	kg
48	8.6	=	kg
50	8.9	=	kg
52	9.3	=	kg
54	9.7	=	kg
56	10.0	=	kg
58	10.4	=	kg
60	10.8	=	kg
62	11.1	=	kg
64	11.5	=	kg
66	11.8	=	kg
68	12.2	=	kg
70	12.5	=	kg
72	12.9	=	kg
74	13.3	=	kg
76	13.6	=	kg
78	14.0	=	kg
80	14.3	=	kg
82	14.7	=	kg
84	15.1	=	kg
86	15.4	=	kg
88	15.8	=	kg
90	16.1	=	kg
92	16.5	=	kg
94	16.9	=	kg
96	17.2	=	kg
98	17.6	=	kg
100	17.9	=	kg
102	18.3	=	kg
104	18.7	=	kg
106	19.0	=	kg
108	19.4	=	kg
110	19.7	=	kg
112	20.1	=	kg
114	20.5	=	kg
116	20.8	=	kg
118	21.2	=	kg
120	21.5	=	kg

<According to indoor unit horsepower for Hot Water Module (HWM)>

Indoor Unit Capacity HP	Corrective amount of refrigerant kg	Number of connected indoor units Number	Corrective amount of refrigerant on each indoor unit horsepower kg
2.5	0.2		= kg
5			= kg

<According to indoor unit horsepower for Fresh Air Intake>

Corrective amount of refrigerant: 0 kg

<According to indoor unit horsepower for High Efficiency 4-Way Cassette (MMU-UP**H*)>**

Indoor Unit Capacity HP	Corrective amount of refrigerant kg	Number of connected indoor units Number	Corrective amount of refrigerant on each indoor unit horsepower kg
1	0.2		= kg
1.3			= kg
1.7	0.6		= kg
2			= kg
2.5			= kg
3			= kg
3.2			= kg
4			= kg
5			= kg
6			= kg

Next, refer to the following table below, calculate the corrective amount of refrigerant according to system diversity (D)

Corrective amount of refrigerant varies according to the system diversity (D)

Diversity D(%)	Corrective amount of refrigerant (kg)
50% ≤ D < 60%	-2.5
60% ≤ D < 70%	-2.0
70% ≤ D < 80%	-1.5
80% ≤ D < 90%	-1.0
90% ≤ D < 95%	-0.5
95% ≤ D	0

Lastly, add the corrective amount of refrigerant according to system diversity (D), the corrective amount of refrigerant according to indoor unit horsepower(C) and the additional amount of refrigerant by the pipe diameter on liquid side and the pipe length (B) to the compensation amount of refrigerant according to total outdoor unit horsepower (A)

This is the final additional amount of refrigerant.

If a minus sign is indicated as the result, the additional amount of refrigerant is zero (0) kg, do not reduce the refrigerant.

Compensation amount of refrigerant according to total outdoor unit horsepower (A)	kg
Additional amount of refrigerant by pipe length (B)	kg
Corrective amount of refrigerant according to indoor unit horsepower (C)	kg
Corrective amount of refrigerant according to system diversity (D)	kg
Total additional amount of refrigerant	kg


7-3. Check at Main Power-on

After turning on the main power of the indoor units and outdoor unit in the refrigerant line to conduct a test operation, check the following items in each outdoor and indoor unit.

(After turning on the main power, be sure to check in order: indoor unit outdoor unit.)

<Check on the outdoor unit>

- (1) Check that all the rotary switches, SW01, SW02, and SW03, on the interface PC board of the header unit are set to "1."
- (2) If another check code is displayed on the 7-segment display [B], remove the cause of the problem referring to Section, "8. TROUBLESHOOTING".
- (3) Check that "L08" is displayed on the 7-segment display [B] on the interface PC board of the header unit.
(L08: Indoor address not set up)
(If the address setup operation has already been completed during servicing, etc., the above check code is not displayed, and only "U1" is displayed on the 7-segment display [A].)





<Check on the indoor unit>



(1) Display check on the remote controller (in the case of a wired remote controller)

Check that a frame, as shown in the following figure at left, is displayed on the LC display section of the remote controller.

<RBC-AMT*>



<RBC-ASCU11*>



If no frame is displayed, as shown in the above figure at right, the remote controller does not have a normal supply of power; check the following items.

- Check the power supply of the indoor unit.
- Check the cabling between the indoor unit and the remote controller.
- Check whether there is a cutoff of wire around the indoor control PC board or not, and check for connection failures of the connectors.
- Check for failure of the transformer for the indoor electrical control box.
- Check for failure of the indoor control PC board.

7-4. Address Setup


This product requires address setup before operation.
Follow this procedure for address setup.

7-4-1. Precautions

- (1) Address setup is not performed simply by turning on the power supply.
- (2) For indoor units, address setup can be done either by manual address setup or by automatic address setup:
Automatic address setup: Setup from SW06 on the interface P.C. board of the header unit
Manual address setup: Setup from the wired remote controller. (For details, refer to “7-4-3. Address Setup Procedure.”)
- (3) Automatic setup usually takes about 5 minutes per line. In some cases, however, it may take up to 10 minutes.
- (4) It is unnecessary to operate the air conditioner to achieve address setup.

7-4-2. Address Setup and Check Procedure

Procedure	Item	Operation and check contents																																		
1	Header outdoor unit setting	Turn on DIP switch 1 of SW101 on the header outdoor unit interface P.C.boards. And, turn on DIP switch 2 of SW100.																																		
2	Indoor unit power-on	Turn on the power of the indoor unit for the refrigerant line for which the address is to be set up.																																		
3	Outdoor unit power-on	Turn on the power of all the outdoor units for the refrigerant line for which the address is to be set up.																																		
4	7-segment display check	Check that “L08” is displayed on the 7-segment display [B] on the interface PC board of the header unit in the system where the address is to be set up.																																		
5	Address setup start	Confirm the items in “7-4-3. Address Setup Procedure,” and then set up the address according to the operation procedure. (Be careful to note that the setup operation may differ in group control and central control systems.) Note: The address cannot be set up if switches are not operated.																																		
6	Display check after setup	<ul style="list-style-type: none">After address setup, “U1” “ ” is displayed on the 7-segment display.For follower outdoor units, “U2” to “U5” are displayed on the 7-segment display [A].If a check code is displayed on the 7-segment display [B], remove the cause of the problem referring to “8 TROUBLESHOOTING.”																																		
7	Communication setting start	Confirm the items in “7-4-3. Address Setup Procedure,” and then set up the communication according to the operation procedure. Note: The address cannot be set up if switches are not operated.																																		
8	Display check after communication setup	<ul style="list-style-type: none">After communication setup, “c.c.” “Fin” is displayed on the 7-segment display.If a unit that has already been set for communication is connected, it cannot be set correctly. In this case, clear the communication settings and set again.																																		
9	System information check after setup	Using the 7-segment display function, check the system information of the scheduled system. (This check is executed on the interface PC board of the header unit.)																																		
			Rotary switch setup			7-segment display		SW01	SW02	SW03	[A]	[B]	System capacity	1	2	3	[Number of horsepower]	[H P]	Number of connected outdoor units	1	3	3	[Number of units]	[P]	Number of connected indoor units	1	4	3	[Number of connected units]		Communication Type	2	16	2	[Type] Type : 0=TCC-Link, 1=TU2C-Link	
				Rotary switch setup			7-segment display																													
		SW01		SW02	SW03	[A]	[B]																													
		System capacity	1	2	3	[Number of horsepower]	[H P]																													
		Number of connected outdoor units	1	3	3	[Number of units]	[P]																													
		Number of connected indoor units	1	4	3	[Number of connected units]																														
Communication Type	2	16	2	[Type] Type : 0=TCC-Link, 1=TU2C-Link																																
After the above checks, return rotary switches SW01, SW02, and SW03 to 1/1/1.																																				




7-4-3. Address Setup Procedure

Before setting the address, it is necessary to set the DIP-SW on the header outdoor unit interface P.C. board.

1. Follow the steps below to open the electrical control box cover

- (1) Loosen the screws on the left and right side of the electrical control box cover.
- (2) Remove the screw A for MMY-MUP220 and MUP240.
(There is no screw A for MMY-MUP080, MUP100, MUP120, MUP140, MUP14A, MUP160, MUP180 and MUP200)
- (3) Hold the lower side of the electrical control box cover to draw it toward you while lifting it up, and remove the electrical control box cover.



2. Follow the steps below to set the DIP switch on the header outdoor unit interface P.C. board.


2-1. Header outdoor unit setting

Turn on DIP switch 1 of SW101 on the header outdoor unit interface P.C. boards*.

And, turn on DIP switch 2 of SW100. (Termination resistance of Uv line)

* Header outdoor unit setting is required also of an outdoor independent system.

Interface P.C. board on the header outdoor unit



2-2.Line (system) address setting

For the central control among two or more refrigerant lines or group control among two or more refrigerant lines, set the line (system) address.

(Example)	Controlling a single refrigerant line centrally	Controlling 2 or more refrigerant lines centrally
System wiring diagram		
Line (system) address setting	No	Set the address

(Example)	Controlling 2 or more refrigerant lines as a group (*)
System wiring diagram	
Line (system) address setting	Set the address

* Only if each refrigerant line has the same communication type (either TU2C-Link or TCC-Link), the group control among multiple refrigerant lines is available. If one refrigerant line has TU2C-Link and another refrigerant line has TCC-Link in the system, the group control among multiple refrigerant lines is unavailable.

**(1) Set a line (system) address for each system using SW 101 and 102 on the interface P.C. board on the header outdoor unit of each system.
(Factory default: Address 1)**

NOTE

Be sure to set a unique address on each system. Do not use a same address as another system (refrigerant line) or a "Digital Inverter" side.

Interface P.C. board on the header outdoor unit

Line address switches on the outdoor interface PC board (O : switch on, X : switch off)



Line (system) address	SW101				SW102			
	1	2	3	4	1	2	3	4
1		x	x	x	x	x	x	x
2		x	x	x	x	x	x	O
3		x	x	x	x	x	O	x
4		x	x	x	x	x	O	O
5		x	x	x	x	O	x	x
6		x	x	x	x	O	x	O
7		x	x	x	x	O	O	x
8		x	x	x	x	O	O	O
9		x	x	x	O	x	x	x
10		x	x	x	O	x	x	O
11		x	x	x	O	x	O	x
12		x	x	x	O	x	O	O
13		x	x	x	O	O	x	x
14		x	x	x	O	O	x	O

Line (system) address	SW101				SW102			
	1	2	3	4	1	2	3	4
15		x	x	x	O	O	O	x
16		x	x	x	O	O	O	O
17		x	x	O	x	x	x	x
18		x	x	O	x	x	x	O
19		x	x	O	x	x	O	x
20		x	x	O	x	x	O	O
21		x	x	O	x	O	x	x
22		x	x	O	x	O	x	O
23		x	x	O	x	O	O	x
24		x	x	O	x	O	O	O
25		x	x	O	O	x	x	x
26		x	x	O	O	x	x	O
27		x	x	O	O	x	O	x
28		x	x	O	O	x	O	O

Note: if you set it to something other than the table, the system address will be 28.

■ : SW101 Bit 1 is for header outdoor unit setting, so it is not used for system address setting.


(2) After completing address setting of all systems, turn ON DIP switch 1 of SW100 on the header outdoor unit interface P.C. board of the lowest system address number.

Switch setting (setting example when controlling 2 or more refrigerant lines centrally)

Outdoor units (setting manually)

*The items in bold font must be set manually.

Outdoor unit's interface P.C. board	Header unit	Follower unit	Header unit	Follower unit	Header unit	Factory default
SW101 Bit1 (Header unit setting)	ON	(No setting required)	ON	(No setting required)	ON	OFF
SW101 Bit2-4, SW102 Bit1-4 (Line (system) address)	1	(No setting required)	2	(No setting required)	3	1
SW100 Bit1 (Terminator of central control line (Uh))	ON	(No setting required)	(No setting required)	(No setting required)	(No setting required)	OFF
SW100 Bit2 (Terminator of indoor and outdoor communication line(Uv))	ON	(No setting required)	ON	(No setting required)	ON	OFF



3. Attach the electrical control box cover.

4. Address setup

■ Automatic address setup


Only if the address of all indoor units in the same system is not set, the following address will be set automatically.

- System address (Indoor unit code [12]) The system address of the indoor units are automatically set to the same number as the system address set in both SW101 and 102 of the outdoor center unit I/F board.
- Indoor address (Indoor unit code[13]) Indoor address automatically set in order from one.
- Group address (Indoor unit code[14]) The host and guest group addresses (header =1, follower = 2) are automatically set for the indoor units group connected by remote controller.

Open the access door cover and follow the steps below to set the address.


REQUIREMENT

- High voltage parts exist in the electrical control box.
If you set addresses on an outdoor unit, operate the unit through the access door as shown in the illustration below to avoid electric shock. Do not remove the cover of electrical control box.
- * After finishing operations, close the access door cover and fix it with the screw.




- 1 Turn on indoor units first, and then turn on outdoor units.
- 2 About 1 minute after turning the power on, confirm that the 7-segment display on the interface P.C. board of the header outdoor unit indicates **U. 1. Err (U. 1. flash)** and **L08** alternately at 1 second intervals.
- 3 Press SW06 for more than 1 second to start the automatic address setting.
(It may take up to 10 minutes (normally about 5 minutes) to complete one line's setting.)
- 4 The 7-segment display indicates **Auto 1 → Auto 2 → Auto 3**.
The setting is complete when the display changes to **U. 1. - - - (U. 1. flash)** or **U. 1. - - - (U. 1. light)**.
- 5 Repeat steps 2 to 4 for other refrigerant lines.
- 6 Set the central control address.
(For the setting of the central control address, refer to the installation manuals of the central control devices.)

Interface P.C. board on the header outdoor unit



REQUIREMENT


- When 2 or more refrigerant lines are controlled as a group, be sure to turn on all the indoor units in the group before setting addresses.
- If you set the unit addresses of each line separately, each line's header indoor unit is set separately. In that case, the Code No. "L03" (Indoor header unit overlap) is indicated as running starts. Change the group address to make one unit the header unit using wired remote controller.



Manual address setup from the remote controller

With indoor wiring work completed and outdoor wiring work not done—in cases where indoor unit addresses are decided in advance from the wired remote controller, or in cases where addresses are change after address setup.

(Wiring example for 2 refrigerant lines)




Line address	1	1	1	2	2
Indoor address	1	2	3	1	2
Group address	1	2	2	2	2
	Header	Follower	Follower	Follower	Follower

In the above example, where remote controllers are not yet wired, set the address manually after individually connecting the wired remote controller.



(Wiring during manual address setup)




After address setup, return to the original wiring over remote controllers.

Group address

Individual: 0000
Header unit: 0001
Follower unit: 0002

In cases of remote controller group control



<RBC-AMT*>

- 1 Arrange one indoor unit and one remote controller set to 1 by 1.
- 2 Turn on the power.
- 3 Push the **SET** + **CL** + **TEST** buttons simultaneously for 4 seconds or more.
LCD begins blinking.

▼ (Refrigerant line address)

- 4 Using the **TEMP.** buttons, set the DN code to 12.
- 5 Using the **TIME** buttons, set up the line address (match it with the line address on the interface P.C. board of the header unit on the same refrigerant line).
- 6 Push the **SET** button (OK when the display goes on).

▼ (Indoor address)

- 7 Using the **TEMP.** buttons, set the DN code to 13.
- 8 Using the **TIME** buttons, set up the indoor address.
(TU2C-LINK : 0001~0128
TCC-LINK : 0001~0064)
- 9 Push the **SET** button (OK when the display goes on).

▼ (Group address)


- 10 Using the **TEMP.** buttons, set the DN code to 14.
- 11 Using the **TIME** buttons, set Individual = 0000, Header unit = 0001, Follower unit = 0002.
- 12 Push the **SET** button (OK when the display goes on).

▼ (Central control address)

- 13 Using the **TEMP.** buttons, set DN code to 03.
- 14 Using the **TIME** buttons, set up the central control address. (TU2C-LINK : 0001~0128
TCC-LINK : 0001~0064)
- 15 Push **SET** button. (OK when display goes on).
- 16 Push the **TEST** button.
Setup is finished ("Setting up" blinks; when "Setting up" goes off, operation is possible).

- 17 Return to the original wiring over remote controllers.

<RBC-ASCU11*>




1 Pair the indoor unit to set and the remote controller one-to-one.

2 Turn on the power.

3 Push and hold menu button and [▽] setting button simultaneously for 10 seconds or more.


After a while, the display flashes as shown in the figure.

“ALL” is displayed as indoor unit numbers during initial communication immediately after the power has been turned on.



▼ (Refrigerant line address)

4 Push the Timer off button.



5 Push the menu button to make Code No. flash. Change Code No. to 12 with [▽] [△] setting button.

6 Push the menu button to make Set data [****] flash. Set the system address with [▽] [△] setting button.

(Match the address with the address on the interface P.C. board of the header outdoor unit in the same refrigerant line.)

7 Push the Timer off button.

(When the display changes from [- -] to Set data [****] flashing, the setup is completed.)

▼ (Indoor address)

8 Push the menu button to make Code No. flash. Change Code No. to 13 with [▽][△] setting button.

9 Push the menu button to make Set data [****] flash. Set the indoor unit address with [▽][△] setting button.

(TU2C-LINK : 0001~0128

TCC-LINK : 0001~0064)

10 Push the Timer off button.

(When the display changes from [– –] to Set data [****] flashing, the setup is completed.)

▼ (Group address)

11 Push the menu button to make Code No. flash. Change Code No. to 14 with [▽][△] setting button.

12 Push the menu button to make Set data [****] flash. Set the group address with [▽][△] setting button.

If the indoor unit is individual, set the address to ,0000 ; header unit, 0001 ; follower unit, 0002.

13 Push the Timer off button.

(When the display changes from [– –] to Set data [****] flashing, the setup is completed.)

▼ (Central control address)

14 Push the menu button to make Code No. flash. Change Code No. to 03 with [▽][△] setting button.

15 Push the menu button to make Set data [****] flash. Set the indoor unit address with [▽][△] setting button.

(TU2C-LINK : 0001~0128

TCC-LINK : 0001~0064)

16 Push the Timer off button.

(When the display changes from [– –] to Set data [****] flashing, the setup is completed.)

17 When all the settings have been completed, push ON/OFF button to determine the settings.

“SETTING” flashes and then the display content disappears and the air conditioner enters the normal stop mode. (The remote controller is unavailable while “SETTING” is flashing.)

NOTE


- (1) The Code No. [E04] (Indoor / outdoor communication trouble) will appear if line (system) addresses are mistakenly set.
- (2) When manual address setup has been done from a remote controller, and central control over refrigerant lines is to be done, setup the header unit of each line as follows:
 - Using SW101 and SW102 on the interface PC board of the header unit of each line, setup the line address for each line.
 - Turn ON DIP switch 1 of SW100 on the header outdoor unit interface P.C.board of the lowest system address number.
 - After that, set up the central control address. (For central control address setup, refer to the installation manual of the central control devices.)

■ Changing the indoor unit address using a remote controller

To change an indoor unit address using a wired remote controller.

<RBC-AMT*>

- ▼ The method to change the address of an individual indoor unit (the indoor unit is paired with a wired remote controller one-to-one), or an indoor unit in a group. (The method is available when the addresses have already been set)



(Execute it while the units are stopped.)


- 1** Push and hold the , , and buttons at the same time for more than 4 seconds.
(If 2 or more indoor units are controlled in a group, the first indicated UNIT No. is that of the head unit.)
- 2** Push the button (left side of the button) repeatedly to select an indoor unit number to change if 2 or more units are controlled in a group. (The fan and louvers of the selected indoor unit are activated.)
(The fan of the selected indoor unit is turned on.)
- 3** Push the TEMP. / buttons repeatedly to select for CODE No..
- 4** Push the TIME / buttons repeatedly to change the value indicated in the SET DATA section to that you want.
- 5** Push the button.
- 6** Push the button (left side of the button) repeatedly to select another indoor UNIT No. to change.
Repeat steps **4** to **6** to change the indoor unit addresses so as to make each of them unique.
- 7** Push the button (left side of the button) to check the changed addresses.
- 8** If the addresses have been changed correctly, push the button to finish the procedure.

To change an indoor unit address using a wired remote controller.

<RBC-ASCU11*>

The method to change the address of an individual indoor unit (the indoor unit is paired with a wired remote controller one-to-one), or an indoor unit in a group.

(The method is available when the addresses have already been set automatically.)



(Execute it while the units are stopped.)

- 1** Push and hold menu button and [▽] setting button simultaneously for 10 seconds or more.
(If 2 or more indoor units are controlled in a group, the first indicated UNIT No. is that of the head unit.)
- 2** Each time [▽] [△] setting button is pushed, indoor unit numbers in the group control change cyclically.
Select the indoor unit to change settings for.
(The fan and louvers of the selected indoor unit are activated.)
(The fan of the selected indoor unit is turned on.)
- 3** Push the Timer off button.
- 4** Push the menu button to make Code No. flash. Change Code No. to 13 with [▽] [△] setting button.
- 5** Push the menu button to make Set data [****] flash.
Push the [▽] [△] buttons repeatedly to change the value indicated in the SET DATA section to that you want.
- 6** Push the Timer off button.
(When the display changes from [— —] to Set data [****] flashing, the setup is completed.)
- 7** When all the settings have been completed, push ON/OFF button to determine the settings.
“ **SETTING** ” flashes and then the display content disappears and the air conditioner enters the normal stop mode. (The remote controller is unavailable while “ **SETTING** ” is flashing.)
- 8** To change settings of another indoor unit, repeat from Procedure 1.


■ Confirming the indoor unit addresses and the position of an indoor unit using the remote controller

◆ Confirming the numbers and positions of indoor units

To see the indoor unit address of an indoor unit which you know the position of

- ▼ When the unit is individual (the indoor unit is paired with a wired remote controller one-to-one), or it is a group-controlled one.

<RBC-AMT*>




(Execute it while the units are running.)

1 Push the  button if the units stop.


2 Push the  button (left side of the button).

A unit numbers **1-1** is indicated on the LCD (it will disappear after a few seconds). The indicated number shows the system address and indoor unit address of the unit.

When 2 or more indoor units are connected to the remote controller (group-controlled units), a number of other connected units appears each time you push the  button (left side of the button).

To find an indoor unit's position from its address

▼ When checking unit numbers controlled as a group



(Execute it while the units are stopped.)

The indoor unit numbers in a group are indicated one after another. The fan and louvers of the indicated units are activated.

1 Push and hold the and buttons at the same time for more than 4 seconds.

- ALL appears on UNIT No. on the LCD display.
- The fans and louvers of all the indoor units in the group are activated.

2 Push the button (left side of the button). Each time you push the button, the indoor unit numbers are indicated one after another.

- The first-indicated unit number is the address of the header unit.
- Only the fan and louvers of the indicated indoor unit are activated.

3 Push the button to finish the procedure.


All the indoor units in the group stop.

■ **Using wired remote controller (RBC-AMT* etc.), all the indoor units addresses in the same system are changed.**


(The method is available when the addresses have already been set automatically.)












The method is available when the addresses have already been set. The indoor address of other refrigerant systems cannot be changed.

* Enter the address check/change mode and change the addresses.

If no number appears on UNIT No., no outdoor unit exists on the line. Push  button and select another line following step 2.

(Execute it while the units are stopped.)



- 1** Push and hold the TIME  and  buttons at the same time for more than 4 seconds.
At first, the line 1 and CODE No. **AC** (Address Change) are indicated on the LCD display.
- 2** Push  (left side of the button) and  buttons repeatedly to select a system address.
- 3** Push the  button.
 - The address of one of the indoor units connected to the selected refrigerant line is indicated on the LCD display and the fan and louvers of the unit are activated.
At first, the current indoor unit address is displayed in SET DATA.
(No system address is indicated.)
- 4** Push the TIME  /  buttons repeatedly to change the value of the indoor unit address in SET DATA.
Change the value in SET DATA to that of a new address.
- 5** Push the  button to confirm the new address on SET DATA.
- 6** Push the  button (left side of the button) repeatedly to select another address to change.
Each time you push the button, the indoor unit numbers in a refrigerant line are indicated one after another. Only the fan and louvers of the selected indoor unit are activated.
Repeat steps 4 to 6 to change the indoor unit addresses so as to make each of them unique.
- 7** Push the  button.
(All the segments on the LCD display light up.)
- 8** Push the  button to finish the procedure.

■ Procedure to setup address 65 to 128 from the remote controller

Under TCC-Link settings (factory shipping settings), setting addresses from 65 and above are not available from the remote controller. Setting the indoor address or the zone address to 65 to 128 must be done under TU2C-Link settings, which can be performed by the procedures shown below.

* Be sure that all of the outdoor units, indoor units, and the remote controller in the same system support TU2C-Link.

TU2C-Link communication is not available if any of these do not support TU2C-Link.

Method 1 (Changing the address after automatic address setup)

Follow the procedures below if the power supply and communication line wiring work has been completed.

- 1) Turn the power for every outdoor unit and indoor unit on.
- 2) Perform "Automatic address setup" from the header outdoor unit.
The system address, indoor address, and the group address will be set for every indoor unit in the system automatically.
- 3) Perform "Communication setting" from the header outdoor unit.
TU2C-Link will be set if all the outdoor units, indoor units, and the remote controller support TU2C-Link.
(Outdoor DN code (O.DN) [082]=0003, indoor DN code (I.DN) [FC]=0003)
For the units in the farthest rooms, the indoor termination resistance will automatically be set to on.
(Indoor DN code (I.DN) [1FC]=0001 (ON))
- 4) Change the indoor address (or the group address) to any address within 1 to 128 according to the method to change the indoor address using the remote controller.


* If there are more than 65 indoor units connected:

Addresses above 65 will automatically be set by automatic address setup even if TCC-Link settings are implemented.

While the TCC-Link settings are set, indoor units which are assigned with the addresses 65 to 128 will not work, until setting the TU2C-Link settings by performing communication settings after the automatic address setup, which will render the indoor units 65 through 128 available.

* The check code [E16] or [L08] will show up if operation is attempted while the TCC-Link setting is implemented and the indoor units with the indoor address 65 to 128 are connected.

<Example> When the indoor address of line 5 is set to 126-128



2) After the automatic address setting

		Indoor A	Indoor B	Indoor C
Line (system) address	I.DN [12]	0005	0005	0005
Indoor address	I.DN [13]	0001	0002	0003
Group address	I.DN [14]	0001	0002	0002
Communication setting	I.DN [FC]	0000	0000	0000
Indoor termination	I.DN [1FC]	0000	0000	0000

3) After the automatic communication settings

		Indoor A	Indoor B	Indoor C
Line (system) address	I.DN [12]	0005	0005	0005
Indoor address	I.DN [13]	0001	0002	0003
Group address	I.DN [14]	0001	0002	0002
Communication setting	I.DN [FC]	0003	0003	0003
Indoor termination	I.DN [1FC]	0000	0000	0001

4) After changing the indoor address with the remote control.

		Indoor A	Indoor B	Indoor C
Line (system) address	I.DN [12]	0005	0005	0005
Indoor address	I.DN [13]	0126	0127	0128
Group address	I.DN [14]	0001	0002	0002
Communication setting	I.DN [FC]	0003	0003	0003
Indoor termination	I.DN [1FC]	0000	0000	0001


Method 2 (Setting the address manually from the remote controller)

Follow the procedure below if setting the indoor unit address manually from the remote controller is desired due to the indoor address not being set (factory default) and automatic address setting not being possible for reasons such as the outdoor unit installation not being installed.

<RBC-AMSU51*>

- 1) Arrange one indoor unit and one remote controller set to 1 by 1.
Turn on the power.
- 2) After confirming that "SETTING" is blinking on the remote controller, turn the screen to the "Field setting menu" by pushing the "MENU" and "V" together for 4 seconds or longer.
Select the "7. DN setting" using the "Λ" and "V" button and push the "F2(Set)" button.
Select the "Indoor unit" using the "Λ" and "V" button and push the "F2(Set)" button.
- 3) Set the Indoor Unit Function Code (I.DN) to [14], and the Data to [0000] (Individual).
 - Set the group address to (individual).
- 4) Set the Indoor Unit Function Code (I.DN) to [FC], and the Data to [0003](Individual).
 - Set the system to TU2C-Link communication.
- 5) Push the "MENU" button and complete the settings for the time being.
- 6) After the remote controller reboots, turn the screen to the "Field setting menu" by pushing the "MENU" and "V" together for 4 seconds or longer.
- 7) Bring up the "DN setting" screen by following the same procedure as in 2) above, and change to the Function Code (DN) I.DN setting screen of "Indoor unit".
- 8) Set the Line address by setting the Indoor Unit Function Code (I.DN) to [12].
- 9) Set the indoor unit address by setting the Indoor Unit Function Code (I.DN) to [13].
- 10) When connecting to the remote controller group control,
Set the DN code to [14], Data [0001] (header) for the header indoor unit, and the DN code to [14], Data [0002] (follower) for the follower indoor unit.
- 11) If necessary, set the zone address to the Indoor Unit Function Code (I.DN) to [03].

Example) When setting the Indoor address to 126 to 128 in Line 5 is desired



Before making settings (At shipment)		Indoor A	Indoor B	Indoor C
Line (system) address	I.DN [12]	00Un	00Un	00Un
Indoor unit address	I.DN [13]	00Un	00Un	00Un
Group address	I.DN [14]	00Un	00Un	00Un
Communication setting	I.DN [FC]	0000	0000	0000
Indoor termination	I.DN [1FC]	0000	0000	0000

After setting 3) and 4)

Line (system) address	I.DN [12]	00Un	00Un	00Un
Indoor unit address	I.DN [13]	00Un	00Un	00Un
Group address	I.DN [14]	0000	0000	0000
Communication setting	I.DN [FC]	0003	0003	0003
Indoor termination	I.DN [1FC]	0000	0000	0000

After setting 8),9) and 10) (11))

Line (system) address	I.DN [12]	0005	0005	0005
Indoor unit address	I.DN [13]	0126	0127	0128
Group address	I.DN [14]	0001	0002	0002
Communication setting	I.DN [FC]	0003	0003	0003
Indoor termination	I.DN [1FC]	0000	0000	0000

<Setting the indoor terminal resistance manually (if the farthest room is known)>

- 12) Set the Indoor Unit Function Code I.DN [1FC] to "0001" (indoor terminal resistance ON).
- 13) After installing the outdoor unit, set the Outdoor Unit Function Code O.DN [82] to "0003" (TU2C-Link) for the header outdoor unit and the follower outdoor unit.
- 14) Reset the outdoor / indoor unit power supply to complete the setting.

<Setting the indoor terminal resistance automatically (if the farthest room is unknown)>

The indoor terminal resistance settings will be available after installing the outdoor unit and performing the communication method settings from the header outdoor unit, thus the farthest room will be detected automatically, and indoor terminal resistance can be set.

Make sure that this is done after 11), **since the communication method settings has to be performed after changing back to TCC-LINK settings.**

- 15) Clear the communication method from the header outdoor unit after installing the outdoor unit.
All the communication method settings for the indoor and outdoor unit in the same system will be set to TCC-LINK.
(The indoor addresses will not be changed at this time.)
- 16) Perform the communication method settings from the header outdoor unit. If all of the outdoor unit, the indoor units, and the remote controller in the same system supports TU2C-LINK, they will be set to TU2C-LINK settings, and the indoor terminal resistance settings will turn on automatically.
- 17) Reset the outdoor / indoor unit power supply to complete the setting.

<When the farthest indoor unit is known and the indoor terminating resistor is set manually>

- 12) After setting the indoor terminating resistor

Line (system) address	I.DN [12]	0005	0005	0005
Indoor unit address	I.DN [13]	0126	0127	0128
Group address	I.DN [14]	0001	0002	0002
Communication setting	I.DN [FC]	0003	0003	0003
Indoor termination	I.DN [1FC]	0000	0000	0001

<If you do not know the farthest indoor unit and use automatic communication settings>

- 15) After resetting communication settings

Line (system) address	I.DN [12]	0005	0005	0005
Indoor unit address	I.DN [13]	0126	0127	0128
Group address	I.DN [14]	0001	0002	0002
Communication setting	I.DN [FC]	0000	0000	0000
Indoor termination	I.DN [1FC]	0000	0000	0000

- 16) After automatic communication setting

Line (system) address	I.DN [12]	0005	0005	0005
Indoor unit address	I.DN [13]	0126	0127	0128
Group address	I.DN [14]	0001	0002	0002
Communication setting	I.DN [FC]	0003	0003	0003
Indoor termination	I.DN [1FC]	0000	0000	0001

■ Resetting the address (Resetting to the factory default (address undecided))

Method 1

Clearing each address separately using a wired remote controller.

Set the system address, indoor unit address and group address to "00Un" using a wired remote controller. (For the setting procedure, refer to the address setting procedures using the wired remote controller on the previous pages.)

* Address not set will be either "00Un" or "0099", depending on the type of the remote controller.

Central control address (I.DN [03]) • Indoor unit address (I.DN [13])

Remote controller	Communication Type	Unfixed	Display order
U series	TU2C-LINK	00Un	• • • ⇔ 0128 ⇔ 00Un ⇔ 0001 ⇔ • • •
	TCC-LINK	00Un	• • • ⇔ 0064 ⇔ 00Un ⇔ 0001 ⇔ • • •
Other than U series	TCC-LINK	0099	• • • ⇔ 0064 ⇔ 0099 ⇔ 0001 ⇔ • • •

Line address (I.DN [12])

Remote controller	Communication Type	Unfixed	Display order
U series	TU2C-LINK	00Un	• • • ⇔ 0128 ⇔ 00Un ⇔ 0001 ⇔ • • •
	TCC-LINK	00Un	• • • ⇔ 0030 ⇔ 00Un ⇔ 0001 ⇔ • • •
Other than U series	TCC-LINK	0099	• • • ⇔ 0030 ⇔ 0099 ⇔ 0001 ⇔ • • •

Group address (I.DN [14])

Remote controller	Communication Type	Unfixed	Display order
U series	TU2C-LINK	00Un	• • • ⇔ 0002 ⇔ 00Un ⇔ 0000 ⇔ • • •
	TCC-LINK		
Other than U series	TCC-LINK	0099	• • • ⇔ 0002 ⇔ 0099 ⇔ 0000 ⇔ • • •

Method 2

Clearing all the indoor unit addresses on a refrigerant line at once from the outdoor unit.

- 1 Turn off the refrigerant line to reset to the factory default.**
- 2 Turn on the indoor and outdoor units of the refrigerant line for which you want to initialize the addresses. About one minute after turning on the power, confirm that the 7-segment display on the header outdoor unit indicates "U.1. - - -" and operate the interface P.C. board on the header outdoor unit of the refrigerant line as follows.**

SW01	SW02	SW03	SW04	Clearable addresses
2	1	2	Confirm that the 7-segment display indicates "A.d.buS" and turn SW04 ON for more than five seconds.	System/indoor unit/group address
2	2	2	Confirm that the 7-segment display indicates "A.d.nEt" and turn SW04 ON for more than five seconds.	Central control address

- 3 Confirm that the 7-segment display indicates "A.d. c.L." and set SW01, SW02 and SW03 to 1, 1, 1 respectively.**
- 4 After finished clearing the address successfully, "U.1.Err" and "L08 " appear alternatively at 1 second intervals on the 7-segment display.**
- 5 Set the addresses again after finishing the clearance.**

Communication setting

If all outdoor units, indoor units, remote controllers are U series models, you can change to TU2C-LINK communication by following the steps below. (The factory default setting is TCC-LINK communication)

CAUTION

- Be sure to complete the address setting before communication setting.
- It may takes about 1 to 3 minutes to address one refrigerant line.
- Settings on the outdoor unit are required for communication setting.
(Communication setting is not started simply by turning on the power.)
- If a unit that has already been set for communication is connected, it cannot be set correctly.
In this case, clear the communication settings and set again.
- The indoor unit DN code (FC) and outdoor unit DN code (82) are automatically set for the set communication.
In the case of the TU2C-LINK system, the terminating resistance (indoor unit DN code (1FC)) of the indoor unit that maximizes the wiring length from the outdoor unit is automatically set.

■ Communication setting (Auto setting)

1. Turn on indoor units first, and then turn on outdoor units.
2. Set the rotary switches on the interface P.C. board of the header outdoor unit SW01 to [2], SW02 to [16] and SW03 to [2].
3. The 7-segment display switches between “c.c. b P S” and “c.c. 0 “ at 1-second intervals.
4. Push and hold SW04 for more than 5 seconds.
5. The 7-segment display flashes “c.c.i n”.
6. The 7-segment display switches between “c.c. i n” and “c.c. * * * “ at 1-second intervals.
Check the number of connected indoor units [* * *].
If the number of indoor units is right, move on to 7.


(When the number of the connected indoor units differs from the number of indoor units displayed on the 7-segment display, clear the communication type setting to eliminate the cause.
To clear the communication type setting, push and hold the SW05 for 5 seconds or more.
The 7-segment display flashes “c.c.r S t” .
After a while, the 7-segment display switches between “c. c. b p s” and “c.c. 0”
Set the rotary switch back to SW01 to [1], SW02 to [1], SW03 to [1].

7. Push and hold SW06 for more than 5 seconds.
8. The 7-segment display flashes “c.c.b p s” .
After that, the setting is complete when the 7-segment display changes to “c.c F i n” .
(If the 7-segment display changes to “c.c. E r r”, try again.)
9. After a while, the 7-segment display switches between “c.c. b p s” and “c.c. 1 “ (or “ c.c. o “) at 1-second intervals.
10. Set the rotary switch on the interface P.C. board of the header outdoor unit back to SW01=[1], SW02=[1], SW03=[1].

Communication Type	7-segment display		Outdoor unit DN code No. (Q.DN)	Indoor unit DN code No. (I.DN)	
			[082] (Communication setting)	[FC] (Communication setting)	[1FC] (Indoor termination resistance setup)
TU2C-Link (U series and future models)	[A] [c.c.] [c.c.]	[B] [b P S] [1]	0003	0003	The farthest indoor unit (*1) 0001 Indoor units other than the left column 0000
TCC-Link (Other than U series)	[A] [c.c.] [c.c.]	[B] [b P S] [1]	0000	0000	0000

*1 : Only the indoor unit that has the longest wiring length from the outdoor unit.
The indoor address of the indoor unit with the terminator turned on is confirm the items in "7-7-11. Monitor Function of Remote Controller Switch".

Interface P.C. board on the header outdoor unit




■ Procedure to set up the communication method manually

The communication method and the terminal resistance settings can be changed by setting the outdoor DN code (O.DN) and the Indoor Unit Function Code (I.DN).

(See also 6-4. Method to set Outdoor Unit Function Code No. (O.DN) for operation method.)


<Procedure to set the TU2C-Link communication setting>

- 1) Set the Outdoor Unit Function Code (O.DN) [082] of all outdoor units to "0003".
 - 2) Set the Indoor Unit Function Code (I.DN) [FC] of all indoor units to "0003".
 - 3) Set the Indoor Unit Function Code (I.DN) [1FC] of the farthest indoor unit to "0001" (set the indoor terminating resistor to ON).
- * If which indoor unit is the unit in the farthest room is unknown, perform the communication method automatic setup.



<Procedure to set the TCC-Link communication setting>

- 1) Set the Outdoor Unit Function Code (O.DN) [082] of all outdoor units to "0000".
- 2) Set the Indoor Unit Function Code (I.DN) [FC] of all indoor units to "0000".
- 3) Set the Indoor Unit Function Code (I.DN) [1FC] of the farthest indoor unit to "0001" (set the indoor terminating resistor to OFF).




* The indoor DN code (I.DN) cannot be set regarding [FC] and [1FC] for the indoor units which are not the U Series; the communication method will be TCC-Link.

■ Procedure to clear the communication method (restoring the factory default [TCC-Link communication settings])


- This is a function in which the communication method setting for all the outdoor units and indoor units (every outdoor unit connected to the Uc line and every indoor unit connected to the Uv line) will reset to the TCC-Link communication settings. Also, the indoor terminal resistance settings for every indoor unit will be set back to OFF.
- The addresses for the indoor units (indoor address, line address, group address, and the zone address) will not be cleared.
- This function is also effective with unaddressed indoor units if connected to the Uv line.
- This function will not be available if there are no indoor units that can communicate with the outdoor unit. There must be at least one indoor unit that can communicate with the outdoor unit (in which the communication method is matched with the outdoor unit and its address is already set) to use this function. This function is available even if the communication method settings for the indoor unit and outdoor unit in the same system of TCC-Link and TU2C-Link coexist. The settings for the header outdoor unit to be operated can be either TCC-Link communication settings or TU2C-Link communication settings.

[Operation method]

1. Turn off indoor units first, and then turn off outdoor units.
2. Turn on DIP switch 2 of SW106 on the header outdoor unit interface P.C.boards.
3. Turn on the outdoor unit first, then turn on the indoor unit after about 20 seconds.
(Turn on the header unit, and then 20 seconds or more later, turn on the follower units and indoor units. If the follower units cannot be turned on after the header unit has been turned on, turn on both of them simultaneously.)
4. The 7-segment display indication “ - r S t. - “. Check all the units have turned on more than app 1 minute. Turn off all the indoor and outdoor units.
5. Turn off DIP switch 2 of SW106 on the header outdoor unit interface P.C.board.



<Example> Communication method clear operation in a system with mixed communication settings



■ In the case of an increase in address-undefined indoor units (extension, etc.)

To set up the indoor address of a unit with an address that is undefined due to the extension of indoor units or replacement of PC board, etc., follow the methods below.

1. Clear the communication setting

Setup procedure

- (1) Turn off indoor unit first, and then turn off outdoor units.
- (2) Turn on DIP switch 2 of SW106 on the header outdoor unit interface P.C. board.
- (3) Turn on the outdoor unit first, then turn on the indoor unit after about 20 second.
(Turn on the header unit, and then 20 seconds or more later, turn on the follower units and indoor units. If the follower units cannot be turned on after the header unit has been turned on, turn on both of them simultaneously.)
- (4) The 7-segment display indication “ - r S t. - ”. Check all the units have turned on more than approx. 1 minute. Turn off all the indoor and outdoor units.
- (5) Turn off DIP switch 2 of SW106 on the header outdoor unit interface P.C. board.

2. Address setting

Method 1

Set up an address individually from a wired remote controller.

(Line address, Indoor address, Group address, Central address)

For the setup method, refer to “Manual address setup from the remote controller.” above.

Method 2

Set up an address from the outdoor unit.

- * Leave the addresses of the units for which addresses have already been set up as they are. Set up an address only for the unit where the address is undefined.
Addresses are allocated from lower numbers.

Setup procedure

- (1) Turn on the indoor/outdoor power for the refrigerant line for which an address is to be set up.
After approximately 1 minute, check that “U.1. - - -” is displayed on the 7-segment display.
- (2) Execute the following operation on the interface PC board of the header unit.

SW01	SW02	SW03	SW04
2	14	2	After checking that “In.At” is displayed on the 7-segment display, push SW04 for 5 seconds or more.


“AUTO1” → “AUTO2” → “AUTO3” → ... → “AUTO9” ... is counted and displayed on the 7-segment display.

- (3) When “U.1. - - -” is displayed on the 7-segment display, the setup operation finished.
Turn off the indoor/outdoor power.

3. Communication setting (Auto setting)

Setup procedure

- (1) Turn on indoor units first, and then turn on outdoor units.
- (2) Set the rotary switch of the interface P.C. board on the header outdoor unit to SW01=[2], SW02=[16] and SW03=[2].
- (3) The 7-segment display switches between “c.c. b p s” and “c.c. 0” at 1-second intervals.
- (4) Push and hold SW04 for more than 5 seconds.
- (5) The 7-segment display flashes “c.c.i n”.
- (6) The 7-segment display switches between “c.c. i n” and “c.c. ***” at 1-second intervals.
Check the number of connected indoor units [***].
(When the number of the connected indoor units differs from the number of indoor units displayed on the 7-segment display, clear the communication type setting to eliminate the cause.
To clear the communication type setting, push and hold the SW05 for 5 seconds or more.
The 7-segment display flashes “c.c.r S t”.
After a while, the 7-segment display switches between “c.c. b p s” and “c.c. 0”.
Set the rotary switch back to SW01 to [1], SW02 to [1], SW03 to [1].)
- (7) Push and hold SW06 for more than 5 seconds.
- (8) The 7-segment display flashes “c.c.b p s”.
After that, the setting is complete when the 7-segment display changes to “c.c F i n”.
(If the 7-segment display changes to “c.c. E r r”, try again.)
- (9) After a while, the 7-segment display switches between “c.c. b p s” and “c.c. 1” (or “c.c. o”) at 1-second intervals.
- (10) Set the rotary switch on the interface P.C. board of the header outdoor unit back to SW01=[1], SW02=[1], SW03=[1].



■ Procedures for adding an indoor unit with communication method and address already set

In cases of adding a new indoor unit with the TU2C-Link setup or address setup already completed due to relocation etc., perform the setup 1) to 3) below.

1) Communication method

- Set the communication method of the indoor unit and the already existing system to the same settings.
 - Method 1 The communication method and indoor terminating resistance can be set automatically after performing "Clear communication method", by setting the address to the added indoor unit, and then performing "Automatic setting of communication method".
 - Method 2 Change the indoor DN code (I.DN) [FC] of the additional indoor unit to match the communication method of the existing system.
If the indoor unit to be added is in the farthest room, turn the indoor terminal resistance on, and turn the indoor terminal resistance off for the other (already existing) indoor units.

2) Indoor terminal resistance

- If setting to TCC-Link communication method, turn the indoor terminal resistance OFF for every indoor unit in the same system.
The indoor terminal resistance for every indoor unit can be turned off at once by performing the communication method clear from the header outdoor unit.
- If setting to TU2C-Link communication method, turn the indoor terminal resistance for one of the indoor units in the farthest room ON.
If which indoor unit is the unit in the farthest room is unknown, check the address for the indoor unit that the indoor termination resistance has been automatically set by performing "communication method automatic setup" after performing "communication method setup".

3) Address setup

- Change the system address to match the already-existing system.
- Make sure not to set duplicate indoor addresses.
 - Method 1 Perform the method "In case of adding an unaddressed indoor unit (due to expansion etc.)" after setting the communication method of the indoor unit to be added to that of the already-existing system, and clearing the address.
 - Method 2 Change the communication method setting and the address for the indoor unit to be added manually from the indoor DN code (I.DN).


* The following functions are available under both TU2C-Link communication and TCC-Link communication. Note however, that the address clear and automatic address settings will not function as intended if these functions were to be performed under mixed communication methods.

- Clear all indoor addresses, system address, and group addresses at once... Set the rotary switch SW01/SW02/SW03 on header outdoor unit to [2/1/2], and press SW04 for five seconds or longer.
- Clear all zone addresses at once ... Set the rotary switch SW01/SW02/SW03 on header outdoor unit to [2/2/2], and press SW04 for five seconds or longer.
- Automatic address setting ... Press SW06 on header outdoor unit when all indoor units have no indoor address set, and a "L08" error is occurring.
- Automatic address setting for unaddressed indoor units ... Set the rotary switch SW01/SW02/SW03 on header outdoor unit to [2/14/2], and press the SW04 five seconds or longer.

■ (Reference) Method to clear when communication method settings, address set / unset are coexisting


- If units with different communication method settings or units with set / unset addresses are coexisting, It can be changed back to the factory default settings by performing "Clear communication method" – "Clear all addresses (line, indoor, and group addresses) at once". Redo the address settings and communication method setting after this.

* Make sure that the communication method clearing is performed in advance.
If the addresses are batch-cleared before clearing the communication method, the communication method cannot be cleared since there will be no indoor units that can communicate with the outdoor unit.




Communication clearing method

- Communication settings for outdoor units and indoor units will automatically change from 3 to 0, and the indoor terminal resistance setting will automatically change from 1 to 0




Batch-clearing of addresses (Line, indoor, and group addresses)




**(Reference) Operations for communication method automatic setup / communication method clear, automatic address setting / address batch clear
(When the outdoor unit, indoor unit, and the remote controller are all U series)**

[Communication method settings] ... See the section on automatic settings for communication method.
 [Clear communication method] ... See the section on how to clear the communication method.
 [Automatic address setting] ... Press SW06 on header outdoor unit when all indoor units have no indoor address set, and an "L08" trouble is occurring.
 [Batch clear all indoor addresses, line address, and group addresses] ... Set the rotary switch SW01/SW02/SW03 on header outdoor unit to [2]/[1/2], and press the SW04 for five seconds or longer.



7-4-4. Check after Address Setup when Central Control System Is Connected

When the central control system is connected, check that the following setup has finished after address setup.



	Main check items	Check
Terminator resistor	(1) Is the terminator resistor (SW100-bit1) of the header unit with the smallest line address number in the central control turned on? (Setup is unnecessary for follower units. (Factory default : OFF))	
	(2) Is the terminator resistor (SW100-bit1) of the header units, except for the line with the smallest central control line address, turned off? (Setup is unnecessary for follower units. (Factory default : OFF))	
Line address	(3) Are addresses in the line address (SW101,SW102) not duplicated in each refrigerant line?	

NOTE


The figure above does not show all the electric wires.

For details, refer to the installation manuals for the outdoor unit, indoor unit, remote controller, or optional devices.

7-5. Troubleshooting in Test Operation

If there are phenomena such as the output of a check code or the remote controller is not accepted when powered on after wiring work or during address setup operation, the following causes are considered.

7-5-1. A Check Code is Displayed on the Remote Controller

Check the code displayed on the indoor remote controller	Header unit 7-segment display	Cause	Countermeasures
E04		When outdoor power is off	Check that the header outdoor unit power is on
	L08	Address setup trouble <ul style="list-style-type: none"> Only line addresses of the connected indoor units are undefined. The outdoor line address and the line addresses of all the indoor units do not match. The indoor addresses are duplicated. (Units except those displaying E04 are duplicated.) A header unit is not set up in group control (except groups displaying E04). 	Set up the address again.
	E08 ⇔ -XXX Alternate blinking	Duplication of indoor addresses (address number in the subcode of the check code are duplicated).	Set up the address again.
	E07	When the terminator resistor (SW100 bit2) in the communication line between indoor and outdoor units (Uv) on the outdoor unit has not been turned on or two or more terminator resistors have been turned on (After address setup, when terminator resistor setup is changed after powering-on) 	Check SW100 bit 1 or bit 2 of the header unit. No connection between multiple refrigerant lines: Turn off SW100 bit 1 and turn on bit 2. Connection between multiple refrigerant lines: Turn on SW100 bit 1 of only the connected header unit for one line. Turn on SW100 bit2 of all the header units. *Factory default : SW100 bit 1 is off, bit 2 is off.
		Transmission circuit trouble at the interface side (P.C. board failure)	Replace the interface PC board.
	E06	After address setup, communication from all the indoor units is interrupted under the condition that a normal operation can be performed.	Check and correct disconnection of the indoor/outdoor communication line (the communication line between the header unit and the leading indoor unit). Check for the influence of communication noise. In TU2C-LINK communication system, if the termination resistance is not set in any of the indoor units.
E16	E16.X	Exceeded the number or capacity of connected indoor units	Adjust the number or capacity of connected indoor units.
E23	E23	Communication between outdoor units has stopped.	Check the number of connected outdoor units. Check that outdoor unit power is on.
E25	E25	Duplication of outdoor addresses (only when an outdoor address was manually set up)	Do not use manual setup for outdoor addresses.
E26	E26 ⇔ -XX Alternate blinking	Number of connected outdoor units has decreased. <ul style="list-style-type: none"> When installing an outdoor backup The power of a follower unit is not turned on. 	Correction of the cause of trouble occurrence <ul style="list-style-type: none"> If it occurs when installing a backup, clear the trouble after setup finishes. If the power of a follower unit is not turned on, turn on the power.
L04	L04	Duplication of outdoor line addresses <ul style="list-style-type: none"> Line address setup trouble (occurred after connection between U1/U2 and U3/U4 connectors) 	Modify the line address setup of the header unit between lines. (Set up SW13 and SW14 on the interface PC board.)
L05(*)	L06	Duplication of indoor units with priority	Set up priority only for one indoor unit.
L06(*)	None	There are two or more indoor units set up with priority.	Among indoor units indicating "L05," set one unit with priority.
L08	L08	Address setup trouble <ul style="list-style-type: none"> Only indoor addresses of all the connected indoor units are undefined. 	Set up the addresses again. Modify the setup.

* "L05": Displayed on the indoor unit set up with priority

"L06": Displayed on the indoor units except the one set up with priority

7-5-2. No Remote Controller Response with Check Code

(Operation from the indoor remote controller is not accepted, and a check code is displayed on the 7-segment display of the interface PC board of the header unit)

Indoor remote controller status	Header unit 7-segment display	Cause	Countermeasures
No response	L08	Line addresses and indoor addresses of all the connected indoor units are not set.	Set up addresses.
		There is no header unit of group control.	Set up a group address.
	E19 ⇄ -00 Alternate blinking	Indoor unit power is not turned on.	Turn on the power again. (In the order: indoor → outdoor)
		Indoor/outdoor communication line is not correctly connected to the U1/U2 terminal of the header unit (Fig. 1). (Indoor/outdoor cannot communicate before address setup.)	Correct wiring
		When the terminator resistor (SW100 bit2) in the communication line between indoor and outdoor units (Uv) on the outdoor unit has not been turned on or two or more terminator resistors have been turned on (After address setup, when terminator resistor setup is changed after powering-on)	Check SW100 bit 1 or bit 2 of the header unit. No connection between multiple refrigerant lines: Turn off SW100 bit 1 and turn on bit 2. Connection between multiple refrigerant lines: Turn on SW100 bit 1 of only the connected header unit for one line. Turn on SW100 bit2 of all the header units. * Factory default : SW100 bit 1 is off, bit 2 is off.
	E19 ⇄ -02 Alternate blinking	When connecting an indoor/outdoor communication line between outdoor units under the condition of a connected communication line between outdoor units (Fig. 2).	Correct wiring
		SW08 setup trouble	Turn all SW08 switches to "off."
	E20 ⇄ -01 Alternate blinking	Address setup is performed with connecting an indoor/outdoor communication line between outdoor units (Fig. 3).	Correct wiring
		Address setup is performed under the condition of connecting multiple refrigerant lines (Fig. 3).	Correct wiring



7-5-3. No Remote Controller Response without Check Code

(There is no display of a check code on the 7-segment display on the interface PC board of the header unit, although there is indoor unit that is not accepting operation from the indoor remote controller)

Indoor remote controller status	Header unit 7-segment display	Cause	Countermeasures
No response	None	The communication line is not connected between indoor and outdoor (the unit that does not respond to the indoor remote controller).	Improve the wiring.
		Line address and indoor address are not set (the unit that does not respond to the indoor remote controller).	Set up the address.
		The power of the header unit of the group is not turned on in indoor group control (the unit that does not respond to the indoor remote controller).	Turn on the power.
		Group address is set to the follower unit for individual control (the unit that does not respond to the indoor remote controller).	Set the group address to "0" in the case of individual control.
No display on the indoor remote controller (no line is output.)	None	The power is not turned on (the unit that is not displayed on the indoor remote controller).	Turn on the power.
		The indoor remote controller is not connected with a wire (the unit that is not displayed on the indoor remote controller).	Improve the wiring.
		Miswiring of the indoor remote controller (the unit that is not displayed on the indoor remote controller)	Improve the wiring.
		Indoor remote controller communication circuit trouble (the unit that is not displayed on the indoor remote controller) If 220 V is incorrectly applied to the indoor remote controller terminal, the remote controller communication circuit fails.	Remove the quick connect terminal connected to indoor remote controller terminals A/B, and check the voltage. If voltage is not applied (normally 15 to 18 V), replace the PC board.

7-5-4. Connected Indoor/Outdoor Unit Quantity Check

(In checking the number of connected outdoor units and connected indoor units after address setup, a lower number of connected units is displayed (There are outdoor/ indoor units that do not operate in a test operation))

Status	Cause	Counter measures
The number of connected outdoor units is few.	Miswiring of communication lines between outdoor units or an unconnected wire (Fig. 4). (Address setup operation finished without recognizing a miswired follower unit.)	After improvement of wiring, set up the addresses again and check the number of connected outdoor units.
The number of connected indoor units is few.	Miswiring of communication lines between indoor units or an unconnected wire (Fig. 5). (Address setup operation finished without recognizing a miswired indoor unit.)	After modification of wiring, set up the addresses again and check the number of connected indoor units.
The number of indoor units connected to a group is few in group operation from an indoor remote controller.	The indoor remote controller is not connected with wire. Miswiring of the indoor remote controller	Using the main indoor remote controller connected to a group, start a test operation, specify the unit that is not operating (the unit not connected to the group), and then check the wiring.
	Indoor remote controller communication circuit trouble If 220 V is incorrectly applied to the remote controller terminal, the remote controller communication circuit fails.	Using the main indoor remote controller connected to a group, start a test operation and then specify the unit that is not operating (the unit not connected to the group). Remove the quick connect terminal connected to remote controller terminals A/B, and check the voltage. If voltage is not applied (normally 15 to 18 V), replace the PC board.


Miswiring example

Figure	Remote controller status	Header unit 7-segment display	Miswiring example
Fig 1	No response	E19, 02	<ul style="list-style-type: none"> • Follower unit is incorrectly set to header unit. <ul style="list-style-type: none"> • Indoor/outdoor communication line is miswired to header unit of other system.
Fig 2	E04	L08	<ul style="list-style-type: none"> • Indoor/outdoor communication line is miswired to Uh (U3/U4). <ul style="list-style-type: none"> • Indoor/outdoor communication line is not connected.

Figure	Status	Miswiring example
Fig 3	The number of connected outdoor units is few.	<ul style="list-style-type: none"> • Outdoor communication line is miswired to Uh (U3/U4).
Fig 4	The number of connected indoor units is few.	<ul style="list-style-type: none"> • Indoor/outdoor communication line is miswired to remote controller terminal (A/B). <ul style="list-style-type: none"> • There is an indoor unit not connected to the indoor/outdoor communication line.

7-6. Test Operation (test run) Check

7-6-1. Fan Check



Check every indoor unit in turn.

7-6-2. Cooling/Heating Test Operation Check

The cooling/heating test operation check can be performed on both the indoor remote controller and the outdoor header unit interface PC board.






(1) Test operation start/stop operation


Test operation from the indoor remote controller

- Wired remote controller: Refer to the items below in “Test operation” of the wired remote controller.
- Wireless remote controller: Refer to the items below in “Test operation” of the wireless remote controller.

▼ Wired remote controller

<RBC-AMT*>


Procedure	Operation content
1	When the Test button is pushed for 4 seconds or more, “TEST” is displayed in the display section, and the unit enters test operating mode. 
2	Push the  button.
3	Using the Select Mode button, select the “* COOL” or “* HEAT” operating mode. <ul style="list-style-type: none"> • Do not use an operating mode other than “* COOL” or “* HEAT”. • Temperature adjustment is unavailable during test operation. • Trouble is detected as usual. 
4	When the test operation has finished, push the  button to stop the operation. (The same display as in procedure 1 appears in the display section.)
5	Push the Test button to clear the test operating mode. (“TEST” disappears from the display section, and the status returns to the normal stopped status.) 





<RBC-ASCU11*>





Be sure to stop the air conditioner before making settings.

(Change the setup while the air conditioner is not working.)



- 1 Push and hold OFF timer button and [] setting button simultaneously for 10 seconds or more. [TEST] is displayed on the display part and the test run is permitted.**




- 2 Push ON/OFF button.**
- 3 Push menu button to select the operation mode. Select [ Cool] or [ Heat] with [] [] setting button.**

- Do not run the air conditioner in a mode other than [Cool] or [Heat].
- The temperature setting function does not work during test run.
- The check code is displayed as usual.

- 4 After the test run, push OFF timer button to stop a test run.**

([TEST] disappears on the display and the air conditioner enters the normal stop mode.)



▼ Wireless remote controller

1 Turn on the power of the air conditioner. When power is turned on for the first time after installation, it takes approx. 5 minutes until the remote controller becomes available. In the case of subsequent power on, it takes approx. 1 minute until the remote controller becomes available. Execute a test run after the predetermined time has passed.

2 Push “ON/OFF” button on the remote controller, select [ Cool] or [ Heat] with “MODE” button, and then select [ HIGH] with “FAN” button.

3

Cooling test run	Heating test run
Set the temperature to 17°C with the temp. setup buttons.	Set the temperature to 30°C with the temp. setup buttons.

4

Cooling test run	Heating test run
After confirming a signal receiving sound “beep” immediately set the temperature to 18°C with the temp. setup buttons.	After confirming a signal receiving sound “beep” immediately set the temperature to 29°C with the temp. setup buttons.

5

Cooling test run	Heating test run
After confirming a signal receiving sound “beep” immediately set the temperature to 17°C with the temp. setup buttons.	After confirming a signal receiving sound “beep” immediately set the temperature to 30°C with the temp. setup buttons.

6 Repeat procedures 4 → 5 → 4 → 5. Indicators “Operation” (green), “Timer” (green), and “Ready” (orange) in the wireless receiver section flash in approx. 10 seconds, and the air conditioner starts operation. If any of these indicators does not flash, repeat procedures 2 to 5.

7 Upon completion of the test run, push “ON/OFF” button to stop operation.

<Overview of test run operations using the wireless remote controller>

Cooling test run:

ON/OFF → 17°C → 18°C → 17°C → 18°C → 17°C → 18°C → 17°C → (test run) → ON/OFF

Heating test run:

ON/OFF → 30°C → 29°C → 30°C → 29°C → 30°C → 29°C → 30°C → (test run) → ON/OFF


Test operation from the outdoor unit

- Refer to “7-7-2. Function to Start/Stop (ON/OFF) Indoor Unit from Outdoor Unit” in “7-7. Service Support Function.”

CAUTION

- The test run is a forced run that ignores the set temperature. Be sure to stop the test run after work, paying attention to the room temperature.
- After 60 minutes, the test run will be completed to protect the equipment, and the normal operation will be started according to the set temperature.

(2) Test operation



Note 1: Criteria for the difference between suction and discharge temperatures

(1) Cooling operation

After operating for a minimum of 30 minutes in "COOL" mode, if the T dry bulb temperature difference between suction and discharge air of the indoor unit is 8°C or more, it is normal.

(2) Heating operation

After operating for a minimum of 30 minutes in "HEAT" mode, if the T dry bulb temperature difference between suction and discharge air of the indoor unit is 15°C or more, it is normal.

* If demand from the indoor unit on the outdoor unit is low because the difference between the temperature set by the remote controller and the temperature of the room is small, then the T temperature difference is small.

* Consider that T temperature difference may diminish in cases of a system in which the connected indoor unit capacity exceeds the outdoor unit capacity, the pipe length is long, or a large difference exists among outdoor units.

Note 2: Criteria for operating power current

The table below shows the maximum current for each outdoor unit. Under standard conditions, operating current is about 80% of the value shown in the table below.

Model	MMY-MUP	0801*	1001*	1201*	1401*	14A1*
Current value	(A)	15.4	20.5	24.5	27.5	27.0
Model	MMY-MUP	1601*	1801*	2001*	2201*	2401*
Current value	(A)	30.5	34	36	51	54

Note 3: Criteria for cycle status

(1) These data are based on operating a 4-way Air Discharge Cassette type air conditioner of 100% connection with standard piping length.

Data may vary depending on temperature conditions, installed pipe length, and room shape combinations, or indoor unit connection capacity.

For pressure criteria in different temperature conditions, refer to (2).

Outdoor Unit MMY-MUP	Operating Mode	Pressure (MPa)		Pipe Surface Temperature (°C)					Compressor Rotation (rps)		Indoor Fan	Air Temperature (DB/WB)(°C)	
				Discharge	Suction	Indoor Heat Exchanger	Outdoor Heat Exchanger	Liquid Temperature	Compressor 1	Compressor 2		Outdoor	Indoor
		Pd	Ps	TD1	TS1	TC2	TE1	TL3	Cmp. 1	Cmp. 2		TO	TA
0801*	Cooling	3.0	1.0	79	21	15	39	26	50	—	High	35	27
	Heating	2.4	0.7	67	2	25	1	21	57	—	High	7	20
1001*	Cooling	3.1	1.0	82	21	15	40	26	56	—	High	35	27
	Heating	2.8	0.7	79	2	23	0	17	63	—	High	7	20
1201*	Cooling	3.4	1.1	86	21	15	40	29	65	—	High	35	27
	Heating	2.5	0.7	75	1	25	0	16	75	—	High	7	20
1401*	Cooling	3.7	1.1	91	20	16	41	33	77	—	High	35	28
	Heating	2.4	0.7	73	1	26	-1	22	83	—	High	7	20
14A1*	Cooling	3.1	1.0	81	19	15	41	33	77	—	High	35	27
	Heating	2.5	0.7	73	1	26	-1	22	83	—	High	7	20
1601*	Cooling	3.2	1.0	85	19	15	43	28	65	—	High	35	27
	Heating	2.5	0.6	71	-1	27	1	17	68	—	High	7	20
1801*	Cooling	3.4	1.0	90	19	14	42	28	70	—	High	35	27
	Heating	2.5	0.6	72	-2	27	2	22	77	—	High	7	20
2001*	Cooling	3.3	0.9	92	20	14	43	31	77	—	High	35	27
	Heating	2.5	0.6	79	0	25	0	1	82	—	High	7	20
2201*	Cooling	3.5	1.0	94	27	15	42	29	71	70	High	35	27
	Heating	2.7	0.6	82	-1	25	0	-4	79	77	High	7	20
2401*	Cooling	3.7	1.0	98	21	15	43	30	78	77	High	35	27
	Heating	2.6	0.6	81	-1	24	0	20	79	77	High	7	20

* This compressor is driven with a 6-pole motor. The value of the compressor frequency (rps) measured with a clamp meter at the compressor lead line is three times the rotation count (rps) of the compressor.

* Each compressor may have a different frequency as a measure against resonance.

* The temperature of the indoor heat exchanger (TC) indicates TCJ sensor temperature when cooling, and TC2 sensor temperature when heating, respectively.

(2) Criteria for operating pressure

Operating Mode	Pressure (MPa)		Temperature (°C)	
	Pd	PS	Indoor	Outdoor
Cooling	2.0 ~ 3.3	0.5 ~ 0.9	18 ~ 32	25 ~ 35
Heating	2.5 ~ 3.3	0.5 ~ 0.7	15 ~ 32	5 ~ 35

* Criteria after 14 minutes or more has passed since operating started

7-7. Service Support Function


7-7-1. Check Function for Connecting of Refrigerant and Control Lines

This function is provided to check misconnection of the refrigerant pipes and the control transmission line (Wiring over lines) between indoor unit and outdoor unit by using the switch on the interface P.C. board of the header unit.

However, be sure to check the following items prior to executing this check function.


- 1 This check function does not work when a group operation by remote controller is performed and it is used over outdoor units.
- 2 When using this check system, be sure to check for each 1 line in the unit of outdoor unit. If checking the multiple lines at the same time, misjudgment may be caused.

(Check procedure)




On rotations of outdoor fans

Outdoor fans may rotate slowly to control pressure when cooling with low outer air temperature or heating with excessive load. For control content, also refer to items in Section 5, “Control Outline: Outdoor Unit, Outdoor Fan Control.”



Interface P.C. board



7-7-2. Function to Start/Stop (ON/OFF) Indoor Unit from Outdoor Unit

The following functions of the indoor unit can start or stop by the switches on the interface P.C. board of the header unit.


No	Function	Outline	Setup/Release	7-segment display	
1	Cooling test operation	Changes the mode of all the connected indoor units collectively to cooling test operation. Note) Control operation same as usual test operation from remote control is performed.	[Setup] Set SW01/SW02/SW03 to [2/5/1], and press SW04 for 2 seconds or more. [Release] Return SW01/SW02/SW03 to [1/1/1].	Section A [C.]	Section B [– C]
2	Heating test operation	Changes the mode of all the connected indoor units collectively to heating test operation. Note) Control operation same as usual test operation from remote control is performed.	[Setup] Set SW01/SW02/SW03 to [2/6/1], and press SW04 for 2 seconds or more. [Release] Return SW01/SW02/SW03 to [1/1/1].	Section A [H.]	Section B [– H]
3	Fan test operation	Changes operation mode of all the connected indoor units collectively to test operation mode. Note) Control operation same as usual test operation from remote control is performed.	[Setup] Set SW01/SW02/SW03 to [2/9/1], and push SW04 for 2 seconds or more. [Release] Return SW01/SW02/SW03 to [1/1/1].	Section A [F.]	Section B [– F]
4	Batch start	Starts all the connected indoor units collectively. Note) The contents follow to the setup of remote controller.	[Setup] Set SW01/SW02/SW03 to [2/7/1], and press SW04 for 2 seconds or more. [Release] Return SW01/SW02/SW03 to [1].	Section A [C.H]	Section B [11] [00] is displayed on Section B for 5 seconds.
	Batch stop	Stops all the connected indoor units collectively.	[Setup] Set SW01/SW02/SW03 to [2/7/1], and press SW05 for 2 seconds or more. [Release] Return SW01/SW02/SW03 to [1].	Section A [C.H]	Section B [00] [00] is displayed on Section B for 5 seconds.
5	Individual start	Starts the specified indoor unit. Notes) • The contents follow to the setup of remote controller. • The other indoor units keep the status as they are.	[Setup] Set SW01 to [16], set SW02 and SW03 to address No. (1 to 128) to be started, and press SW04 for 2 seconds or more. [Release] Return SW01/SW02/SW03 to [1/1/1].	Section C []	Section D [] Section C: Displays the corresponding indoor address. Section D: Displays [11] for 5 seconds from operation-ON.
	Individual stop	Stops the specified indoor unit. Note) The other indoor units keep the status as they are.	[Setup] Set SW01 to [16], set SW02 and SW03 to address No. (1 to 128) to be stopped, and press SW05 for 2 seconds or more. [Release] Return SW01/SW02/SW03 to [1/1/1].	Section C []	Section D [] Section C: Displays the corresponding indoor address. Section D: Displays [00] for 5 seconds from operation-OFF.
	Individual test operation	Operates the specified indoor unit. Note) The other indoor units keep the status as they are.	[Setup] Set SW01 to [16], set SW02 and SW03 to address No. to be operated, and press SW04 for 10 seconds or more. [Release] Return SW01/SW02/SW03 to [1/1/1].	Section C []	Section D [] Section C: Displays the corresponding indoor address. Section D: Displays [FF] for 5 seconds from test operation-ON.

NOTE 1) This start/stop function only sends the signals from the outdoor unit to the indoor unit, such as start, stop, operation mode, etc. It does not resend the signals even if the indoor unit does not follow the sent signals.

NOTE 2) The above controls are not used during abnormal stop.

NOTE 3) If the signal receiving unit of the Compact 4-way Cassette type has never received a signal from the wireless remote controller, the indoor unit cannot be started or stopped (ON/OFF) from the outdoor unit. In the case above, follow the steps below.


- 1) Point the wireless remote controller at the receiving unit on the indoor unit and press the START/STOP button on the wireless remote controller.
- 2) Confirm that the receiving unit sounds “Pi” and the operation lamp (green) on the receiving unit lights up, and then start/stop (ON/OFF) the indoor unit from the outdoor unit.




(1) Cooling test operation function

This function is provided to change collectively the mode of all the indoor units connected to the same system for the cooling test operation mode, by using switches on the interface board of the header unit.

<Operation procedure>



Interface P.C. board





NOTE) The test operation returns to the normal operation after 60 minutes.

- The test run is a forced run that ignores the set temperature. Be sure to stop the test run after work, paying attention to the room temperature.
- After 60 minutes, the test run will be completed to protect the equipment, and the normal operation will be started according to the set temperature. However, if there is no remote controller (using a Central controller), please manually stop the test run after 60 minutes because there are some type of indoor unit that will continue operating test run even after 60 minutes.

(2) Heating test operation function

This function is provided to change collectively the mode of all the indoor units connected to the same system for the heating test operation mode, by using switches on the interface board of the header unit.

<Operation procedure>




NOTE) The test operation returns to the normal operation after 60 minutes.

- The test run is a forced run that ignores the set temperature. Be sure to stop the test run after work, paying attention to the room temperature.
- After 60 minutes, the test run will be completed to protect the equipment, and the normal operation will be started according to the set temperature. However, if there is no remote controller (using a Central controller), please manually stop the test run after 60 minutes because there are some type of indoor unit that will continue operating test run even after 60 minutes.


(3) Fan test operation function

This function is provided to change collectively the mode of all the indoor units connected to the same system for the fan test operation mode by using switches on the interface P.C. board of the header unit.

<Operation procedure>



Interface P.C. board




NOTE)

- Be sure to stop the test run after work.
- The test run finished after 60 minutes and the operation returns to normal operation. However, if there is no remote controller (using a central controller), please manually stop the test run after 60 minutes because there are some type of indoor unit that will continue operating test run even after 60 minutes.


(4) Batch start/stop (ON/OFF) function

This function is provided to start/stop collectively all the indoor units connected to the same system by using switches on the interface board of the header unit.

<Operation procedure>



Interface P.C. board




(5) Individual start/stop (ON/OFF) individual test operation function

This function is provided to start/stop (ON/OFF) individually each indoor unit connected to the same system by using switches on the interface board of the header unit.

Set SW01 [16] and set SW02, SW03 to indoor address No. (1 to 128) to be started (Refer to the following table*) - only the setup indoor unit starts operation.

(In the rotary switches of the indoor unit which operates in a group by the remote controller, the follower unit cannot be individually started or stopped. In this case, [- -] is displayed on 7-segment display [D] on the interface P.C. board of the header unit.)

<Operation procedure>



NOTE) The individual test operation returns to the normal operation after 60 minutes.

- The test run is a forced run that ignores the set temperature. Be sure to stop the test run after work, paying attention to the room temperature.
- After 60 minutes, the test run will be completed to protect the equipment, and the normal operation will be started according to the set temperature. However, if there is no remote controller less setting is set, some indoor models will not complete the test run even after 60 minutes have passed.

7-7-3. Check Code Clearing Function

(1) Clearing from the main remote controller

<RBC-AMT*>


▼ Check code clearing in outdoor unit

Check code of the outdoor unit currently detected is cleared by the unit of one refrigerant circuit system to which the indoor units operated by the remote controller is connected. (Check code of the indoor unit is not cleared.)

For clearing check codes, the service monitor function of the remote controller is used.

<Method>

- 1** Change the mode to service monitor mode by pushing **CL** + **TEST** buttons simultaneously for 4 seconds or more.
- 2** Using **TEMP.** buttons, set CODE No. to "FF".
- 3** The display in Section A in the following figure is counted with interval of 5 seconds as "0005" → "0004" → "0003" → "0002" → "0001" → "0000".
When the count arrives "0000", the check code is cleared.
* However, counting from "0005" is repeated on the display.
- 4** When **TEST** button is pushed, the status returns to the normal status.



▼ Check code clearing in indoor unit


Check code in the indoor unit is cleared by **ON / OFF** button on the remote controller.

(Only check code of the indoor unit connected with operating remote controller is cleared.)

<RBC-ASCU11*>

▼ Clearing a check code of the outdoor unit

There is no such function in the remote controller.






- 1** Push the [OFF timer] button for over 10 seconds.
- 2** Each time the [▽ or △] button is pushed, the recorded troubleshooting history is displayed in sequence.
- 3** Push the [menu] button for over 10 seconds, doing so deletes the entire troubleshooting history of the indoor unit.
- 4** After you have finished checking, push the [ON/OFF] button to return to normal mode.

(2) Clearing check code by using switches on the interface board of the header unit

Using the switches on the interface P.C. board of the header unit, this function is to clear the currently detected check code for each refrigerant circuit system without resetting the power supply.

Check codes in both outdoor and indoor units are once cleared, and check code detection is performed again.

- | | |
|--|---|
| <p>[1] Set the rotary switches on the interface P.C. board of the header unit as follows.
Set SW01/SW02/SW03 to [2/16/1]</p> | <p>7-segment display
[A] [B]
[E r][]</p> |
|  | |
| <p>[2] Press the push-switch SW04 on the same board for 5 seconds or more.</p> | |
|  | |
| <p>[3] [C L] is displayed in 7-segment display [B] on the board (for 5 seconds), and check code is completely cleared.</p> | <p>7-segment display
[A] [B]
[E r][C L]</p> |



(3) Clearing check code by resetting power

This function is provided to clear check code in a system by resetting the power of all the outdoor and the indoor units. As same as the clearing method by the interface P.C. board, check codes of both the outdoor and the indoor units are once cleared, and check code detection is performed again.



<Method>

- (1) Be sure to reset power of both the outdoor and the indoor units.
- (2) Turn on the power of the indoor unit prior to the power of the outdoor unit.
(If the power is turned on in reverse order, a check code [E19] (No. of header unit trouble) is output.)

NOTE) After power reset, it requires usually 3 minutes to power-on due to the initial communication of the system. In some cases, it requires max. 10 minutes.

7-7-4. Remote Controller Distinction Function

This function is provided to distinguish the remote controller connected to the indoor unit from the outdoor unit for a refrigerant circuit system by using switches on the interface P.C. board of the header unit.
<Distinction procedure>



7-7-5. Pulse Motor Valve (PMV) Forced Open/Close Function in Indoor Unit

This function is provided to open or close forcedly PMV for 2 minutes in all the indoor units by the switch operation on the interface P.C. board of the header unit.

This function is also used to open PMV fully when turning off the power and executing an operation.

<Operation>

[Open fully]

Set the switches SW01/SW02/SW03 on the interface P.C. board of the header unit to [2/3/1], and press SW04 for 2 seconds or more.

(Display appears on 7-segment display for 2 minutes as follows.) [P] [FF]

[Close fully]

Set the switches SW01/SW02/SW03 on the interface P.C. board of the header unit to [2/3/1], and press SW05 for 2 seconds or more.

(Display appears on 7-segment display for one minute as follows.) [P] [00]

[Clear]

After 2 minutes (1 minutes for “Close fully”) after setting up, the opening automatically returns to the normal opening.

7-7-6. Pulse Motor Valve (PMV) Forced Open/Close Function and Solenoid valve Forced ON

Function in Outdoor Unit

The solenoid valves provided to outdoor units can be forced ON (open) by switching operations at the interface P.C. board of the outdoor unit.

Also, the pulse motor valves (PMV1, PMV2, PMV3, PMV4) of the outdoor unit can be forced to full-open, half open, and full-closed for two minutes.


Use this function to check for valve or PMV malfunctioning, clogging, and so forth.

[Control start method]


- Set the rotary switches [SW01/SW02/SW03] on the interface P.C. board of the outdoor unit to [2/1/3].
When [H.r — —] is displayed, press the push switch [SW04] for one second or longer, which changes the display to [H. r — —], and this control is started.

[Method to switch solenoid valve/PMV display]

- Solenoid valve display is made immediately after starting control.
The 7-segment display is [H. r — —].
- Pressing the push switch [SW06] switches the display to [P. * * * *], which is PMV display.
Each time the push switch [SW06] is pressed, the display changes between solenoid valve display and pulse motor valve (PMV) display.



- Follow the method below for solenoid valve and PMV operations.
* Take care, as operations of each of the solenoid valve and PMV are enabled, regardless of which is displayed.



[Method of operating solenoid valve (forced ON)]

- Set the rotary switch [SW02] to 2, and five seconds later SV41 will come ON. [H.r 41] will be displayed in the 7-segment display in the solenoid valve display screen.
- Any desired solenoid valve can be forced ON by changing the setting No. of the rotary switch [SW02].
The following table shows the forced-ON/normal control patterns for each solenoid valve.

Rotary switch			7-segment display (solenoid valve display)	Operation patterns of solenoid valve/heater (✓ : Forced ON, — : normal control)				
SW01	SW02	SW03		SV41	SV42	SV3D	SV3F	Compressor 1, 2 case heater
2	1	# Used in PMV operations	[H.r — — —]	—	—	—	—	✓
	2		[H.r 4 1]	✓	—	—	—	✓
	3		[H.r 4 2]	—	✓	—	—	✓
	4		[H.r 3 D]	—	—	✓	—	✓
	5		[H.r 3 F]	—	—	—	✓	✓
	6		[H.r 3 —]	—	—	✓	✓	✓
	7 ~ 15		[H.r — — —]	—	—	—	—	✓
	16		[H.r A L L]	✓	✓	✓	✓	✓

* The 7-segment display will show [H.r —] for outdoor unit models that do not have solenoid valves.

[Method of operating pulse motor valve (PMV) (forced open/close)]

(1) Use the rotary switch [SW03] to select the PMV to operate.

When [P#.] is displayed in the PMV display, PMV# is operating according to normal control.

(#: selected PMV No.)






(2) Pressing the push switch [SW04] for one second sets the selected PMV# to full-open.

The PMV display will be [P# . F o].

Each time the push switch [SW04] is pressed again for one second, the opening changes in the order of full open [P# . F o] → half-open [P# . C o] → full-closed [P# . F c] → normal control [P# .] → full-open [P# . F o] → ... , and so on.

(3) The PMV opening returns to normal control after two minutes elapses from changing the opening.

(Operation method example) Operation of PMV 1

Rotary switch			Push switch	7-segment display (pulse motor valve (PMV) display)	Opening		
SW01	SW02	SW03	SW04 (Change PMV opening)				
2	* Used in solenoid valve selection	3		[P1.]	PMV1 Normal control		
			 Long-press 1 second	[P1.F o]	PMV1 Full-open		2 minutes elapsed
			 Long-press 1 second	[P1.C o]	PMV1 Half-open		2 minutes elapsed
			 Long-press 1 second	[P1.F c]	PMV1 Full-closed		2 minutes elapsed
			Long-press 1 second				

(4) To operate a different PMV, select with the rotary switch [SW03], and operate the opening with the push switch [SW04].

Even when [SW03] is switched, the PMV opening operated immediately before remains effective, so up to four PMV openings can be operated in parallel.

Rotary switch			Push switch	7-segment display (pulse motor valve (PMV) display)	Opening
SW01	SW02	SW03	SW04		
2	* Used in solenoid valve selection	3	Long-press 1 second to change opening	[P1.]	PMV1 Normal control
				[P1.F o]	PMV1 Full-open
				[P1.C o]	PMV1 Half-open
				[P1.F c]	PMV1 Full-closed
		4	Long-press 1 second to change opening	[P2.]	PMV2 Normal control
				[P2.F o]	PMV2 Full-open
				[P2.C o]	PMV2 Half-open
				[P2.F c]	PMV2 Full-closed
		5	Long-press 1 second to change opening	[P3.]	PMV3 Normal control
				[P3.F o]	PMV3 Full-open
				[P3.C o]	PMV3 Half-open
				[P3.F c]	PMV3 Full-closed
		6	Long-press 1 second to change opening	[P4.]	PMV4 Normal control
				[P4.F o]	PMV4 Full-open
				[P4.C o]	PMV4 Half-open
				[P4.F c]	PMV4 Full-closed

[Cancellation method]

To cancel (end) control of this function, perform one of the following methods. The solenoid valve and pulse motor valve (PMV) will return to normal control.

- Press the push switch [SW05] for one second or longer.
- Set the rotary switch [SW01] to other than [2].

7-7-7. Fan Operation Check in Outdoor Unit

This function is provided to check the fan operation of the outdoor unit by using switches on the interface P.C. board in the outdoor unit. The fan speed can be controlled by setting of the switches. Use this function to check the operation or abnormal sound in the fan system. And, use this function while the system is stopped.

NOTE) Do not use this function during operation of the compressor. It may damage the compressor.

Two fans move synchronously in two fan model (MMY-MUP14A1* to MUP2401*).

[Operation]

- (1) Set the switches SW01/SW02/SW03 on the interface P.C. board of the outdoor unit to [2/1/4].
- (2) When [F. d] is displayed in 7-segment display [A], keep pressing the switch SW04 for 2 seconds or more.
- (3) When [63] is displayed in 7-segment display [B], the fan starts operation. (Max. mode operation)
- (4) After that, by changing the setup number of the switches SW02 and SW03, 7-segment display [B] and the fan mode are changed.
(Mode output pattern of the fan is as follows.)

SW02	SW03	7-segment display [B]	Fan mode
1	4	[63]	63
2		[62]	62
3		[61]	61
4		[60]	60
5		[59]	59
6		[58]	58
7		[57]	57
8		[56]	56
9		[55]	55
10		[54]	54
11		[53]	53
12		[52]	52
13		[51]	51
14		[50]	50
15		[49]	49
16		[48]	48
1	5	[47]	47
2		[46]	46
3		[45]	45
4		[44]	44
5		[43]	43
6		[42]	42
7		[41]	41
8		[40]	40
9		[39]	39
10		[38]	38
11		[37]	37
12		[36]	36
13		[35]	35
14		[34]	34
15		[33]	33
16		[32]	32

SW02	SW03	7-segment display [B]	Fan mode
1	6	[31]	31
2		[30]	30
3		[29]	29
4		[28]	28
5		[27]	27
6		[26]	26
7		[25]	25
8		[24]	24
9		[23]	23
10		[22]	22
11		[21]	21
12		[20]	20
13		[19]	19
14		[18]	18
15		[17]	17
16		[16]	16
1	7	[15]	15
2		[14]	14
3		[13]	13
4		[12]	12
5		[11]	11
6		[10]	10
7		[9]	9
8		[8]	8
9		[7]	7
10		[6]	6
11		[5]	5
12		[4]	4
13		[3]	3
14		[2]	2
15		[1]	1
16		[0]	0

[Clear]

This function is cleared by one of the following operations.

- (1) When SW01 setting number was changed to other number.
- (2) Press-switch SW05 was pressed for 2 seconds or more.

7-7-8. Abnormal Outdoor Unit Discrimination Method By Fan Operating Function


This function is provided to forcibly operate the fan of the outdoor unit in which a check code occurred or the fan of the normal outdoor unit by the switch operation on the interface P.C. board in the header unit.
To specify which one of the follower units connected to the system had problem, use this function for the system stop due to a follower unit problem (Check code [E28]).

[Operation]

<In case to operate the fan in the failed outdoor unit only>

- (1) Check that the switches SW01/SW02/SW03 on the interface P.C. board in the header unit are set to [1/1/1].

7-segment display



- (2) Press the push-switch SW04 for 2 seconds or more.
- (3) [E 1] is displayed on 7-segment display [A].
- (4) The fan of the outdoor unit in which problem occurred starts operation within approx. 10 seconds after [E 1] was displayed.

<In case to operate the fans in all the normal outdoor units>

- (1) Check that the switches SW01/SW02/SW03 on the interface P.C. board in the header unit are set to [1/1/1].
- (2) Press the push-switches SW04 and SW05 at the same time for 2 seconds or more.
- (3) [E 0] is displayed on 7-segment display [A].
- (4) The fans of all the normal outdoor units start operation with the Max. fan speed within approx. 10 seconds after [E 0] was displayed.

[Release]

Press the push-switch SW05 on the interface P.C. board in the header unit for 2 seconds or more.
The outdoor fan which was operated stops.

- * Check that [U. 1] is displayed on 7-segment display [A], and then finish the work.

7-7-9. Manual Adjustment Function of Outside Temperature (TO) Sensor

This function is provided to fix TO sensor value manually by the switch operation on the interface P.C. board in the outdoor unit. When the unit stops abnormally due to TO sensor failure, etc, an emergent operation is available by setting up the value manually to position near the current outside temperature.

[Operation]

- (1) Set the rotary switches on the interface P.C. board to numbers as follows:
 - SW01/SW02/SW03 to [2/1/15]
 - 7-segment display: [t o]
- (2) Keep pressing the push-switch SW04 on the interface P.C. board for 1 second or more. The mode changes to the TO sensor value fix manual mode.
- (3) Pressing the push-switch SW04 increases the setting temperature and pressing the SW05 decreases the setting temperature. Set the temperature to any values.

[Clear]

Return SW01/SW02/SW03 on the interface P.C. board in the outdoor unit to [1/1/1].

NOTE) If operated with TO sensor fixed by this function, the system control operation of the air conditioner may not be based on the specification of the product. Therefore an emergent operation should be restricted to a day or so.

When the outside temperature is 45°C or more, set to 45°C (SW02="9")

<Service support function list>

SW01	SW02	SW03	7-segment display [A]	Function contents
2	1	1	[J . C]	Refrigerant circuit and control communication line check function (Cooling operation)
	2		[J . H]	Refrigerant circuit and control communication line check function (Heating operation)
	3		[P .]	Indoor PMV forced full open function
	4		[A . 1]	Indoor remote controller discriminating function
	5		[C .]	Cooling test operation function
	6		[H .]	Heating test operation function
	7		[C . H]	Indoor collective start/stop (ON/OFF) function
	9		[F .]	Fan test operation function
	11		[r . d]	Outdoor refrigerant recovery operation function (Reclaim function)
	16		[E . r]	Check code clear function

2	1~16	3	[H . r]	Solenoid valve forced open/close function
2	1~16	4~7	[F . d]	Fan forced operation function
2	1~16	15	[t . o]	Outside temperature sensor manual adjustment function

16	1 to 16	1	[01] to [16]	Indoor No. 1 to 16	Set number of SW02
		2	[17] to [32]	Indoor No. 17 to 32	Set number of SW02 + 16
		3	[33] to [48]	Indoor No. 33 to 48	Set number of SW02 + 32
		4	[49] to [64]	Indoor No. 49 to 64	Set number of SW02 + 48
		5	[65] to [80]	Indoor No. 65 to 80	Set number of SW02 + 64
		6	[81] to [96]	Indoor No. 81 to 96	Set number of SW02 + 80
		7	[97] to [112]	Indoor No. 97 to 112	Set number of SW02 + 96
		8	[113] to [128]	Indoor No. 113 to 128	Set number of SW02 + 112

SW01	SW02	SW03	7-segment display [A/B]	Function contents
1	1	1	[U 1] [E28]	Follower unit check code / Corresponding unit fan operation function

7-7-10. Refrigerant leakage detection

The refrigerant leakage can be confirmed by using the switches on Interface P.C.board of the outdoor unit. If there is a leak, the location must be found in order to recover the refrigerant.

After that, implement appropriate countermeasure and refill the refrigerant to its standard volume.

Refrigerant leaks can be detected by comparing the Actual opening of PMV with the Calculated opening of PMV* during the operation.

* Calculated opening of PMV: calculated from the initial value(C.i/H.i), the pressure sensor value (C.i/H.i), the compressor's , and the opening of PMV. The initial values are automatically saved when the specified conditions are met.
(A leak can be detected only when C.i/H.i = 1)

[Operation]

(1) Confirming the refrigerant leakage

Set SW01 to 03 as shown in the following table to confirm whether the leaks are being detected.

(It also can be confirmed by remote control monitor function. Refer to 7-7-11. Monitor function of remote controller switch.)

(2) Clearing the initial value

If the system is changed (e.g. indoor units are increased/replaced, outdoor units are moved, or refrigerant is refilled/increased) it is necessary to clear the initial value that had been saved.

Make sure that the compressor has stopped, and then press and hold SW04 for at least 5 seconds.

SW01	SW02	SW03	Display detail	
2	13	14	Refrigerant leakage detection	A [L. d]
				B Normal: [... .. 0] Possibility of leakage: [... .. 1] Clear the data: [...C.L] (Only Display for 5 seconds)

(3) Checking the record of the initial value

Set SW01 to 03 as shown in the following table to confirm the record of the initial value.

SW01	SW02	SW03	Display detail	
2	14	14	Cooling initial value	A [C. i]
				B Incomplete: [... .. 0] Completed: [... .. 1]
2	15	14	Heating initial value	A [H. i]
				B Incomplete: [... .. 0] Completed: [... .. 1]

[Clear]

Return SW01/SW02/SW03 on the Interface P.C.board in the outdoor unit to [1/1/1] .

NOTE)

(a) During the operation, the slow leaks can be detected.

However, if the air-conditioner cannot cooling down / cannot warming up / make an unusual stop, the slow leaks might not be detectable. The fast leaks always cannot be detected.

(b) Poor refrigerant circulation may be detected as a refrigerant leaks.

(e.g. plugged strainers / capillaries, malfunction / clogging of the PMV / 2-way valve / 4-way valve)

(c) Due to the outside temperature, the initial value may not be recorded, or it may be impossible to determine the leakage.

(d) The initial value cannot be saved until the accumulated operating time has reached at least 20 hours.

(e) The initial value cannot be saved if the indoor unit's operating ratio is low.

(f) If the following indoor units are connected, leakage determination is not possible.

- Air to air heat exchanger with DX coil unit

7-7-11. Monitor Function of Remote Controller Switch

Switching to the service monitor mode

<Content>

The sensor temperature or operation status of the remote controller, indoor unit, or the outdoor unit can be known by switching to the service monitor mode from the remote controller.

[Procedure]

<RBC-AMT*>

- 1 Push **TEST** + **CL** buttons simultaneously for 4 seconds or more to call up the service monitor mode.

The service monitor goes on, and temperature of the CODE No. 00 is firstly displayed.


- 2 Push the temperature setup **TEMP.** buttons to select the CODE No. to be monitored.

For displayed codes, refer to the table next page.

- 3 Push **SET** button to determine the item to be monitored.



Then monitor the sensor temperature or operation status of indoor unit and the outdoor unit in the corresponding refrigerant line.

- 4 Pushing **TEST** button returns the display to the normal display.



<RBC-ASCU11*>

- 1 Push the [menu] button for over 10 seconds.
- 2 Every pushing [▽] [△] buttons, the indoor unit numbers in group control are displayed successively.
- 3 Push the [OFF timer] button to confirm the selected indoor unit.
- 4 Every pushing [▽] [△] buttons, CODE No. of the item is changed successively.
- 5 After you have finished checking, push the [ON/OFF] button to return to normal mode.



	Code No.	Data name	Display format	Unit	Remote controller display example
Indoor unit data *2	00	Room temperature (Use to control)	X1	°C	[0024]=24°C
	01	Room temperature (Remote controller)	X1	°C	
	02	Indoor suction air temperature (TA)	X1	°C	
	03	Indoor coil temperature (TCJ)	X1	°C	
	04	Indoor coil temperature (TC2)	X1	°C	
	05	Indoor coil temperature (TC1)	X1	°C	
	06	Indoor discharge air temperature (TF) *1	X1	°C	
	07	Indoor fan motor number of revolutions	X1	rpm	[1000]=1000rpm
	08	Indoor PMV opening	X1/10	pls	[0150]=1500pls
	F3	Filter sign time	X1	h	[2500]=2500h
System data	F9	Suction exchanger (TSA) *1 temperature of air to air heat	X1	°C	[0024]=24°C
	FA	Outside air temperature (TOA) *1	X1	°C	
	0A	No. of connected indoor units	X1	units	[0048]=48 units
	0B	Total horsepower of connected indoor units	X10	HP	[0415]=41.5HP
	0C	No. of connected outdoor units	X1	units	[0003]=3 units
	0D	Total horsepower of outdoor units	X10	HP	[0420]=42HP

	Code No.					Data name	Display format	Unit	Remote controller display example
	U1	U2	U3	U4	U5				
Outdoor unit individual data 1 *3	10	20	30	40	50	High-pressure sensor detection pressure(Pd)	X100	Mpa	[0123]=1.23MPa
	11	21	31	41	51	Low-pressure sensor detection pressure (Ps)	X100	Mpa	
	12	22	32	42	52	Compressor 1 discharge temperature (TD1)	X1	°C	[0024]=24°C
	13	23	33	43	53	Compressor 2 discharge temperature (TD2)	X1	°C	
	14	24	34	44	54	Suction temperature (TS1)	X1	°C	
	15	25	35	45	55	Suction temperature (TS3)	X1	°C	
	16	26	36	46	56	Outdoor heat exchanger temperature (TE1)	X1	°C	
	17	27	37	47	57	Outdoor sub-heat exchanger temperature (TE2)	X1	°C	
	18	28	38	48	58	Outdoor sub-heat exchanger temperature (TE3)	X1	°C	
	19	29	39	49	59	Outside ambient temperature (TO)	X1	°C	
	1A	2A	3A	4A	5A	Temperature at liquid side (TL1)	X1	°C	
	1B	2B	3B	4B	5B	Suction temperature (TS2)	X1	°C	
	1C	2C	3C	4C	5C	Suction temperature (TS3)	X1	°C	
	1D	2D	3D	4D	5D	Outdoor coil temperature (TG1)	X1	°C	
	1E	2E	3E	4E	5E	Outdoor coil temperature (TG2)	X1	°C	
	1F	2F	3F	4F	5F	Outdoor coil temperature (TG3)	X1	°C	

	Code No.					Data name	Display format	Unit	Remote controller display example
	U1	U2	U3	U4	U5				
Outdoor unit individual data 2 *4	60	70	80	90	A0	Compressor oil temperature 1 (TK1)	X1	°C	[0024]=24°C
	61	71	81	91	A1	Compressor oil temperature 2 (TK2)	X1	°C	
	62	72	82	92	A2	PMV 1 opening	X1	pls	[0500]=500pls
	63	73	83	93	A3	PMV 2 opening	X1	pls	
	64	74	84	94	A4	PMV 3 opening	X1	pls	
	65	75	85	95	A5	PMV 4 opening	X1	pls	
	66	76	86	96	A6	Compressor 1 current (I1)	X10	A	[0135]=13.5A
	67	77	87	97	A7	Compressor 2 current (I2)	X10	A	
	68	78	88	98	A8	Compressor 1 revolutions	X10	rps	[0642]=64.2rps
	69	79	89	99	A9	Compressor 2 revolutions	X10	rps	
	6A	7A	8A	9A	AA	Outdoor fan mode	X1	mode	[0058]=58 mode
	6B	7B	8B	9B	AB	Inverter of Compressor 1 heat sink temperature (TH1)	X1	°C	[0024]=24°C
	6C	7C	8C	9C	AC	Inverter of Compressor 2 heat sink temperature (TH2)	X1	°C	
	6D	7D	8D	9D	AD	Inverter of outdoor fan 1 heat sink temperature (TH Fan1)	X1	°C	
	6E	7E	8E	9E	AE	Inverter of outdoor fan 2 heat sink temperature (TH Fan2)	X1	°C	
	6F	7F	8F	9F	AF	Outdoor unit horsepower	X1	HP	[0016]=16HP

	Code No.	Data name	Display format	Unit	Remote controller display example
Outdoor unit individual data 3 *5	B0	Heating/cooling recovery control	0 : Normal 1 : Recovery controlled		[0010]=Heating recovery control [0001]=Cooling recovery control
	B5	Instantaneous electric power	X1/10	W	[0090]=900W
	B6	Integrated electric power consumption	X1/100	Wh	[0090]=9000Wh
	B8	Termination resistance setting indoor unit address display	9999 : No setting 1~ : Setting address		[9999]=Case where no terminating resistance is set to any of the indoor units [0048]=Termination resistance setting Indoor unit address 48
	B9	Communications protocol	0 : TCC-LINK 1 : TU2C-LINK		[0000]=TCC-LINK [0001]=TU2C-LINK
	BA	Uv line communication speed	0 : 9600 bps 1 : 19200 bps		[0000]=9600bps [0001]=19200bps
	BB	Demand control	0 : Normally 1 : Demand control		[0000]=Normally [0001]=Demand control

*1 Only a part of indoor unit types is installed with the discharge air temperature sensor. This temperature is not displayed for other types.

*2 When the units are connected to a group, data of the header indoor unit only can be displayed.

*3 The first digit of code No. indicates the outdoor unit number.

*4 The upper digit of code No. -5 indicates the outdoor unit number.

- 1 * , 6 * ... U1 outdoor unit (Header unit)
- 2 * , 7 * ... U2 outdoor unit (Follower unit 1)
- 3 * , 8 * ... U3 outdoor unit (Follower unit 2)
- 4 * , 9 * ... U4 outdoor unit (Follower unit 3)
- 5 * , A * ... U5 outdoor unit (Follower unit 4)

*5 Only the Code No. "B *" of U1 outdoor unit (Header unit) is displayed.

7-8. Wave Tool Advance for SMMS-u Series

7-8-1. Before the Use of Wave Tool Advance

Wave Tool Advance (WTA) is an application for the Android OS or iOS smartphone. You can use this application to check system capacity, to make a test operation, to get a test operation result, and to make a simple report.

Please move to the following URL(or QR Code), and confirm "Objective product list" and "Smartphone model & OS Version". After confirmation, download/install the Wave Tool Advance Application (WTA App.) and USER GUIDE. Be sure to read the USER GUIDE before the use of this application.


<Wave Tool Advance Support URL>
https://www.toshiba-carrier.co.jp/global/appli/smms_wave_tool_advance/index.htm



※Notice
WTA App. is not supported SMMS-e series. Please use the "SMMS Wave Tool" when using the SMMS-e series. You can download and install "SMMS Wave Tool" from the following URL.
<SMMS Wave Tool Support URL>
https://www.toshiba-carrier.co.jp/global/appli/smms_wave_tool/index.htm


7-8-2. About Wave Tool Advance

- This application is the NFC(Near Field Communication) function of smartphone.
- When it is used, make sure that the NFC antenna on the smartphone is aligned with the "TOUCH" mark on the NFC tag.
- Refer to the USER GUIDE of the Wave Tool Advance for the details.



7-8-3. Valid/Prohibition/Permission setting for Test operation from WTA App.

- WTA App Test operation function enables setting within 48 hours elapsed from outdoor unit power ON. If Power ON time is over 48 hours, it can not use WTA App test operation. (Other WTA App function can be used.)
- You should decide whether to make use of this test operation function at its own responsibility and also be sure to confirm notices in the Operating Manual before performing the test operation.
- If you want to prohibit the test operation from WTA App, perform the following steps.
 - * High voltage parts exist in the electrical control box. If you set switch setting, set it from the access door cover of the electrical control box cover to avoid electric shock.
 - After finishing steps, slide the access cover to the position before and fix it with the screw.
- Refer to following table for setting change of the test operation function to be effective after 48hours.



Relationship with Power ON time and Test operation function.

	Status	7-segment display at O.DN Code No.05
Validness	Until 48 hours elapsed from the outdoor unit power ON, WTA App can start a test operation. After 48 hours, it cannot.	d. 0. 0. 0. 0. 0. 0.
Prohibition	Regardless of the elapsed time, WTA App cannot start a test operation.	d. 0. 0. 0. 0. 0. 1.
Permission	Regardless of the elapsed time, WTA App can start a test operation.	d. 0. 0. 0. 0. 0. 2.

■ For example; How to prohibit Test operation from WTA (If you need)

Steps	Items	Rotary switch			Push SW			7-segment display
		SW01	SW02	SW03	SW04	SW05	SW06	
1	Change rotary switch position for Outdoor DN code setting	9	1	1	-	-	-	dn.SET
2	Push SW04 for activate DN code	9	1	1	Push	-	-	dn.001
3	Change DN code Number to "dn.005" with SW05 or SW06	9	1	1	-	Push	Push	dn.005
4	Change data value display with SW04 **"d.0000" shows validness of TEST operation by WTA App., (Because PWR ON within 48h).	9	1	1	Push	-	-	d.0000
5	Change value to "d.0001" with SW05 or SW06 **"d.0001" shows prohibition of TEST operation by WTA App.,	9	1	1	-	Push	Push	d.0001
6	Push SW04 more than 2sec. 7-seg display will change from flashing to lighting.	9	1	1	Push more than 2 sec	-	-	Flashing--> d.0001 Lighting
7	Return to default Rotary switch position.	1	1	1	-	-	-	U * ---
8	Turn ON/OFF outdoor unit main power supplies. Keep turn off time 60 seconds or more.							

* Do it again if the 7-segment display is different from the above.

* The functions other than the test operation of this Application can work normally even if the test operation function are prohibited.

7-8-4. Confirmation for NFC tag Communication

When you cannot read out the information of the NFC tag with your smartphone, perform the following step.

Step	Rotary switch			Push switch			7-segment display	Check result
	SW01	SW02	SW03	SW04	SW05	SW06		
1	2	16	14	—	—	—	nFc.	Normal
							nFc.Er	NFC tag wiring trouble Check NFC tag wiring
2	1	1	1				U * ---	(Return to Rotary switch)

If above check is no problem, refer to User Guide of Wave Tool Advance.

Trademark

Android is a trademark or registered trademark of Google LLC.

IOS is trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

QR Code is a trademark or registered trademark of DENSO WAVE Inc.

8. TROUBLESHOOTING

8-1. Overview

(1) Before engaging in troubleshooting

(a) Applicable models

Super Modular Multi System (SMMS-u) models.

(Indoor units: MM*-U(A)P***, Outdoor units: MMY-MUP*****HT**)

(b) Tools and measuring devices required

- Screwdrivers (Philips, flat head), spanners, long-nose pliers, nipper, pin to push reset switch, etc.
- Multimeter, thermometer, pressure gauge, etc.

(c) Things to check prior to troubleshooting (behaviors listed below are normal)


NO.	Behavior	Possible cause
1	A compressor would not start	<ul style="list-style-type: none"> • The air conditioner is being controlled by the 3-minute protective function. • It is in standby status though the room temperature has reached the setup temperature. • It is being operated in timer mode or fan mode. • It is being in initial communication.
2	An indoor fan would not start	<ul style="list-style-type: none"> • The air conditioner is being controlled by the cool air discharge preventive function in "heating"?
3	An outdoor fan would not start or would change speed for no reason	<ul style="list-style-type: none"> • The air conditioner is being operated in "cooling" under the low outside air temperature. • It is being operated in defrost operation.
4	An indoor fan would not stop	<ul style="list-style-type: none"> • The air conditioner is being controlled by function of residual heat elimination being performed as part of the air conditioner shutdown process after heating operation.
5	The air conditioner would not respond to a start/stop command from a remote controller	<ul style="list-style-type: none"> • The air conditioner is being operated under external or remote control.

CAUTION

The cooling performance may be declining considerably when total operating capacity of cooling indoor units is less than 4 HP WHILE AMBIENT TEMPERATURE IS BELOW 0°C.

(2) Troubleshooting procedure

When a problem occurs, proceed with troubleshooting in accordance with the procedure shown below.



NOTE

Rather than a product trouble (see the List of Check Codes below), the problem could have been caused by a microprocessor malfunction attributable to a poor quality of the power source or an external noise. Check for possible noise sources, and shield the remote controller wiring and signal wires as necessary.

8-2. Troubleshooting method

The remote controllers (main remote controller and central remote controller) and the interface P.C. board of an outdoor unit have an LCD display (remote controller) or a 7-segment display (outdoor interface P.C. board) to display operational status. Using this self-diagnosis feature, the trouble site / trouble part may be identified in the event of a trouble by following the method described below.

The list below summarizes check codes detected by various devices. Analyze the check code according to where it is displayed and work out the nature of the problem in consultation with the list.

- When investigating a problem on the basis of a display provided on the indoor remote controller or central remote controller See the “Remote control or main remote controller display” section of the list.
- When investigating a problem on the basis of a display provided on an outdoor unit - See the “Outdoor 7-segment display” section of the list.
- When investigating a problem on the basis of a wireless remote controller-controlled indoor unit - See the “Light sensor indicator light block” section of the list.





























































List of Check Codes (Indoor Unit)

(Check code detected by indoor unit)





○ : Lighting, ◎ : Flashing, ● : Goes off

ALT.: Flashing is alternately when there are two flashing LED





SIM: Simultaneous flashing when there are two flashing LED

Check code			Display of receiving unit				Typical problem site	Description of Check code
Central control or main remote controller display	Outdoor 7-segment display		Indicator light block					
		Sub-code	Operation 	Timer 	Flash 	Flash		
E03	—	—					Indoor-remote controller periodic communication trouble	Communication from remote controller or network adaptor has been lost (so has central control communication).
E04	—	—					Indoor-outdoor periodic communication trouble	Signals are not being received from outdoor unit.
E08	E08	Duplicated indoor address					Duplicated indoor address	Indoor unit detects address identical to its own.
E10	—	—					Indoor inter-MCU communication trouble	MCU communication between main controller and motor microcontroller is failure.
E11	—	—					Communication check code between Application control kit and indoor unit	Communication check code between Application control kit and indoor unit P.C. board.
E18	—	—					Trouble in periodic communication between indoor header and follower unit	Periodic communication between indoor header and follower units cannot be maintained.
F01	—	—				ALT	Indoor heat exchanger temperature sensor (TCJ) trouble	Heat exchanger temperature sensor (TCJ) has been open/short-circuited.
F02	—	—				ALT	Indoor heat exchanger temperature sensor (TC2) trouble	Heat exchanger temperature sensor (TC2) has been open/short-circuited.
F03	—	—				ALT	Indoor heat exchanger temperature sensor (TC1) trouble	Heat exchanger temperature sensor (TC1) has been open/short-circuited.
F10	—	—				ALT	Room air temperature sensor (TA/TSA) trouble	Room air temperature sensor (TA) has been open/short-circuited.
F11	—	—				ALT	Discharge air temperature sensor (TF/TFA) trouble	Discharge air temperature sensor (TF) has been open/short-circuited.
F29	—	—				SIM	P.C. board or other indoor trouble	Open/Short-circuit of indoor air suction temperature sensor (TRA) was detected.
L03	—	—				SIM	Duplicated indoor group header unit	There is more than one header unit in group.
L07	—	—				SIM	Connection of group control cable to stand-alone indoor unit	There is at least one stand-alone indoor unit to which group control cable is connected.
L08	L08	—				SIM	Indoor group address not set	Address setting has not been performed for one or more indoor units (also detected at outdoor unit end).
L09	—	—				SIM	Indoor capacity not set	Capacity setting has not been performed for indoor unit.
L20	—	—				SIM	Duplicated central control address	There is duplication in central control address setting.
L30	L30	Detected indoor unit No.				SIM	Indoor external trouble input (interlock)	Unit shutdown has been caused by external trouble input (CN80).
P01	—	—				ALT	Indoor AC fan trouble	Indoor AC fan trouble is detected (activation of fan motor thermal relay).
P10	P10	Detected indoor unit No.				ALT	Indoor overflow trouble	Float switch has been activated.
P12	—	—				ALT	Indoor DC fan trouble	Indoor DC fan trouble (e.g. overcurrent or lock-up) is detected.
P31	—	—				ALT	Other indoor unit trouble	Follower unit cannot be operated due to header unit alarm (E03/L03/L07/L08).

(Check code detected by remote controller)

Check code			Display of receiving unit				Typical fault site	Description of trouble
Remote control	Outdoor 7-segment display		Indicator light block					
		Sub-code	Operation 	Timer 	Ready 	Flash 		
E01	—	—	⊙	●	●		No master remote control, failure remote control communication (reception)	Signals cannot be received from indoor unit; master remote controller has not been set (including two remote controller control).
E02	—	—	⊙	●	●		Failure remote control communication (transmission)	Signals cannot be transmitted to indoor unit.
E09	—	—	⊙	●	●		Duplicated master remote control	Both remote controllers have been set as master remote controller in two remote controller control (alarm and shutdown for header unit and continued operation for follower unit)

(Check code detected by central control device)

Check code			Display of receiving unit				Typical fault site	Description of trouble
Central control	Outdoor 7-segment display		Indicator light block					
		Sub-code	Operation 	Timer 	Ready 	Flash 		
C05	—	—	No indication (when main remote control also in use)				Failure central control communication (transmission)	Central control device is unable to transmit signal due to duplication of central control device
C06	—	—					Failure central control communication (reception)	Central control device is unable to receive signal.
C12	—	—	—				Bracket alarm for general-purpose device control interface	Device connected to general-purpose device control interface is failure.
P30	—	—	As per alarm unit (see above)				Group control follower unit trouble	Group follower unit is troubled (unit No. and above detail [***] displayed on main remote controller)
S01	—	—	—				Failure central control communication (reception)	Central control device is unable to receive signal.

Note: The same trouble, e.g. a communication trouble, may result in the display of different check codes depending on the device that detects it.
Moreover, check codes detected by the main remote controller/central control device do not necessarily have a direct impact on air conditioner operation.




List of Check Codes (Outdoor Unit)

















































(Check code detected by outdoor interface - typical examples)

If "HELLO" is displayed on the outdoor 7-segment for 1 minute or more, turn off the power supply once and then turn on the power supply again after passage of 30 seconds or more. When the same symptom appears, it is considered there is a possibility of I/F board trouble.

○ : Lighting, ◎ : Flashing, ● : Goes off
 ALT.: Flashing is alternately when there are two flashing LED
 SIM: Simultaneous flashing when there are two flashing LED





































Check code			Display of receiving unit				Typical problem site	Description of problem																																																																																								
Outdoor 7-segment display		Central control or main remote controller display	Indicator light block																																																																																													
	Sub-code		Operation ⏻	Timer ⌚	Ready ⚙	Flash																																																																																										
E06	Number of indoor units from which signal is received normally	E06	●	●	◎		Signal lack of indoor unit	<ul style="list-style-type: none">Indoor unit initially communicating normally fails to return signal (reduction in number of indoor units connected).In TU2C-LINK communication system, if the termination resistance is not set in any of the indoor units																																																																																								
E07	—	(E04)	●	●	◎		Indoor-outdoor communication circuit trouble	Signal cannot be transmitted to indoor units (→ indoor units left without communication from outdoor unit).																																																																																								
E08	Duplicated indoor address	(E08)	◎	●	●		Duplicated indoor address	More than one indoor unit are assigned same address (also detected at indoor unit end).																																																																																								
E12	01: Indoor-outdoor communication 02: Outdoor-outdoor communication	E12	◎	●	●		Automatic address starting trouble	<ul style="list-style-type: none">Indoor automatic address setting is started while automatic address setting for equipment in other refrigerant line is in progress.Outdoor automatic address setting is started while automatic address setting for indoor units is in progress.																																																																																								
E15	—	E15	●	●	◎		Indoor unit not found during automatic address setting	Indoor unit fails to communicate while automatic address setting for indoor units is in progress.																																																																																								
E16	00: Capacity over 01: Number of units connected	E16	●	●	◎		Too many indoor units connected/capacity over	Combined capacity of indoor units is too large. The maximum combined of indoor units shown in the specification table.																																																																																								
E19	00: No header unit 02: Two or more header units	E19	●	●	◎		Trouble in number of outdoor header units	There is no or more than one outdoor header unit in one refrigerant line.																																																																																								
E20	01: Connection of outdoor unit from other refrigerant line 02: Connection of indoor unit from other refrigerant line	E20	●	●	◎		Connection to other refrigerant line found during automatic address setting	Indoor unit from other refrigerant line is detected while indoor automatic address setting is in progress.																																																																																								
E23	—	E23	●	●	◎		Outdoor-outdoor communication transmission trouble	Signal cannot be transmitted to other outdoor units.																																																																																								
E25	—	E25	●	●	◎		Duplicated follower outdoor address	There is duplication in outdoor addresses set manually.																																																																																								
E26	Address of outdoor unit from which signal is not received normally	E26	●	●	◎		Signal lack of outdoor unit	Follower outdoor unit initially communicating normally fails to do so (reduction in number of follower outdoor units connected).																																																																																								
E28	Detected outdoor unit No.	E28	●	●	◎		Outdoor follower unit trouble	Outdoor header unit detects trouble relating to follower outdoor unit (detail displayed on follower outdoor unit).																																																																																								
E31	<table><tr><th colspan="4">P.C.board</th><th colspan="4">P.C.board</th></tr><tr><th colspan="2">Compressor</th><th colspan="2">Fan Motor</th><th colspan="2">Compressor</th><th colspan="2">Fan Motor</th></tr><tr><th>1</th><th>2</th><th>1</th><th>2</th><th>1</th><th>2</th><th>1</th><th>2</th></tr><tr><td>01</td><td>○</td><td></td><td></td><td>11</td><td>○</td><td></td><td>○</td></tr><tr><td>02</td><td></td><td>○</td><td></td><td>12</td><td></td><td>○</td><td>○</td></tr><tr><td>03</td><td>○</td><td>○</td><td></td><td>13</td><td>○</td><td>○</td><td>○</td></tr><tr><td>08</td><td></td><td></td><td>○</td><td>18</td><td></td><td></td><td>○</td></tr><tr><td>09</td><td>○</td><td></td><td>○</td><td>19</td><td>○</td><td></td><td>○</td></tr><tr><td>0A</td><td></td><td>○</td><td>○</td><td>1A</td><td></td><td>○</td><td>○</td></tr><tr><td>0B</td><td>○</td><td>○</td><td>○</td><td>1B</td><td>○</td><td>○</td><td>○</td></tr><tr><td>10</td><td></td><td></td><td>○</td><td></td><td></td><td></td><td></td></tr></table> <p>Circle (○): Trouble P.C. board</p> <p>80 : Communication trouble between MCU and Sub MCU</p>	P.C.board				P.C.board				Compressor		Fan Motor		Compressor		Fan Motor		1	2	1	2	1	2	1	2	01	○			11	○		○	02		○		12		○	○	03	○	○		13	○	○	○	08			○	18			○	09	○		○	19	○		○	0A		○	○	1A		○	○	0B	○	○	○	1B	○	○	○	10			○					E31	●	●	◎		P.C. board communication trouble Sub MCU communication trouble	There is no communication between P.C. boards in inverter box.
P.C.board				P.C.board																																																																																												
Compressor		Fan Motor		Compressor		Fan Motor																																																																																										
1	2	1	2	1	2	1	2																																																																																									
01	○			11	○		○																																																																																									
02		○		12		○	○																																																																																									
03	○	○		13	○	○	○																																																																																									
08			○	18			○																																																																																									
09	○		○	19	○		○																																																																																									
0A		○	○	1A		○	○																																																																																									
0B	○	○	○	1B	○	○	○																																																																																									
10			○																																																																																													
F04	—	F04	◎	◎	○	ALT	Outdoor discharge temperature sensor (TD1) trouble	Outdoor discharge temperature sensor (TD1) has been open/short-circuited.																																																																																								
F05	—	F05	◎	◎	○	ALT	Outdoor discharge temperature sensor (TD2) trouble	Outdoor discharge temperature sensor (TD2) has been open/short-circuited.																																																																																								
F06	01: TE1 sensor 02: TE2 sensor 03: TE3 sensor	F06	◎	◎	○	ALT	Outdoor heat exchanger liquid side temperature sensor (TE1, TE2, TE3) trouble	Outdoor heat exchanger liquid side temperature sensors (TE1, TE2, TE3) have been open/short-circuited.																																																																																								
F07	01: TL1 sensor 02: TL2 sensor 03: TL3 sensor	F07	◎	◎	○	ALT	Outdoor liquid temperature sensor (TL1,TL2,TL3) trouble	Outdoor liquid temperature sensor (TL1,TL2,TL3) has been open/short-circuited.																																																																																								
F08	—	F08	◎	◎	○	ALT	Outdoor outside air temperature sensor (TO) trouble	Outdoor air temperature sensor (TO) has been open/short-circuited.																																																																																								
F09	01: TG1 sensor 02: TG2 sensor 03: TG3 sensor	F09	◎	◎	○	ALT	Outdoor heat exchanger gas side temperature sensor (TG1, TG2, TG3) trouble	Outdoor heat exchanger gas side temperature sensors (TG1, TG2, TG3) have been open/short-circuited.																																																																																								

Check code			Display of receiving unit				Typical problem site	Description of problem
Outdoor 7-segment display		Central control or main remote controller display	Indicator light block					
	Sub-code		Operation 	Timer 	Ready 	Flash		
F12	01: TS1 sensor 03: TS3 sensor 04: TS3 sensor disconnect	F12	⊙	⊙	○	ALT	<ul style="list-style-type: none">Outdoor suction temperature sensor (TS1,TS3) troubleWhen TS3 detects an unusual temperature during compressor operation and PMV4 operation in cooling mode	<ul style="list-style-type: none">Outdoor suction temperature sensor (TS1,TS3) has been open/short-circuited.When the disconnect of outdoor temperature sensor (TS3) is detected.
F15	—	F15	⊙	⊙	○	ALT	Outdoor temperature sensor (TE1,TL1) wiring trouble	Wiring trouble in outdoor temperature sensors (TE1,TL1) has been detected.
F16	—	F16	⊙	⊙	○	ALT	Outdoor pressure sensor (Pd, Ps) wiring trouble	Wiring trouble in outdoor pressure sensors (Pd, Ps) has been detected.
F23	—	F23	⊙	⊙	○	ALT	Low pressure sensor (Ps) trouble	Output voltage of low pressure sensor (Ps) is zero.
F24	—	F24	⊙	⊙	○	ALT	High pressure sensor (Pd) trouble	Output voltage of high pressure sensor (Pd) is zero or provides abnormal readings when compressors have been turned off.
F31	—	F31	⊙	⊙	○	SIM	Outdoor EEPROM trouble	Outdoor EEPROM is failure (alarm and shutdown for header unit and continued operation for follower unit)
H05	—	H05	●	⊙	●		Outdoor discharge temperature sensor (TD1) wiring trouble	Wiring/installation trouble or detachment of outdoor discharge temperature sensor (TD1) has been detected.
H06	—	H06	●	⊙	●		Activation of low-pressure protection	Low pressure (Ps) sensor detects abnormally low operating pressure.
H07	—	H07	●	⊙	●		Low oil level protection	Temperature sensor for oil level detection (TK1,TK2) detects abnormally low oil level.
H08	01: TK1 sensor trouble 02: TK2 sensor trouble	H08	●	⊙	●		Trouble in temperature sensor for oil level detection (TK1,TK2)	Temperature sensor for oil level detection (TK1,TK2) has been open/short-circuited.
H15	—	H15	●	⊙	●		Outdoor discharge temperature sensor (TD2) wiring trouble	Wiring/installation trouble or detachment of outdoor discharge temperature sensor (TD2) has been detected.
H16	01: TK1 oil circuit trouble 02: TK2 oil circuit trouble	H16	●	⊙	●		Oil level detection circuit trouble	No temperature change is detected by temperature sensor for oil level detection (TK1,TK2) despite compressor having been started.
L04	—	L04	⊙	○	⊙	SIM	Duplicated outdoor refrigerant line address	Identical refrigerant line address has been assigned to outdoor units belonging to different refrigerant piping systems.
L06	Number of priority indoor units (check code L05 or L06 depending on individual unit)	L05	⊙	●	⊙	SIM	Duplicated priority indoor unit (as displayed on priority indoor unit)	More than one indoor unit have been set up as priority indoor unit.
		L06	⊙	●	⊙	SIM	Duplicated priority indoor unit (as displayed on indoor unit other than priority indoor unit)	More than one indoor unit have been set up as priority indoor unit.
L08	—	(L08)	⊙	●	⊙	SIM	Indoor group address not set	Address setting have not been performed for one or more indoor units (also detected at indoor end).
L10	—	L10	⊙	○	⊙	SIM	Outdoor capacity not set	Outdoor unit capacity has not been set (after P.C. board replacement).
L17	—	L17	⊙	○	⊙	SIM	Outdoor model incompatibility trouble	Outdoor unit that cannot be connected is connected.
L23	02: Switch setting trouble of outdoor unit	L23	⊙	○	⊙	SIM	SW setting trouble	Switch setting trouble of outdoor units when HWM (Hot water module) is connected.
L28	—	L28	⊙	○	⊙	SIM	Too many outdoor units connected	More than six outdoor units have been connected.

Check code			Display of receiving unit																																																																																													
Outdoor 7-segment display			Indicator light block		Typical problem site	Description of problem																																																																																										
	Sub-code	Central control or main remote controller display	Operation 	Timer 			Ready 	Flash																																																																																								
L29	<table><tr><th colspan="4">P.C.board</th><th colspan="4">P.C.board</th></tr><tr><th colspan="2">Compressor</th><th colspan="2">Fan Motor</th><th colspan="2">Compressor</th><th colspan="2">Fan Motor</th></tr><tr><th>1</th><th>2</th><th>1</th><th>2</th><th>1</th><th>2</th><th>1</th><th>2</th></tr><tr><td>01</td><td>○</td><td></td><td></td><td>11</td><td>○</td><td></td><td>○</td></tr><tr><td>02</td><td></td><td>○</td><td></td><td>12</td><td></td><td>○</td><td>○</td></tr><tr><td>03</td><td>○</td><td>○</td><td></td><td>13</td><td>○</td><td>○</td><td>○</td></tr><tr><td>08</td><td></td><td></td><td>○</td><td>18</td><td></td><td></td><td>○</td></tr><tr><td>09</td><td>○</td><td></td><td>○</td><td>19</td><td>○</td><td></td><td>○</td></tr><tr><td>0A</td><td></td><td>○</td><td>○</td><td>1A</td><td></td><td>○</td><td>○</td></tr><tr><td>0B</td><td>○</td><td>○</td><td>○</td><td>1B</td><td>○</td><td>○</td><td>○</td></tr><tr><td>10</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></tr></table> <div>Circle (○): Trouble P.C. board</div>	P.C.board				P.C.board				Compressor		Fan Motor		Compressor		Fan Motor		1	2	1	2	1	2	1	2	01	○			11	○		○	02		○		12		○	○	03	○	○		13	○	○	○	08			○	18			○	09	○		○	19	○		○	0A		○	○	1A		○	○	0B	○	○	○	1B	○	○	○	10								L29				SIM	Trouble in number of P.C. boards	There are insufficient number of P.C. board in inverter box.
	P.C.board				P.C.board																																																																																											
	Compressor		Fan Motor		Compressor		Fan Motor																																																																																									
1	2	1	2	1	2	1	2																																																																																									
01	○			11	○		○																																																																																									
02		○		12		○	○																																																																																									
03	○	○		13	○	○	○																																																																																									
08			○	18			○																																																																																									
09	○		○	19	○		○																																																																																									
0A		○	○	1A		○	○																																																																																									
0B	○	○	○	1B	○	○	○																																																																																									
10																																																																																																
	00	L29				SIM	The number of P.C. board trouble	When there is much number of an inverter P.C. board to model setting of an interface P.C. board.																																																																																								
L30	Detected indoor unit No.	(L30)				SIM	Indoor external trouble input (interlock)	Indoor unit has been shut down for external trouble input in one refrigerant line (detected by indoor unit).																																																																																								
P03	—	P03				ALT	Outdoor discharge (TD1) temperature trouble	Outdoor discharge temperature sensor (TD1) has detected abnormally high temperature.																																																																																								
P04	01: Compressor 1 02: Compressor 2	P04				ALT	Activation of high-pressure SW	High-pressure SW is activated.																																																																																								
P05	00: Power detection trouble 01: Open phase 02: Power supply miswiring	P05				ALT	Power detection trouble /Open phase detection /Power supply miswiring detection	Open phase is detected when power is turned on. Inverter DC voltage is too high (overvoltage) or too low (undervoltage).																																																																																								
P07	00 : Compressor 1 or 2 heat sink trouble 01 : Compressor 1 heat sink trouble 02 : Compressor 2 heat sink trouble	P07				ALT	Heat sink overheating trouble	Temperature sensor built into IPM (TH) detects overheating.																																																																																								
	04: Heat sink dewing						Heat sink dewing trouble	Outdoor liquid temperature sensor (TL2) has detected abnormally low temperature.																																																																																								
P10	Indoor unit No. detected	(P10)				ALT	Indoor unit overflow	Indoor unit has been shutdown in one refrigerant line due to detection of overflow (detected by indoor unit).																																																																																								
P11	—	P11				ALT	Outdoor heat exchanger freeze trouble	Remaining frost on outdoor heat exchanger has been detected repeatedly.																																																																																								
P13	—	P13				ALT	Outdoor liquid backflow detection trouble	State of refrigerant cycle circuit indicates liquid backflow operation.																																																																																								
P14	01: Outdoor unit valve is close	P14				ALT	Another refrigerant cycle protection	Outdoor unit valve is forget to open during test run.																																																																																								
P15	01: TS condition 02: TD condition	P15				ALT	Gas leak detection	Outdoor suction temperature sensor (TS1) detects sustained and repeated high temperatures that exceed standard value.																																																																																								
P17	—	P17				ALT	Outdoor discharge (TD2) temperature trouble	Outdoor discharge temperature sensor (TD2) detects abnormally high temperature.																																																																																								
P19	Outdoor unit No. detected	P19				ALT	4-way valve reversing trouble	Abnormality in refrigerating cycle is detected during heating operation.																																																																																								
P20	—	P20				ALT	Activation of high-pressure protection	High pressure (Pd) sensor detects high pressure that exceeds standard value.																																																																																								

MG-CTT: Magnet contactor

(Check code detected by Inverter of Compressor featuring in outdoor unit - typical examples)

Check code		Central control or main remote controller display	Display of receiving unit				Typical problem site	Description of problem
Outdoor 7-segment display			Indicator light block					
	Sub-code		Operation 	Timer 	Ready 	Flash		
F13	1*: Compressor 1 2*: Compressor 2	F13				ALT	Trouble in temperature sensor built into indoor IPM (TH)	Temperature sensor built into indoor IPM (TH) has been open/short-circuited.
H01	1*: Compressor 1 2*: Compressor 2	H01					Compressor breakdown	Inverter current (Idc) detection circuit detects overcurrent.
H02	1*: Compressor 1 2*: Compressor 2	H02					Compressor trouble (lockup)	Compressor lockup is detected
H03	1*: Compressor 1 2*: Compressor 2	H03					Current detection circuit trouble	Abnormal current is detected while inverter compressor is turned off.
H17	1*: Compressor 1 2*: Compressor 2	H1 7					Compressor trouble (Step out)	Compressor is in step-out condition.
P05	1*: Compressor 1 side 2*: Compressor 2 side	P05				ALT	Compressor Vdc trouble	Inverter DC voltage is too high (overvoltage) or too low (undervoltage).
P07	1*: Compressor 1 side 2*: Compressor 2 side	P07				ALT	Heat sink overheat trouble	Temperature sensor built into IPM (TH) detects overheating.
P11	—	P11				ALT	Outdoor heat exchanger freeze trouble	Remaining frost on outdoor heat exchanger has been detected repeatedly.
P22	1*: Fan P.C. board 1 2*: Fan P.C. board 2	P22				ALT	Outdoor fan P.C. board trouble	Outdoor fan P.C. board detects trouble.
P26	1*: Compressor 1 2*: Compressor 2	P26				ALT	Activation of IPM, compressor short-circuit protection	Short-circuit protection for compressor motor driver circuit components is activated (momentary overcurrent).
P29	1*: Compressor 1 2*: Compressor 2	P29				ALT	Compressor position detection circuit trouble	Compressor motor position detection trouble is detected.

Note: The above check codes are examples only, and different check codes may be displayed depending on the outdoor unit configuration


8-3.Troubleshooting based on information displayed on remote controller

Using main remote controller (RBC-ASCU11*)

<RBC-ASCU11*>

(1) Confirmation and check

If a problem occurs with the air conditioner, the OFF timer indicator alternately shows the check code and the indoor Unit No. in which the problem occurred.



(2) Troubleshooting history and confirmation

You can check the troubleshooting history with the following procedure if a problem occurs with the air conditioner.

(The troubleshooting history records up to 4 incidents.)

You can check it during operation or when operation is stopped.

- If you check the troubleshooting history during OFF timer operation, the OFF timer will be canceled.

Procedure	Description of operation
1	<p>Push the OFF timer button for over 10 seconds and the indicators appear as an image indicating the troubleshooting history mode has been entered. If [Service check] is displayed, the mode enters in the troubleshooting history mode.</p> <ul style="list-style-type: none">• [01: Order of troubleshooting history] appears in the temperature indicator.• The OFF timer indicator alternately shows the [check code] and the [indoor Unit No.] in which the problem occurred.
2	<p>Each time the setting button is pushed, the recorded troubleshooting history is displayed in sequence. The troubleshooting history appears in order from [01] (newest) to [04] (oldest).</p> <div> CAUTION</div> <p>In the troubleshooting history mode, DO NOT push the Menu button for over 10 seconds, doing so deletes the entire troubleshooting history of the indoor unit.</p>
3	<p>After you have finished checking, push the ON/OFF button to return to the regular mode.</p> <ul style="list-style-type: none">• If the air conditioner is operating, it remains operated even after the ON/OFF button has been pushed. To stop its operation, push the ON/OFF button again.

REQUIREMENT

Do not push the button as it would erase the whole trouble history of the indoor unit.

How to read displayed information

<7-segment display symbols>

0123456789A b C d E F H J L P

<Corresponding alphanumerical letters>

0 1 2 3 4 5 6 7 8 9 A b C d E F H J L P

Using indoor unit indicators (receiving unit light block) (wireless type)


To identify the check code, check the 7-segment display on the header unit. To check for check codes not displayed on the 7-segment display, consult the “List of Check Codes (Indoor Unit)” in “8-2. Troubleshooting method”.

● : Goes off ○ : Lighting ☼ : Blinking (0.5 seconds)



Light block	Check code	Cause of trouble		
Operation Timer Ready ● ● ● All lights out	—	Power turned off or trouble in wiring between receiving and indoor units		
Operation Timer Ready ☀ ● ● Blinking	E01	Trouble reception	Receiving unit	Trouble or poor contact in wiring between receiving unit and indoor units
	E02	Trouble transmission		
	E03	Loss of communication		
	E08	Duplicated indoor unit No. (address)	Setting trouble	
	E09	Duplicated master remote controller		
	E10	Communication trouble between indoor unit MCU		
	E11	Communication trouble between Application control kit and indoor unit P.C. board		
	E12	Automatic address starting trouble		
	E18	Trouble or poor contact in wiring between indoor units, indoor power turned off		
Operation Timer Ready ● ● ☀ Blinking	E04	Trouble or poor contact in wiring between indoor and outdoor units (loss of indoor-outdoor communication)		
	E06	Trouble reception in indoor-outdoor communication (dropping out of indoor unit)		
	E07	Trouble transmission in indoor-outdoor communication		
	E15	Indoor unit not found during automatic address setting		
	E16	Too many indoor units connected / overloading		
	E19	Trouble in number of outdoor header units		
	E20	Detection of refrigerant piping communication trouble during automatic address setting		
	E23	Trouble transmission in outdoor-outdoor communication		
	E25	Duplicated follower outdoor address		
	E26	Trouble reception in outdoor-outdoor communication, dropping out of outdoor unit		
	E28	Outdoor follower unit trouble		
	E31	P.C. board communication trouble		
Operation Timer Ready ● ☀ ☀ Alternate blinking	P01	Indoor AC fan trouble		
	P10	Indoor overflow trouble		
	P11	Outdoor heat exchanger freezing trouble		
	P12	Indoor DC fan trouble		
	P13	Outdoor liquid backflow detection trouble		
	P14	Outdoor unit valve is closed		
Operation Timer Ready ☀ ● ☀ Alternate blinking	P03	Outdoor discharge (TD1) temperature trouble		
	P04	Activation of outdoor high-pressure SW		
	P05	Open phase / power failure Inverter DC voltage (Vdc) trouble MG-CTT trouble		
	P07	Outdoor heat sink overheating trouble - Poor cooling of electrical component (IGBT) of outdoor unit		
	P15	Gas leak detection - insufficient refrigerant charging		
	P17	Outdoor discharge (TD2) temperature trouble		
	P18	Outdoor discharge (TD3) temperature trouble		
	P19	Outdoor 4-way valve reversing trouble		
	P20	Activation of high-pressure protection		
	P22	Outdoor fan P.C. board trouble		
	P26	Outdoor IPM, Compressor short-circuit trouble		
	P29	Compressor position detection circuit trouble		
	P31	Shutdown of other indoor unit in group due to trouble (group follower unit trouble)		

MG-CTT: Magnet contactor

Light block	Check code	Cause of trouble	
<div>Operation Timer Ready</div> <div><div><div></div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div><div></div></div><div></div></div> <div>Alternate blinking</div>	F01	Heat exchanger temperature sensor (TCJ) trouble	
	F02	Heat exchanger temperature sensor (TC2) trouble	
	F03	Heat exchanger temperature sensor (TC1) trouble	
	F10	Ambient temperature sensor (TA/TSA) trouble	
	F11	Discharge temperature sensor (TF) trouble	
<div>Operation Timer Ready</div> <div><div><div></div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div><div></div></div><div></div></div> <div>Alternate blinking</div>	F04	Discharge temperature sensor (TD1) trouble	
	F05	Discharge temperature sensor (TD2) trouble	
	F06	Heat exchanger temperature sensor (TE1, TE2, TE3) trouble	
	F07	Liquid temperature sensor (TL1, TL2, TL3) trouble	
	F08	Outside air temperature sensor (TO) trouble	
	F09	Heat exchanger gas side temperature sensor (TG1, TG2, TG3) trouble	
	F12	Suction temperature sensor (TS1, TS3) trouble	
	F13	Heat sink sensor (TH) trouble	
	F15	Wiring trouble in heat exchanger sensor (TE1) and liquid temperature sensor (TL) Outdoor unit temperature sensor wiring / installation trouble	
	F16	Wiring trouble in outdoor high pressure sensor (Pd) and low pressure sensor (Ps) Outdoor pressure sensor wiring trouble	
	F23	Low pressure sensor (Ps) trouble	Outdoor unit pressure sensor trouble
	F24	High pressure sensor (Pd) trouble	
<div>Operation Timer Ready</div> <div><div><div></div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div><div></div></div><div></div></div> <div>Synchronized blinking</div>	F29	Trouble in indoor EEPROM	
<div>Operation Timer Ready</div> <div><div></div><div><div></div><div></div><div></div><div></div><div></div><div></div></div><div></div></div> <div>Blinking</div>	H01	Compressor breakdown	Outdoor unit compressor related trouble
	H02	Compressor lockup	
	H03	Current detection circuit trouble	
	H05	Wiring / installation trouble or detachment of outdoor discharge temperature sensor (TD1)	
	H06	Abnormal drop in low-pressure sensor (Ps) reading	Protective shutdown of outdoor unit
	H07	Abnormal drop in oil level	
	H08	Trouble in temperature sensor for oil level detection circuit (TK1, TK2)	
	H15	Wiring / installation trouble or detachment of outdoor discharge temperature sensor (TD2)	
	H16	Oil level detection circuit trouble - Trouble in outdoor unit TK1, TK2 circuit	
	H17	Compressor trouble (Step-out)	
<div>Operation Timer Ready</div> <div><div><div></div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div><div></div></div><div></div></div> <div>Synchronized blinking</div>	L02	Outdoor unit model mismatched trouble	
	L03	Duplicated indoor group header unit	
	L05	Duplicated priority indoor unit (as displayed on priority indoor unit)	
	L06	Duplicated priority indoor unit (as displayed on indoor unit other than priority indoor unit)	
	L07	Connection of group control cable to stand-alone indoor unit	
	L08	Indoor group address not set	
	L09	Indoor capacity not set	
	<div>Operation Timer Ready</div> <div><div><div></div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div><div></div></div><div></div></div> <div>Synchronized blinking</div>	L04	Duplicated outdoor refrigerant line address
L10		Outdoor capacity not set	
L17		Outdoor model incompatibility trouble	
L20		Duplicated central control address	
L23		SW setting trouble	
L28		Too many outdoor units connected	
L29		Trouble in number of P.C. boards	
L30		Indoor external interlock trouble	

Light block	Check code	Cause of trouble
Operation Timer Ready 	F30	Occupancy sensor trouble
	F31	Outdoor EEPROM trouble

Other (indications not involving check code)

Light block	Check code	Cause of trouble
Operation Timer Ready 	—	Test run in progress
Operation Timer Ready 	—	Setting incompatibility (automatic cooling / heating setting for model incapable of it and heating setting for cooling-only model)

8-4. Check Codes list

For other types of outdoor units, refer to their own service manuals.

Controller	Check code		Location of detection	Description	System status	Check code detection condition(s)	Check items (locations)
	Outdoor 7-segment display						
Check code	Sub-code						
C05	—		Central control device	Central control device transmission trouble	Continued operation	Central control device is unable to transmit signal.	<ul style="list-style-type: none"> • Check for failure in central control device. • Check for failure in central control communication line. • Check termination resistance setting.
C06	—		Central control device	Central control device reception trouble	Continued operation	Central control device is unable to receive signal.	<ul style="list-style-type: none"> • Check for failure in central control device. • Check for failure in central control communication line. • Check terminator resistor setting. • Check power supply for devices at other end of central control communication line. • Check failure in P.C. boards of devices at other end of central control communication line.
C12	—		General-purpose device I/F	Batch alarm for general-purpose device control interface	Continued operation	Trouble signal is input to control interface for general-purpose devices.	<ul style="list-style-type: none"> • Check trouble input.
E01	—	—	Remote controller	Indoor-remote controller communication trouble (detected at remote controller end)	Stop of corresponding unit	Communication between indoor P.C. board and remote controller is disrupted.	<ul style="list-style-type: none"> • Check remote controller inter-unit tie cable (A/B). • Check for broken wire or connector bad contact. • Check indoor power supply. • Check for failure in indoor P.C. board. • Check remote controller address settings (when two remote controllers are in use). • Check remote controller P.C. board.
E02	—	—	Remote controller	Remote controller transmission trouble	Stop of corresponding unit	Signal cannot be transmitted from remote controller to indoor unit.	<ul style="list-style-type: none"> • Check internal transmission circuit of remote controller. --- Replace remote controller as necessary.
E03	—	—	Indoor unit	Indoor-remote controller communication trouble (detected at indoor end)	Stop of corresponding unit	There is no communication from remote controller (including wireless) or network adaptor.	<ul style="list-style-type: none"> • Check remote controller and network adaptor wiring.
E04	—	—	Indoor unit	Indoor-outdoor communication circuit trouble (detected at indoor end)	Stop of corresponding unit	Indoor unit is not receiving signal from outdoor unit.	<ul style="list-style-type: none"> • Check order in which power was turned on for indoor and outdoor units. • Check indoor address setting. • Check indoor-outdoor tie cable. • Check outdoor terminator resistor setting (SW100, Bit 2).

Check code			Location of detection	Description	System status	Check code detection condition(s)	Check items (locations)
Controller	Outdoor 7-segment display						
Check code	Sub-code						
E04	E06	No. of indoor units from which signal is received normally	I/F	Dropping out of indoor unit	All stop	Condition 1 All indoor unit initially communicating normally fails to return signal for specified length of time. Condition 2 Outdoor I / F board SW103, Bit4 : OFF (Factory default)	<ul style="list-style-type: none"> • Check power supply to indoor unit. (Is power turned on?) • Check connection of indoor-outdoor communication cable. • Check connection of communication connectors on indoor P.C. board. • Check connection of communication connectors on outdoor P.C. board. • Check for failure in indoor P.C. board. • Check for failure in outdoor P.C. board (I/F).
	—	—	Indoor unit	Indoor-outdoor communication circuit trouble	Only specified indoor units stop	Condition 1 Indoor unit initially communicating normally fails to return signal for specified length of time.	<ul style="list-style-type: none"> • Check power supply to indoor unit. (Is power turned on?) • Check indoor-outdoor power-on sequence. • Check indoor address setting • Check wiring of Indoor-outdoor communication wires • Check outdoor terminator resistor setting (SW100, Bit 2).
E04/E06	E06	No. of indoor units from which signal is received normally	Indoor unit	Indoor-outdoor communication circuit trouble (E04)	All stop	Condition 1 One indoor unit or more initially communicating normally fails to return signal for specified length of time. Condition 2 Outdoor I / F board SW103, Bit4 : ON (To switch the check code detection condition.) <div style="text-align: center;"> </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> Display on main remote controller. Indoor units unavailable for indoor / outdoor communication. : E04 Indoor units available for indoor / outdoor communication. : E06 </div> In TU2C-LINK communication system, if the termination resistance is not set in any of the indoor units.	<ul style="list-style-type: none"> • Check power supply to indoor unit. (Is power turned on?) • Check indoor-outdoor power-on sequence. • Check indoor address setting • Check wiring of Indoor-outdoor communication wires • Check outdoor terminator resistor setting (SW100, Bit 2).
			I/F	Dropping out of indoor unit (E06)			<ul style="list-style-type: none"> • Check power supply to indoor unit. (Is power turned on?) • Check connection of indoor-outdoor communication cable. • Check connection of communication connectors on indoor P.C. board. • Check connection of communication connectors on outdoor P.C. board. • Check for failure in indoor P.C. board. • Check for failure in outdoor P.C. board (I/F).
—	E07	—	I/F	Indoor-outdoor communication circuit trouble (detected at outdoor end)	All stop	Signal cannot be transmitted from outdoor to indoor units for 30 seconds continuously.	<ul style="list-style-type: none"> • Check outdoor terminator resistor setting (SW100, Bit 2). • Check connection of indoor-outdoor communication circuit.
E08	E08	Duplicated indoor address	Indoor unit I/F	Duplicated indoor address	All stop	More than one indoor unit are assigned same address.	<ul style="list-style-type: none"> • Check indoor addresses. • Check for any change made to remote controller connection (group/ individual) since indoor address setting.

Controller	Check code		Location of detection	Description	System status	Check code detection condition(s)	Check items (locations)
	Outdoor 7-segment display	Sub-code					
E09	—	—	Remote controller	Duplicated master remote controller	Stop of corresponding unit	In two remote controller configuration (including wireless), both controllers are set up as master. (Header indoor unit is shut down with alarm, while follower indoor units continue operating.)	<ul style="list-style-type: none"> • Check remote controller settings. • Check remote controller P.C. boards.
E10	—	—	Indoor unit	Indoor inter-MCU communication trouble	Stop of corresponding unit	Communication cannot be established/maintained upon turning on of power or during communication.	<ul style="list-style-type: none"> • Check for failure in indoor P.C. board
E12	E12	01: Indoor-outdoor communication 02: Outdoor-outdoor communication	I/F	Automatic address starting trouble	All stop	<ul style="list-style-type: none"> • Indoor automatic address setting is started while automatic address setting for equipment in other refrigerant line is in progress. • Outdoor automatic address setting is started while automatic address setting for indoor units is in progress. 	<ul style="list-style-type: none"> • Check whether the outdoor unit of other systems or the indoor unit is connected to Uv (U1/U2) line or Uc (U5/U6) line. • Perform automatic address setting again after disconnecting communication cable to that refrigerant line.
E15	E15	—	I/F	Indoor unit not found during automatic address setting	All stop	Indoor unit cannot be detected after indoor automatic address setting is started.	<ul style="list-style-type: none"> • Check connection of indoor-outdoor communication line. • Check for trouble in indoor power supply system. • Check for noise from other devices. • Check for power failure. • Check for failure in indoor P.C. board.
E16	E16	00: Capacity over 01-: No. of units connected	I/F	Too many indoor units connected	All stop	<ul style="list-style-type: none"> • Combined capacity of indoor units is too large. <p>Note: If this code comes up after backup setting for outdoor unit failure is performed, perform "No capacity over detected" setting.</p> <p><"No capacity over detected" setting method> Turn on SW103 / Bit 3 on I/F P.C. board of outdoor header unit. For Cooling Only model, this check code is not displayed even if it exceeds the combined capacity of indoor units.</p> <ul style="list-style-type: none"> • More than 128 indoor units are connected. 	<ul style="list-style-type: none"> • Check capacities of indoor units connected. • Check combined HP capacities of indoor units. • Check HP capacity settings of outdoor units. • Check No. of indoor units connected. • Check for failure in outdoor P.C. board (I/F).
E18	—	—	Indoor unit	Trouble in communication between indoor header and follower units	Stop of corresponding unit	Periodic communication between indoor header and follower units cannot be maintained.	<ul style="list-style-type: none"> • Check remote controller wiring. • Check indoor power supply wiring. • Check P.C. boards of indoor units.
E19	E19	00: No header unit 02: Two or more header units	I/F	Trouble in number of outdoor header units	All stop	<ul style="list-style-type: none"> • There are more than one outdoor header units in one line. • There is no outdoor header unit in one line. 	<ul style="list-style-type: none"> • The outdoor unit which turned on SW101 and the bit 1 of the interface P.C. board is set to Header unit. • Check SW101 bit 1 of follower outdoor unit. • Check connection of indoor-outdoor communication line. • Check for failure in outdoor P.C. board (I/F).
E20	E20	01: Connection of outdoor unit from other line 02: Connection of indoor unit from other line	I/F	Connection to other line found during automatic address setting	All stop	Equipment from other line is found to have been connected when indoor automatic address setting is in progress.	Check whether the outdoor unit of other systems or the indoor unit is connected to Uv (U1/U2) line or Uc (U5/U6) line.

Check code			Location of detection	Description	System status	Check code detection condition(s)	Check items (locations)																																																																																									
Controller	Outdoor 7-segment display																																																																																															
	Check code	Sub-code																																																																																														
E23	E23	—	I/F	Outdooroutdoor communication transmission trouble	All stop	Signal cannot be transmitted to other outdoor units for at least 30 seconds continuously.	<ul style="list-style-type: none">• Check power supply to outdoor units. (Is power turned on?)• Check connection of tie cables between outdoor units for bad contact or broken wire.• Check communication connectors on outdoor P.C. boards.• Check for failure in outdoor P.C. board (I/F).• Check termination resistance setting for communication between outdoor units.																																																																																									
E25	E25	—	I/F	Duplicated follower outdoor address	All stop	There is duplication in outdoor addresses set manually.	Note: Do not set outdoor addresses manually.																																																																																									
E26	E26	Address of outdoor unit from which signal is not received normally	I/F	Signal lack of outdoor unit	All stop	Outdoor unit initially communicating normally fails to return signal for specified length of time.	<ul style="list-style-type: none">• Backup setting is being used for outdoor units.• Check power supply to outdoor unit. (Is power turned on?)• Check connection of tie cables between outdoor units for bad contact or broken wire.• Check communication connectors on outdoor P.C. boards.• Check for failure in outdoor P.C. board (I/F).																																																																																									
The check code which occurred follower outdoor unit is displayed	E28	Detected outdoor unit No.	I/F	Outdoor follower unit trouble	All stop	Outdoor header unit receives trouble code from outdoor follower unit.	<ul style="list-style-type: none">• Check check code displayed on outdoor follower unit. <p><Convenient functions> If SW04 is pressed and held for at least 1 second while [E28] is displayed on the 7-segment display of outdoor header unit, the fan of the outdoor unit that has been shut down due to an trouble comes on. If SW04 and SW05 are pressed simultaneously, the fans of normal outdoor units come on. To stop the fan or fans, press SW05 on its own.</p>																																																																																									
E31	E31	<table border="1"><thead><tr><th colspan="4">P.C. board</th></tr><tr><th></th><th colspan="2">Compressor</th><th colspan="2">Fan Motor</th></tr><tr><th></th><th>1</th><th>2</th><th>1</th><th>2</th></tr></thead><tbody><tr><td>01</td><td>O</td><td></td><td></td><td></td></tr><tr><td>02</td><td></td><td>O</td><td></td><td></td></tr><tr><td>03</td><td>O</td><td>O</td><td></td><td></td></tr><tr><td>08</td><td></td><td></td><td>O</td><td></td></tr><tr><td>09</td><td>O</td><td></td><td>O</td><td></td></tr><tr><td>0A</td><td></td><td>O</td><td>O</td><td></td></tr><tr><td>0B</td><td>O</td><td>O</td><td>O</td><td></td></tr><tr><td>10</td><td></td><td></td><td></td><td>O</td></tr><tr><td>11</td><td>O</td><td></td><td></td><td>O</td></tr><tr><td>12</td><td></td><td>O</td><td></td><td>O</td></tr><tr><td>13</td><td>O</td><td>O</td><td></td><td>O</td></tr><tr><td>18</td><td></td><td></td><td>O</td><td>O</td></tr><tr><td>19</td><td>O</td><td></td><td>O</td><td>O</td></tr><tr><td>1A</td><td></td><td>O</td><td>O</td><td>O</td></tr><tr><td>1B</td><td>O</td><td>O</td><td>O</td><td>O</td></tr></tbody></table> <p>Circle (O): Trouble P.C. board</p>	P.C. board					Compressor		Fan Motor			1	2	1	2	01	O				02		O			03	O	O			08			O		09	O		O		0A		O	O		0B	O	O	O		10				O	11	O			O	12		O		O	13	O	O		O	18			O	O	19	O		O	O	1A		O	O	O	1B	O	O	O	O	I/F	P.C. board communication trouble	All stop	Communication is disrupted between P.C. board in inverter box.	<ul style="list-style-type: none">• Check wiring and connectors involved in communication between P.C. board I/F P.C. board for bad contact or broken wire.• Check for failure in outdoor P.C. board (I/F, comp. P.C. board or Fan P.C. board).• Check for external noise.
P.C. board																																																																																																
	Compressor		Fan Motor																																																																																													
	1	2	1	2																																																																																												
01	O																																																																																															
02		O																																																																																														
03	O	O																																																																																														
08			O																																																																																													
09	O		O																																																																																													
0A		O	O																																																																																													
0B	O	O	O																																																																																													
10				O																																																																																												
11	O			O																																																																																												
12		O		O																																																																																												
13	O	O		O																																																																																												
18			O	O																																																																																												
19	O		O	O																																																																																												
1A		O	O	O																																																																																												
1B	O	O	O	O																																																																																												
		80		Communication trouble between MCU and Sub MCU	All stop	Communication between MCU and Sub MCU stopped.	<ul style="list-style-type: none">• Operation of power supply reset (OFF for 60 seconds or more)• Outdoor I/F PC board trouble check																																																																																									

Controller	Check code		Location of detection	Description	System status	Check code detection condition(s)	Check items (locations)
	Outdoor 7-segment display						
	Check code	Sub-code					
F01	—	—	Indoor unit	Indoor TCJ sensor trouble	Stop of corresponding unit	Sensor resistance is infinity or zero (open/short circuit).	<ul style="list-style-type: none"> • Check connection of TCJ sensor connector and wiring. • Check resistance characteristics of TCJ sensor. • Check for failure in indoor P.C. board.
F02	—	—	Indoor unit	Indoor TC2 sensor trouble	Stop of corresponding unit	Sensor resistance is infinity or zero (open/short circuit).	<ul style="list-style-type: none"> • Check connection of TC2 sensor connector and wiring. • Check resistance characteristics of TC2 sensor. • Check for failure in indoor P.C. board.
F03	—	—	Indoor unit	Indoor TC1 sensor trouble	Stop of corresponding unit	Sensor resistance is infinity or zero (open/short circuit).	<ul style="list-style-type: none"> • Check connection of TC1 sensor connector and wiring. • Check resistance characteristics of TC1 sensor. • Check for failure in indoor P.C. board.
F04	F04	—	I/F	TD1 sensor trouble	All stop	Sensor resistance is infinity or zero (open/short circuit).	<ul style="list-style-type: none"> • Check connection of TD1 sensor connector. • Check resistance characteristics of TD1 sensor. • Check for failure in outdoor P.C. board (I/F).
F05	F05	—	I/F	TD2 sensor trouble	All stop	Sensor resistance is infinity or zero (open/short circuit).	<ul style="list-style-type: none"> • Check connection of TD2 sensor connector. • Check resistance characteristics of TD2 sensor. • Check for failure in outdoor P.C. board (I/F).
F06	F06	01: TE1 sensor trouble 02: TE2 sensor trouble 03: TE3 sensor trouble	I/F	TE1/TE2/TE3 sensor trouble	All stop	Sensor resistance is infinity or zero (open/short circuit).	<ul style="list-style-type: none"> • Check connection of TE1/TE2/TE3 sensor connectors. • Check resistance characteristics of TE1/TE2/TE3 sensors. • Check for failure in outdoor P.C. board (I/F).
F07	F07	01: TL1 sensor trouble 02: TL2 sensor trouble 03: TL3 sensor trouble	I/F	TL1/TL2/TL3 sensor trouble	All stop	Sensor resistance is infinity or zero (open/short circuit).	<ul style="list-style-type: none"> • Check connection of TL1/TL2/TL3 sensor connector. • Check resistance characteristics of TL1/TL2/TL3 sensor. • Check for failure in outdoor P.C. board (I/F).
F08	F08	—	I/F	TO sensor trouble	All stop	Sensor resistance is infinity or zero (open/short circuit).	<ul style="list-style-type: none"> • Check connection of TO sensor connector. • Check resistance characteristics of TO sensor. • Check for failure in outdoor P.C. board (I/F).
F09	F09	01: TG1 sensor trouble 02: TG2 sensor trouble 03: TG3 sensor trouble	I/F	TG1/TG2/TG3 sensor trouble	All stop	Sensor resistance is infinity or zero (open/short circuit).	<ul style="list-style-type: none"> • Check connection of TG1/TG2/TG3 sensor connectors. • Check resistance characteristics of TG1/TG2/TG3 sensors. • Check for failure in outdoor P.C. board (I/F).
F10	—	—	Indoor unit	Indoor TA sensor trouble	Stop of corresponding unit	Sensor resistance is infinity or zero (open/short circuit).	<ul style="list-style-type: none"> • Check connection of TA sensor connector and wiring. • Check resistance characteristics of TA sensor. • Check for failure in indoor P.C. board.

Controller	Check code		Location of detection	Description	System status	Check code detection condition(s)	Check items (locations)
	Outdoor 7-segment display						
	Check code	Sub-code					
F11	—	—	Indoor unit	Indoor TF sensor trouble	Stop of corresponding unit	Sensor resistance is infinity or zero (open/short circuit).	<ul style="list-style-type: none"> • Check connection of TF sensor connector and wiring. • Check resistance characteristics of TF sensor. • Check for failure in indoor P.C. board.
F12	F12	01: TS1 sensor trouble 03: TS3 sensor trouble 04: TS3 sensor disconnect	I/F	TS1/TS3 sensor trouble	All stop	<ul style="list-style-type: none"> • Sensor resistance is infinity or zero (open/short circuit). • When TS3 detects an unusual temperature during compressor operation and PMV4 operation in cooling mode. 	<ul style="list-style-type: none"> • Check connection of TS1/TS3 sensor connector • Check resistance characteristics of TS1/TS3 sensor. • The attachment check of TS3 sensor. • Check for failure in indoor P.C. board.
F13	F13	1*: Compressor 1 side 2*: Compressor 2 side	Compressor P.C. board	TH sensor trouble	All stop	Sensor resistance is infinity or zero (open/short circuit).	<ul style="list-style-type: none"> • Failure in IPM built-in temperature sensor → Replace Compressor P.C. board.
F15	F15	—	I/F	Outdoor temperature sensor wiring trouble (TE1, TL1)	All stop	During compressor operation in HEAT mode, TL1 continuously provides temperature reading higher than indicated by TL1 by at least specified margin for 3 minutes or more.	<ul style="list-style-type: none"> • Check installation of TE1 and TL1 sensors. • Check resistance characteristics of TE1 and TL1 sensors. • Check for outdoor P.C. board (I/F) trouble
F16	F16	—	I/F	Outdoor pressure sensor wiring trouble (Pd, Ps)	All stop	Readings of high-pressure Pd sensor and low-pressure Ps sensor are switched. Output voltages of both sensors are zero.	<ul style="list-style-type: none"> • Check connection of high-pressure Pd sensor connector. • Check connection of low-pressure Ps sensor connector. • Check for failure in pressure sensors Pd and Ps. • Check for trouble in outdoor P.C. board (I/F). • Check for compressor poor compression.
F23	F23	—	I/F	Ps sensor trouble	All stop	Output voltage of Ps sensor is zero.	<ul style="list-style-type: none"> • Check for connection trouble involving Ps sensor and Pd sensor connectors. • Check connection of Ps sensor connector. • Check for failure in Ps sensor. • Check for compressor poor compression. • Check for failure in 4-way valve. • Check for failure in outdoor P.C. board (I/F). • Check for failure in SV4 circuit.
F24	F24	—	I/F	Pd sensor trouble	All stop	Output voltage of Pd sensor is zero (sensor open-circuited). Pd > 4.15MPa despite compressor having been turned off.	<ul style="list-style-type: none"> • Check connection of Pd sensor connector. • Check for failure in Pd sensor. • Check for failure in outdoor P.C. board (I/F).
F29	—	—	Indoor unit	Other indoor trouble	Stop of corresponding unit	Indoor P.C. board does not operate normally.	<ul style="list-style-type: none"> • Check for failure in indoor P.C. board (failure EEPROM)
F31	F31	—	I/F	Outdoor EEPROM trouble	All stop *1	Outdoor P.C. board (I/F) does not operate normally.	<ul style="list-style-type: none"> • Check power supply voltage. • Check power supply noise. • Check for failure in outdoor P.C. board (I/F).

*1 Total shutdown in case of header unit
Continued operation in case of follower unit

Controller	Check code		Location of detection	Description	System status	Check code detection condition(s)	Check items (locations)
	Outdoor 7-segment display						
	Check code	Sub-code					
H01	H01	1*: Compressor 1 side 2*: Compressor 2 side	Compressor P.C. board	Compressor breakdown	All stop	Inverter current detection circuit detects overcurrent and shuts system down.	<ul style="list-style-type: none"> • Check power supply voltage. (AC380V \pm 10%). • Check for failure in compressor. • Check for possible cause of abnormal overloading. • Check for failure in outdoor P.C. board (Compressor).
H02	H02	1*: Compressor 1 side 2*: Compressor 2 side	Compressor P.C. board	Compressor trouble (lockup) MG-CTT trouble	All stop	Overcurrent is detected several seconds after startup of inverter compressor.	<ul style="list-style-type: none"> • Check for failure in compressor. • Check power supply voltage. (AC380V \pm 10%). • Check compressor system wiring, particularly for open phase. • Check connection of connectors/terminals on compressor P.C. board. • Check conductivity of case heater. (Check for refrigerant problem inside compressor.) • Check for failure in outdoor P.C. board (Compressor). • Check outdoor MG-CTT.
H03	H03	1*: Compressor 1 side 2*: Compressor 2 side	Compressor P.C. board	Current detection circuit trouble	All stop	Current flow of at least specified magnitude is detected despite inverter compressor having been shut turned off.	<ul style="list-style-type: none"> • Check current detection circuit wiring. • Check failure in outdoor P.C. board (Compressor).
H05	H05	—	I/F	TD1 sensor miswiring (incomplete insertion)	All stop	Discharge temperature of compressor 1 (TD1) does not increase despite compressor being in operation.	<ul style="list-style-type: none"> • Check installation of TD1 sensor. • Check connection of TD1 sensor connector and wiring. • Check resistance characteristics of TD1 sensor. • Check for failure in outdoor P.C. board (I/F).
H06	H06	—	I/F	Activation of low-pressure protection	All stop	Low-pressure Ps sensor detects operating pressure lower than 0.02MPa.	<ul style="list-style-type: none"> • Check service valves to confirm full opening (both gas and liquid sides). • Check outdoor PMVs for clogging (PMV1, 2, 3). • Check for failure in SV4 circuits. • Check for failure in low-pressure Ps sensor. • Check indoor filter for clogging. • Check valve opening status of indoor PMV. • Check refrigerant piping for clogging. • Check operation of outdoor fan (during heating). • Check for insufficiency in refrigerant quantity.
H07	H07	—	I/F	Low oil level protection	All stop	Operating compressor detects continuous state of low oil level for about 2 hours.	<p><All outdoor units in corresponding line to be checked></p> <ul style="list-style-type: none"> • Check connection and installation of TK1 and TK2 sensors. • Check resistance characteristics of TK1 and TK2 sensors. • Check for gas or oil leak in same line. • Check for refrigerant problem inside compressor casing. • Check SV3D, SV3F valves for failure. • Check oil return circuit of oil separator for clogging. • Check oil equalizing circuit for clogging.

Controller	Check code		Location of detection	Description	System status	Check code detection condition(s)	Check items (locations)
	Outdoor 7-segment display						
	Check code	Sub-code					
H08	H08	01: TK1 sensor trouble 02: TK2 sensor trouble	I/F	Trouble in temperature sensor for oil level detection	All stop	Sensor resistance is infinity or zero (open/short circuit).	<ul style="list-style-type: none"> • Check connection of TK1 sensor connector. • Check resistance characteristics of TK1 sensor. • Check for failure in outdoor P.C. board (I/F).
					All stop	Sensor resistance is infinity or zero (open/short circuit).	<ul style="list-style-type: none"> • Check connection of TK2 sensor connector. • Check resistance characteristics of TK2 sensor. • Check for failure in outdoor P.C. board (I/F).
H15	H15	—	I/F	TD2 sensor miswiring (incomplete insertion)	All stop	Discharge temperature of (TD2) does not increase despite compressor 2 being in operation.	<ul style="list-style-type: none"> • Check installation of TD2 sensor. • Check connection of TD2 sensor connector and wiring. • Check resistance characteristics of TD2 sensor. • Check for failure in outdoor P.C. board (I/F).
H16	H16	01: TK1 oil circuit trouble 02: TK2 oil circuit trouble	I/F	Oil level detection circuit trouble	All stop	No temperature change is detected by TK1 despite compressor 1 having been started.	<ul style="list-style-type: none"> • Check for disconnection of TK1 sensor. • Check resistance characteristics of TK1 sensor. • Check for connection trouble involving TK1 and TK2 sensors • Check for clogging in oil equalizing circuit capillary. • Check for refrigerant entrapment inside compressor.
						No temperature change is detected by TK2 despite compressor 2 having been started.	<ul style="list-style-type: none"> • Check for disconnection of TK2 sensor. • Check resistance characteristics of TK2 sensor. • Check for connection trouble involving TK1 and TK2 sensors • Check SV3F valve malfunction. • Check for clogging in oil equalizing circuit capillary. • Check for refrigerant entrapment inside compressor.
H17	H17	1*: Compressor 1 side 2*: Compressor 2 side	Compressor P.C. board	Compressor trouble (Step-out)	All stop	Compressor is in step-out condition.	<ul style="list-style-type: none"> • Check power supply voltage. (AC380V ± 10%). • Check for failure in compressor. • Check for possible cause of abnormal overloading. • Check for failure in outdoor P.C. board (compressor).
L02	L02	Detected indoor unit address	Indoor unit	Outdoor units model disagreement trouble	Stop of corresponding unit	In case of different outdoor unit (Not corresponded to Air to Air Heat Exchanger type)	<ul style="list-style-type: none"> • Check outdoor unit model. (Check whether the outdoor unit corresponds to Air to Air Heat Exchanger type or not.)
L03	—	—	Indoor unit	Duplicated indoor header unit	Stop of corresponding unit	There are more than one header units in group.	<ul style="list-style-type: none"> • Check indoor addresses. • Check for any change made to remote controller connection (group/individual) since indoor address setting.
L04	L04	—	I/F	Duplicated outdoor line address	All stop	There is duplication in line address setting for outdoor units belonging to different refrigerant piping systems.	<ul style="list-style-type: none"> • Check line addresses.

Check code			Location of detection	Description	System status	Check code detection condition(s)	Check items (locations)																																																																																								
Controller	Outdoor 7-segment display																																																																																														
	Check code	Sub-code																																																																																													
L05	—	—	I/F	Duplicated priority indoor unit (as displayed on priority indoor unit)	All stop	More than one indoor units have been set up as priority indoor unit.	• Check display on priority indoor unit.																																																																																								
L06	L06	No. of priority indoor units	I/F	Duplicated priority indoor unit (as displayed on indoor unit other than priority indoor unit)	All stop	More than one indoor units have been set up as priority indoor unit.	• Check displays on priority indoor unit and outdoor unit.																																																																																								
L07	—	—	Indoor unit	Connection of group control cable to standalone indoor unit	Stop of corresponding unit	There is at least one standalone indoor unit to which group control cable is connected.	• Check indoor addresses.																																																																																								
L08	L08	—	Indoor unit	Indoor group / addresses not set	Stop of corresponding unit	Address setting has not been performed for indoor units.	• Check indoor addresses. Note: This code is displayed when power is turned on for the first time after installation.																																																																																								
L09	—	—	Indoor unit	Indoor capacity not set	Stop of corresponding unit	Capacity setting has not been performed for indoor unit.	Set indoor capacity. (DN = 11)																																																																																								
L10	L10	—	I/F	Outdoor capacity not set	All stop	Initial setting of I/F P.C. board has not been implemented.	• Check model setting of P.C. board for servicing outdoor I/F P.C. board.																																																																																								
L17	L17	—	I/F	Outdoor model incompatibility trouble	All stop	Outdoor unit that cannot be connected is connected.	• Check the model name of the outdoor unit.																																																																																								
L20	—	—	Network adaptor Indoor unit	Duplicated central control address	All stop	There is duplication in central control address setting.	• Check central control addresses.																																																																																								
L23	—	—	I/F	SW setting trouble	All stop	Outdoor P.C. board (I/F) does not operate normally.	• Check switch setting of outdoor P.C. board (I/F).																																																																																								
L28	L28	—	I/F	Too many outdoor units connected	All stop	There are more than 5 outdoor units.	• Check No. of outdoor units connected (Only up to 5 units per system allowed). • Check communication lines between outdoor units. • Check for failure in outdoor P.C. board (I/F).																																																																																								
L29	L29	<table><tr><th colspan="4">P.C. board</th></tr><tr><th colspan="2">Compressor</th><th colspan="2">Fan Motor</th></tr><tr><th></th><th>1</th><th>2</th><th>1</th><th>2</th></tr><tr><td>01</td><td>O</td><td></td><td></td><td></td></tr><tr><td>02</td><td></td><td>O</td><td></td><td></td></tr><tr><td>03</td><td>O</td><td>O</td><td></td><td></td></tr><tr><td>08</td><td></td><td></td><td>O</td><td></td></tr><tr><td>09</td><td>O</td><td></td><td>O</td><td></td></tr><tr><td>0A</td><td></td><td>O</td><td>O</td><td></td></tr><tr><td>0B</td><td>O</td><td>O</td><td>O</td><td></td></tr><tr><td>10</td><td></td><td></td><td></td><td>O</td></tr><tr><td>11</td><td>O</td><td></td><td></td><td>O</td></tr><tr><td>12</td><td></td><td>O</td><td></td><td>O</td></tr><tr><td>13</td><td>O</td><td>O</td><td></td><td>O</td></tr><tr><td>18</td><td></td><td></td><td>O</td><td>O</td></tr><tr><td>19</td><td>O</td><td></td><td>O</td><td>O</td></tr><tr><td>1A</td><td></td><td>O</td><td>O</td><td>O</td></tr><tr><td>1B</td><td>O</td><td>O</td><td>O</td><td>O</td></tr></table> <p>Circle (O): Trouble P.C. board</p>	P.C. board				Compressor		Fan Motor			1	2	1	2	01	O				02		O			03	O	O			08			O		09	O		O		0A		O	O		0B	O	O	O		10				O	11	O			O	12		O		O	13	O	O		O	18			O	O	19	O		O	O	1A		O	O	O	1B	O	O	O	O	I/F	Trouble in No. of P.C. board	All stop	Insufficient number of P.C. board are detected when power is turned on.	• Check model setting of P.C. board for servicing outdoor I/F P.C. board. • Check connection of UART communication connector. • Check compressor P.C. board, fan P.C. board, and I/F P.C. board for failure.
		P.C. board																																																																																													
Compressor		Fan Motor																																																																																													
	1	2	1	2																																																																																											
01	O																																																																																														
02		O																																																																																													
03	O	O																																																																																													
08			O																																																																																												
09	O		O																																																																																												
0A		O	O																																																																																												
0B	O	O	O																																																																																												
10				O																																																																																											
11	O			O																																																																																											
12		O		O																																																																																											
13	O	O		O																																																																																											
18			O	O																																																																																											
19	O		O	O																																																																																											
1A		O	O	O																																																																																											
1B	O	O	O	O																																																																																											
		00	I/F	The number of inverter P.C. boards is abnormal.	All stop	When there is much number of an inverter P.C. board to model setting of an interface P.C. board.	• Check I/F P.C. board exchange has been correctly performed as a procedure. • Check for failure in I/F P.C. board. • Check for inverter P.C. board for compressors and inverter P.C. board for fan																																																																																								

Controller	Check code		Location of detection	Description	System status	Check code detection condition(s)	Check items (locations)
	Outdoor 7-segment display						
	Check code	Sub-code					
L30	L30	Detected indoor address	Indoor unit	Indoor external interlock (External abnormal input)	Stop of corresponding unit	<ul style="list-style-type: none"> Indoor unit has been shut down due to external abnormal input signal. 	When external device is connected: 1) Check for trouble in external device. 2) Check for trouble in indoor P.C. board. When external device is not connected: 1) Check for trouble in indoor P.C. board.
—	L31	—	I/F	Extended IC trouble	Continued operation	There is part failure in P.C. board (I/F).	Check outdoor P.C. board (I/F).
P01	—	—	Indoor unit	Indoor fan motor trouble	Stop of corresponding unit		<ul style="list-style-type: none"> Check the lock of fan motor (AC fan). Check wiring.
P03	P03	—	I/F	Discharge temperature TD1 trouble	All stop	Discharge temperature (TD1) exceeds 115 °C.	<ul style="list-style-type: none"> Check outdoor service valves (gas side, liquid side) to confirm full opening. Check outdoor PMVs (PMV1, 2, 3, 4) for clogging. Check resistance characteristics of TD1 sensor. Check for insufficiency in refrigerant quantity. Check for failure in 4-way valve. Check for leakage of SV4 circuit. Check SV4 circuit (wiring or installation trouble in SV41 or SV42).
P04	P04	01: Compressor 1 side 02: Compressor 2 side	I/F	Activation of high-pressure SW	All stop	High-pressure SW is activated.	<ul style="list-style-type: none"> Check connection of high-pressure SW connector. Check for failure in Pd pressure sensor. Check outdoor service valves (gas side, liquid side) to confirm full opening. Check for failure in outdoor fan. Check for failure in outdoor fan motor. Check outdoor PMVs (PMV1, 2, 3) for clogging. Check indoor/outdoor heat exchangers for clogging. Check for short-circuiting of outdoor suction/discharge air flows. Check for failure in indoor P.C. board (I/F). Check for trouble in indoor fan system (possible cause of air flow reduction). Check opening status of indoor PMV. Check indoor-outdoor communication line for wiring trouble. Check for failure operation of check valve in discharge pipe convergent section. Check gas balancing SV4 valve circuit. Check for refrigerant overcharging.
P05	P05	00: Power detection trouble 01: Open phase 02: Power supply miswiring	I/F	Power detection trouble / Open phase detection / Power supply miswiring	All stop	<ul style="list-style-type: none"> Open phase is detected when power is turned on. Inverter DC voltage is too high (overvoltage) or too low (undervoltage). 	<ul style="list-style-type: none"> Check for failure in indoor P.C. board (I/F). Check wiring of outdoor power supply. Check power supply voltage.
		1*: Compressor 1 side 2*: Compressor 2 side	Compressor P.C. board	Compressor Vdc trouble			

Controller	Check code		Location of detection	Description	System status	Check code detection condition(s)	Check items (locations)
	Outdoor 7-segment display						
	Check code	Sub-code					
P07	P07	1*: Compressor 1 side 2*: Compressor 2 side	Compressor P.C. board	Heat sink overheating trouble	All stop	Temperature sensor built into IPM (TH) is overheated.	<ul style="list-style-type: none"> • Check outdoor fan system trouble. • Check IPM and heat sink for thermal performance for failure installation. (e.g. mounting screws and thermal conductivity) • Check for failure in Compressor P.C. board. (failure IPM built-in temperature sensor (TH))
		01: Compressor 1 heat sink trouble 02: Compressor 2 heat sink trouble 04: Heat sink dewing	I/F	Heat sink overheating trouble Heat sink dewing trouble	All stop	Condensation detection on heat sink has occurred four times or more in operation. Temperature sensor built into IPM (TH) is overheated.	<ul style="list-style-type: none"> • Check outdoor fan system trouble. • Check IPM and heat sink for thermal performance for troubled installation. (e.g. mounting screws and thermal conductivity) • Check for failure in compressor P.C. board. (failure IPM built-in temperature sensor (TH)) • Check shortage of refrigerant. • Check outdoor service valves. • Check connection of TL2 sensor. • Check resistance characteristics of TL2 sensor. • Check resistance characteristics of TO sensor. • Check malfunctions of Pd and Ps sensors. • Check outdoor I/F P.C. board malfunction. • Check PMV2 and PMV3. • Check refrigerant stagnation.
P10	P10	Detected indoor address	Indoor unit	Indoor overflow trouble	All stop	<ul style="list-style-type: none"> • Float switch operates. • Float switch circuit is open-circuited or disconnected at connector. 	<ul style="list-style-type: none"> • Check float switch connector. • Check operation of drain pump. • Check drain pump circuit. • Check drain pipe for clogging. • Check for failure in indoor P.C. board.
P11	—	—	I/F	Outdoor heat exchanger freeze trouble	All stop	<ul style="list-style-type: none"> • Outdoor heat exchanger remaining frost detection has occurred eight times or more due to abnormal frost formation in heating operation. 	<ul style="list-style-type: none"> • Check shortage of refrigerant. • Check connection of TE1, TE2 and TE3 sensors. • Check resistance characteristics of TE1, TE2, and TE3 sensors. • Check disconnection of TS1 sensor. • Check resistance characteristics of TS1 sensor. • Check outdoor I/F P.C. board malfunction. • Check operation of 4 way valve. • Check operation of outdoor PMV (1, 2, 3). • Check short circuit from outlet air to inlet air.
P12	—	—	Indoor unit	Indoor fan motor trouble	Stop of corresponding unit	<ul style="list-style-type: none"> • Motor speed measurements continuously deviate from target value. • Overcurrent protection is activated. 	<ul style="list-style-type: none"> • Check connection of fan connector and wiring. • Check for failure in fan motor. • Check for failure in indoor P.C. board. • Check impact of outside air treatment (OA).

Check code			Location of detection	Description	System status	Check code detection condition(s)	Check items (locations)
Controller	Outdoor 7-segment display						
	Check code	Sub-code					
P13	P13	—	I/F	Outdoor liquid backflow detection trouble	All stop	<During cooling operation> When system is in cooling operation, high pressure is detected in the unit that has been turned off. <During heating operation> When system is in heating operation, low pressure is detected to be high in unit that has been turned off.	<ul style="list-style-type: none">• Check full-close operation of outdoor PMV (1, 2, 3, 4).• Check for failure in Pd or Ps sensor.• Check failure in outdoor P.C. board (I/F).• Check capillary of oil separator oil return circuit for clogging.• Check for leakage of check valve in discharge pipe
P14	P14	01: Outdoor unit valve is closed	I/F	Another refrigerant cycle protection	All stop	Outdoor unit valve is forgotten to open during test run.	<ul style="list-style-type: none">• Check service valves to confirm full opening. (both gas and liquid sides)• Check connection indoor-outdoor unit communication cable.• Check indoor unit sensor and PMV.• Check for broken or clogging at refrigerant piping.
P15	P15	01: TS condition	I/F	Gas leak detection (TS1 condition)	All stop	Protective shutdown due to sustained suction temperature at or above judgment criterion for at least 10 minutes is repeated four times or more. <TS trouble judgment criterion> In cooling operation: 60 °C In heating operation: 40 °C	<ul style="list-style-type: none">• Check for insufficiency in refrigerant quantity.• Check outdoor service valves (gas side, liquid side) to confirm full opening.• Check PMVs (PMV1, 2, 3, 4) for clogging.• Check resistance characteristics of TS1 sensor.• Check for failure in 4-way valve.• Check SV4 circuit for leakage
		02: TD condition	I/F	Gas leak detection (TD condition)	All stop	Protective shutdown due to sustained discharge temperature (TD1 or TD2) at or above 108 °C for at least 10 minutes is repeated four times or more.	<ul style="list-style-type: none">• Check for insufficiency in refrigerant quantity.• Check PMVs (PMV 1, 2, 3, 4) for clogging.• Check resistance characteristics of TD1 and TD2 sensors.• Check indoor filter for clogging.• Check piping for clogging.• Check SV4 circuit (for leakage or coil installation trouble).
P17	P17	—	I/F	Discharge temperature TD2 trouble	All stop	Discharge temperature (TD2) exceeds 115 °C.	<ul style="list-style-type: none">• Check outdoor service valves (gas side, liquid side) to confirm full opening.• Check outdoor PMVs (PMV1, 2, 3, 4) for clogging.• Check resistance characteristics of TD2 sensor.• Check for failure in 4-way valve.• Check SV4 circuit for leakage.• Check SV4 circuit (for wiring or installation trouble involving SV41 and SV42).
P19	P19	Detected outdoor unit No.	I/F	4-way valve reversing trouble	All stop	Abnormal refrigerating cycle data is collected during heating operation.	<ul style="list-style-type: none">• Check for failure in main body of 4-way valve.• Check for coil failure in 4-way valve and loose connection of its connector.• Check resistance characteristics of TS1 and TE1, TE2 sensors.• Check output voltage characteristics of Pd and Ps pressure sensors.• Check for wiring trouble involving TE1 and TL1 sensors.

Controller	Check code		Location of detection	Description	System status	Check code detection condition(s)	Check items (locations)
	Outdoor 7-segment display	Sub-code					
P20	P20	—	I/F	Activation of high-pressure protection	All stop	<p><During cooling operation> Pd sensor detects pressure equal to or greater than 3.85 MPa.</p> <p><During heating operation> Pd sensor detects pressure equal to or greater than 3.6 MPa.</p>	<ul style="list-style-type: none"> • Check for failure in Pd pressure sensor. • Check service valves (gas side, liquid side) to confirm full opening. • Check for failure in outdoor fan. • Check for failure in outdoor fan motor. • Check outdoor PMV (PMV1, 2, 3, 4) for clogging. • Check indoor/outdoor heat exchangers for clogging. • Check for short-circuiting of outdoor suction/discharge air flows. • Check for failure in outdoor P.C. board (I/F). • Check for failure in indoor fan system (possible cause of air flow reduction). • Check opening status of indoor PMV. • Check indoor-outdoor communication line for wiring trouble. • Check for trouble operation of check valve in discharge pipe convergent section. • Check gas balancing SV4 valve circuit. • Check for refrigerant overcharging.
P22	P22	1*: Fan P.C. board 1 2*: Fan P.C. board 2	Fan INV. P.C. board	Outdoor fan P.C. board trouble	All stop	Protected operation of Fan inverter P.C. board	<ul style="list-style-type: none"> • Check fan motor. • Check for failure in fan P.C. board. • Check connection of fan motor connector. • Check power voltage of the main power supply.
P26	P26	1*: Compressor 1 side 2*: Compressor 2 side	Compressor P.C. board	IPM, Compressor shortcircuit protection trouble	All stop	Overcurrent is momentarily detected during startup of compressor.	<ul style="list-style-type: none"> • Check connector connection and wiring on compressor P.C. board. • Check for failure in compressor (layer shortcircuit). • Check for failure in outdoor P.C. board (Compressor).
P29	P29	1*: Compressor 1 side 2*: Compressor 2 side	Compressor P.C. board	Compressor position detection circuit trouble	All stop	Position detection is not going on normally.	<ul style="list-style-type: none"> • Check wiring and connector connection. • Check for compressor layer short-circuit. • Check for failure in compressor P.C. board.
P30	Differs according to nature of alarm-causing trouble		Central control device	Group control follower unit trouble	Continued operation	Trouble occurs in follower unit under group control. ([P30] is displayed on central control remote controller.)	• Check check code of unit that has generated alarm.
	(L20 displayed.)			Duplicated central control address	Continued operation	There is duplication in central control addresses.	• Check address settings.
P31	—	—	Indoor unit	Other indoor trouble (group follower unit trouble)	Stop of corresponding unit	There is trouble in other indoor unit in group, resulting in detection of E07/L07/L03/L08.	• Check indoor P.C. board.
S01	—	—	Central control device	Central control device reception trouble	Continued operation	Central control device is unable to receive signal.	<ul style="list-style-type: none"> • Check for failure in central control device. • Check for failure in central control communication line. • Check terminator resistor setting. • Check power supply for devices at other end of central control communication line. • Check failure in P.C. boards of devices at other end of central control communication line.


▼ Points to Note When Servicing Compressor

- (1) When checking the outputs of inverters, remove the wiring from all the compressors.

▼ How to Check Inverter Output

- (1) Turn off the power supply.
- (2) Remove compressor leads from the compressor P.C. board.
(The model with two compressor should remove the wiring for two sets (6 leads).)
- (3) Turn on the power supply and start cooling or heating operation.
- (4) Check the output voltage across each pair of inverter-side. If the result is unsatisfactory according to the judgment criteria given in the table below, replace the compressor P.C. board.

No.	Measured leads	Criterion
1	CN201 - CN202	240-400V
2	CN202 - CN203	240-400V
3	CN203 - CN201	240-400V




▼ How to Check Resistance of Compressor Winding



- (1) Turn off the power supply.
- (2) Remove compressor leads from the compressor P.C. board. (Be sure to remove all the leads.)
- (3) With each compressor, check the phase-to-phase winding resistances and winding-to-outdoor cabinet resistance using a multimeter.
 - Earth trouble?
 - It is normal if the winding-to-outdoor cabinet resistance is 10MΩ or more.
 - Inter-winding short circuit?
 - It is normal if the phase-to-phase resistances are in the 0.1-0.4Ω range. (Use a digital multimeter.)



▼ How to Check Outdoor Fan Motor



- (1) Turn off the power supply.
- (2) Remove fan motor leads from the fan P.C. board for the outdoor fan.
- (3) Rotate the fan by hand. If the fan does not turn, the fan motor is troubled (locked up). Replace the fan motor. If the fan turns, measure the phase-to-phase winding resistances using a multimeter. It is normal if the measurements are in the 9.3-11.5Ω range. (Use a digital multimeter.)



8-5. Diagnosis procedure for each check code























Check code	Check code name	Cause
[F03]	Indoor TC1 sensor trouble	TC1 sensor Open/Short-circuit

Is TC1 sensor connector (CN100: Brown) on indoor P.C. board normally connected?

No

Correct connection of connector.

Yes

Are characteristics of TC1 sensor resistance value normal?

No

Replace TC1 sensor.

Yes

Replace indoor main P.C. board.

*See "Indoor unit temperature sensor characteristics" on "8-10. Sensor Characteristics".

Check code	Check code name	Cause
[F04]	TD1 sensor trouble	TD1 sensor Open/Short-circuit

This check code means detection of Open/Short-circuit of TD1 sensor. Check disconnection of circuit for connection of connector (TD1 sensor: CN502, White) and characteristics of sensor resistance value. (See "Outdoor unit temperature sensor characteristics" on "8-10. Sensor Characteristics".)
If sensor is normal, replace outdoor I/F P.C. board.

Check code	Check code name	Cause
[F05]	TD2 sensor trouble	TD2 sensor Open/Short-circuit

This check code means detection of Open/Short-circuit of TD2 sensor. Check disconnection of circuit for connection of connector (TD2 sensor: CN380, Black) and characteristics of sensor resistance value. (See "Outdoor unit temperature sensor characteristics" on "8-10. Sensor Characteristics".)
If sensor is normal, replace outdoor I/F P.C. board.

Check code	Check code name	Cause
[F06]	TE1, TE2, TE3 sensor trouble	TE1, TE2, TE3 sensor Open/Short-circuit

This check code means detection of Open/Short-circuit of TE1, TE2 or TE3 sensor. Check disconnection of circuit for connection of connector (TE1 sensor: CN381, White, TE2 sensor: CN381, White, TE3 sensor: CN384, Blue) and characteristics of sensor resistance value. (See "Outdoor unit temperature sensor characteristics" on "8-10. Sensor Characteristics".)
If sensor is normal, replace outdoor I/F P.C. board.

Check code	Check code name	Cause
[F07]	TL1, TL2, TL3 sensor trouble	TL1, TL2, TL3 sensor Open/Short-circuit

Sub-code: 01: TL1, 02: TL2, 03: TL3

This check code means detection of Open/Short-circuit of TL1, TL2, TL3 sensor. Check disconnection of circuit for connection of connector (TL1, 2, 3: CN378 White) and characteristics of sensor resistance value. (See "Outdoor unit temperature sensor characteristics" on "8-10. Sensor Characteristics".)
If sensor is normal, replace outdoor I/F P.C. board.

Check code	Check code name	Cause
[F08]	TO sensor trouble	TO sensor Open/Short-circuit

This check code means detection of Open/Short-circuit of TO sensor. Check disconnection of circuit for connection of connector (TO sensor: CN507, Yellow) and characteristics of sensor resistance value. (See "Outdoor unit temperature sensor characteristics" on "8-10. Sensor Characteristics".)
If sensor is normal, replace outdoor I/F P.C. board.

Check code	Check code name	Cause
[F09]	TG1, TG2, TG3 sensor trouble	TG1, TG2, TG3 sensor Open/Short-circuit

Sub-code: 01: TG1, 02: TG2, 03: TG3

This check code means detection of Open/Short-circuit of TG1, TG2, TG3 sensor. Check disconnection of circuit for connection of connector (TG1, TG2 sensor: CN381, White, TG3 sensor: CN384, Blue) and characteristics of sensor resistance value. (See "Outdoor unit temperature sensor characteristics" on "8-10. Sensor Characteristics".)
If sensor is normal, replace outdoor I/F P.C. board.



Check code	Check code name	Cause
[F10]	Indoor TA/TSA sensor trouble	TA sensor Open/Short-circuit



This check code means detection of Open/Short-circuit of TA sensor. Check disconnection of circuit for connection of connector (TA/TSA sensor: CN104, Yellow) and characteristics of sensor resistance value. (See "Indoor unit temperature sensor characteristics" on "8-10. Sensor Characteristics".)
If sensor is normal, replace indoor P.C. board.



Check code	Check code name	Cause
[F12]	TS1, TS3 sensor trouble	1. TS1, TS3 sensor open/Short-circuit 2. 04: TS3 sensor disconnect


Sub-code: 01: TS1, 03: TS3, 04: TS3 sensor disconnect

This is detection of open/short-circuit and disconnection of TS3 sensor. Check installation of TS3, disconnection of circuit for connection of connector (TS1, TS3 sensor: CN378 White) and resistance characteristics of sensor. (See "Outdoor unit temperature sensor characteristics" on "8-10. Sensor Characteristics".)
If sensor is normal, replace outdoor I/F P.C. board.









In some cases, it may be difficult to check the leakage of clogging in the following condition of refrigerant stagnation in low ambient temperature condition.
In this case, take a longer operating time prior to check.
(Criterion: Discharge temperature of TD1 and TD2 are 60°C or higher)

(*1) Checking leakage and clogging on SV3F valve

a) Leakage check

- Turn off the power supply, take off connector of SV3F valve, and then start a test operation after power ON.
- After operation for several minutes, check temperature at secondary side of SV3F valve. ((1) in the figure) → If temperature is low, leakage occurs in the SV3F valve.
Replace SV3F valve.

b) Clogging check

- While outdoor unit is operating, set up SW01/02/03=[2] [1] [3] (7-segment display [Hr] [... ..]), and push SW04 for 2 seconds or more.
- Set up SW02=[8] and turn on SV3F valve. (7-segment display [Hr] [... 3C])
- While outdoor units are operating, check temperature change at secondary side of SV3F valve. ((1) in the figure.)
→ If temperature does not drop (equivalent to outside air temperature), it is a clogging of SV3F valve.
Replace SV3F valve.

(*2) Checking the oil return circuit from oil separator and clogging in SV3D valve

a) Oil return circuit

- While outdoor unit is operating, check temperature (secondary side of capillary) on oil return circuit. ((2) in the figure.)
→ If temperature is low equivalent to suction temperature), a clogging of strainer of oil return circuit or capillary is considered. Replace the clogged part.


b) Clogging check for SV3D valve

- While outdoor unit is operating, set up SW01/02/03 = [2] [1] [3] (7-segment display [Hr] [... ..]), and push SW04 for 1 seconds or more.
- Set up SW02 = [4], and turn on SV3D valve. (7-segment display [Hr] [... 3 d])
- If temperature is low at secondary side of the valve or it does not change, clogging of valve, capillary, or strainer is considered. ((3) in the figure.) Replace the clogged part.

(*3) Checking the oil equalization circuit

a) Clogging check for oil-equalization circuit

- Drive the outdoor unit. (Drive all compressors in the unit.)
- After driving for 10 minutes or more, check whether temperature of TK1, TK2 sensors and temperature of oil-equalization circuit capillary ((4) in the figure) has increased.
(Criterion)
TK1, TK2=TD1, TD2 temperature - Approx. 10 to 30°C
Oil-equalization capillary tubes should be higher sufficiently than outside air temperature and suction temperature.
- If temperature is low, clogging of capillary or strainer is considered. Repair the failure parts.




Check code	Check code name	Cause
[H08]	Oil level detective temperature sensor trouble	TK1 and TK2 sensor Open/Short-circuit

Sub-code:
01: TK1 sensor trouble 02: TK2 sensor trouble


The detected trouble is an oil level detective temperature sensor trouble. Check disconnection of the wiring and resistance value of the sensor.
If the sensors are normal, replace the outdoor I/F P.C. board.

Circuit	Connector
TK1	CN502 white
TK2	CN380 black


Check code	Check code name	Cause
[H15]	Outdoor discharge temperature sensor (TD2) misconnection	1. Coming-off of TD2 sensor 2. Misinstallation of TD2 sensor, miswiring, characteristics trouble of resistance value



Check code	Check code name	Cause
[H16]	Oil level detection circuit trouble TK1 temperature detective circuit trouble (Sub-code: 01)	1. Coming-off of TK1 sensor, miswiring, characteristics trouble of resistance value 2. Oil-equalization circuit trouble (Check valve, capillary clogging, strainer clogging) 3. Refrigerant stagnation in the compressor shell



Check code	Check code name	Cause
[H16]	Oil level detection circuit trouble TK2 temperature detective circuit trouble (Sub-code: 02)	1. Coming-off of TK2 sensor, miswiring, characteristics trouble of resistance value 2. Oil-equalization circuit trouble (Check valve, capillary clogging, strainer clogging) 3. Refrigerant stagnation in the compressor shell



Check code	Check code name	Cause
[H17]	Compressor trouble (step-out etc.)	The clause of [H01] is referred to.


Refer to the cause of [H01] for a diagnostic procedure.

Check code	Check code name	Cause
[L02]	Indoor / outdoor model mismatch	When the indoor unit that does not correspond is connected with the outdoor unit

Check code	Check code name	Cause
[L03]	Duplicated indoor header units	There are two or more indoor header units in a group during group control.

- 1) Check whether the connection on remote controllers (group and/or individual) has been changed since the group configuration and address checking on the remote controllers finished.
- 2) If the group configuration and address are normal when power has been turned on, the mode automatically shifts to address setup mode. For setting up addresses again, refer to "Address setup".

Check code	Check code name	Cause
[L04]	Duplicated setup of outdoor line address	Outdoor line addresses are duplicated.



Check code	Check code name	Cause
[L05]	Duplicated indoor units with priority (Displayed on indoor unit with priority)	Two or more prior indoor units exist.

This check code is displayed on the indoor unit set as a prior one when two or more prior indoor units are detected.

- Priority setup with two or more units is not available. As only one indoor unit with priority is valid, change the setup.


Check code	Check code name	Cause
[L06]	Duplicated indoor units with priority (Displayed on the indoor units other than ones with priority and on the outdoor unit)	Two or more indoor units with priority are duplicated.



Sub-code: amount of indoor units with priority



When priority is given to two or more indoor units, this check code is displayed on indoor units other than the units set as prior ones and the outdoor unit.



- As only one indoor unit with priority is valid, change the setup. Change the setup so that only one indoor unit has priority.


Check code	Check code name	Cause
[L07]	A group line exists in an individual indoor unit	A group line is connected to an individual indoor unit.













Check code	Check code name	Cause
[P07-1* , 2*]	Heat sink overheating trouble	1. Power voltage trouble 2. Heat sink installation trouble 3. Clogging at PMV2, 3 4. Compressor P.C. Board trouble



Sub-code:
00: Compressor temperature sensor trouble
1* : Compressor 1 TH sensor trouble
2* : Compressor 2 TH sensor trouble






Check code	Check code name	Cause
[P07-04]	Heat sink dewing trouble	1. Power voltage trouble 2. Refrigerant stagnation in accumulator 3. Refrigerant leakage 4. Outdoor fan system trouble 5. TL2 sensor trouble 6. TO sensor trouble 7. Interface P.C. Board trouble



Sub-code:
04: Heat sink dewing trouble




























8-6. 7-Segment Display Function

7-segment display on outdoor unit (interface P.C. board)

The interface control P.C. board features a 7-segment LED display designed to check operational status. Display items can be changed by changing the combination of the number settings of rotary switches provided on the P.C. board (SW01, SW02 and SW03).



Interface P.C. board



Checking Procedure to Be Followed in Event of Abnormal Shutdown

If the system is shut down due to a trouble in the outdoor unit, perform checks in the following steps:


1 Open the panel of the outdoor unit and inspection window of the electric parts box, and check the 7-segment display.

The check code is displayed in the 7-segment display.

Checking Procedure to be Followed in Event of Abnormal Shutdown

In the event of a system shutdown due to an abnormal state at the outdoor unit, perform checks in the following steps.

1. Open the panel of the outdoor unit and inspection window of the electric parts box, and check the 7-segment display.



2. Confirm the check code, and perform checking following the diagnostic procedure for that check code.
 3. In the event of the 7-segment display of the header unit being check code [E28. * *], there is an abnormality occurring at a follower unit. Push the push-switch SW04 of the header unit for several seconds. The outdoor fan will run only in the outdoor unit where the trouble has occurred, so open the panel of the unit where the fan is running, and confirm the check code of the 7-segment display.
 4. Perform checking following the diagnostic procedure for that check code.
- * To check the check code, set the rotary switches SW01/SW02/SW03 to [1/1/1].

2 Check the check code and follow the applicable diagnostic procedure.

3 If the 7-segment display shows [E28. _ _], there is a trouble in a follower unit.

Press the push-switch SW04 on the header unit and hold for several seconds.

As the fan of the outdoor unit in which the trouble has occurred comes on, open the panel of the unit, and check the check code shown on the 7-segment display.

4 Perform checks in accordance with the diagnostic procedure applicable to the check code.

(1) Display of System Information (Displayed on Header Outdoor Unit Only)

SW01	SW02	SW03	Display detail					
1	1	3	-		-			
	2		System capacity		A	[...8]~[120]:8 to 120 HP		
				B	[HP]			
	3		No. of outdoor units		A	[...1]~[...5]:1 to 5		
				B	[...P]			
	4		No. of indoor units connected / No. of units with cooling thermostat ON		(1) [... ... 0] ~ [... ... 128] : 0 ~ 128 (Number of connected units) (2) [C 0] ~ [C ... 128] : 0 ~ 128 (Number of cooling thermostat ON) *Switch the display of (1) and (2) with SW04			
	5		No. of indoor units connected / No. of units with heating thermostat ON		(1) [... ... 0] ~ [... ... 128] : 0 ~ 128 (Number of connected units) (2) [H 0] ~ [H ... 128] : 0 ~ 128 (Number of heating thermostat ON) *Switch the display of (1) and (2) with SW04			
	6		Amount of compressor command correction		A	Value displayed in hexadecimal format		
				B				
	7		Release control		A	Normal: [r. ...], During release control: [r.1]		
				B	-			
	8		Oil equalization control		Normal: [oiL-0]			
				During oil equalization control: [oiL-1]				
	9		-		-			
	10		Refrigerant/oil recovery operation		A	Oil recovery in cooling: [C1], Normal: [C ...]		
				B	Refrigerant recovery in heating: [H1], Normal: [H ...]			
	11		Automatic addressing		A	[Ad]		
				B	During automatic addressing: [... FF], Normal: [... ...]			
	12		Power peak-cut		A	[dU]		
				Normal: [... ...], During 50-90% capacity operation: [_50_90] While control is based on BUS line input: [E50-E90]				
	13		Optional control (P.C. board input)		Displays optional control status		A	B
					Operation mode selection: During priority heating (normal)		h.*	***.
		Priority cooling			c.*	***.		
		Heating only			H.*	***.		
		Cooling only			C.*	***.		
		Priority given to No. of indoor units in operation			n.*	***.		
		Priority given to specific indoor unit			U.*	***.		
		External master ON/OFF: Normal			*....	***.		
Start input		*.1.			***.			
Stop input		*.0.			***.			
Night operation: Normal		**.			...*.			
Start input		*.*			1.*.			
Snowfall operation: Normal		*.*			*....			
Start input		*.*			*.1.*			
14	Optional control (BUS line input)		Same as above					
15	-		-					
16	-		A	-				
			B	-				
	15	No. of HWM (Hot water module) recorded on the I/F P.C.board		A	[ho]			
		B	[...0] to [...2] = 0 to 2					

(2) Display of Outdoor Unit Information (Displayed on Each Outdoor Unit)

SW01	SW02	SW03	Display detail				
1	1		Check code data	A	Outdoor unit No.: [U1] to [U5]		
			B	If there is no check code, [U. *. - - -] is displayed. If there is check code, [U. *. err] ⇔ [000]. [△△] ([000] : Check code, [△△] : Sub-code) (The display switches alternately) (*: Outdoor unit No.)			
			<SW04> push SW function: Fan operation at outdoor unit with trouble. 7-segment display section A: [E.1] <SW04 + SW05> push SW function: Fan operation at outdoor unit without trouble. 7-segment display section A: [E.0] <SW05> push SW function: Fan operation function check mode is cancelled.				
	2	-	A	-			
			B	-			
	3	Operation mode	A	Stop [... ...] Normal cooling: [... C], Normal heating: [... H], Normal defrosting: [... J]			
			B	-			
	4	Outdoor unit HP capacity	A	8HP: [... 8], 10HP: [... 10], 12HP: [... 12], 14HP: [14], 16HP: [16], 18HP: [18], 20HP: [20], 22HP: [22], 24HP: [24]			
			B	[...HP]			
	5		Compressor operation command*Operation data of each compressor is displayed in turn in 2 second intervals.				
			Normal: Compressor speed (rps) is displayed in decimal format. 7-segment display (A/B): [C1.] ⇒ [... **, *] ⇒ [C2.] ⇒ [... **, *]				
			<SW04> push SW function: Switches to display of operating current (decimal value). 7-segment display (A/B): [i1.] ⇒ [...****] ⇒ [i2.] ⇒ [...****] Pressing of <SW05> restores normal display.				
	6	Outdoor fan mode	A	[FP]			
			B	Mode 0 to 63: [... 0] to [63]			
	7	Compressor backup	A	[C.b.]			
			B	Displays compressor backup setting status Normal: [... ..] Compressor No. 1 backup: [1] Compressor No. 2 backup: [... 1 ...]			
	8	-	A	-			
			B	-			
	9	Control valve output data	Displays control output status of solenoid valve		A	B	
	4-way valve: ON				H. 1	
	4-way valve: OFF				H. 0	
	-				-	-	
	SV3D: ON / SV3F: OFF				3. ...	1 0 ...	
	SV3D: OFF / SV3F: ON				3. ...	0 1 ...	
SV41: ON / SV42: OFF			4. ...	1 0 ...			
11	SV41: OFF / SV42: ON			4. ...	0 1 ...		
12							
13							
14	PMV1//PMV2PMV3 opening	Displays opening data in decimal format.		PMV1	* *	* *.P	
"Switch display of PMV1, PMV2, and PMV3 by pressing <SW04>"		PMV2	... *	* *.P			
		PMV3	... *	* *.P			
15	PMV4 opening	Displays opening data in decimal format.		PMV4	... *	* *.P	
16	Oil level judgment status						
	Normal	A	[o L.]				
		B	Initial display: [... ..], Oil level judgment result: [#.*.\$] Displayed letters #, * and \$ represent judgment results for compressor Nos. 1 and 2, respectively ("0" for normal and "1" or "2" for low level).				
	<SW04> push SW function: Displays low level confirmed judgment result of each compressor.						
	*Pressing of <SW05> restores normal display.	A	[L d.]				
		B	Compressor No. 1 low level being confirmed: [L] Compressor No. 2 low level being confirmed: [... L ...]				
	<SW15> push SW function : for 2 seconds, change display to low level judgement timer						
	*Pressing of <SW05> restores normal display	A	[T ...,]				
B		Low level judgment timer : [120] (i.e. : 120 minutes)					

(3) Display of Outdoor Cycle Data (Displayed at Each Outdoor Unit)

SW01	SW02	SW03	Display detail				
1	1	2	Pd pressure data	Pd pressure (MPaG) is displayed in decimal format. (MPaG: Approx. 10 times magnitude of kg/cm ² G)	A	B	
	2		Ps pressure data	Ps pressure (MPaG) is displayed in decimal format.	P d.	*. **	
	3		PL pressure conversion data	Converted PL pressure (MPaG) is displayed in decimal format.	P s.	*. **	
	4		TD1 sensor data	Temperature sensor reading (°C) is displayed in decimal format.	P L.	*. **	
	5		TD2 sensor data	<ul style="list-style-type: none"> • Letter symbol and data are displayed alternately, for 1 second and display for 3 seconds, respectively. • Data is displayed in [*]. • Data with negative value is displayed as [- *]. 	Letter symbol	t d	1
	7		TS1 sensor data		Data	*	*. **
	9		TS3 sensor data		Letter symbol	t d	2
	10		TE1 sensor data		Data	*	*. **
	11		TE2 sensor data		Letter symbol	t S	1
	12		TE3 sensor data		Data	*	*. **
	13		TL1 sensor data		Letter symbol	t S	3
	14		TL2 sensor data		Data	*	*. **
	15		TL3 sensor data		Letter symbol	t E	1
	16		TO sensor data		Data	*	*. **
					Letter symbol	t E	2
					Data	*	*. **
					Letter symbol	t E	3
					Data	*	*. **
					Letter symbol	t L	1
					Data	*	*. **
					Letter symbol	t L	2
					Data	*	*. **
					Letter symbol	t L	3
					Data	*	*. **
					Letter symbol	t o
					Data	*	*. **

SW01	SW02	SW03	Display detail				
1	1	5	TK1 sensor data	Temperature sensor reading (°C) is displayed in decimal format.	Letter symbol	F 1
	2		TK2 sensor data		Data	*	*. **
	6		TG1 sensor data		Letter symbol	F 2
	7		TG2 sensor data		Data	*	*. **
	8		TG3 sensor data		Letter symbol	t G	1
	9		Predicted TK1 (TK1_Pre data)		Data	*	*. **
	10		Predicted TK2 (TK2_Pre data)		Letter symbol	t G	2
					Data	*	*. **
					Letter symbol	tG	3
					Data	*	*. **
					Letter symbol	F1	PrE
					Data	*	*. **
					Letter symbol	F2	PrE
					Data	*	*. **

(4) Display of Outdoor Cycle Data (Displayed at Header Unit)

* This method is used when displaying follower unit information on the 7-segment display of the header unit.

SW01	SW02	SW03	Display detail				
3	1	1~4	Trouble data	A	[U.*], *SW03 setting No. + 1 (Outdoor unit No. U2 to U5)		
				B	Check code is displayed (latest one only). If there is no check code: [— —].		
	2		—	A	—		
				B	—		
	3		Outdoor unit HP capacity	A	[U.*], *SW03 setting No. + 1 (Outdoor unit No. U2 to U5)		
				B	8HP: [... 8], 10HP: [... 10], 12HP: [... 12], 14HP: [14], 16HP: [16], 18HP: [18], 20HP: [20], 22HP: [22], 24HP: [24]		
	4		Compressor operation command	A	[U.*], *SW03 setting No. + 1 (Outdoor unit No. U2 to U5)		
				B	Indicates which compressor is ON.		
					* Any unconnected compressors is represented by “—”.		B
					When compressor No. 1 is ON	1 0	
			When compressor No. 2 is ON	0 1			
	5		Fan operation mode	A	[U.*], *SW03 setting No. + 1 (Outdoor unit No. U2 to U5)		
				B	At rest: [F ... 0], In mode 63: [F 6 3]		
	6		Release signal	A	[U.*], *SW03 setting No. + 1 (Outdoor unit No. U2 to U5)		
				B	Normal: [r], Upon receiving release signal: [r ... 1]		
	7		Oil level judgment	A	[U.*], *SW03 setting No. + 1 (Outdoor unit No. U2 to U5)		
				B	Normal: [...], Low level: [... ... L]		
	8		Compressor 1 operating current	A	[U.*], *SW03 setting No. + 1 (Outdoor unit No. U2 to U5)		
B		[**.*], *.* is value of operating current in decimal format.					
9	Compressor 2 operating current	A	[U.*], *SW03 setting No. + 1 (Outdoor unit No. U2 to U5)				
		B	[**.*], *.* is value of operating current in decimal format.				

Note: Follower unit is selected by setting SW03.

SW03	7-segment display section A
1	U2
2	U3
3	U4
4	U5

(5) Display of Indoor Unit Information (Displayed on Header Unit Only)

SW01	SW02	SW03	Display detail				
4	1~16	1~8	Indoor check code	B	No check code : [- - -]		
			Indoor BUS communication signal receiving status	B	Upon receiving signal : [... ... 1], Other times : [..... ...]		
Indoor HP capacity			B	... 0.3, ...0.4, ...0.5, ...0.6 ... 0.8, ...1.0, ...1.2, ...1.7, ...2.0 ... 2.5, ...3.0, ...3.2, ...4.0, ...5.0 ... 6.0, ...8.0, ...10.0, ...16.0, ...20.0			
Indoor request command (S code, operation mode)			B	[#.... *] # represents mode : COOL : [C. ... *], HEAT : [H ... F] FAN : [F. ... *], OFF : [S ... *] * represents S code : [#.. ... 0] to [#.. ... F]			
6			Indoor PMV opening data	B	Displayed in decimal format		
7			Indoor temperature sensor data1	B	Switch temperature display of TA, TCJ, TC1 and TC2 with SW06		
8			Indoor temperature sensor data2	B	Switch temperature display of TF, TA2 and TA3 with SW06		
9			1	1	Outdoor DN code setting		Outdoor DN code setting

Note: Indoor address No. is selected by setting SW02 and SW03 and displayed on 7-segment display, section A.

SW02	SW03	Indoor address	7-segment display section A
1 ~ 16	1	SW02 setting number	[01] ~ [16]
1 ~ 16	2	SW02 setting number +16	[17] ~ [32]
1 ~ 16	3	SW02 setting number +32	[33] ~ [48]
1 ~ 16	4	SW02 setting number +48	[49] ~ [64]
1 ~ 16	5	SW02 setting number +64	[65] ~ [80]
1 ~ 16	6	SW02 setting number +80	[81] ~ [96]
1 ~ 16	7	SW02 setting number +96	[97] ~ [112]
1 ~ 16	8	SW02 setting number +112	[113] ~ [128]

(6) Display of Outdoor EEPROM Writing Check Code (Displayed on Header Unit Only)


* The latest check code written in the EEPROM of each outdoor unit is displayed.

(This function is used to check the trouble code after the resetting of the power supply.)

To display the check code, push SW04 and hold for at least 5 seconds after setting SW01 to 03 as shown in the table below.

SW01	SW02	SW03	Indoor address	7-segment display section A	
1	1	16	Latest check code of header unit (U1)	E. 1.	***
	2		Latest check code of follower unit No. 1 (U2)	E. 2.	***
	3		Latest check code of follower unit No. 2 (U3)	E. 3.	***
	4		Latest check code of follower unit No. 3 (U4)	E. 4.	***
	5		Latest check code of follower unit No. 4 (U5)	E. 5.	***

• 7-Segment Display



Set SW01/SW02/SW03 to [1/1/16] and push SW04 and hold for at least 5 seconds. The latest check code of the header unit (U1) will be displayed.


If the setting of SW02 is changed, the latest check code of a follow unit (U2-U5) will be displayed.

8-7. Oil Level Judgment Display

The current compressor oil level judgment results can be accessed by setting the switches provided on the interface P.C. board of an outdoor unit.
Perform the checks in accordance with the procedure described below.

1 Operation Procedure

- (1) Start the operation.
- (2) Set the switches provided on the interface P.C. board of the outdoor unit for which oil level judgment results are required as follows: SW01/SW02/SW03 = 1/16/1
- (3) The oil level judgment result will be displayed on the 7-segment display. 7-segment display: [oL] [# * ...]
The letters #, and * are digits that represent judgment results for compressor Nos. 1 and 2, respectively.
(See the table below for the interpretation of the judgment results.)
- (4) When checking is completed, revert the SW01/SW02/SW03 setting to [1/1/1].



2 Oil Level Judgment Results

Displayed digit	Judgment result	Description
0	Normal	The amount of oil in the compressor is sufficient.
1	Low level	The amount of oil in the compressor is insufficient. (Both “1” and “2” stand for insufficiency.) If this result persists, the system will turn itself off in a protective shutdown.
2		

Display example

7-segment display [oL] [0 0 ...] Oil level is normal for compressors 1 and 2.
[oL] [2 2 ...] Oil level is low for compressors 1 and 2.
[oL] [0 2 ...] Oil level is low for compressor 2 and normal for compressors 1.


— Judgment result for compressor 2
— Judgment result for compressor 1

8-8. SMMS-u Outdoor Interface P.C. Board Function Setting Change Table

1. Switch/Function Setting Change

SW No.		Change contents	
SW100	DIP SW 2 bit	bit1 Uh communication termination resistance for central control	OFF: No termination resistance ON: With termination resistance
		bit2 Uv communication termination resistance between indoor and outdoor units	OFF: No termination resistance ON: With termination resistance
SW101	DIP SW 4 bit	bit1 Setup of header outdoor unit	OFF: Follower outdoor unit ON: Header outdoor unit
		bit2	* Used by combining with SW102 (4 bit)
		bit3 Line address setup	
		bit4	
SW102	DIP SW 4 bit	bit1	* Used by combining with SW101 (3 bit)
		bit2	
		bit3	
		bit4	
SW103	DIP SW 4 bit	bit1 Compressor 1 backup	OFF: Normal ON: Compressor 1 Backup when compressor 1 was in trouble
		bit2 Compressor 2 backup	OFF: Normal ON: Compressor 2 Backup when compressor 2 was in trouble
	* All bit1 and 2 are ON : Setup of outdoor unit backup		
	■ In case of header outdoor unit		
		Bit3 Trouble judgment for over-capacity of indoor unit connection	OFF: Trouble judgement (Normal) ON: None (When outdoor unit backup set)
		bit4 Trouble judgment for No. of connected indoor units	OFF: None ON: Trouble judgement
SW104	DIP SW 4 bit	bit1	
		bit2	
		bit3	
		bit4	
SW105	DIP SW 4 bit	bit1 Corresponds to 2-core wire	OFF: Normal (3-core wire <Successive MAKE signal> or 4-core wire <Pulse signal>) ON: 2-core wire <Successive MAKE signal : Use only ON input terminal>
		bit2 Demand control (Expansion change)	OFF: Normal demand (1 type) ON: Intermediate demand (3 types)
		bit3	
		bit4	
SW106	DIP SW 4 bit	bit1 Change of EEPROM data backup function	OFF: Normal ON: No data backup
		bit2 Communication setup reset	OFF: Normal ON: Reset of communication setup and communication termination resistance between indoor units

Interface Board Switches and jumper wire positions to be used in the Function setup switching table



8-9. Leakage/Clogging of Refrigerating Cycle Circuit

List of Check Codes Generated upon Occurrence of Leakage/Clogging in Outdoor Cycle or Oil Circuit Part

(MMY-MUP0801*, 1001*, 1201*, 1401*)


Clogging

Part	Location of Problem (Refer to next page)	Unit generating check code	Detected problem and check code	Symptom
Outdoor PMV1, 2	A	Corresponding unit	Activation of high-pressure protection Activation of low-pressure protection Discharge temp. trouble (TD1)	P20 H06 P03 Rise of pressure Fall of pressure Rise of discharge temp. (Compressor 1)
Outdoor PMV4	B	Corresponding unit	Discharge temp. trouble (TD1)	P03 Rise of discharge temp. (Compressor 1)
Check valve in discharge pipe convergent section	C	Corresponding unit	High-pressure protection trouble High-pressure SW system trouble	P20 P04-01 Abnormal rise of pressure
Oil-equalization circuit Capillary or Strainer	E	Corresponding unit	Oil level detection circuit trouble Oil level low detection and protection	H16-01 H07 Oil circuit trouble or Oil level low
SV3D valve	F	Corresponding unit	Oil level low detection and protection	H07 Oil level low
SV3D valve circuit Capillary or Strainer	G	Corresponding unit	Oil level low detection and protection	H07 Oil level low
SV3F valve or SV3F valve circuit Strainer	H	Corresponding unit	Oil level low detection and protection	H07 Oil level low
SV41 valve	I	Corresponding unit	High-pressure protection trouble	P20 Rise of pressure
Inverter heat sink	J	Corresponding unit	Heat sink overheating trouble	P07-01 Rise of IPM (TH) temp. (Compressor 1)

Leakage

Part	Location of Problem (Refer to next page)	Unit generating check code	Detected problem and check code	Symptom
Outdoor PMV1, 2	A	Corresponding unit	Outdoor liquid backflow trouble Oil level low detection and protection	P13 H07 Refrigerant entrapment
		Other connected unit	Discharge temp. trouble (TD1)	P03 Rise of discharge temp. (Compressor 1)
Outdoor PMV4	B	Corresponding unit	Outdoor liquid backflow trouble Oil level low detection and protection	P13 H07 Oil level low
Check valve in discharge pipe convergent section	C	Corresponding unit	Oil level low detection and protection Compressor breakdown Compressor trouble (lockup)	H07 H01-01 H02-01 Refrigerant entrapment
SV41 valve	I	Corresponding unit	Discharge temp. trouble (TD1)	P03 Rise of discharge temp. (Compressor 1)
4-way valve	K	Corresponding unit	4-way valve reversing trouble Gas leak detection	P19 P15 Incorrect internal position of 4-way valve

Outdoor Unit (8, 10, 12, 14HP)
Model: MMY-MUP0801*, 1001*, 1201*, 1401*



Symbol						
Solenoid valve	Capillary tube	Check valve	Check joint	Strainer	Temperature sensor	Distributor

List of Check Codes Generated upon Occurrence of Leakage/Clogging in Outdoor Cycle or Oil Circuit Part
(MMY-MUP14A1*, 1601*, 1801*, 2001*)


Clogging

Part	Location of Problem (Refer to next page)	Unit generating check code	Detected problem and check code		Symptom
Outdoor PMV1, 2, 3	A	Corresponding unit	Activation of high-pressure protection Activation of low-pressure protection Discharge temp. trouble (TD1)	P20 H06 P03	Rise of pressure Fall of pressure Rise of discharge temp. (Compressor 1)
Outdoor PMV4	B	Corresponding unit	Discharge temp. trouble (TD1)	P03	Rise of discharge temp. (Compressor 1)
Check valve in discharge pipe convergent section	C	Corresponding unit	High-pressure protection trouble High-pressure SW system trouble	P20 P04-01	Abnormal rise of pressure
Oil-equalization circuit Capillary or Strainer	E	Corresponding unit	Oil level detection circuit trouble Oil level low detection and protection	H16-01 H07	Oil circuit trouble or Oil level low
SV3D valve	F	Corresponding unit	Oil level low detection and protection	H07	Oil level low
SV3D valve circuit Capillary or Strainer	G	Corresponding unit	Oil level low detection and protection	H07	Oil level low
SV3F valve or SV3F valve circuit Strainer	H	Corresponding unit	Oil level low detection and protection	H07	Oil level low
SV41 valve	I	Corresponding unit	High-pressure protection trouble	P20	Rise of pressure
Inverter heat sink	J	Corresponding unit	Heat sink overheating trouble	P07-01	Rise of IPM (TH) temp. (Compressor 1)

Leakage

Part	Location of Problem (Refer to next page)	Unit generating check code	Detected problem and check code		Symptom
Outdoor PMV1, 2	A	Corresponding unit	Outdoor liquid backflow trouble Oil level low detection and protection	P13 H07	Refrigerant entrapment
		Other connected unit	Discharge temp. trouble (TD1)	P03	Rise of discharge temp. (Compressor 1)
Outdoor PMV4	B	Corresponding unit	Outdoor liquid backflow trouble Oil level low detection and protection	P13 H07	Oil level low
Check valve in discharge pipe convergent section	C	Corresponding unit	Oil level low detection and protection Compressor breakdown Compressor trouble (lockup)	H07 H01-01 H02-01	Refrigerant entrapment
SV41 valve	I	Corresponding unit	Discharge temp. trouble (TD1)	P03	Rise of discharge temp. (Compressor 1)
4-way valve	K	Corresponding unit	4-way valve reversing trouble Gas leak detection	P19 P15	Incorrect internal position of 4-way valve

Outdoor Unit (14A, 16, 18, 20HP)
Model: MMY-MUP14A1*, 1601*, 1801*, 2001*



List of Check Codes Generated upon Occurrence of Leakage/Clogging in Outdoor Cycle or Oil Circuit Part
(MMY-MUP2201*, 2401*)


Clogging

Part	Location of Problem (Refer to next page)	Unit generating check code	Detected problem and check code		Symptom
Outdoor PMV1, 2, 3	A	Corresponding unit	Activation of high-pressure protection Activation of low-pressure protection Discharge temp. trouble (TD1)	P20 H06 P03	Rise of pressure Fall of pressure Rise of discharge temp. (Compressor 1) Rise of discharge temp. (Compressor 2)
			Discharge temp. trouble (TD2)	P17	
Outdoor PMV4	B	Corresponding unit	Discharge temp. trouble (TD1)	P03	Rise of discharge temp. (Compressor 1)
			Discharge temp. trouble (TD2)	P17	Rise of discharge temp. (Compressor 2)
Check valve in discharge pipe convergent section	C	Corresponding unit	High-pressure protection trouble High-pressure SW system trouble	P20 P04-XX	Abnormal rise of pressure
Check valve in discharge pipe	D	Corresponding unit	High-pressure SW system trouble	P04-XX	Abnormal rise of pressure
Oil-equalization circuit Capillary or Strainer	E	Corresponding unit	Oil level detection circuit trouble Oil level low detection and protection	H16-XX H07	Oil circuit trouble or Oil level low
SV3D valve or SV3F valve circuit Strainer	F	Corresponding unit	Oil level low detection and protection	H07	Oil level low
SV3D valve circuit Capillary or Strainer	G	Corresponding unit	Oil level low detection and protection	H07	Oil level low
SV3F valve or SV3F valve circuit Strainer	H	Corresponding unit	Oil level low detection and protection	H07	Oil level low
SV41, 42 valve	I	Corresponding unit	High-pressure protection trouble	P20	Rise of pressure
Inverter heat sink	J	Corresponding unit	Heat sink overheating trouble	P07-XX	Rise of IPM (TH) temp.
Oil-Return circuit Capillary or Strainer	L	Other connected unit	Outdoor liquid back flow trouble	P13	Oil level low

Leakage

Part	Location of Problem (Refer to next page)	Unit generating check code	Detected problem and check code		Symptom
Outdoor PMV1, 2	A	Corresponding unit	Outdoor liquid backflow trouble Oil level low detection and protection	P13 H07	Refrigerant entrapment
		Other connected unit	Discharge temp. trouble (TD1)	P03	Rise of discharge temp. (Compressor 1)
			Discharge temp. trouble (TD2)	P17	Rise of discharge temp. (Compressor 2)
Outdoor PMV4	B	Corresponding unit	Outdoor liquid backflow trouble Oil level low detection and protection	P13 H07	Oil level low
Check valve in discharge pipe convergent section	C	Corresponding unit	Oil level low detection and protection Compressor breakdown Compressor trouble (lockup)	H07 H01-XX H02-XX	Refrigerant entrapment
Check valve in discharge pipe	D	Corresponding unit	Oil level low detection and protection Compressor breakdown Compressor trouble (lockup)	H07 H01-XX H02-XX	Refrigerant entrapment
SV41, 42 valve	I	Corresponding unit	Discharge temp. trouble (TD1)	P03	Rise of discharge temp. (Compressor 1)
			Discharge temp. trouble (TD2)	P17	Rise of discharge temp. (Compressor 2)
4-way valve	K	Corresponding unit	4-way valve reversing trouble Gas leak detection	P19 P15	Incorrect internal position of 4-way valve

Outdoor Unit (22, 24HP)
Model: MMY-MUP2201*, 2401*




8-10. Sensor Characteristics

Outdoor Unit


▼ Temperature sensor characteristics

Outdoor TS1, TS3, TE1, TE2, TE3, TL1, TL2, TL3 and TO sensors




Temperature [°C]	Resistance [kΩ]
-20	101.7
-15	76.3
-10	57.7
-5	44.0
0	33.8
5	26.1
10	20.4
15	16.0
20	13.0
25	10.0
30	8.0
35	6.4
40	5.2
45	4.2
50	3.5
55	2.8
60	2.3
65	1.9
70	1.6
75	1.4
80	1.1

Outdoor TD1, TD2, TK1 and TK2 sensors



Temperature [°C]	Resistance [kΩ]
0	162.2
5	125.8
10	98.3
15	77.5
20	61.5
25	49.1
30	39.5
35	32.0
40	26.1
45	21.4
50	17.6
55	14.6
60	12.1
65	10.2
70	8.5
75	7.2
80	6.1
85	5.2
90	4.5
95	3.8
100	3.3
105	2.9
110	2.5
115	2.2
120	1.9

Outdoor TG1, TG2 and TG3 sensors



Temperature [°C]	Resistance [kΩ]
-20	98.9
-15	74.1
-10	56.1
-5	42.8
0	33.0
5	25.6
10	20.0
15	15.8
20	12.5
25	10.0
30	8.0
35	6.5
40	5.3
45	4.4
50	3.6
55	3.0
60	2.5
65	2.1
70	1.7
75	1.5
80	1.3

Outdoor Unit



▼ Pressure sensor characteristics

- Input/output wiring summary

Pin No.	High pressure side (PD)		Low pressure side (PS)	
	Input/output name	Lead wire color	Input/output name	Lead wire color
1	OUTPUT	White	—	—
2	—	—	OUTPUT	White
3	GND	Black	GND	Black
4	+5V	Red	+5V	Red

- Output voltage vs. pressure


High pressure side (PD)	Low pressure side (PS)
0.5~4.5V 0~3.92MPa	0.5~4.5V 0~2.0MPa



Indoor Unit


▼ Temperature sensor characteristics

Indoor TA(TSA), TRA,TF(TFA) sensor




Temperature [°C]	Resistance [kΩ]
0	33.8
5	26.1
10	20.4
15	16.0
20	12.6
25	10.0
30	8.0
35	6.4
40	5.2
45	4.2
50	3.5
55	2.8
60	2.3

Indoor TC1 sensor



Temperature [°C]	Resistance [kΩ]
-20	98.3
-15	73.7
-10	55.8
-5	42.6
0	32.8
5	25.5
10	20.0
15	15.7
20	12.5
25	10.0
30	8.1
35	6.5
40	5.3
45	4.4
50	3.6
55	3.0
60	2.5
65	2.1
70	1.7
75	1.5
80	1.2
85	1.1
90	0.9
95	0.8
100	0.7

Indoor TC2 and TCJ, TOA sensor



Temperature [°C]	Resistance [kΩ]
-20	102.9
-15	76.6
-10	57.7
-5	44.0
0	38.8
5	26.1
10	20.4
15	16.0
20	12.6
25	10.0
30	8.0
35	6.4
40	5.2
45	4.2
50	3.5
55	2.8
60	2.3
65	1.9
70	1.6
75	1.4
80	1.2

8-11. Pressure Sensor Output Check

Outdoor Unit

▼ Pd sensor characteristics

0 to 4.15 MPa (0.5 to 4.73V output for 0 to 4.15 MPa)

Voltage readings across pins 2 and 3 of CN501 on indoor unit main P.C. board (with negative-side probe of multimeter placed on pin 3)

VOLT	Pd (MPa)	Pd (kg/cm ²)	VOLT	Pd (MPa)	Pd (kg/cm ²)	VOLT	Pd (MPa)	Pd (kg/cm ²)	VOLT	Pd (MPa)	Pd (kg/cm ²)	VOLT	Pd (MPa)	Pd (kg/cm ²)
0.00	0.00	0.0	1.00	0.49	5.0	1.99	1.46	14.9	2.99	2.44	24.9	3.98	3.42	34.8
0.02	0.00	0.0	1.02	0.51	5.2	2.01	1.48	15.1	3.01	2.46	25.1	4.00	3.44	35.0
0.04	0.00	0.0	1.04	0.53	5.4	2.03	1.50	15.3	3.03	2.48	25.3	4.02	3.45	35.2
0.06	0.00	0.0	1.06	0.54	5.5	2.05	1.52	15.5	3.05	2.50	25.5	4.04	3.48	35.4
0.08	0.00	0.0	1.07	0.56	5.7	2.07	1.54	15.7	3.07	2.52	25.7	4.06	3.49	35.6
0.10	0.00	0.0	1.09	0.58	5.9	2.09	1.56	15.9	3.09	2.54	25.9	4.08	3.51	35.8
0.12	0.00	0.0	1.11	0.60	6.1	2.11	1.58	16.1	3.11	2.56	26.1	4.10	3.53	36.0
0.14	0.00	0.0	1.13	0.62	6.3	2.13	1.60	16.3	3.13	2.57	26.3	4.12	3.55	36.2
0.16	0.00	0.0	1.15	0.64	6.5	2.15	1.62	16.5	3.15	2.59	26.4	4.14	3.57	36.4
0.18	0.00	0.0	1.17	0.66	6.7	2.17	1.64	16.7	3.16	2.61	26.6	4.16	3.59	36.6
0.20	0.00	0.0	1.19	0.68	6.9	2.19	1.66	16.9	3.18	2.63	26.8	4.18	3.61	36.8
0.22	0.00	0.0	1.21	0.70	7.1	2.21	1.67	17.1	3.20	2.65	27.0	4.20	3.63	37.0
0.23	0.00	0.0	1.23	0.72	7.3	2.23	1.69	17.3	3.22	2.67	27.2	4.22	3.65	37.2
0.25	0.00	0.0	1.25	0.74	7.5	2.25	1.71	17.5	3.24	2.69	27.4	4.24	3.67	37.4
0.27	0.00	0.0	1.27	0.76	7.7	2.27	1.73	17.7	3.26	2.71	27.6	4.26	3.69	37.6
0.29	0.00	0.0	1.29	0.77	7.9	2.29	1.75	17.9	3.28	2.73	27.8	4.28	3.70	37.8
0.31	0.00	0.0	1.31	0.79	8.1	2.31	1.77	18.0	3.30	2.75	28.0	4.30	3.72	38.0
0.33	0.00	0.0	1.33	0.81	8.3	2.32	1.79	18.2	3.32	2.77	28.2	4.32	3.74	38.2
0.35	0.00	0.0	1.35	0.83	8.5	2.34	1.81	18.4	3.34	2.79	28.4	4.34	3.76	38.4
0.37	0.00	0.0	1.37	0.85	8.7	2.36	1.83	18.6	3.36	2.80	28.6	4.36	3.78	38.6
0.39	0.00	0.0	1.39	0.87	8.9	2.38	1.85	18.8	3.38	2.82	28.8	4.38	3.80	38.8
0.41	0.00	0.0	1.41	0.89	9.1	2.40	1.87	19.0	3.40	2.84	29.0	4.40	3.82	38.9
0.43	0.00	0.0	1.43	0.91	9.3	2.42	1.89	19.2	3.42	2.86	29.2	4.41	3.84	39.1
0.45	0.00	0.0	1.45	0.93	9.5	2.44	1.90	19.4	3.44	2.88	29.4	4.43	3.86	39.3
0.47	0.00	0.0	1.47	0.95	9.6	2.46	1.92	19.6	3.46	2.90	29.6	4.45	3.88	39.5
0.49	0.00	0.0	1.48	0.97	9.8	2.48	1.94	19.8	3.48	2.92	29.8	4.47	3.90	39.7
0.51	0.01	0.1	1.50	0.99	10.0	2.50	1.96	20.0	3.50	2.94	30.0	4.49	3.92	39.9
0.53	0.03	0.3	1.52	1.00	10.2	2.52	1.98	20.2	3.52	2.96	30.2	4.51	3.93	40.1
0.55	0.05	0.5	1.54	1.02	10.4	2.54	2.00	20.4	3.54	2.98	30.4	4.53	3.95	40.3
0.57	0.07	0.7	1.56	1.04	10.6	2.56	2.02	20.6	3.56	3.00	30.5	4.55	3.97	40.5
0.59	0.08	0.9	1.58	1.06	10.8	2.58	2.04	20.8	3.57	3.02	30.7	4.57	3.99	40.7
0.61	0.10	1.1	1.60	1.08	11.0	2.60	2.06	21.0	3.59	3.03	30.9	4.59	4.01	40.9
0.63	0.12	1.3	1.62	1.10	11.2	2.62	2.08	21.2	3.61	3.05	31.1	4.61	4.03	41.1
0.65	0.14	1.4	1.64	1.12	11.4	2.64	2.10	21.4	3.63	3.07	31.3	4.63	4.05	41.3
0.66	0.16	1.6	1.66	1.14	11.6	2.66	2.12	21.6	3.65	3.09	31.5	4.65	4.07	41.5
0.68	0.18	1.8	1.68	1.16	11.8	2.68	2.13	21.8	3.67	3.11	31.7	4.67	4.09	41.7
0.70	0.20	2.0	1.70	1.18	12.0	2.70	2.15	22.0	3.69	3.13	31.9	4.69	4.11	41.9
0.72	0.22	2.2	1.72	1.20	12.2	2.72	2.17	22.2	3.71	3.15	32.1	4.71	4.13	42.1
0.74	0.24	2.4	1.74	1.21	12.4	2.73	2.19	22.3	3.73	3.17	32.3	4.73	4.15	42.3
0.76	0.26	2.6	1.76	1.23	12.6	2.75	2.21	22.5	3.75	3.19	32.5			
0.78	0.28	2.8	1.78	1.25	12.8	2.77	2.23	22.7	3.77	3.21	32.7			
0.80	0.30	3.0	1.80	1.27	13.0	2.79	2.25	22.9	3.79	3.23	32.9			
0.82	0.31	3.2	1.82	1.29	13.2	2.81	2.27	23.1	3.81	3.25	33.1			
0.84	0.33	3.4	1.84	1.31	13.4	2.83	2.29	23.3	3.83	3.26	33.3			
0.86	0.35	3.6	1.86	1.33	13.6	2.85	2.31	23.5	3.85	3.28	33.5			
0.88	0.37	3.8	1.88	1.35	13.8	2.87	2.33	23.7	3.89	3.30	33.7			
0.90	0.39	4.0	1.90	1.37	13.9	2.89	2.35	23.9	3.89	3.32	33.9			
0.92	0.41	4.2	1.91	1.39	14.1	2.91	2.36	24.1	3.91	3.34	34.1			
0.94	0.43	4.4	1.93	1.41	14.3	2.93	2.38	24.3	3.93	3.36	34.3			
0.96	0.45	4.6	1.95	1.43	14.5	2.95	2.40	24.5	3.95	3.38	34.5			
0.98	0.47	4.8	1.97	1.44	14.7	2.97	2.42	24.7	3.97	3.40	34.7			

Outdoor Unit

▼ PS sensor characteristics

0 to 2.24 MPa (0.5 to 5V output for 0 to 2.24 MPa)

Voltage readings across pins 2 and 3 of CN500 on indoor unit main P.C. board (with negative-side probe of multimeter placed on pin 3)

VOLT	PS (MPa)	PS (kg/cm ²)	VOLT	PS (MPa)	PS (kg/cm ²)	VOLT	PS (MPa)	PS (kg/cm ²)	VOLT	PS (MPa)	PS (kg/cm ²)	VOLT	PS (MPa)	PS (kg/cm ²)
0.01	0.00	0.0	1.00	0.25	2.6	2.00	0.75	7.7	3.00	1.25	12.7	4.00	1.75	17.8
0.03	0.00	0.0	1.02	0.26	2.7	2.02	0.76	7.8	3.02	1.26	12.8	4.01	1.76	17.9
0.05	0.00	0.0	1.04	0.27	2.8	2.04	0.77	7.9	3.04	1.27	12.9	4.03	1.77	18.0
0.07	0.00	0.0	1.06	0.28	2.9	2.06	0.78	8.0	3.05	1.28	13.0	4.05	1.78	18.1
0.09	0.00	0.0	1.08	0.29	3.0	2.08	0.79	8.1	3.07	1.29	13.1	4.07	1.79	18.2
0.11	0.00	0.0	1.10	0.30	3.1	2.10	0.80	8.2	3.09	1.30	13.2	4.09	1.80	18.3
0.13	0.00	0.0	1.12	0.31	3.2	2.12	0.81	8.3	3.11	1.31	13.3	4.11	1.81	18.4
0.14	0.00	0.0	1.14	0.32	3.3	2.14	0.82	8.4	3.13	1.32	13.4	4.13	1.82	18.5
0.16	0.00	0.0	1.16	0.33	3.4	2.16	0.83	8.5	3.15	1.33	13.5	4.15	1.82	18.6
0.18	0.00	0.0	1.18	0.34	3.5	2.18	0.84	8.6	3.17	1.34	13.6	4.17	1.83	18.7
0.20	0.00	0.0	1.20	0.35	3.6	2.20	0.85	8.7	3.19	1.35	13.7	4.19	1.84	18.8
0.22	0.00	0.0	1.22	0.36	3.7	2.21	0.86	8.8	3.21	1.36	13.8	4.21	1.85	18.9
0.24	0.00	0.0	1.24	0.37	3.8	2.23	0.87	8.9	3.23	1.37	13.9	4.23	1.86	19.0
0.26	0.00	0.0	1.26	0.38	3.9	2.25	0.88	9.0	3.25	1.38	14.0	4.25	1.87	19.1
0.28	0.00	0.0	1.28	0.39	4.0	2.27	0.89	9.1	3.27	1.39	14.1	4.27	1.88	19.2
0.30	0.00	0.0	1.30	0.40	4.1	2.29	0.90	9.2	3.29	1.40	14.2	4.29	1.89	19.3
0.32	0.00	0.0	1.32	0.41	4.2	2.31	0.91	9.3	3.31	1.41	14.3	4.30	1.90	19.4
0.34	0.00	0.0	1.34	0.42	4.3	2.33	0.92	9.4	3.33	1.42	14.4	4.32	1.91	19.5
0.36	0.00	0.0	1.36	0.43	4.4	2.35	0.93	9.5	3.35	1.42	14.5	4.34	1.92	19.6
0.38	0.00	0.0	1.38	0.44	4.5	2.37	0.94	9.6	3.37	1.43	14.6	4.36	1.93	19.7
0.40	0.00	0.0	1.39	0.45	4.6	2.39	0.95	9.7	3.39	1.44	14.7	4.38	1.94	19.8
0.42	0.00	0.0	1.41	0.46	4.7	2.41	0.96	9.8	3.41	1.45	14.8	4.40	1.95	19.9
0.44	0.00	0.0	1.43	0.47	4.8	2.43	0.97	9.9	3.43	1.46	14.9	4.42	1.96	20.0
0.46	0.00	0.0	1.45	0.48	4.9	2.45	0.98	10.0	3.45	1.47	15.0	4.44	1.97	20.1
0.48	0.00	0.0	1.47	0.49	5.0	2.47	0.99	10.1	3.46	1.48	15.1	4.46	1.98	20.2
0.50	0.00	0.0	1.49	0.50	5.1	2.49	1.00	10.2	3.48	1.49	15.2	4.48	1.99	20.3
0.52	0.01	0.1	1.51	0.51	5.2	2.51	1.01	10.3	3.50	1.50	15.3	4.50	2.00	20.4
0.54	0.02	0.2	1.53	0.52	5.3	2.53	1.02	10.4	3.52	1.51	15.4	4.52	2.01	20.5
0.55	0.03	0.3	1.55	0.53	5.4	2.55	1.02	10.5	3.54	1.52	15.5	4.54	2.02	20.6
0.57	0.04	0.4	1.57	0.54	5.5	2.57	1.03	10.6	3.56	1.53	15.6	4.56	2.03	20.7
0.59	0.05	0.5	1.59	0.55	5.6	2.59	1.04	10.7	3.58	1.54	15.7	4.58	2.04	20.8
0.61	0.06	0.6	1.61	0.56	5.7	2.61	1.05	10.8	3.60	1.55	15.8	4.60	2.05	20.9
0.63	0.07	0.7	1.63	0.57	5.8	2.63	1.06	10.9	3.62	1.56	15.9	4.62	2.06	21.0
0.65	0.08	0.8	1.65	0.58	5.9	2.64	1.07	11.0	3.64	1.57	16.0	4.64	2.07	21.1
0.67	0.09	0.9	1.67	0.59	6.0	2.66	1.08	11.1	3.66	1.58	16.1	4.66	2.08	21.2
0.69	0.10	1.0	1.69	0.60	6.1	2.68	1.09	11.2	3.68	1.59	16.2	4.68	2.09	21.3
0.71	0.11	1.1	1.71	0.61	6.2	2.70	1.10	11.2	3.70	1.60	16.3	4.70	2.10	21.4
0.73	0.12	1.2	1.73	0.62	6.3	2.72	1.11	11.3	3.72	1.61	16.4	4.71	2.11	21.5
0.75	0.13	1.3	1.75	0.62	6.4	2.74	1.12	11.4	3.74	1.62	16.5	4.73	2.12	21.6
0.77	0.14	1.4	1.77	0.63	6.5	2.76	1.13	11.5	3.76	1.63	16.6	4.75	2.13	21.7
0.79	0.15	1.5	1.79	0.64	6.6	2.78	1.14	11.6	3.78	1.64	16.7	4.77	2.14	21.8
0.81	0.16	1.6	1.80	0.65	6.7	2.80	1.15	11.7	3.80	1.65	16.8	4.79	2.15	21.9
0.83	0.17	1.7	1.82	0.66	6.8	2.82	1.16	11.8	3.82	1.66	16.9	4.81	2.16	22.0
0.85	0.18	1.8	1.84	0.67	6.9	2.84	1.17	11.9	3.84	1.67	17.0	4.83	2.17	22.1
0.87	0.19	1.9	1.86	0.68	7.0	2.86	1.18	12.0	3.86	1.68	17.1	4.85	2.18	22.2
0.89	0.20	2.0	1.88	0.69	7.1	2.88	1.19	12.1	3.88	1.69	17.2	4.87	2.19	22.3
0.91	0.21	2.1	1.90	0.70	7.2	2.90	1.20	12.2	3.89	1.70	17.3	4.89	2.20	22.4
0.93	0.22	2.2	1.92	0.71	7.3	2.92	1.21	12.3	3.91	1.71	17.4	4.91	2.21	22.5
0.95	0.22	2.3	1.94	0.72	7.4	2.94	1.22	12.4	3.93	1.72	17.5	4.93	2.22	22.6
0.96	0.23	2.4	1.96	0.73	7.5	2.96	1.23	12.5	3.95	1.73	17.6	4.95	2.22	22.7
0.98	0.24	2.5	1.98	0.74	7.6	2.98	1.24	12.6	3.97	1.74	17.7	4.97	2.23	22.8
												4.99	2.24	22.9

9. BACKUP OPERATION (EMERGENCY OPERATION)

This product offers backup modes of operation to tide over certain emergency situations. If a trouble occurs in one of the compressors, it is possible to operate the system on an emergency basis by operating only the remaining compressor, (compressor backup operation).

If one of the outdoor units fails in a combined outdoor unit system, the system can be operated on an emergency basis by keeping only the remaining outdoor unit(s), (outdoor unit backup operation).

Perform backup operation setting in accordance with the procedure described below.

9-1. Note for Backup Operation


The method of backup operation differs according to the contents of trouble as shown in the table below.

Contents of trouble	Method of backup operation	Setting procedure
One of the compressors in the same unit fails (see Note 1)	Compressor backup (see Note 2)	Go to 9-2.
All the compressors in the same unit fail	Outdoor unit backup or cooling-season outdoor unit backup (see Notes 1, 3, 4 and 5)	Go to 9-3. or 9-4.
A trouble occurs in a compressor motor coil (e.g. a layer short-circuit)		
A trouble occurs in a refrigerating cycle part, fan or related part, or electrical part		
A trouble occurs in a temperature sensor or pressure sensor		


Note 1: If the compressor has failed due to a trouble in its motor coil (e.g. a layer short-circuit), do not perform compressor backup operation because of severe oil degradation. It could damage other outdoor units.

Note 2: Keep the number of backed-up outdoor units under compressor backup operation to one in the system (single refrigerant line).


Note 3 : Keep the total backup outdoor units lower or equal than 50% of the outdoor units in one system refrigerant line.



Note 4 : Count the outdoor unit that is having backup compressor operation as one operable outdoor unit. The backup operation is still possible to do as long as the total backup outdoor units lower or equal than 50% of total outdoor units.



Note 5 : It is possible to do backup operation even the system is connected with different chassis size and different weight of outdoor units.



9-2. Compressor Backup Operation Setting


<Outline>

If a failure occurs to one of the compressors installed in outdoor unit, follow the procedure described below to back up the failed compressor by using the remaining, normal compressor.

Note: The backup operation of compressor cannot be done for MMY-MUP0801*, MMY-MUP1001*, MMY-MUP1201*, MMY-MUP1401*, MMY-MUP14A1*, MMY-MUP1601*, MMY-MUP1801* and MMY-MUP2001*, because only one compressor is installed in these models.

<Work Procedure>

- (1) Turn off the power supply to all the outdoor units connected to the system.
- (2) Set the DIP switches of SW103, provided on the interface P.C. board of the outdoor unit with the failure compressor, as shown in the table below.



	SW103			
	Bit 1	Bit 2	Bit 3	Bit 4
Factory default setting	OFF	OFF	OFF	OFF
When compressor No.1 (front left) is failed	ON	OFF	OFF	OFF
When compressor No.2 (front right) is failed	OFF	ON	OFF	OFF


(3) Change the connection of wiring as shown in the below.

Outdoor Unit (22, 24HP)

Model: MMY-MUP2201", MUP2401"

1. When compressor No.1 is failure : No change the connection of wiring

2. When compressor No.2 is failure : Connection of wiring is changed as shown below.



(4) Turn on the power supply to all the units connected to the system.

This is the end of compressor backup operation setting.

9-3. Outdoor Unit Backup Operation Setting

<Outline>

This product allows outdoor unit backup operation setting to be performed either at the header unit or a follower unit. If any of the failure modes specified below occurs to one of the outdoor units in a multi-outdoor unit system, proceed with outdoor unit backup operation.

- A compressor failure (e.g. a layer short-circuit or a compressor failure in which no compressor is available to back up the failed compressor)
- A failure of a pressure sensor (Pd or Ps) or a temperature sensor (TD1, TD2, TS1, TS3, TE1, TE2, TE3, TG1, TG2, TG3, TK1, TK2, TL1, TL2 or TL3)

Note: Keep the number of backed-up outdoor units to one in the system (single refrigerant line).

9-3-1. Follower outdoor unit backup operation setting (failure of follower outdoor unit)

<Work procedure>

(1) Turn off the power supply to all the indoor and outdoor units connected to the system.

[Setup of failed follower outdoor unit]

(2) Fully close the gas pipe service valve of the failed outdoor unit.

(3) Leave the service valve of the liquid pipe fully open (to prevent refrigerant stagnation in the unit).


However, if there is a leakage from an outdoor PMV (unable to close), fully close the liquid pipe service valve.

(4) <In case of failure in compressor, electrical part, P.C. board>


From this point on, keep the power supply to the failed unit off.

<Case of refrigerating cycle parts failing (pressure sensor, temperature sensor, refrigerating cycle parts, fan system part)>


- In a case where the outdoor unit that is a terminal connection fails, disconnect the communication line to the outdoor unit from terminal [Uc(U5/U6)], and cover each of the lines U5 and U6 with insulating tape.




- In a case where an intermediate-connection outdoor unit fails, disconnect the communication line between both adjacent outdoor units from terminal [Uc(U5/U6)], and connect the communication lines.




(Reference) Normal wiring






[Setup of header unit]

- (5) Turn on Bit3 of SW103 on the interface P.C. board of the header unit.
(Setting to prevent connected indoor units capacity over failure (E16))



- (6) Turn on the power supply to all the units connected to the system other than the failed follower unit.
Determine what to do with the power supply to the failed follower unit in the following manner.
<In case of failure in compressor, electrical part, P.C. board>
Leave the power supply off.
<In case of failure in refrigerating circuit or related part (pressure sensor, temperature sensor, refrigerating cycle part, or fan system part)>
Turn on the power supply to protect the compressor (by turning on the case heater).
(When the power supply to the unit is turned on, [E19] (failure in the number of outdoor header units) will be displayed on the 7-segment display. However, this will not cause any problems.)
- (7) Perform settings needed to gain permission for backup operation from the header unit (failure clearance).
- 1) Set SW01/02/03 on the interface P.C. board to 1/1/1 and confirm that [U1] [E26] (dropping out of an outdoor unit) is displayed on the 7-segment display.
 - 2) Set SW01/02/03 on the interface P.C. board to 2/16/1. Upon confirming that [Er] [... ..] is displayed on the 7-segment display, press SW04 and hold for 5 seconds or more.
 - 3) [Er] [... CL] (failure clearance completed) will be displayed on the 7-segment display.
 - 4) Set SW01/02/03 back to 1/1/1. (The display should change to [U1] [- - -].)

- (7)
Set SW01/02/03 to 1/1/1
[U1] [E26] will be displayed.
↓
Set SW01/02/03 to 2/16/1.
[Er] [... ..] will be displayed.
↓
Press SW04 and hold for 5 seconds or more
[Er] [... CL] will be displayed.
↓
Set SW01/02/03 back to 1/1/1.
[U1] [- - -] will be displayed.



This is the end of follower outdoor unit backup operation setting. Check the operation.

9-3-2. Header outdoor unit backup operation setting (failure of header outdoor unit)

<Work procedure>

(1) Turn off the power supply to all the units connected to the system at the source.

[Setup of failed header outdoor unit]

(2) Fully close the gas pipe service valve of the failed outdoor unit.


(3) Leave the service valves of the liquid pipes fully open (to prevent refrigerant stagnation in the failed).

(4) <In case of failure in compressor, electrical part, P.C. board>

From this point on, keep the power supply to the failed unit off.

<In case of failure in refrigerating circuit or related part (pressure sensor, temperature sensor, refrigerating cycle part, or fan system part)>

Disconnect the line for outdoor-outdoor communication [Uc (U5/U6)] and cover the U5 and U6 line with insulating tape separately. (Do not cover the line by mixing the U5 and U6 line altogether).



[Selection of new header unit]

(5) Select a new header unit from the follower units on the basis of the following criteria:


- If only one follower unit is connected, select it as the header unit.
- If two follower units are connected, select the follower unit that is nearest to the failed header unit.

[Setup of new header unit]

(6) Set SW101 and SW102 on the interface P.C. board same as the setting of failed header unit (refrigerant line address setting).


(7) Turn on Bit3 of SW103 on the interface P.C. board. (Setting to prevent connected indoor unit capacity over failure. (E16))

- (8) Set Bits 1 and 2 of SW100 on the interface P.C. board same as that of the failed header unit (terminator resistance setting).



[Wiring changes to communication line]

- (9) Redirect the indoor-outdoor communication line connected to the failed header unit [Uv (U1/U2)] to the unit selected as the header unit [Uv (U1/U2)].
- (10) If a central control device is connected, connect the central control communication line [Uh (U3/U4)] to the communication line terminal of the unit selected as the new header unit [Uh (U3/U4)], and connect up the tie connector between the [Uv (U1/U2)] and [Uh (U3/U4)] terminals.



- (11) Turn on the power supply to all the units connected to the system other than the failed unit. Determine what to do with the power supply to the failed unit in the following manner.
- <In case of failure in compressor, electrical part, P.C. board>
Leave the power supply off.
 - <In case of failure in refrigerating circuit or related part (pressure sensor, temperature sensor, refrigerating cycle part, or fan system part)>
Turn on the power supply to protect the compressor (by turning on the case heater).
(When the power supply to the unit is turned on, [E19] (failure in the number of outdoor header units) will be displayed on the 7-segment display. However, this will not cause any problems.)

This is the end of header outdoor unit backup operation setting. Check the operation.

9-4. Cooling-Season Outdoor Unit Backup Operation Setting

<Outline>

Limited to summer and other situations where there is no need for heating operation, this function makes it possible to get backup operation up and running quickly without going through the normal setup procedure, regardless of which type of outdoor unit has failed, the header unit or a follower unit.

In this backup operation, the system behaves in exactly the same way as described in the "Outdoor Unit Backup

Operation Setting" section, except that it cannot perform heating operation.

Note 1: When the system is set up for this function, heating operation is not available.
("HEATING STANDBY" displayed on the remote controller.)

Note 2: If the unit failure has been caused by a failure in the interface P.C. board or electric circuit, this function is not available. In that case, follow the procedure specified in the "Outdoor Unit Backup Operation Setting" section.

<Work procedure>

(1) Turn off the power supply to all the units connected to the system.

[Setup of failed outdoor unit]


Regardless of whether the failed outdoor unit is the header unit or a follower unit, there is no difference in the setup procedure.

(2) Turn on Bits 1 and 2 of SW103 provided on the interface P.C. board.

(3) If there is a leakage from an outdoor PMV (unable to close), fully close the liquid pipe service valve.

(4) Turn on the power supply to all the units connected to the system.

If the failure involves poor insulation of a compressor motor, remove the compressor leads before the power is turned on.



This is the end of cooling-season outdoor unit backup operation setting.

9-5. Outdoor Unit Automatic Backup Operation Outline (available only for TU2C-LINK)

Outline

In case of the outdoor unit failure, this product supports automatic backup operation for both header and follower units.
In system with connection of two or more outdoor units, if the automatic backup operation setting is ON and the following check codes occur, the automatic backup operation function allows continuous operation.

Check Code : F**	F04,F05,F06,F07,F08,F09,F12,F15,F16,F23,F24,F31
Check Code : H**	H03,H08,H16
Check Code : P**	P03,P04,P05,P07,P11,P17,P18,P20,P22,P26,P29

If the following check codes occur, automatic backup operation function cannot be carried on and trouble/abnormality is confirmed. In this case, do [Outdoor Unit Backup Setting] as described before.

Check Code : E**	Indoor-outdoor unit communication signal trouble
Check Code : L**	Setting trouble
Check Code : H**	H01,H02,H06,H07
Check Code : P**	P10,P13,P15,P19

If the check codes above occur, please refer to check code diagnosis procedure.

Outdoor Unit Automatic Backup Setting

To turn ON the automatic backup operation setting, change the outdoor unit check code 3D to 0.
(The factory setting is ON, to disable the automatic backup operation setting, change the outdoor unit DN code 3D to 1)


Check Code (----) Display during Outdoor Unit Automatic Backup Operation

If the outdoor unit is on the automatic backup operation, check code(----)will be displayed on the remote controller.
The check code(----)will be also displayed on the outdoor unit targeted for backup operation, please contact a service center immediately to repair the failure outdoor unit.

10. OUTDOOR UNIT REFRIGERANT RECOVERY METHOD

10-1. Refrigerant Recovery from Troubled Outdoor Unit (Reclaim)

This product supports refrigerant reclaim, a function which allows refrigerant to be recovered from an outdoor unit in need of repair using a normal outdoor unit in a system featuring multiple outdoor units.



10-1-1. Note for refrigerant recovery operation

When performing reclaim operation, take note of the following matters:

- Note 1:** The reclaim refrigerant recovery rate changes with outside temperature and other factors. After reclaim is completed, recover any residual gas using a refrigerant recovery device, etc., and be sure to measure the amount of recovered refrigerant. (The refrigerant recovery rate can be improved by heating the accumulator of the outdoor unit to be repaired during reclaim operation.)
- Note 2:** If reclaim has been performed, the system cannot be operated until the troubled outdoor unit is repaired.
(Continued operation would be impossible due to a refrigerant overcharge.)
- Note 3:** If outdoor PMV 1 happens to be unable to open or PMVs 2 and 3 happen to be unable to open, the refrigerant in the heat exchangers cannot be recovered. In that case, recover any residual gas in the heat exchangers using a tube piercing valve or some other tool. After a reclaim operation, do not perform any brazing until the residual gas in the heat exchangers is recovered.

10-1-2. Refrigerant recovery procedure A (Case that the troubled outdoor unit turn on)

<Work procedure>


Turn on the power supply to the system at the source, but leave the system switched off.

If the trouble involves poor insulation of a compressor motor, remove the motor leads before the power is turned on.

[Setup of failed outdoor unit]

- (1) Connect the check joint of liquid pipe and the low pressure-side check joint using a charge hose, and purge the hose of air (to recover refrigerant from the liquid tank and heat exchangers).
- (2) Fully close the liquid pipe service valve of the troubled outdoor unit.
(Leave the service valves of the gas pipe fully open.)
- (3) Set SW01/02/03 on the interface P.C. board of the failed outdoor unit to 2/11/1. After [rd] [... ..] is displayed on the 7-segment display, press SW04 and hold for 5 seconds or more.

- (4) [rd] [... FF] will be displayed on the 7-segment display, and reclaim operation will start.
- * To put the operation on hold midway, turn off the power supply to all the outdoor units, or press SW05 on the interface P.C. board.
- (5) Approx. 20 minutes after the system starts up , fully close the gas pipe service value of the troubled outdoor unit.
- (6) Press SW05 on the interface board to finish the reclaim operation.
- (7) Turn off the power supply to all the outdoor units , and recover the residual refrigerant in the outdoor unit using a refrigerant re device. Be sure to measure the amount of recovered refrigerant. (This is necessary to determine how much additional refrigerant will be needed after the completion of the repair.)



This is the end of the refrigerant recovery operation.

Set SW01/02/03 of the troubled outdoor unit and the outdoor unit for pressure adjustment back to 1/1/1.

10-1-3. Refrigerant recovery procedure B (Case that the troubled outdoor unit does not turn on)

<Outline>

If outdoor unit backup operation setting is performed, use an alternative refrigerant recovery procedure as described below, provided that the power cannot be turned on for the troubled outdoor unit. (Refrigerant will be recovered from the failed outdoor unit using the test cooling operation function.)

Note: If the power cannot be turned on the troubled outdoor unit, the solenoid valves and PMVs of the unit cannot be turned on, so that it reduces the amount of recovered refrigerant compared to a standard reclaim operation. Recover the residual gas in the unit using a refrigerant recovery device, and be sure to measure the amount of recovered refrigerant.


<Work procedure>

[Setup of troubled outdoor unit]

- (1) Connect the liquid pipe check joint and the low pressure-side check joint using a gauge manifold, and purge the manifold of air (to recover refrigerant from the heat exchangers).
- (2) Fully close the liquid pipe packed valve of the troubled outdoor unit.
(Leave the service valve of the gas pipe fully open.)

[Setup of unit selected as header unit (hereafter “header outdoor unit”)]

- (3) Set SW01/02/03 on the interface P.C. board of the header outdoor unit to 2/5/1. After [C.] [... ..] is displayed on the 7-segment display, press SW04 and hold for 5 seconds or more.
- (4) After [C. ...] [... – C] is displayed on the 7-segment display, the system starts operating in the test cooling operation mode.
- (5) Set SW01/02/03 on the interface P.C. board of the header outdoor unit to 1/2/2 to have the low-pressure sensor\ output (MPa) displayed on the 7-segment display.
- (6) Approx. 20 minutes after the system starts on , fully close the gas pipe service value of the failed outdoor unit.
- (7) Press SW05 on the interface board to finish the reclaim operation.
- (8) Turn off the power supply to all the outdoor units , and recover the residual refrigerant in the outdoor unit using a refrigerant recovery device. Be sure to measure the amount of recovered refrigerant.
(This is necessary to determine how much additional refrigerant will be needed after the completion of the repair.)



This is the end of the refrigerant recovery operation.

Set SW01/02/03 of the troubled outdoor unit and the outdoor unit for pressure adjustment back to 1/1/1.

10-2. How to Operate System While Troubled Outdoor Unit Being Repaired

<Outline>

After refrigerant is recovered from the troubled outdoor unit through a reclaim operation, the overall amount of refrigerant held by the system becomes excessive, and this makes it impossible to operate the remaining outdoor units even though they are not troubled. However, operation is still possible if the system-wide amount of refrigerant is adjusted in accordance with the procedure described below.

<Work procedure>

- (1) Follow the steps specified in “10-1. Refrigerant Recovery from Troubled Outdoor Unit (Reclaim)”.
- (2) Adjust the amount of refrigerant held by the system by removing some of it using a refrigerant recovery device, etc.
Determine the amount of refrigerant to be removed according to the capacity of the failed outdoor unit. (See the table below.)

Example: If you are under repairing of a 16HP outdoor unit in the 50HP system

(combination of outdoor unit: 18HP + 16HP + 16HP):

Amount of refrigerant to be remove from this system = 11 kg

- (3) Set up the outdoor unit from which refrigerant has been recovered in the manner described in “9-3. Outdoor Unit Backup Operation Setting”.
This completes the procedure.

System capacity (HP)	Outdoor unit combination					Amount of refrigerant (kg)
8	8	-	-	-	-	7.5
10	10	-	-	-	-	7.7
12	12	-	-	-	-	8.3
14	14	-	-	-	-	8.3
14A	14A	-	-	-	-	9.8
16	16	-	-	-	-	10.0
18	18	-	-	-	-	11.0
20	20	-	-	-	-	13.0
22	22	-	-	-	-	14.0
24	24	-	-	-	-	14.5
26	14	12	-	-	-	16.6
28	14	14	-	-	-	16.6
30	18	12	-	-	-	20.7
32	20	12	-	-	-	21.3
34	20	14	-	-	-	21.3
36	24	12	-	-	-	22.8
38	24	14	-	-	-	22.8
40	20	20	-	-	-	26.0
42	24	18	-	-	-	25.5
44	24	20	-	-	-	27.5
46	24	22	-	-	-	28.5
48	24	24	-	-	-	29.0
50	24	14	12	-	-	31.1
52	24	14	14	-	-	31.1
54	20	20	14	-	-	34.3
56	24	20	12	-	-	35.8
58	24	20	14	-	-	35.8
60	24	24	12	-	-	37.3
62	24	24	14	-	-	37.3

System capacity (HP)	Outdoor unit combination					Amount of refrigerant (kg)
64	24	20	20	-	-	37.3
66	24	22	20	-	-	41.5
68	24	24	20	-	-	42.0
70	24	24	22	-	-	43.0
72	24	24	24	-	-	43.5
74	24	24	14	12	-	45.6
76	24	24	14	14	-	45.6
78	24	20	20	14	-	48.8
80	24	24	20	12	-	50.3
82	24	24	20	14	-	50.3
84	24	24	24	12	-	51.8
86	24	24	24	14	-	51.8
88	24	24	20	20	-	55.0
90	24	24	22	20	-	56.0
92	24	24	24	20	-	56.5
94	24	24	24	22	-	57.5
96	24	24	24	24	-	58.0
98	24	24	24	14	12	60.1
100	24	24	24	14	14	60.1
102	24	24	20	20	14	63.3
104	24	24	24	20	12	64.8
106	24	24	24	20	14	64.8
108	24	24	24	24	12	66.3
110	24	24	24	24	14	66.3
112	24	24	24	20	20	69.5
114	24	24	24	22	20	70.5
116	24	24	24	24	20	71.0
118	24	24	24	24	22	72.0
120	24	24	24	24	24	72.5

10-3. Work procedure after Repair

When vacuuming in the repaired outdoor unit, follow the procedure described below.

<Work procedure>

- (1) Follow the procedure below to fully open PMV 1, 2, 3, and 4 and turn off the outdoor unit within 2 minutes after the operation is completed.

Note) The PMV fully open operation by the following operation will return to fully closed after 2 minutes.


1. Set [SW01/SW02/SW03] on the interface board to [2/1/3], and after [H.r] [.....] is displayed on the 7-segment display, press [SW04] and hold for 5 seconds or more.
2. Press [SW06] and hold for 5 seconds or longer, and [P.1] [F o...] is displayed on the 7-segment display. (PMV1 fully open)
3. Set [SW01/SW02/SW03] on the interface board to [2/1/4], and after [P.2] [.....] is displayed on the 7-segment display, press [SW04] and hold for 5 seconds or longer, and [P.2][Fo...] is displayed on the 7-segment display. (PMV2 fully open)
4. 3. Similarly, set [SW01/SW02/SW03] to [2/1/5], set [SW01/SW02/SW03] to [2/1/6], press [SW04] and hold for 5 seconds or more, and each have 7 segments. [P.3][Fo...] (PMV3 fully open), [P.4][Fo...] (PMV4 fully open) are displayed on the display.

Note) 7-segment display and operation method: [P.X] [* * ...]

- The initial state is normal control, and [.....] is displayed in *.
- When push SW4 is pressed for 5 seconds, it fully opens for 2 minutes, and [F o...] is displayed in *.
- Pressing again for 5 seconds displays an intermediate opening for 2 minutes, and [C o...] is displayed in *.
- Pressing it again for 5 seconds closes it completely for 2 minutes and displays [Fc...] in *.
- Press again for 5 seconds to return to normal control.


- (2) Return [SW01/SW02/SW03] on the interface board to [1/1/1].

- (3) Be sure to perform vacuuming in from the three check joints shown in the diagram below (liquid pipe, discharge pipe and suction pipe).



11. REPLACING COMPRESSORS

11-1. Compressor Replacement Procedure (Outline)



WARNING

In situations such as indoor unit relocation and repairs, it is not possible to recover all the refrigerant held by the system in the outdoor units. It could cause a serious accident, such as blow out or injury. Be sure to perform refrigerant recovery using a refrigerant recovery device.

WARNING

When detaching a pipe by heating with a burner at brazed joint, take care as any oil left in the piping may burn in a momentary flash of fire when the brazed filler metal melts.

*1 The full-opening of PMV 1, 2, 3 via rotary switch is automatically undone after 2 minutes, causing the valves to fully close.

To maintain fully open state, turn off the power switch of the outdoor unit within 2 minutes

*2 The SMMS-u and the SMMS-i and SMMS-e use different types of compressors. Be sure to check the service part code.

This flowchart only shows the standard compressor replacement procedure. Since the situation can differ site by site, perform the task in accordance with the following judgment criteria:

1. The compressors that are used as service parts are filled with oil as listed below (per 1 compressor):

8, 10, 12, 14, 22, 24HP	1900 cc
14A, 16, 18, 20HP	3000 cc

2. The oil volume that was filled in the outdoor unit is listed as below:

8, 10, 12, 14HP	3400 cc
14A, 16, 18, 20HP	5000 cc
22, 24HP	5800 cc

3. The removed compressors normally filled with oil as listed below (per 1 compressor):


8, 10, 12, 14, 22, 24HP	800~1400 cc
14A, 16, 18, 20HP	2000~2600 cc

Oil separator's oil volume is normally around 0~1000 cc.

11-2. Replacement of Compressors

<Checking color of oil in troubled compressor>

- Lay the troubled compressor down, draw a small amount of oil via the oil equalization pipe, and check its color against color samples.
- Determine the number of compressors to be replaced according to the color checking result.
ASTM grade: Below 4 → Replace the troubled compressor only.
ASTM grade: 4 or above → Replace both the troubled compressor and the normal compressor(s).



WARNING

When detaching a pipe by heating with a burner at brazed joint, take care as any oil left in the piping may burn in a momentary flash of fire when the brazing filler metal melts.

Model: MMY-MUP0801*, 1001*, 1201*, 1401*, 2201* and 2401*

For 8, 10, 12, 14, 22, 24HP

[When replacing troubled compressor only]

<Measuring amount of oil in troubled compressor>

Put the troubled compressor above the scale to measure the amount of oil.

Amount of oil in troubled compressor: $A \text{ [cc]} = (\text{Weight of compressor as it was dismantled (kg)} - 26.0\text{kg}) \times 1042$
(Specific volume of oil: 1042 [cc/kg])

* The weight of the compressor without oil inside is 26.0 kg.

<Adjusting amount of oil in new compressor> (1900 cc at shipment)

- Perform the adjustment on the basis of how much oil the troubled compressor contained, A [cc], by following the steps below.

1 Amount of oil in troubled compressor A [cc]: $0 \leq A < 1100$

(1) Adjust the amount of oil in the new compressor to 1100 cc.

(Lay the new compressor down and draw 800 [cc] of oil via the oil-equalization pipe.)

Notes:

- Do not draw more than 800 [cc] of oil as it may cause damage to the compressor.
- If the troubled compressor contained 500cc or less, there may have been a problem with the oil equalization circuit, etc. Perform checks in accordance with “11-3. Check Procedure to Search Cause of Compressor Oil Shortage”.

2 Amount of oil in troubled compressor A [cc]: $1100 \leq A < 1900$


(1) Adjust the amount of oil in the new compressor to A cc.

(Lay the new compressor down and draw $(1900 - A)$ [cc] of oil via the oil equalization pipe.)

3 Amount of oil in troubled compressor A [cc]: $1900 \leq A$

(1) Adjust the amount of oil in the new compressor to A cc.

(Insert a hose into the discharge pipe or oil equalization pipe of the new compressor and inject $(A - 1900)$ [cc] of oil using a funnel, etc.)



Model: MMY-MUP14A1*, 1601*, 1801* and 2001*

For 14A, 16, 18, 20HP

[When replacing troubled compressor only]

<Measuring amount of oil in troubled compressor>

Put the troubled compressor above the scale to measure the amount of oil.

Amount of oil in troubled compressor: $A \text{ [cc]} = (\text{Weight of compressor as it was dismantled (kg)} - 42.6\text{kg}) \times 1042$
(Specific volume of oil: 1042 [cc/kg])

* The weight of the compressor without oil inside is 42.6 kg.

<Adjusting amount of oil in new compressor> (3000 cc at shipment)

- Perform the adjustment on the basis of how much oil the troubled compressor contained, $A \text{ [cc]}$, by following the steps below.

1 Amount of oil in troubled compressor $A \text{ [cc]}$: $0 \leq A < 2500$

(1) Adjust the amount of oil in the new compressor to 2500cc.

(Lay the new compressor down and draw 500 [cc] of oil via the oil-equalization pipe.)

Notes:

- Do not draw more than 500 [cc] of oil as it may cause damage to the compressor.
- If the troubled compressor contained 500cc or less, there may have been a problem with the oil equalization circuit, etc. Perform checks in accordance with "11-3. Check Procedure to Search Cause of Compressor Oil Shortage".

2 Amount of oil in troubled compressor $A \text{ [cc]}$: $2500 \leq A < 3000$


(1) Adjust the amount of oil in the new compressor to $A \text{ cc}$.

(Lay the new compressor down and draw $(3000 - A) \text{ [cc]}$ of oil via the oil equalization pipe.)

3 Amount of oil in troubled compressor $A \text{ [cc]}$: $3000 \leq A$

(1) Adjust the amount of oil in the new compressor to $A \text{ cc}$.

(Insert a hose into the discharge pipe or oil equalization pipe of the new compressor and inject $(A-3000) \text{ [cc]}$ of oil using a funnel, etc.



Model: MMY-MUP2201* and 2401*

For 22, 24HP

[When replacing normal as well as troubled compressor] - applicable to

<Remove the normal compressor>

- Remove the normal compressor in the same way as the troubled compressor.

Note:

- Be sure to insulate the removed compressor leads using insulation tape, etc.

WARNING

When detaching a pipe by heating with a burner at brazed joint, take care as any oil left in the piping may burn in a momentary flash of fire when the brazing filler metal melts.

<Measuring amount of oil in normal compressor>

- As was the case with the troubled compressor, measure the amount of oil contained by placing the compressor on a scale.
Amount of oil in normal compressor: $B \text{ [cc]} = (\text{Weight of compressor as it was dismantled (kg)} - 26.0 \text{ kg}) \times 1042$
(Specific volume of oil: 1042 [cc/kg])
- * The weight of the compressor without oil inside is 26.0 kg.

<Adjusting amount of oil in new compressors>

- Perform the adjustment on the basis of how much oil the failure compressor contained, A [cc], and how much oil the normal compressor contained, B [cc], by following the steps below.

1 Combined amount of oil in troubled and normal compressors $A+B \text{ [cc]}: 0 \leq A+B < 2200$

(1) Adjust the amount of oil in the two new compressors to 1000 cc each (total 2200 cc).

- Lay the compressors down and draw 800 [cc] of oil from each of them via their oil equalization pipes.

Notes:

- Do not draw more than 800 [cc] of oil from a compressor as it may cause damage.
- If the troubled compressor contained 500cc or less, there may have been a problem with the oil equalization circuit, etc. Perform checks in accordance with "11-3. Check Procedure to Search Cause of Compressor Oil Shortage".

2 Combined amount of oil in troubled and normal compressors $A+B \text{ [cc]}: 2200 \leq A+B < 3800$


(1) Adjust the amount of oil in the two new compressors to $(A+B)/2$ cc each.

- Lay the compressor down and draw $[3800-(A+B)]/2$ [cc] of oil from each of them via their oil equalization pipes.

3 Combined amount of oil in troubled and normal compressors $A+B \text{ [cc]}: 3800 \leq A+B$

(1) Adjust the amount of oil in the two new compressors to $(A+B)/2$ cc each.

(Insert a hose into the discharge pipe or oil equalization pipe of each compressor and inject $(A+B)/2-1900$ [cc] of oil using a funnel, etc.)



<Installing compressor>

- Install a compressor by following the dismantling procedure in reverse.

Notes:

- The tightening torque of the screws, used to fix the compressor's lead wires, is 2.5 N•m.
- The tightening torque of the hexagonal bolts, used to mount the compressor, is 19.6 N•m.
- If oil has been drawn from the accumulator, repair the cut pipe through pinching and brazing.

<Vacuum-pumping>

(Single outdoor unit system)

- Before performing vacuum-pumping, fully open PMV1, 2 and 3. If they are closed, the heat exchangers of the outdoor unit cannot be vacuum-pumped.
- Connect a vacuum pump consecutively to the check joints placed in the liquid and discharge pipes and on the high-pressure side of the suction pipe, and turn it on.
- Operate the vacuum drying until the vacuum gauge indicates 1 mmHg.

<Method to fully open PMV manually>

(1) Turn on the power switch of the outdoor unit.

(2) Fully open the PMV1.

(3) Fully open the PMV2.

(4) Fully open the PMV3

(5) Turn off the power switch of the outdoor unit


* Please refer to chapter 7-7-6 to fully open the PMV1, 2, and 3.

* Step (4) is not needed for Model: MMY-MUP0801*, 1001*, 1201* and 1401*

<Refrigerant charging>

- Inject the same amount of refrigerant as the recovered residual refrigerant via the charging port of the liquid-side service valve.

11-3. Check Procedure to Search Cause of Compressor Oil Shortage




<MMY-MUP0801*, 1001*, 1201* and 1401*>

Check items and procedures to follow when checking oil circuit with compressor(s) disconnected

Check item	Location	Procedure
Leakage of outdoor PMV Leakage of check valve in discharge pipe convergent section	A, B, D	1) With PMV 1, 2 and 4 fully closed, apply pressure to the check joint of liquid pipe with nitrogen, and check the pressure at the check joint of discharge pipe. If the pressure at the check joint of discharge pipe increases, there is a leak from PMV1 (A) or PMV2 (B) and check valve of discharge pipe (D). Replace the troubled parts. 2) If the pressure does not increase, fully open outdoor PMV 1, 2 and check the pressure at the check joint of discharge pipe again. If the pressure increases, there is a leak from the check valve of discharge pipe (D). Replace the part.
Clogging of SV3D valve Clogging of oil-return capillary Clogging of oil-return distributor	F	3) With pressure applied to the check joint of discharge pipe with nitrogen, manually open the SV3D valve. If gas does not escape from the suction pipe section of the disconnected compressor, the SV3D valve, oil-return capillary or oil-return distributor is clogged. Replace the part.

Outdoor Unit (8, 10, 12, 14HP)
Model : MMY-MUP0801*, 1001*, 1201* and 1401*



Symbol						
Solenoid valve	Capillary tube	Check valve	Check joint	Strainer	Temperature sensor	Distributor


<MMY-MUP14A1*, 1601*, 1801* and 2001*>

Check items and procedures to follow when checking oil circuit with compressor(s) disconnected

Check item	Location	Procedure
Leakage of outdoor PMV Leakage of check valve in discharge pipe convergent section	A, B C, D	1) With PMV 1, 2, 3 and 4 fully closed, apply pressure to the check joint of liquid pipe with nitrogen, and check the pressure at the check joint of discharge pipe. If the pressure at the check joint of discharge pipe increases, there is a leak from PMV1 (A), 2 (B) or 3 (C) and check valve of discharge pipe (D). Replace the troubled parts. 2) If the pressure does not increase, fully open outdoor PMV1 and 2 and check the pressure at the check joint of discharge pipe again. If the pressure increases, there is a leak from the check valve of discharge pipe (D). Replace the part.
Clogging of SV3D valve Clogging of oil-return capillary Clogging of oil-return distributor	F	3) With pressure applied to the check joint of discharge pipe with nitrogen, manually open the SV3D valve. If gas does not escape from the suction pipe section of the disconnected compressor, the SV3D valve, oil-return capillary or oil-return distributor is clogged. Replace the part.

Outdoor Unit (14A, 16, 18, 20HP)

Model: MMY-MUP14A1*, 1601*, 1801* and 2001*




Symbol						
Solenoid valve	Capillary tube	Check valve	Check joint	Strainer	Temperature sensor	Distributor

<MMY-MUP2201*, 2401*>

Check items and procedures to follow when checking oil circuit with compressor(s) disconnected


Check item	Location	Procedure
Leakage of outdoor PMV Leakage of check valve in discharge pipe convergent section	A,B C,D	1) With PMV 1, 2, 3 and 4 fully closed, apply pressure to the check joint of liquid pipe with nitrogen, and check the pressure at the check joint of discharge pipe. If the pressure at the check joint of discharge pipe increases, there is a leak from PMV1 (A), 2 (B) or 3 (C) and check valve of discharge pipe (D). Replace the troubled parts. 2) If the pressure does not increase, fully open outdoor PMV1 and 3 and check the pressure at the check joint of discharge pipe again. If the pressure increases, there is a leak from the check valve of discharge pipe (D). Replace the part.
Leakage of check valve in discharge pipe	E	3) With pressure applied to the check joint of discharge pipe with nitrogen, if gas escapes from the discharge pipe section of the disconnected compressor, there is a leak from the check valve of discharge pipe (E). Replace the part.
Clogging of SV3D valve Clogging of oil-return capillary Clogging of oil-return distributor	F	4) With pressure applied to the check joint of discharge pipe with nitrogen, manually open the SV3D valve. If gas does not escape from the suction pipe section of the disconnected compressor, the SV3D valve, oil-return capillary or oil-return distributor is clogged. Replace the part.






Outdoor Unit (22, 24HP)
Model: MMY-MUP2201*, 2401*












Symbol						
Solenoid valve	Capillary tube	Check valve	Check joint	Strainer	Temperature sensor	Distributor








12. OUTDOOR UNIT PARTS REPLACEMENT METHODS





No.	Part	Work procedure	Remarks
1	Cabinet	<p>⚠ WARNING</p> <p>Wear a pair of gloves. Otherwise, you will risk an injury involving a replacement part or some other object.</p> <p>1. Detachment</p> <ol style="list-style-type: none"> 1) Stop the air conditioner operation, and turn off the circuit breaker. 2) Remove the front cabinet (right). (M5 × 10 6 pcs) 3) Remove the front cabinet (left). (M5 × 10 4 pcs) 4) Remove the top plate. (M5 × 10 8 pcs) Front: 3 pcs, Back:3 pcs, Left and Right: 1 pcs each 5) Remove the front cabinet (upper) (M5 × 10 5 pcs) <ul style="list-style-type: none"> * Remove the NFC holder first (M4 × 10 1 pcs) • Remove the back side cabinet (upper). (M5 × 10 5 pcs) 6) Remove the side panel (right and left). Each (M5 × 10 4 pcs) 7) Remove the right side panel. (Only 990W cabinet) (M5 × 10 5 pcs) <ul style="list-style-type: none"> * Each cabinet has the hooks. Lift the cabinet to remove the hooks. 	<p>NFC holder</p>  <p>Hook</p>
		<p>2. Attachment</p> <p>Carry out installation by following reverse procedure in the detachment 1) to 7).</p> <p>Hang the hooks into the slit on the metal frame to securely attach each cabinet.</p>	







No.	Part	Work procedure	Remarks
2	Propeller fan and Fan motor	<p>⚠ WARNING</p> <p>Wear a pair of gloves. Otherwise, you will risk an injury involving a replacement part or some other object.</p> <p>1. Detachment</p> <ol style="list-style-type: none"> 1) Stop the air conditioner operation, and turn off the circuit breaker. 2) Remove the screws for the top plate. (M5 × 10, 8 pcs: Front, 3 pcs. Back, 3 pcs. Left and Right, 1 pcs each.) 3) Remove the flange nut securing the fan motor and propeller fan. (To loosen the nut, turn it clockwise.) 4) Remove the square washer. 5) Remove the propeller fan. <p>⚠ CAUTION</p> <p>Lift it straight up. Do not forcibly pull it, or it may get stuck.</p> <ol style="list-style-type: none"> 6) Disconnect the connectors for the fan motor leads from the Fan IPDU, and remove the fan motor leads. (Remove the wire clamp and binding band.) 7) Remove the fan motor. (M6 × 20, 4 pcs) 	   
		<p>2. CAUTION for replacement or attachment</p> <ol style="list-style-type: none"> 1) Insert the propeller fan while aligning the D-cut surface of the fan motor shaft with the arrow mark (▲) on the fan. (If the propeller fan is tightly mounted on the shaft without securing alignment between the D-cut surface and the arrow mark (▲), it may cause the fan to melt and fall off due to friction heat.) 2) Be sure to put the square washer in place. (Otherwise, unusual noises and vibrations may result.) 3) Tighten the flange nut at a torque of 14.7 N•m. (To tighten the flange nut, turn it counterclockwise.) [When attaching two fan motors for 16~24 HP] Be sure to attach them to the original positions. Fan motor 1: Attach it to the left side. Connect the fan motor connector to the upper fan P.C. board. Fan motor 2: Attach it to the right side. Connect the fan motor connector to the lower fan P.C. board. 	





No.	Part	Work procedure	Remarks
3	Heat exchanger	<p>⚠ WARNING</p> <p>Wear a pair of gloves. Otherwise, you will risk an injury involving a replacement part or some other object.</p> <p>1. Detachment</p> <p>1) Remove No. 1. Cabinet, No.2. propeller fan/fan motor, and No. 5. Reactor. (Only 14A~24HP)</p> <p>2) Remove the discharge cabinet, motor base, beams in four sides, and two rear supports.</p> <p><8 to 14HP(Fig.1)></p> <p>Discharge cabinet : Screws M5×10, 8 pcs Motor base : M5×10, 4 pcs Beams in four sides : M5×10, 21 pcs Rear supports : M5×10, 6 pcs</p> <p><14A to 24HP(Fig.2 to 4)></p> <p>Discharge cabinet : M5×10, 12 pcs, M4×14, 2 pcs Closing panel : M5×10, 3 pcs Fixing board : M5×10, 3 pcs Upper beams : M5×10, 2 pcs Motor base : M5×10, 8 pcs Beams in four sides : M5×10, 23 pcs Rear supports : M5×10, 6 pcs</p>  <p>Fig. 5</p>	<p><8 to 14HP></p>  <p>Fig. 1</p> <p><14A to 24HP></p>  <p>Fig. 2</p>  <p>Fig. 3</p>  <p>Fig. 4</p>




No.	Part	Work procedure	Remarks
3	Heat exchanger (continued)	<p data-bbox="359 212 933 246">3) Cut the pipes at the heat exchanger (Fig.6, Fig.7).</p> <div data-bbox="359 268 861 750"> <p data-bbox="375 280 518 302"><8 to 14HP></p>  <p data-bbox="550 358 853 414">(1) Header pipe at the gas side (Main heat exchanger)</p> <p data-bbox="550 448 853 504">(3) Header pipe at the gas side (Sub-heat exchanger)</p> <p data-bbox="550 582 853 638">(2) Distributor at the liquid side (Main heat exchanger)</p> <p data-bbox="550 694 853 750">(4) Distributor at the liquid side (Sub-heat exchanger)</p> </div> <div data-bbox="877 268 1396 750"> <p data-bbox="885 280 1061 302"><14A to 24HP></p>  <p data-bbox="1093 324 1396 380">(1) Header pipe at the gas side (Main heat exchanger)</p> <p data-bbox="1093 436 1396 492">(2) Distributor at the liquid side (Main heat exchanger)</p> <p data-bbox="1093 526 1396 582">(3) Header pipe at the gas side (Sub-heat exchanger)</p> <p data-bbox="1093 638 1396 694">(4) Distributor at the liquid side (Sub-heat exchanger)</p> </div> <p data-bbox="598 750 662 784">Fig. 6</p> <p data-bbox="1141 750 1204 784">Fig. 7</p> <p data-bbox="359 851 981 907">4) Remove the heat exchanger while draw it upward or at rear side</p> <p data-bbox="327 907 726 940"><8 to 14HP (Fig.8)> : M5 × 10, 2 pcs</p> <p data-bbox="327 940 758 974"><14A to 24HP (Fig.9)> : M5 × 10, 8 pcs</p> <div data-bbox="391 1030 869 1624">  <p data-bbox="726 1579 869 1624">M5×10, 2 pcs</p> </div> <div data-bbox="869 1030 1396 1657">  <p data-bbox="933 1176 1077 1220">M5×10, 8 pcs</p> </div> <p data-bbox="542 1624 606 1657">Fig. 8</p> <p data-bbox="1045 1624 1109 1657">Fig. 9</p> <p data-bbox="327 1713 510 1747">2. Attachment</p> <p data-bbox="327 1747 965 1803">Carry out installation by following reverse procedure in the detachment 1) to 4).</p>	

No.	Part	Work procedure	Remarks
4	Inverter assembly	<p>⚠ WARNING</p> <p>Wear a pair of gloves. Otherwise, you will risk an injury involving a replacement part or some other object.</p> <p>1. Detachment</p> <ol style="list-style-type: none"> 1) Stop the air conditioner operation, and turn off the circuit breaker. 2) Remove the inverter cover. (M4 × 10, 2 pcs.) 3) Remove the connectors and clamp, and remove each wire. 4) Remove the fixing screws for the heat sink. (8 to 20 HP : M4 × 16, 5 pcs 22 to 24 HP : M4 × 16, 6 pcs) Tighten the screws removed to the hole next to upper and lower slotted hole to remove the heat sink 5) Remove the fixing screws for the box. (M5 × 10, 4 pcs for right and left, 2 pcs for top) 6) Lift up the box lightly to disengage the fixing hook at the right-lower part. (The lower part of the box comes out toward you.) 7) Hold the top board with both hands to disengage the top hook. <div data-bbox="400 963 635 1357">  <p>[8-14HP] 4) Fixing screws for the heat sink (5 pcs)</p> </div> <div data-bbox="689 960 914 1357">  <p>[14A-20HP] 4) Fixing screws for the heat sink (5 pcs)</p> </div> <div data-bbox="557 1480 758 1968">  <p>[22-24HP] 4) Fixing screws for the heat sink (6 pcs)</p> </div>	<div data-bbox="1018 226 1406 528">  <p>5) Screw</p> <p>5) Screw</p> <p>Fixing part : Screw slot hole (Tentative structure) * Loosen the screw without removing it.</p> </div> <div data-bbox="1018 535 1406 1016">  <p>2) Screw for inverter cover</p> <p>3) Comp., FM, or Reactor lead</p> <p>3) Coil, sensor, heater, or NFC lead</p> <p>3) Power supply Signal lead</p> <p>[8-14HP] Wiring position</p> </div> <div data-bbox="1018 1088 1406 1561">  <p>3) Coil, sensor, heater, or NFC lead</p> <p>3) Comp., FM, or Reactor lead</p> <p>3) Power supply Signal lead</p> <p>[14A-20HP] Wiring position</p> </div> <div data-bbox="1018 1606 1406 2054">  <p>3) Coil, sensor, heater, or NFC lead</p> <p>3) Comp., FM, or Reactor lead</p> <p>3) Power supply Signal lead</p> <p>[22-24HP] Wiring position</p> </div>





No.	Part	Work procedure	Remarks
4	Inverter assembly (continued)	<p>2. Attachment</p> <p>1) Carry out installation by following reverse procedure in the detachment 1) to 7).</p> <p>NOTE 1 Apply thickly the heat sink grease to the refrigerant cooling heat sink and install the inverter box. Return the wires to the original state. (Application amount : 100 to 200 μm) Heat dissipation grease (Part No. : 43167044)</p> <p>NOTE 2 If the refrigerant cooling heat sink is twisted significantly, adjust it so that it is parallel to the contact surface with the refrigerant cooling heat sink of the box; otherwise, poor contact may cause operation stop.</p> <p style="text-align: center;">Tightening torque of each fixing screws.</p> <div style="border: 1px solid black; border-radius: 15px; padding: 10px; margin: 10px 0;"> <p>Fix the following screws with the specified tightening torque.</p> <p>Power supply terminal block : 2.5 to 3.0 N•m Earth terminal block : 5.5 to 6.6 N•m Signal terminal block : 1.2 to 1.4 N•m INV P.C.boardComp.fixing : 1.9 to 2.1 N•m INV P.C.boardReactor fixing : 1.9 to 2.1 N•m Refrigerant cooling heat sink fixed screw : 1.4 to 1.5 N•m</p> </div>	 <p>5) Fixing screws for the box (6 pcs). (Equal to 8-24HP)</p> <p>6) Disengage the fixing hook at the lower right. (Equal to 8-24HP)</p>  <p>7) Lift the inverter assembly lightly to disengage the upper hook (2 pcs), and remove the inverter assembly. (Equal to 8-24HP)</p>  <p>(NOTE1) Apply the the heat sink grease to the refrigerant cooling heat sink and install the inverter box.</p>  <p>(NOTE 2) Adjust the refrigerant cooling heat sink so that it is parallel to the heat sink on the box. Follow the size below for the space between the waterproof cover and the refrigerant cooling heat sink Top space : 4 to 6mm, Bottom space : 4 to 6mm</p>



No.	Part	Work procedure	Remarks
4	Waterproof cover assembly	<p>1. Detachment</p> <ol style="list-style-type: none"> 1) Stop the air conditioner operation, and turn off the circuit breaker. 2) Remove the inverter assembly. (Refer to the detachment for No.4 inverter assembly.) 3) Remove the binding band at the upper of the refrigerant cooling heat sink and the fixing rubber at the lower. 4) Loosen the clamp at the left side of the waterproof cover (8-20HP : 2 pcs, 22-24HP : 3 pcs) to remove the fan motor and reactor. 5) Remove the screws fixing right side of the cover and remove the two hooks hanged on the pillar. (M5 × 10, 7 pcs) 6) Remove the screws fixing left side of the cover and two hooks hanged on the pillar, and remove the cover from the right side of the heat sink while turning the cover clockwise. (8 to 20HP : M5 × 10, 4 pcs 22 to 24HP : M5 × 10, 5 pcs) <p>NOTE Remove the refrigerant cooling heat sink with care not to bend it.</p> <p>2. Attachment</p> <ol style="list-style-type: none"> 1) Carry out installation by following reverse procedure in the detachment 1) to 5). <p>NOTE If the refrigerant cooling heat sink is twisted significantly, adjust it so that it is parallel to the contact surface with the refrigerant cooling heat sink of the box; otherwise, poor contact may cause operation stop.</p> <ol style="list-style-type: none"> 1) Carry out installation by following reverse procedure in the detachment 1) to 7). <p>NOTE Align the refrigerant cooling heat sink with the rib at the upper-center of the fixing rubber to install the fixing rubber for the heat sink.</p>	<p>3) Cut the binding band</p>  <p>Align the heat sink with the rib at the upper-center of the fixing rubber to install the fixing rubber.</p>  <p>Fix the refrigerant cooling heat sink positioned along engraving of waterproof cover.</p> <p>3) Remove the screws (M4) and the clamp, and remove the fixing rubber.</p>  <p>4) Remove the fan motor and reactor lead from the clamp. (8-20HP : 2 pcs 22,24HP : 3 pcs)</p>  <p>6) Remove the left waterproof cover from the right side of the heat sink, while turning the cover clockwise.</p>  <p>Fixing the right waterproof cover</p> <p>5) Fixing screw (Red) (8 to 24HP : 7 pcs) Hooking claw (Black : right 2 pcs) Fixing the left waterproof cover</p> <p>5) Fixing screw (Blue) (8 to 20HP : 4 pcs, 22 to 24HP : 5 pcs) Hooking claw (Black : left 2 pcs)</p> 

No.	Part	Work procedure	Remarks
5	Reactor assembly (8-14HP)	<p>⚠ WARNING</p> <p>Wear a pair of gloves. Otherwise, you will risk an injury involving a replacement part or some other object.</p> <p>1. Detachment</p> <ol style="list-style-type: none"> 1) Stop the air conditioner operation, and turn off the circuit breaker. 2) Following to works 1) to 5) in 1 of No.1 Cabinet, remove the cabinets. 3) Remove the screws for the reactor box. (M5 × 10 2 pcs) 4) Remove the top plate for reactor box. (M4 × 8 3pcs) 5) Remove the front cover for reactor box. (M4 × 8 4pcs, Hook at the left) 6) Remove the reactor. (M4 × 8 2pcs, Hook at the left) 	 <p>3) Reactor box</p>  <p>4) Top plate for reactor box</p> <p>5) Front cover for reactor box</p>  <p>3) Screw for reactor box</p>  <p>3) Screw for reactor box</p>
		<p>2. Attachment</p> <p>Carry out installation by following reverse procedure in the detachment 1) to 7).</p> <p>Hook the hooks on each cabinet securely into the square holes in the supports.</p>	




No.	Part	Work procedure	Remarks
5	Reactor assembly (14A-24HP)	<p>⚠ WARNING</p> <p>Wear a pair of gloves. Otherwise, you will risk an injury involving a replacement part or some other object.</p> <p>1. Detachment</p> <ol style="list-style-type: none"> 1) Stop the air conditioner operation, and turn off the circuit breaker. 2) Following to works 1) to 5) in 1 of No.1 Cabinet, remove the cabinets. 3) Remove the screws for the fixed plate of reactor box. (M5 × 10, 4 pcs) 4) Remove the screws for the reactor box, and draw the reactor box toward you. (M5 × 10, 2 pcs, Rear side is hooked) 5) Remove the reactor cover. (M4 × 8, 6 pcs) 6) Remove the reactor. (M4 × 8, 4 pcs) 	<p>3) Fixed plate of reactor box</p>  <p>4) Screw for reactor box</p> <p>5) Screws for reactor cover</p>  <p>6) Screw for reactor box</p> 
		<p>2. Attachment</p> <p>Carry out installation by following reverse procedure in the detachment 1) to 6).</p> <p>Hook the hooks on each cabinet securely into the square holes in the supports.</p> <p>[When attaching two reactors for 22, 24 HP] Be sure to wire the round type terminal leads to the specified reactors.</p> <p>Reactor 1: Wire the round type terminal lead without the black tape to the reactor 1.</p> <p>Reactor 2: Wire the round type terminal lead with the black tape to the reactor 2.</p>	

No.	Part	Work procedure	Remarks
6	Compressor	<div data-bbox="336 210 497 237"> ⚠ WARNING </div> <div data-bbox="336 253 954 331"> Wear a pair of gloves. Otherwise, you will risk an injury involving a replacement part or some other object. </div> <div data-bbox="336 378 517 405"> 1. Detachment </div> <div data-bbox="363 421 911 472"> 1) Carry out work of No. 1 Cabinet and remove the compressor cover and soundproof materials. </div> <div data-bbox="336 477 497 504"> ⚠ WARNING </div> <div data-bbox="336 519 895 593"> Be careful of burns. The compressor cover is very hot immediately after outdoor unit stops. </div> <div data-bbox="392 613 622 640"><8 to 14HP (Fig.10)></div> <div data-bbox="392 645 979 779"> <ul style="list-style-type: none"> Remove the cover in order of top, front (upper), front (lower), and side. Screws for the compressor covers : M5 × 10, 8 pcs <ul style="list-style-type: none"> * Screws for the base plate and the comp. cover : M5 × 10, 4 pcs </div> <div data-bbox="392 797 652 824"><14A to 20HP (Fig.11)></div> <div data-bbox="392 828 979 963"> <ul style="list-style-type: none"> Remove the cover in order of top, front (upper), front (lower), and side. Screws for the compressor covers : M5 × 10, 7 pcs <ul style="list-style-type: none"> * Screws for the base plate and the comp. cover : M5 × 10, 5 pcs </div> <div data-bbox="392 969 636 996"><22 to 24HP (Fig.12)></div> <div data-bbox="392 999 979 1191"> <ul style="list-style-type: none"> Remove the cover in order of top, front (upper), front (lower), and side. Screws for the compressor covers : M5 × 10, 7 pcs <ul style="list-style-type: none"> * Screws for the base plate and the comp. cover : M5 × 10, 4 pcs * Use the ratchet tools with its length adjusted to detach and attach the comp. cover if needed. </div> <div data-bbox="363 1205 979 1305"> 2) Disconnect the compressor lead, case heater, temperature sensor (TD, TK), pipe cover, and pipe fixing rubber, or move them away from parts to be brazed to prevent them from being fired while brazing. </div> <div data-bbox="363 1319 979 1449"> 3) Remove the pipes connected to the compressor in the order of oil equalizer pipe, discharge pipe, suction pipe*. * If the suction pipe cannot be removed through brazing, cut it at the position shown in the figure, and use the repair parts below to install the pipe. </div> <div data-bbox="363 1460 967 1512"> 4) Remove the compressor bolts and anti-vibration take the compressor out of the unit. </div>	<div data-bbox="1070 264 1422 663"> <p><8 to 14HP></p> <p>Fig. 10</p> </div> <div data-bbox="1070 723 1422 1149"> <p><14A to 20HP></p> <p>Fig. 11</p> </div> <div data-bbox="1070 1193 1422 1579"> <p><22 to 24HP></p> <p>Fig. 12</p> </div> <div data-bbox="164 1637 483 2045"> <p><8 to 14HP></p> <p>Fig. 13</p> </div> <div data-bbox="496 1637 1015 2067"> <p><14A to 20HP></p> <p>Fig. 14</p> </div> <div data-bbox="1031 1621 1422 2051"> <p><22 to 24HP></p> <p>Fig. 15</p> </div>

No.	Part	Work procedure	Remarks
6	Compressor (continued)	<p>2. Attachment</p> <ol style="list-style-type: none"> 1) Carry out installation by following reverse procedure in the detachment 1) to 4). 2) Install the compressor and braze the pipes, and then install each wire around the compressor. (Comp.lead, Case heater, Temperature sensor (TD, TK)) Exchange a comp. leads together as replacing a compressors. <p>* The right fig. 1 shows caution when the comp. leads are installed.</p> <ul style="list-style-type: none"> • Incorporate the terminal block into the compressor. • Bend each terminal at 90°while holding the terminal block so that it does not tilt. • To prevent the screws from being slanted, place the comp. leads in the specified position as shown in the figure, and then tighten the screw according to the following steps. <ol style="list-style-type: none"> (1) Temporary tightening the screws by your hand. (2) Tighten the screws securely with an electric screwdriver. (3) Tighten them with the specified torque using a torque wrench driver. (2.5N•m) * Do not screw the screws slantingly. Otherwise, the comp. leads may burn. • Insert the comp. leads into the sealing material, and attach the terminal cover so that they do not pinch with the terminal cover, and then draw out the comp. leads straightly. • Do not apply excessive stress to the comp. leads. • Do not put the protective tubes in the terminal cover. • Note that the leads do not touch the comp. shell. <ol style="list-style-type: none"> 3) Wrap the soundproof material*1 around the compressor and install the compressor cover *2. (Fig. 17 to 19) <p>*1 Wrap the soundproof material around the compressor so that its bottom is put on the legs of the compressor.</p> <p>*2 Install the compressor cover so that pipes or wires around the comp. do not deform or are caught with the cover.</p>	 <p>White Red Black</p> <p>Draw out the comp. leads straight.</p> <p>[When attaching two compressors for 22, 24 HP] Be sure to wire the comp. lead to the specified compressors.</p> <p>Compressor 1: Wire the longer lead to the left compressor. Compressor 2: Wire the shorter lead to the right compressor.</p>
		<p><8 to 14HP></p>  <p>(soundproof material) Wrap it clockwise.</p> <p>Three legs</p> <p>Fig. 17</p>	
		<p><14A to 20HP></p>  <p>(soundproof material) Wrap it counterclockwise</p> <p>Four legs</p> <p>Fig. 18</p>	
			<p><22 to 24HP></p>  <p>(soundproof material) Wrap it clockwise</p> <p>Three legs x 2 units</p> <p>Fig. 19</p>

No.	Part	Work procedure	Remarks
7	4-way valve - detachment/ attachment	<p>⚠ WARNING</p> <p>Wear a pair of gloves. Otherwise, you will risk an injury involving a replacement part or some other object.</p> <p>1. Detachment</p> <ol style="list-style-type: none"> 1) Carry out work of No. 1 Cabinet and disconnect wires around 4-way valve or move them away from parts to be brazed to prevent them from being fired while brazing. 2) Cut the C, S, or E pipes on the top of the four-way valve, and disconnect the D pipes on the bottom with brazing, and then remove the four-way valve. <p>2. Attachment</p> <p>Carry out installation by following reverse procedure in the detachment 1) to 2).</p>	<p><8 to 14HP></p>  <p><14A to 24HP></p> <p>(Work procedure is the same as that of 8 to 14HP)</p> 

No.	Part	Work procedure	Remarks
8-1	Accumulator - detachment/ attachment <8 to 14HP>	<div data-bbox="336 208 986 338"> <p>⚠ WARNING</p> <p>Wear a pair of gloves. Otherwise, you will risk an injury involving a replacement part or some other object.</p> </div> <div data-bbox="336 376 986 1077"> <p>1. Detachment</p> <ol style="list-style-type: none"> 1) Carry out work of No. 1 Cabinet. 2) Disconnect the wires, pipe fixing rubber, or pipe cover, or move them away from parts to be brazed to prevent them from being fired while brazing. 3) Disconnect the pipe joints (1) with the burner, cut the pipes (Service parts*) (2) and (3) with the pipe cutter, to remove the accumulator as shown in the figure below. * Use the pipes in service parts for installation. 4) Disconnect the pipe joint at the outlet side of the 2-way valve (SV3F) with the burner to take out the accumulator and the 2-way valve. Removing the inlet side joint of the 2-way valve (SV3F) may cause oil leak. 5) Remove the oils in the tank so that they do not remain in the 2-way valve, and disconnect the pipe joint at the inlet side of the 2-way valve (SV3F) with the burner. 6) Braze the 2-way valve piping to new accumulator to install the accumulator into the outdoor unit. </div> <div data-bbox="336 1238 986 1906"> <p>2. Attachment</p> <p>Carry out installation by following reverse procedure in the detachment 1) to 4).</p> </div>	<div data-bbox="1082 544 1390 1171"> </div> <div data-bbox="453 1238 1374 1906"> <div> <p>Space after the pipes are removed at 3)</p> </div> <div> <p>Pipes to be removed at 3)</p> </div> </div>

No.	Part	Work procedure	Remarks
8-2	Accumulator - detachment/ attachment <14A to 24HP>	<p>1. Detachment</p> <ol style="list-style-type: none"> 1) Carry out work of No. 1 Cabinet. 2) Disconnect the wires, pipe fixing rubber, or pipe cover, or move them away from parts to be brazed to prevent them from being fired while brazing. 3) Disconnect the pipe joints (1) with the burner, cut the pipes (Service parts*) (2) and (3) with the pipe cutter, to remove the accumulator as shown in the figure below. * Use the pipes in service parts for installation. * Accessary specifications of the discharge pipe differ at 14 to 20HP and 22 to 24 HP. Check the service part table. 4) Disconnect the pipe joint at the outlet side of the 2-way valve (SV3F) with the burner to take out the accumulator and the 2-way valve. Removing the inlet side joint of the 2-way valve (SV3F) may cause oil leak. 5) Remove the oils in the tank so that they do not remain in the 2-way valve, and disconnect the pipe joint at the inlet side of the 2-way valve (SV3F) with the burner. 6) Braze the 2-way valve piping to a new accumulator to install the accumulator into the outdoor unit. <p>2. Attachment</p> <p>Carry out installation by following reverse procedure in the detachment 1) to 4).</p>	 <p>Space after the pipes are removed at 3)</p>  <p>Pipes to be removed at 3)</p> 

13. P.C. BOARD REPLACEMENT PROCEDURES

13-1. Replacement of outdoor P.C. board & Inverter Parts


13-1-1. List of service parts (Inverter)


Parts code	Description	Applicable model	Parts	Product code	Specifications
43T60437	Power supply terminal block	MMY-MUP0801* MMY-MUP1001* MMY-MUP1201* MMY-MUP1401*	JXO-6004	TERMINAL (75A)	AC600V/75A,4P
43T6W888	Noise Filter P.C. board (1)		MCC-1748	ASM-S-PCB (N/F)	—
43T6W891	Interface P.C. board		MCC-1747	ASM-S-PCB (I/F)	—
43T6W892	Inverter P.C. board for Compressor (1)		MCC-1729	ASM-S-PCB (COMP)	50A
43T6W894	Inverter P.C. board for fan		MCC-1734	ASM-S-PCB (FAN)	—
43T52320	Magnet Contactor		FC-1S	MAG-CONTACTOR	—
43T50345	PTC Thermistor		MZ32-101R	THERMISTOR (PTC)	13A/AC500V


Parts code	Description	Applicable model	Parts	Product code	Specifications
43T60437	Power supply terminal block	MMY-MUP14A1* MMY-MUP1601* MMY-MUP1801* MMY-MUP2001*	JXO-6004	TERMINAL (75A)	AC600V/75A,4P
43T6W889	Noise Filter P.C. board (2)		MCC-1748	ASM-S-PCB (N/F)	—
43T55376	Line filter		—	LINE-FILTER	0.9mH/AC460V/50A
43T6W891	Interface P.C. board		MCC-1747	ASM-S-PCB (I/F)	—
43T6W893	Inverter P.C. board for Compressor (2)		MCC-1729	ASM-S-PCB (COMP)	75A
43T6W894	Inverter P.C. board for fan		MCC-1734	ASM-S-PCB (FAN)	—
43T52322	Magnet Contactor		FC-2S	MAG CONTACTOR	—
43T50345	PTC Thermistor		MZ32-101R	THERMISTOR (PTC)	13A/AC500V

Parts code	Description	Applicable model	Parts	Product code	Specifications
43T60437	Power supply terminal block	MMY-MUP2201* MMY-MUP2401*	JXO-6004	TERMINAL (75A)	AC600V/75A,4P
43T6W889	Noise Filter P.C. board (2)		MCC-1748	ASM-S-PCB (N/F)	—
43T55376	Line filter		—	LINE-FILTER	0.9mH/AC460V/50A
43T6W891	Interface P.C. board		MCC-1747	ASM-S-PCB (I/F)	—
43T6W892	Inverter P.C. board for Compressor (1)		MCC-1729	ASM-S-PCB (COMP)	50A
43T6W894	Inverter P.C. board for fan		MCC-1734	ASM-S-PCB (FAN)	—
43T52320	Magnet Contactor		FC-1S	MAG-CONTACTOR	—
43T50345	PTC Thermistor		MZ32-101R	THERMISTOR (PTC)	13A/AC500V

13-1-2. Configuration of inverter assembly









13-1-3. Interface P.C. Board (MCC-1747) Replacement Procedure

Subject part 43T6W891: ALL model

This Interface service P.C. board is commonly installed in different models. Please perform the change by a model after replacement of a service board.

Included item:

- ① MCC-1747 : 1pcs ② Spacer : 4pcs ③ Spacer : 2pcs ④ Support : 1pcs



- ⑤ Bush : 3pcs




- ⑥ Short Connector : 1pcs




Replacement steps:

- (1) Turn off the power supply of the outdoor unit and wait at least 5 minutes for the capacitor to discharge.
- (2) Remove all of the connectors and wiring for a screw terminal (⑦) which were connected to the interface P.C. board. (Remove the connectors by pulling the connector body. Do not pull the wire.)
- (3) Remove three screws (⑧:2pcs, ⑨:1pcs). (These screws are to be re-used after procedure.)
- (4) Remove the P.C. board from the four spacers (②:4pcs, ③:2pcs)
- (5) Set the DIP switch settings of the service board to match the switch settings of the P.C. board being replaced.



Interface P. C. Board (43T6W891)



DIP Switch

- (6) Using a new spacer (②, ③), a support (④), and a bush (⑤), attach the service board.
- (7) Re-connect the connectors and resin cover, screws (⑧, ⑨), screw terminals (⑦). Be sure that all the connectors and the screw terminals are connected correctly and securely inserted.

The torque of the screws

⑦	Screw terminals	M4 × 10	1.2N•m
⑧	Screw	M3 × 25	0.6N•m
⑨	Screw	M4 × 8	1.2N•m

- (8) The product with HP-SW2 should connect HP-SW2 to CN306. The product without HP-SW2 should connect a short connector to CN306.

Caution: Please do not use a short connector for a product with HP-SW2.


The protection circuit does not operate.

- (9) If a component on the P.C. board is bent during board replacement, adjust it manually ensuring that it is not short-circuited or contact other parts.
- (10) Install the cover, then turn on the power supply.

Appendix 1 Data backup

- 1) The Outdoor DN code (O.DN) data that includes the model settings from the interface P.C. board will automatically be backed up to the Inverter P.C. board for Compressor and Inverter P.C. board for fan.

Data backup




- 2) Data backup will be performed under one of the following conditions.
 - Every hour after power on (when the compressor is stopped)
 - When the outdoor DN code (O.DN) has been changed
Caution should be taken, since the old data for the Inverter P.C. board will be overwritten.
- 3) The same backup data will be saved on each inverter P.C. board
- 4) Data backup prohibition settings
Data backup prohibition settings will be activated when bit 1 on SW106 is turned ON.
Set the data backup prohibition settings if backing up on interface P.C. board is not desired.

SW106	Bit 1	OFF : Normal (Data backup will be performed) ON : Data backup will not be performed on Inverter P.C. board.
-------	-------	--

Appendix 2 Data recovery

- 1) Data recovery will be performed from inverter P.C. board for Compressor 1, and if this fails, recovery will be performed from Compressor 2, Fan 1, and Fan 2, in that order.
If this fails as well, the same data will be saved on each Inverter P.C. board, so data recovery will be done if recovery is successful from any of these Inverter P.C. boards.
Skip this procedure if there is an Inverter P.C. board with a failure.

Data recovery



* Recovery is done if recovery is successful from either of the Inverter O.C. board.

- 2) Perform data recovery within one hour after powering if the Interface P.C. board has been replaced with a Service P.C. board. If one hour elapses after powering, data recovery will not be available since the data for the service P.C. board will be written to the Inverter P.C. board.
If one hour is about to elapse before data recovery, turn the power OFF temporarily for the outdoor unit.
- 3) When performing data recovery, important data such as operating time will be recovered with the outdoor DN code (O.DN), so perform data recovery when replacing the Interface P.C. board, and set the Outdoor DN code (O.DN) manually if this is not possible.

Appendix 3 Model settings for case that data cannot be recovered

The model settings are unset on the service P.C. board, and in an unset state, the check code [L10] will be displayed and operation will not be available.

The model settings will be recovered with the data recovery, but if data recovery cannot be performed, set the Outdoor Unit Function Code (O.DN) [003] manually according to the model name of the outdoor unit. Normal operations may not be available if the settings are different from those before replacing.


Model name	O.DN [003]
Undefined	0000
MMY-MUP0801*****	0001
MMY-MUP1001*****	0002
MMY-MUP1201*****	0003
MMY-MUP1401*****	0004
MMY-MUP14A1*****	0005
MMY-MUP1601*****	0006
MMY-MUP1801*****	0007
MMY-MUP2001*****	0008
MMY-MUP2201*****	0009
MMY-MUP2401*****	0010

For the communication method setting (TCC-LINK / TU2C-LINK), all outdoor units and all indoor units in the same system must have the same settings. The factory setting of the service P.C. board is TCC-LINK communication. Check the DN code of the connected outdoor unit or indoor unit, and if it is set to TU2C-LINK, set the service P.C. board to TU2C-LINK as well.


	Outdoor unit (O.DN) [082]	Indoor unit (I.DN) [FC]
TCC-LINK	0000	0000
TU2C-LINK	0003	0003

Replacement Steps:


- (1) Turn off the power supply of the outdoor unit and wait at least 5 minutes for the capacitor to discharge.
- (2) Remove all of the connector and screw terminal (⑤ : 8pcs) which were connected to the Compressor P.C. board
(Remove the connectors by pulling the connector body. Do not pull the wire.)
- (3) Remove six screws (⑥ : 4pcs, ⑦ : 2pcs).
(These screws are to be re-used after procedure.)
- (4) Remove the P.C. board from the four spacers (②) by round-nose pliers.



- (5) Set the SW800 setting of the service P.C. board to match the switch setting from the original P.C. board.
- (6) Replace spacers (②) and attach collar (④) and bush (③) to the service P.C. board (①).



- (7) Apply the Silicone Thermal Grease to the semiconductors (DB01, IC201) on the service P.C. board, and align the positions of the heat sink holes to mount the Compressor P.C. board on the outdoor control unit. And fix the Compressor P.C. board to the outdoor control unit by the spacers (②).



Uniformly apply the Silicone Thermal Grease to the heat dissipating surfaces of the IPM (IC201) and rectifier (DB01).
Note: Do this work carefully. Please do not soil or scratch the area which attaches the semiconductor of a heat sink.

Silicone Thermal Grease use one of the following

- Momentive Performance Materials "TIG1000"
- Dow Corning Toray "SC102"
- Mizutani Electric Ind "HSC1000"
- Shin-Etsu Chemical "G-746" or "G-747"

- (8) Screw the Compressor P.C. board to the heat sink by the six screws (⑥, ⑦) that were removed in step (3).
If the screws are loose, the semiconductors will generate heat, and cause it to breakdown.
Do not use an electric driver or an air driver.
The semiconductor may receive a damage.
- (9) Re-connect the connectors and screw terminals (⑤).
Be sure that all the connectors and the screw terminals are connected correctly and securely inserted.
- (10) If the components on the P.C. board were bent during board replacement, adjust it manually ensuring that it is not short-circuited or contact other parts.
- (11) Install the cover, then turn on the supply. Check the operation.

The torque of the screws

⑤	Screw terminals	M5 × 10	2.0N•m
⑥	DB01, Q201	M4 × 15	1.2N•m
⑦	Collar and bush	M3 × 25	0.6N•m


13-1-5. Fan-Motor P.C. Board (MCC-1734) Replacement Procedure

Subject part 43T6W894: ALL model

This board is commonly installed in different models. Set the DIP switch (SW800) setting of the service board to the switch setting before replacement.

Included item:

① MCC-1734 : 1pcs




② Spacer : 4pcs




Replacement steps:


- Turn off the power supply of the outdoor unit and wait at least 5 minutes for the capacitor to discharge.
- Remove all of the connector which were connected to the Fan-motor P.C. board. (Remove the connectors by pulling the connector body. Do not pull the wire.)
- Remove two screws (③).
(These screws are to be re-used after procedure.)
- Remove the P.C. board from the four spacers (②) by round-nose pliers.
- Set the SW800 setting of the service P.C. board to match the switch setting from the original P.C. board.
- Apply the Silicone Thermal Grease to the semiconductors (IC300) on the service P.C. board, and align the positions of the heat sink holes to mount the Fan-motor P.C. board on the outdoor control unit. And fix the Fan-motor P.C. board to the outdoor control unit by the spacers (②).



Pinch this part by round-nose pliers for removing the P.C. board



② Spacer



Uniformly apply the Silicone Thermal Grease to the heat dissipating surfaces of the IPM (IC300).
Note: Do this work carefully. Please do not soil or scratch the area which attaches the semiconductor of a heat sink.

Silicone Thermal Grease use one of the following

- Momentive Performance Materials "TIG1000"
- Mizutani Electric Ind "HSC1000"
- Shin-Etsu Chemical "G-746" or "G-747"
- Dow Corning Toray "SC102"

- (8) Screw the Fan-motor P.C. board to the heat sink by the two screws (③) that were removed in step (3).
If the screws are loose, the semiconductors will generate heat, and cause it to breakdown.
Do not use an electric driver or an air driver.
The semiconductor may receive a damage.

The torque of the screws

③	Screw	M3 × 14	0.6N•m
---	-------	---------	--------


- (9) Re-connect the connectors. Be sure that all the connectors are connected correctly and securely inserted.
(10) If the components on the P.C. board were bent during board replacement, adjust it manually ensuring that it is not short-circuited or contact other parts.
(11) Install the cover, then turn on the supply. Check the operation.

13-1-6. Noise Filter P.C. Board 1 (MCC-1748) Replacement Procedure

Subject part 43T6W888: MMY-MUP0801*/1001*/1201*/1401*


Included item:

- ① MCC-1748 : 1pcs ② Spacer : 4pcs ③ Spacer : 2pcs ④ Bush : 6pcs



Replacement Steps:

- (1) Turn off the power supply of the outdoor unit and wait at least 5 minutes for the capacitor to discharge.
(2) Remove all of the connector and solderless terminal tab (CN04), screw terminal (⑦ : 6pcs) which were connected to the Noise Filter P.C. board. Solderless terminal tab need to push lock pin. (Remove the connectors by pulling the connector body. Do not pull the wire.)
(3) Remove eight screws (⑤ : 6pcs, ⑥ : 2pcs). (These screws are to be re-used after procedure.)
(4) Remove the P.C. board from the four spacers (② : 4pcs, ③ : 2pcs).
(5) Using a new spacer (②, ③), a bush (④), attach the service board.
(6) Screw the Noise Filter P.C. board by the eight screws (⑤, ⑥) that were removed in step (3).
(7) Re-connect the connectors and screw terminals (⑦), solderless terminal tab (CN04).
Be sure that all the connectors and the screw terminals are connected correctly and securely inserted.
(10) If the components on the P.C. board were bent during board replacement, adjust it manually ensuring that it is not short-circuited or contact other parts.
(11) Install the cover, then turn on the supply. Check the operation.



The torque of the screws


⑤	Screw	M3 × 18	0.6N•m
⑥	Screw	M4 × 8	1.2N•m
⑦	Screw terminals	M6 × 12	2.5N•m

13-1-7. Noise Filter P.C. Board 2 (MCC-1748) Replacement Procedure

Subject part 43T6W889: MMY-MUP14A1*/1601*/1801*/2001*/2201*/2401*

Included item:



- ① MCC-1748 : 1pcs ② Spacer : 4pcs ③ Spacer : 2pcs ④ Bush : 6pcs



Replacement Steps:

- (1) Turn off the power supply of the outdoor unit and wait at least 5 minutes for the capacitor to discharge.
- (2) Remove all of the connector and solderless terminal tab (CN04, CN05, CN14, CN15, CN24) screw terminal (⑦ : 9pcs), Line-Filter which were connected to the Noise Filter P.C. board. Solderless terminal tab need to push lock pin. (Remove the connectors by pulling the connector body. Do not pull the wire.)
- (3) Remove eight screws (⑤ : 6pcs, ⑥ : 2pcs). (These screws are to be re-used after procedure.)
- (4) Remove the P.C. board from the four spacers (② : 4pcs, ③ : 2pcs).
- (5) Using a new spacer (②, ③), a bush (④), attach the service board.
- (6) Screw the Noise Filter P.C. board by the eight screws (⑤, ⑥) that were removed in step (3).
- (7) Re-connect the connectors and screw terminals (⑦), Line-Filter, solderless terminal tab (CN04, CN05, CN14, CN15, CN24). Be sure that all the connectors and the screw terminals are connected correctly and securely inserted.
- (10) If the components on the P.C. board were bent during board replacement, adjust it manually ensuring that it is not short-circuited or contact other parts.
- (11) Install the cover, then turn on the supply. Check the operation.


Noise Filter P.C. board (43T6W889)



How to remove a Line-filter

- a) Remove the solderless terminal tab. (CN05, CN14, CN15, CN24)
- b) Remove the screw terminal. (CN01, CN02, CN03)
- c) Remove the screw (CN11, CN12, CN13), holding the lower Line-filter (L01).
- d) Remove the screw (CN21, CN22, CN23), holding the upper Line-filter (L02).

*L01 and L02 are the same parts.




The torque of the screws

⑤	Screw	M3 × 18	0.6N•m
⑥	Screw	M4 × 8	1.2N•m
⑦	Screw terminals	M6 × 12	2.5N•m


14. EXPLODED DIAGRAM/PARTS LIST

14-1. Outdoor unit (8, 10, 12, 14HP)


MMY-MUP0801*
MMY-MUP1001*
MMY-MUP1201*
MMY-MUP1401*



For MMY-MUP0801*, MMY-MUP1001*, MMY-MUP1201*,
MMY-MUP1401* model



Outdoor Unit (8, 10, 12, 14HP)
Model: MMY-MUP0801*, MUP1001*, MUP1201*, MUP1401*





Symbol						
Solenoid valve	Capillary tube	Check valve	Check joint	Strainer	Temperature sensor	Distributor


MMY-MUP14A1*
MMY-MUP1601*
MMY-MUP1801*
MMY-MUP2001*




For MMY-MUP14A1*, MMY-MUP1601*, MMY-MUP1801*, MMY-MUP2001* model





Model: MMY-MUP14A1*, MUP1601*, MUP1801*, MUP2001*



14-3. Outdoor unit (22, 24HP)
MMY-MUP2201*
MMY-MUP2401*



For MMY-MUP2201*, MMY-MUP2401* model



Outdoor Unit (22, 24HP)
Model: MMY-MUP2201*, MUP2401*

[illegible]


- 314 -

Ref. No.	Part No.	Description	Q'ty/Set MMY-MUP									
			0801*	1001*	1201*	1401*	14A1*	1601*	1801*	2001*	2201*	2401*
001	43T20341	FAN,PROPELLER, PS741-T	1	1	1	1						
001	43T20359	FAN,PROPELLER, PF581-T					2	2	2	2	2	2
002	43T19374	BELLMOUTH	1	1	1	1						
002	43T19375	BELLMOUTH					2	2	2	2	2	2
003	43T19376	BELL MOUTH, COVER	1	1	1	1						
003	43T19377	BELL MOUTH, COVER					2	2	2	2	2	2
004	43T20360	MOTOR, FAN, ICF-620A1000-1	1	1	1	1	2	2	2	2	2	2
005	43T00817	BESE, MOTOR	1	1	1	1	2	2	2	2	2	2
006	43T00913	CABINET ASSY, SIDE, UP	2	2	2	2	2	2	2	2	2	2
007	43T00812	CABIBET, FRONT, UP	1	1	1	1						
007	43T00819	CABIBET, FRONT, UP					1	1	1	1	1	1
008	43T00914	CABINET ASSY, FRONT,UP	1	1	1	1						
008	43T00915	CABINET ASSY, FRONT,UP					1	1	1	1	1	1
009	43T00814	CABINET, FRONT, LEFT	1	1	1	1						
009	43T00815	CABINET, FRONT, LEFT					1	1	1	1	1	1
010	43T00818	CABINET ASSY, FRONT, RIGHT	1	1	1	1	1	1	1	1	1	1
011	43T00816	CABINET, RIGHT	1	1	1	1						
012	43T00810	PANEL	1	1	1	1	1	1	1	1	1	1
013	43T00808	CABINET, TOP	2	2	2	2						
013	43T00809	CABINET, TOP					2	2	2	2	2	2
015	43T19378	GUARD, FAN	1	1	1	1						
015	43T19379	GUARD, FAN					2	2	2	2	2	2
016	43T41559	COMPRESSOR, LA771A3TB-20M	1	1	1	1						
016	43T41560	COMPRESSOR, LA771A3TB-20M									2	2
016	43T41561	COMPRESSOR, LA1201K4FB-10UC					1	1	1	1		
017	43T43644	CONDENSER ASSY, TWO ROW	1	1	1	1						
017	43T43645	CONDENSER ASSY, TWO ROW, LEFT					1	1	1			
017	43T43646	CONDENSER ASSY, THREE ROW, LEFT								1	1	1
018	43T43647	CONDENSER ASSY, TWO ROW, RIGHT					1	1	1			
018	43T43648	CONDENSER ASSY, THREE ROW, RIGHT								1	1	1
019	43T48314	SEPARATOR, OIL	1	1	1	1						
019	43T48325	SEPARATOR, OIL					1	1	1	1	1	1
020	43T48328	ACCUMULATOR, 24L	1	1	1	1						
020	43T48326	ACCUMULATOR, 28L					1	1	1	1		
020	43T48327	ACCUMULATOR, 28L									1	1
021	43T46445	VALVE, CHECK, UCV-A1506DRQ5	1	1	1	1					2	2
022	43T46446	VALVE, CHECK, UCV-A1507DR					1	1	1	1	1	1
023	43T63388	SWITCH, PRESSURE, ACB-4UB237W	1	1	1	1	1	1	1	1	2	2
024	43T46522	VALVE, PACKED, 12.7	1	1	1	1						
024	43T46520	VALVE, PACKED, 15.88					1	1	1	1		
024	43T46521	VALVE, PACKED, 19.05									1	1
025	43T46393	VALVE, BALL, 25.4	1	1	1	1	1	1	1	1	1	1
026	43T46409	JOINT, CHECK	3	3	3	3	3	3	3	3	3	3
027	43T46452	VALVE, 4WAY, SHF-35B-67-04	1	1	1	1	1	1	1	1	1	1
028	43T46523	COIL, SOLENOID, SQ-A2522G-005368 (HT8*)	1	1	1	1	1	1	1	1	1	1
	43T46524	COIL, SOLENOID, SQ-A2520D-000037 (HT7*)	1	1	1	1	1	1	1	1	1	1
029	43T46447	VALVE, PMV, PAM-BA2YGTF-1	1	1	1	1	1	1	1	1	1	1
030	43T46545	VALVE, PMV, DPF(TS1)2.8C-01	1	1	1	1	2	2	2	2	2	2
031	43T46439	VALVE, PMV, UKV-18D64	1	1	1	1	1	1	1	1	1	1
032	43T46525	COIL, PMV, PAM-MD12TF-303	1	1	1	1	1	1	1	1	1	1
033	43T46539	COIL, ASSY, SERVICE PMV	1	1	1	1	1	1	1	1	1	1
034	43T46451	COIL, PMV, UKV-A376	1	1	1	1	1	1	1	1	1	1
035	43T46539	COIL, ASSY, SERVICE PMV					1	1	1	1	1	1
036	43T46408	VALVE, 2WAY, FDF2A88	2	2	2	2	2	2	2	2	3	3
037	43T46527	VALVE, 2WAY, TEV-S1920DQ50	1	1	1	1	1	1	1	1	1	1
038	43T46528	COIL, VALVE, 2WAY, ASSY, FQ-A0522G-001990 (HT8*)	2	2	2	2	2	2	2	2	3	3
	43T46529	COIL, VALVE, 2WAY, ASSY, FQ-A0520D-001989 (HT7*)	2	2	2	2	2	2	2	2	3	3
039	43T46530	COIL, VALVE, 2WAY, ASSY, TEV-SMOAJ2170B1 (HT8*)	1	1	1	1	1	1	1	1	1	1
	43T46531	COIL, VALVE, 2WAY, ASSY, TEV-SMOAQ2247B1 (HT7*)	1	1	1	1	1	1	1	1	1	1
040	43T50401	SENSOR ASSY, LOW PRESSURE, NSK-BH020F-822	1	1	1	1	1	1	1	1	1	1
041	43T50402	SENSOR ASSY, HIGH PRESSURE, NSK-BH038F-823	1	1	1	1	1	1	1	1	1	1

Ref. No.	Part No.	Description	Q'ty/Set MMY-MUP									
			0801*	1001*	1201*	1401*	14A1*	1601*	1801*	2001*	2201*	2401*
044	43T49348	RUBBER, SUPPORTER, PIPE, DIA 25.4					1	1	1	1	3	3
045	43T49349	RUBBER, SUPPORTER, PIPE, DIA 22.2					5	5	5	5	4	4
046	43T49350	RUBBER, SUPPORTER, PIPE, DIA 19.0	2	2	2	2					3	3
047	43T49351	RUBBER, SUPPORTER, PIPE, DIA 15.9					3	3	3	3	2	2
048	43T49352	RUBBER, SUPPORTER, PIPE, DIA 12.7	2	2	2	2	4	4	4	4	4	4
049	43T49353	RUBBER, SUPPORTER, PIPE, DIA 9.52	1	1	1	1	1	1	1	1	1	1
050	43T49354	RUBBER, SUPPORTER, PIPE, DIA 8.0	1	1	1	1	1	1	1	1	3	3
051	43T49355	RUBBER, SUPPORTER, PIPE, DIA 6.4	2	2	2	2	3	3	3	3	4	4
052	43T49376	RUBBER, SUPPORTER, PIPE, DIA.9.5 - DIA.28.6	1	1	1	1						
052	43T49347	RUBBER, SUPPORTER, PIPE, DIA.6.4 - DIA.28.6					1	1	1	1	1	1
053	43T49377	RUBBER, SUPPORTER, PIPE, DIA.6.4 - DIA.28.6	1	1	1	1	1	1	1	1		
054	43T01333	MARK, TOSHIBA	1	1	1	1	1	1	1	1	1	1
055	43T19380	HOLDER, SENSOR, TO	1	1	1	1	1	1	1	1	1	1
056	43T39351	NUT, FLANGE	1	1	1	1	2	2	2	2	2	2
057	43T39350	WASHER	1	1	1	1	2	2	2	2	2	2
059	43T49357	RUBBER, CUSHION	3	3	3	3					6	6
059	43T49387	RUBBER					4	4	4	4		
060	43T47375	TUBE, CAPILLARY, BYPASS, 1.0×2.0×2000L	1	1	1	1	1	1	1	1	1	1
061	43T19333	HOLDER, SENSOR (TS)	12	12	12	12	14	14	14	14	16	16
062	43T47385	BOLT, COMPRESSOR	3	3	3	3					6	6
062	43T47415	BOLT, COMPRESSOR					4	4	4	4		
063	43T49358	BAND, FIX	3	3	3	3	5	5	5	5	7	7
64	43T85798	OWNERS MANUAL (HT8P-A)										
	43T85794	OWNERS MANUAL (HT8(J)P)	1	1	1	1	1	1	1	1	1	1
	43T85795	OWNERS MANUAL (HT7(J)P)										
065	43T47394	STRAINER, DIA 45.0	1	1	1	1						
066	43T47417	STRAINER, DIA 45.0									1	1
067	43T47395	STRAINER, DIA 50.8					1	1	1	1	1	1
068	43T47388	STRAINER, DIA 12.7	3	3	3	3	3	3	3	3	4	4
069	43T47390	STRAINER, DIA 25.4	3	3	3	3	1	1	1	1	1	1
070	43T47414	STRAINER, DIA 25.4	1	1	1	1	3	3	3	3	3	3
072	43T47428	STRAINER, DIA 28.58					1	1	1	1		
073	43T48329	SCREW, SET	1	1	1	1	1	1	1	1	1	1
074	43T48330	SCREW, SET	1	1	1	1	1	1	1	1	1	1
075	43TN9923	PC BOARD ASSY, NFC	1	1	1	1	1	1	1	1	1	1
076	43T63389	HOLDER, NFC	1	1	1	1	1	1	1	1	1	1
077	43T67314	HEATSINK, ASSY	1	1	1	1						
077	43T67312	HEATSINK, ASSY									1	1
077	43T67313	HEATSINK, ASSY					1	1	1	1		
078	43T58346	REACTOR, CH-105	1	1	1	1	1	1	1	1	2	2
079	43T60534	LEAD, ASSY, COMP					1	1	1	1	1	1
080	43T60535	LEAD, ASSY, COMP	1	1	1	1					1	1
081	43T55375	FILTER, NOISE	2	2	2	2	3	3	3	3	4	4
083	43T50403	SENSOR ASSY, TD1, TK1	1	1	1	1	1	1	1	1	1	1
084	43T50404	SENSOR ASSY, TD2, TK2									1	1
085	43T50405	SENSOR ASSY, TE1, TE2, TG1, TG2	1	1	1	1	1	1	1	1	1	1
086	43T50406	SENSOR ASSY, TE3, TG3					1	1	1	1	1	1
087	43T50407	SENSOR ASSY, TL1, TL2, TL3, TS1, TS3	1	1	1	1	1	1	1	1	1	1
088	43T50424	SENSOR, TO	1	1	1	1	1	1	1	1	1	1
090	43T57314	HEATER, CASE, ASSY, 29W/240V, 2200L	1	1	1	1					1	1
091	43T57315	HEATER, CASE, ASSY, 29W/240V, 1900L									1	1
092	43T57313	HEATER, CASE, ASSY, 29W/240V, 2600L					1	1	1	1		

Inverter Assembly


Model: MMY-MUP0801*, 1001*, 1201*, 1401*



Ref. No.	Part No.	Description	Q'ty/Set
701	43T60437	TERMINAL, 4P	1
702	43T6W888	PC BOARD ASSY, NOISE FILTER, MCC-1748	1
705	43T6W891	PC BOARD ASSY, INTERFACE, MCC-1747	1
706	43T6W892	PC BOARD ASSY, COMP, MCC-1729	1
708	43T6W894	PC BOARD ASSY, FAN, MCC-1734	1
709	43T52320	CONTACTOR, MAGNETIC, FC-1S-Z675	1
711	43T50345	THERMISTOR, PTC	1


Inverter Assembly

Model : MMY-MUP14A1*, 1601*, 1801*, 2001*



Ref. No.	Part No.	Description	Q'ty/Set
701	43T60437	TERMINAL, 4P	1
703	43T6W889	PC BOARD ASSY, NOISE FILTER, MCC-1748	1
704	43T55376	FILTER, LINE	2
705	43T6W891	PC BOARD ASSY, INTERFACE, MCC-1747	1
707	43T6W893	PC BOARD ASSY, COMP, MCC-1729	1
708	43T6W894	PC BOARD ASSY, FAN, MCC-1734	2
710	43T52322	CONTACTOR, MAGNETIC, FC-2SUL	1
711	43T50345	THERMISTOR, PTC	1

Inverter Assembly
Model : MMY-MUP2201*, 2401*



Ref. No.	Part No.	Description	Q'ty/Set
701	43T60437	TERMINAL, 4P	1
703	43T6W889	PC BOARD ASSY, NOISE FILTER, MCC-1748	1
704	43T55376	FILTER, LINE	2
705	43T6W891	PC BOARD ASSY, INTERFACE, MCC-1747	1
706	43T6W892	PC BOARD ASSY, COMP, MCC-1729	2
708	43T6W894	PC BOARD ASSY, FAN, MCC-1734	2
709	43T52320	CONTACTOR, MAGNETIC, FC-1S-Z675	2
711	43T50345	THERMISTOR, PTC	2

CARRIER AIR CONDITIONING (THAILAND) CO., LTD.

144/9 MOO 5, BANGKADI INDUSTRIAL PARK, TIVANON ROAD, TAMBOL BANGKADI,
AMPHUR MUANGPATHUMTHANI, PATHUMTHANI 12000, THAILAND