

Montage de l' AUDIOLANCON6A

1

Copper Foil Tape
30mm
10mm

2

Cable 1 → Boot 2 ←

1- Thread the cable through the hole before installation
2- Then thread the screw through the cable

3

S/FTP 10 mm 30mm Min.
or
U/FTP 10 mm 30mm Min.
F/UTP

4

10 mm 30mm Min.
Copper Foil Tape

5

7/8 4/5 3/6 1/2
4/5 7/8 3/6 1/2
7/8 4/5 3/6 1/2 ✓
7/8 4/5 3/6 1/2 ✗

6

7

5~8mm Max.

8

Cut 1 Cut 2
0.2mm Max.

9

Align

10

Hand screwing
Close 1
2 →
Screw

11

	Solid	Stranded	Cable (O.D.)
C6A	22~24AWG	22~24AWG	7.0~8.5mm