

Table with columns for Taille de l'unité, Extérieur °CBS, and Temp. de l'air intér. (14,0 BH to 24,0 BH). Rows include sizes 20, 25, 32, 40, and 50.

Table with columns for Taille de l'unité, Extérieur °CBS, and Temp. de l'air intér. (14,0 BH to 24,0 BH). Rows include sizes 63, 80, 100, and 125.