

FXNQ-A

Calibre de l'unité	Extérieur °CBS	Temp. de l'air intérieur													
		14,0 BH		16,0 BH		18,0 BH		19,0 BH		20,0 BH		22,0 BH		24,0 BH	
		20,0 BS		23,0 BS		26,0 BS		27,0 BS		28,0 BS		30,0 BS		32,0 BS	
		TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
15	35.0	1.1	1.1	1.4	1.3	1.6	1.4	1.7	1.5	1.8	1.4	1.8	1.4	1.9	1.4
20	35.0	1.5	1.4	1.8	1.6	2.1	1.8	2.2	1.9	2.3	1.9	2.4	1.7	2.4	1.8
25	35.0	1.9	1.6	2.3	1.9	2.6	2.1	2.8	2.1	3.0	2.2	3.0	2.1	3.1	2.0
32	35.0	2.4	1.9	2.9	2.2	3.4	2.4	3.6	2.6	3.8	2.6	3.9	2.5	4.0	2.5
40	35.0	3.0	2.5	3.6	2.8	4.2	3.3	4.5	3.3	4.7	3.2	4.9	3.1	5.0	3.2
50	35.0	3.8	3.1	4.5	3.5	5.2	3.9	5.6	4.0	5.9	4.0	6.0	3.9	6.2	3.7
63	35.0	4.8	3.8	5.7	4.3	6.6	4.8	7.1	4.9	7.5	4.8	7.7	4.8	7.8	4.8

TC: Puissance totale (kW)

SHC: Puissance calorifique sensible (kW)