

## Associations possibles

P= Paire

2= Jumeau

3= Triple

4= Double-jumeau

OU_IO_ID	FAA71AUVEB	FAA100AUVEB	FBA100A2VEB	FBA140A2VEB	FBA35A2VEB9	FBA50A2VEB9	FBA71A2VEB9	FCAG35BVEB	FCAG50BVEB	FCAG71BVEB	FCAG100BVEB	FCAG140BVEB	FCAHG71HVEB	FCAHG100HVEB	FCAHG140HVEB	FDXM35F3V1B9	FDXM50F3V1B9	FFA35A2VEB9	FFA50A2VEB9	FHA100AVEB9	FHA140AVEB9	FHA35AVEB99	FHA50AVEB99	FHA71AVEB99	FUA71AVEB9	FUA100AVEB9	FVA100AMVEB	FVA140AMVEB
RZAG71N7V1B		P	P		3	2		3	2		P			P		3	2	3	2	P		3	2			P	P	
RZAG100N7V1B	2			P	4	3	2	4	3	2		P	2		P	4	3	4	3		P	4	3	2	2			P
RZAG125N7V1B	2			P	4	3	2	4	3	2		P	2		P	4	3	4	3		P	4	3	2	2			P
RZAG140N7V1B	2			P	4	3	2	4	3	2		P	2		P	4	3	4	3		P	4	3	2	2			P
RZAG71N7Y1B		P	P		3	2		3	2		P			P		3	2	3	2	P		3	2			P	P	
RZAG100N7Y1B	2			P	4	3	2	4	3	2		P	2		P	4	3	4	3		P	4	3	2	2			P
RZAG125N7Y1B	2			P	4	3	2	4	3	2		P	2		P	4	3	4	3		P	4	3	2	2			P
RZAG140N7Y1B	2			P	4	3	2	4	3	2		P	2		P	4	3	4	3		P	4	3	2	2			P

## Remarques

1. Lorsque vous associez plusieurs unités intérieures, choisissez comme unité maître l'unité dont la commande à distance dispose du plus de fonction.