






Note: Bulkhead combination must be used on a flat surface of a NEMA 4X Enclosure to maintain rating.



1 Bulkhead Opening Requirements



2 Inside of Enclosure Outside of Enclosure



Coupler Module Removal Instructions

