


# 45° Up/Down UTP TG Modular Jacks & Wire Caps


Part Numbers: CJUDCAPBU-^, CJUDCAPIW-^, CJUDCAPRD-^, CJUD%%88TG\*\*






© Panduit Corp. 2018

Category 6A (CJUDCAPBU-^)




Category 6 (CJUDCAPIW-^)



Category 5e (CJUDCAPRD-^)

**Compatible Jack Modules** 





45° ANGLED JACK CJUD%%88TG\*\* (CAT 6 & 6A ONLY)



STANDARD CJ%%88TG\*\*



SPRING SHUTTERED CJH%%88TG\*\*




KEYED CJK%%88TG\*\*




CORROSION RESISTANT CJE%%88TG\*\*

## **Understanding the Label**


**IMPORTANT!**: Determine the desired direction of cable **before** wiring the cap. The cap, in relation to the jack, **must** be kept consistent throughout the entire termination.



For Technical Support: www.panduit.com/resources/install\_maintain.asp





For Technical Support: www.panduit.com/resources/install\_maintain.asp





For Technical Support: www.panduit.com/resources/install\_maintain.asp

## **Down Orientation**











For Technical Support: www.panduit.com/resources/install\_maintain.asp



For Technical Support: www.panduit.com/resources/install\_maintain.asp

## **REMOVAL STEPS**



### Notes:

- 1. For specified performance, follow TIA/EIA 568-C installation guidelines.
- 2. Jack Modules can terminate 22-26 AWG solid data cable with 0.062" (1.57mm) maximum insulated conductor outside diameter.
- Jack Modules may be re-terminated at least 20 times.
  For technical and performance information, consult Panduit Technical Support.

- As with all Wiring Accessories, the following statements apply:
   Never install communications wiring during a lightning storm.
   Never install communications wiring in wet locations unless the jack is specifically designed for use in wet locations.
   Never touch uninsulated communications wiring or terminals unless the communication line has been disconnected at the network interface.
   Use caution when installing or modifying communication wiring.

For Instructions in Local Languages and Technical Support:

www.panduit.com/resources/install\_maintain.asp



E-mail: techsupport@panduit.com

Phone: 866-405-6654