





Note: Faceplates are limited to UTP connectivity applications.




CFPGEBS9SBL

Module Installation



Optional Box

CFPGEBS9SBL



Holes not to be used for screw mount

Box
(not included)

UT4

*Note: UT4 with no cover used in GES9 service outlets both offered by OBO Betterman Holding GmbH & Co KG.

For Instructions in Local Languages
and Technical Support:

www.panduit.com/resources/install_maintain.asp

PANDUIT

www.panduit.com

E-mail:
techsupport@panduit.com

Phone:
866-405-6654