



S1A4558804

Altivar Machine

ATV32, ATV320

Fan Kits



VZ3V32A100




VZ3V32C100




VZ3V32B100




VZ3V32D100



VZ3V303S2001



VZ3V320S3



VZ3V32E100

ATV32H018M2...H075M2, ATV32H037N4...HU15N4 ATV320U02M2B...U07M2B, ATV320U04N4B...U15N4B	VZ3V32A100
ATV32HU11M2...HU22M2, ATV32HU22N4...HU40N4 ATV320U11M2B...U22M2B, ATV320U22N4B...U40N4B	VZ3V32B100
ATV32HU55N4...HU75N4, ATV320U55N4B...U75N4B, ATV320U55N4C...U75N4C	VZ3V32C100
ATV32HD11N4...HD15N4, ATV320D11N4B...D15N4B, ATV320D11N4C...D15N4C ATV320D11S6C...D15S6C	VZ3V32D100
ATV320U11M2C...U22M2C, ATV320U04N4C...U15N4C, ATV320U07S6C...U15S6C	VZ3V303S2001
ATV320U22N4C...U40N4C, ATV320U22S6C...U40S6C	VZ3V320S3
ATV320D18N4C, ATV320D22N4C	VZ3V32E100



DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

- Only appropriately trained persons who are familiar with and fully understand the contents of the present manual and all other pertinent product documentation and who have received all necessary training to recognize and avoid hazards involved are authorized to work on and with this equipment.
- Installation, adjustment, repair and maintenance must be performed by qualified personnel.
- Verify compliance with all local and national electrical code requirements as well as all other applicable regulations with respect to grounding of all equipment.
- Before performing work and/or applying voltage on the equipment, follow the instructions given in the appropriate installation manual.

Failure to follow these instructions will result in death or serious injury.



CAUTION

SHARP EDGES



Use all necessary personal protective equipment (PPE) such as gloves when performing any type of work whatsoever on or with this product.

Failure to follow these instructions can result in injury or equipment damage.

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this product.
© 2024 Schneider Electric. All Rights Reserved.

**UK
CA**

MANUFACTURER
Schneider Electric Industries SAS
35 rue Joseph Monier
Rueil Malmaison 92500 France


UK REPRESENTATIVE
Schneider Electric Limited
Stafford Park 5
Telford, TF3 3BL United Kingdom

EAC


Опция для продуктов Altivar и Altistart.
Пожалуйста, обратитесь к сообщению о
преобразователе частоты EAC /
программном сартере в приложении к
началу работы, размещенном на веб-сайте
производителя. Авторизованный поставщик в
Республике Казахстан:
ТОО «Шнейдер Электрик»
Адрес: 050010, РК, г. Алматы, пр. Достық, 38,
бизнес-центр «Кен Дала», 5 этаж, левое крыло.
Тел.: +7 (727) 339 23 57
Номер службы поддержки клиентов:
Тел.: +7 (727) 339 24 52

Altivar және Altistart өніміне арналған опция.
Өндірушінің веб-сайтында орналастырылған
«Жұмысқа кірісу» қосымшасындағы EAC жиілік инвертер /
бірқалыпты іске қосу құрылғысы хабарламасына сілтеме
жасауыңызды сұраймыз.
Қазақстан Республикасындағы уәкілетті жеткізуші:
ЖШС «Шнейдер Электрик»
Мекен-жайы: 050010, ҚР, Алматы қаласы, Достық даңғылы,
38, «Кең дала» бизнес орталығы, 5-қабат, сол қанат.
тел.: +7 (727) 339 23 57
Клиенттерге қызмет көрсету нөмірі:
тел.: +7 (727) 339 24 52


VZ3V32A100, VZ3V32B100




1




2




3




4




5




VZ3V32C100




1




2




3




4




5




VZ3V32D100




1



2




3




VZ3V32D100


4




5




VZ3V303S2001




1



2




3




VZ3V303S2001


4




5




VZ3V320S3




VZ3V32E100




1



2




3




VZ3V32E100

4



5




1.4 N·m (12.4 lb.in)