




















0041827, 0040827
0041822, 0040822





- ✓ 0041827, 0040827, 0041822, 0040822
- ✗ 0041812, 0040812





⚡ 220-240V~ + ⚠

LED INDICATION		STATUS		DESCRIPTION
 LED Colour	Status	Flashing		
		 ON	 OFF	
Green				 Battery Connected and Charging
		0.25 sec	0.25 sec	 Functional Test in Progress
		1 sec	1 sec	 Duration Test in Progress
Red				 Lamp Fault
		0.25 sec	0.25 sec	 Battery Fault
		1 sec	1 sec	 Battery Needs Replacement
		1 sec	3 sec	 Battery Temperature Error Temperature above 60±2°C or below 0+2° C
Red/Green				 Emergency Mode

