



2 position key selector switch

Indicator light

Emergency push button

	Contacts	Diagram
Device 1	1NO	1 — 4 2 — LED — 3
Device 2	/	6 — LED — 3
Device 3	2NC	8 — 9 10 — 11

