



Illuminated button spring-return

Illuminated button spring-return

Illuminated button spring-return

Illuminated selector switch 2 positions

Indicator light

Emergency push button

	Contacts	Diagram
Device 1	1NO	A1 — A4 A2 — A3
Device 2	1NO	A1 — A5 A6 — A3
Device 3	1NO	A1 — A7 A12 — A3
Device 4	1NO	B1 — B4 B2 — B3
Device 5	/	B6 — B3
Device 6	2NC	B8 — B9 B10 — B11

Connections

