



↙  
Illuminated  
selector switch  
2 positions

↙  
Illuminated  
selector switch  
2 positions

Indicator light

Illuminated  
button  
spring-return

Illuminated  
button  
spring-return

Non-illuminated  
button  
spring-return

Emergency  
push button

|          | Contacts | Diagram                     |
|----------|----------|-----------------------------|
| Device 1 | 1NO      | A1 — A4<br>A2 — A3<br>LED   |
| Device 2 | 1NO      | A1 — A5<br>A6 — A3<br>LED   |
| Device 3 | /        | A12 — A3<br>LED             |
| Device 4 | 1NO      | B1 — B4<br>B2 — B3<br>LED   |
| Device 5 | 1NO      | B1 — B5<br>B6 — B3<br>LED   |
| Device 6 | 1NO      | B1 — B7<br>B12 — B3<br>LED  |
| Device 7 | 2NC      | B8 — B9<br>B10 — B11<br>LED |

