








	Contacts	Diagram	Connections
Illuminated selector switch 3 positions	Device 1 2NO	A1 — A4 A1 — A10 A2 — A3 LED	
Illuminated selector switch 2 positions	Device 2 1NO	A1 — A5 A6 — A3 LED	
Illuminated selector switch 2 positions	Device 3 1NO	A1 — A7 A8 — A3 LED	
Illuminated button spring-return	Device 4 1NO	A1 — A9 A12 — A3 LED	
Illuminated button spring-return	Device 5 1NO	B1 — B4 B2 — B3 LED	
Illuminated button spring-return	Device 6 1NO	B1 — B5 B6 — B3 LED	
Illuminated button spring-return	Device 7 /	B12 — B3 LED	
Emergency push button	Device 8 2NC+1NO	B8 — B9 B10 — B11 B1 — B7	