



Options

Connection	
A1	Supply input +24 Vdc
A2	Supply input 0 Vdc
IS1	Safety input
OS1	Safety output
IS2	Safety input
OS2	Safety output
IE1	Solenoid activation input for double channel mode
IE2	Solenoid activation input for double channel mode
O3	Signalling output, actuator inserted
O4	Signalling output, actuator inserted and locked
I3	Actuator programming input / reset
I5	EDM input (a)
I4	Solenoid activation input for single channel mode

(a) Available for NS 5... version only

	Contacts	Diagram
Device 1	1NO	B1 — B4
		B2 — B3
Device 2	1NO	B1 — B5
		B6 — B3
Device 3	1NO	B1 — B7
		B12 — B3
Device 4	2NC	B8 — B9
		B10 — B11

