


PRODUCT-DETAILS

6108/06-AP-500

6108/06-AP-500 Push-button coupler 2g AP



Informations générales

Extension du type de produit	6108/06-AP-500
Code de produit	2CKA006133A0225
EAN	4011395210963
Description courte	6108/06-AP-500 Push-button coupler 2g AP
Description longue	For contacting conventional 1gang rocker switches. With middle position. For inserting in the ocean surface-mounted housing. Enclosed mounting plate for the following ranges: Busch-Duro 2000® SI/SI Linear, Reflex SI/SI Linear, future® linear, alpha, solo®, Busch-axcent®, carat® and pure stainless steel. The bus can be connected via enclosed terminal block.

Installation

Instructions et manuels	No document needed
-------------------------	--------------------

Technique

Fiche produit, informations techniques	2CKA001373B8908
Tension nominale (U_r)	24 V
Auxiliary Voltage AC/DC	24 V AC/DC
Compatible Bus Systems	KNX (TP)
Product Range	KNX

Design Range	ocean 63x63 Pure Stainless Steel alpha Busch-balance SI Reflex SI/SI Linear Busch-Duro 2000
Type de montage	Flush Mounted
Nombre de batteries	0

Environnement

Température de l'air ambiant	Operation -25 ... +45 °C
Indice de protection	IP20
Statut RoHS	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
Informations RoHS	2CKA200000E4586
REACH Declaration	2CKA309999E9999
SCIP	e376460c-cd29-4d59-bfba-ad99c6e3048c Germany (DE)
Conflict Minerals Reporting Template (CMRT)	9AKK108468A3363

Dimensions

Produit Largeur Net	71 mm
Produit Hauteur Net	71 mm
Produit Longueur Net	37 mm
Poids net	0.1 kg
Profondeur d'encastrement (t ₂)	33 mm

Commande

ID du produit remplacé	6133-0-0225
------------------------	-------------

Certificats et Déclarations (Numéro de document)

Déclaration de Conformité - CE	2CKA100000E1124
--------------------------------	-----------------

Classifications

ETIM 8	EC002466 - Touch sensor connector for bus system
ETIM 9	EC002466 - Touch sensor connector for bus system
Catégorie DEEE	5. Small Equipment (No External Dimension More Than 50 cm)
WEEE B2C / B2B	Business To Consumer
CN8	8536 50 80

Accessories

Identifiant	Description	Type	Quantity	Unit Of Measure
-------------	-------------	------	----------	-----------------

2CKA001731A2022	Rocker for Venetian blind, Two-part rocker alpine white - Reflex SI/SI Linear	2506 JA/02-214	1	piece
2CKA001731A1999	Mechanical Controls Symbol "bell" for Switch/push button, Single rocker white - Busch-Duro 2000	2506 N/KI-212-500	1	piece
2CKA001731A0538	Rocker with labelling field for Switch/push button, Single rocker alpine white - Reflex SI	2506 N/KI-214	1	piece
2CKA001731A0561	Rocker with labelling field for Switch/push button, Single rocker white - Busch-Duro 2000	2506 N-212	1	piece
2CKA001731A0520	Rocker with labelling field for Switch/push button, Single rocker alpine white - Reflex SI	2506 N-214	1	piece
2CKA001731A1395	Rocker for Switch/push button, Single rocker white - Busch-Duro 2000	2506 O-212	1	piece
2CKA001731A1403	Rocker for Switch/push button, Single rocker alpine white - Reflex SI	2506 O-214	1	piece
2CKA001731A2001	Mechanical Controls Without imprint for Switch/push button, Single rocker white - Busch-Duro 2000	2506-212-500	1	piece
2CKA001731A0322	Mechanical Controls Without imprint for Switch/push button, Single rocker white - Busch-Duro 2000	2506-212-506	1	piece
2CKA001731A1889	Mechanical Controls Without imprint for Switch/push button, Single rocker white - Busch-Duro 2000	2506-212-507	1	piece
2CKA001731A1992	Mechanical Controls Without imprint for Switch/push button, Single rocker alpine white - Reflex SI/SI Linear	2506-214-500	1	piece
2CKA001731A1891	Mechanical Controls Without imprint for Switch/push button, Single rocker alpine white - Reflex SI/SI Linear	2506-214-507	1	piece
2CKA001731A1007	Mechanical Controls Without imprint for Switch/push button, Single rocker black - Reflex SI	2506-215	1	piece
2CKA001731A4012	Rocker for Switch/push button, Single rocker red - Reflex SI	2506-217-101	1	piece
2CKA001751A3145	Rocker for Switch/push button, Single rocker red - 63x63	1786-12-82	1	piece
2CKA001751A3090	Mechanical Controls Without imprint for Switch/push button, Single rocker platinum - alpha	1786-20-500	1	piece
2CKA001751A3086	Mechanical Controls Without imprint for Switch/push button, Single rocker bronze - alpha	1786-21-500	1	piece
2CKA001751A3081	Mechanical Controls Without imprint for Switch/push button, Single rocker ivory - alpha	1786-22G-500	1	piece
2CKA001751A3078	Mechanical Controls Without imprint for Switch/push button, Single rocker studio white - alpha	1786-24G-500	1	piece
2CKA001751A3080	Mechanical Controls Without imprint for Switch/push button, Single rocker palladium - alpha	1786-260-500	1	piece
2CKA001751A3085	Mechanical Controls Without imprint for Switch/push button, Single rocker titanium - alpha	1786-266-500	1	piece
2CKA001753A9976	Mechanical Controls Without imprint for Switch/push button, Single rocker ivory - impuls	1786-72-500	1	piece
2CKA001753A9977	Mechanical Controls Without imprint for Switch/push button, Single rocker alpine white - impuls	1786-74-500	1	piece
2CKA001753A0007	Mechanical Controls Without imprint for Switch/push button, Single rocker alpine white - impuls	1786-74-507	1	piece
2CKA001753A0182	Cover Plate for Switch/push button, Single rocker studio white matt - impuls	1786-774	1	piece
2CKA001753A0183	Mechanical Controls Without imprint for Switch/push button, Single rocker studio white matt - impuls	1786-774-507	1	piece
2CKA001753A0153	Cover Plate for Switch/push button, Single rocker black matt - impuls	1786-775	1	piece

2CKA001753A0067	Cover Plate for Switch/push button, Single rocker aluminium silver - impuls	1786-783	1	piece
2CKA001753A5267	Cover Plate for Switch/push button, Single rocker champagne metallic - impuls	1786-79	1	piece
2CKA001753A0008	Mechanical Controls Without imprint for Switch/push button, Single rocker champagne metallic - impuls	1786-79-507	1	piece
2CKA001751A3093	Mechanical Controls Without imprint for Switch/push button, Single rocker grey metallic - 63x63	1786-803-500	1	piece
2CKA001751A3079	Mechanical Controls Without imprint for Switch/push button, Single rocker anthracite - 63x63	1786-81-500	1	piece
2CKA001751A3083	Mechanical Controls Without imprint for Switch/push button, Single rocker ivory white - 63x63	1786-82-500	1	piece
2CKA001751A3075	Mechanical Controls Without imprint for Switch/push button, Single rocker aluminium silver - 63x63	1786-83-500	1	piece
2CKA001751A3116	Mechanical Controls Without imprint for Switch/push button, Single rocker antique brass - 63x63	1786-840-500	1	piece
2CKA001751A3074	Mechanical Controls Without imprint for Switch/push button, Single rocker studio white - 63x63	1786-84-500	1	piece
2CKA001751A3077	Mechanical Controls Without imprint for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1786-866-500	1	piece
2CKA001751A3089	Mechanical Controls Without imprint for Switch/push button, Single rocker studio white matt - 63x63	1786-884-500	1	piece
2CKA001751A3094	Mechanical Controls Without imprint for Switch/push button, Single rocker black matt - 63x63	1786-885-500	1	piece
2CKA001754A4373	Cover Frame 1gang platinum - alpha exclusive	1721 KA-20	1	piece
2CKA001754A4382	Cover Frame 1gang bronze - alpha exclusive	1721 KA-21	1	piece
2CKA001754A43831	Cover Frame 1gang ivory - alpha exclusive	1721 KA-22G	1	piece
2CKA001754A2965	Cover Frame 1gang studio white - alpha exclusive	1721 KA-24G	1	piece
2CKA001754A4520	Cover Frame 1gang palladium - alpha exclusive	1721 KA-260-500	1	piece
2CKA001754A4509	Cover Frame 1gang titanium - alpha exclusive	1721 KA-266-500	1	piece
2CKA001754A4516	Cover Frame 1gang white - Busch-Duro 2000	1721 NS-212-500	1	piece
2CKA001754A4496	Cover Frame 1gang alpine white - Reflex SI	1721 NS-214-500	1	piece
2CKA001754A4093	Cover Frame 1gang white - Busch-Duro 2000 SI Linear	1721 NSKA-212	1	piece
2CKA001754A4497	Cover Frame 1gang alpine white - Reflex SI Linear	1721 NSKA-214-500	1	piece
2CKA001754A4065	Cover Frame 1gang studio white - alpha exclusive	1721 NSKA-24G	1	piece
2CKA001754A4713	Cover Frame 1gang red - future linear	1721-12-182K-101	1	piece
2CKA001754A4240	Cover Frame 1gang anthracite - future linear	1721-181K	1	piece
2CKA001754A4168	Cover Frame 1gang ivory white - future	1721-182	1	piece
2CKA001754A4506	Cover Frame 1gang ivory white - future linear	1721-182K-500	1	piece
2CKA001754A4529	Cover Frame 1gang aluminium silver - future linear	1721-183K-500	1	piece
2CKA001754A4173	Cover Frame 1gang studio white - future	1721-184	1	piece
2CKA001754A4527	Cover Frame 1gang studio white - future linear	1721-184 NSK-500	1	piece
2CKA001754A4504	Cover Frame 1gang studio white - future	1721-184-500	1	piece

2CKA001754A4498	Cover Frame 1gang studio white - future linear	1721-184K-500	1	piece
2CKA001754A4521	Cover Frame 1gang platinum - alpha nea	1721-20-500	1	piece
2CKA001754A4522	Cover Frame 1gang bronze - alpha nea	1721-21-500	1	piece
2CKA001754A4775	Cover Frame 1gang glass purple - Busch-axcent pur	1721-223	1	piece
2CKA001754A4760	Cover Frame 1gang glass sun - Busch-axcent pur	1721-225	1	piece
2CKA001754A4770	Cover Frame 1gang glass avocado - Busch-axcent pur	1721-226	1	piece
2CKA001754A4765	Cover Frame 1gang glass coral - Busch-axcent pur	1721-227	1	piece
2CKA001754A4755	Cover Frame 1gang glass ocean - Busch-axcent pur	1721-228	1	piece
2CKA001754A4780	Cover Frame 1gang glass oyster - Busch-axcent pur	1721-229	1	piece
2CKA001754A4512	Cover Frame 1gang ivory - alpha nea	1721-22G-500	1	piece
2CKA001754A4790	Cover Frame 1gang paper brown - Busch-axcent pur	1721-243	1	piece
2CKA001754A4800	Cover Frame 1gang glass black - Busch-axcent pur	1721-245	1	piece
2CKA001754A4785	Cover Frame 1gang paper blue - Busch-axcent pur	1721-248	1	piece
2CKA001754A4503	Cover Frame 1gang studio white - alpha nea	1721-24G-500	1	piece
2CKA001754A4400	Cover Frame 1gang palladium - alpha nea	1721-260	1	piece
2CKA001754A4391	Cover Frame 1gang titanium - alpha nea	1721-266	1	piece
2CKA001754A4688	Cover Frame 1gang platinum - Busch-axcent pur	1721-270-500	1	piece
2CKA001754A4708	Cover Frame 1gang black matt - Busch-axcent pur	1721-275-500	1	piece
2CKA001754A4698	Cover Frame 1gang titanium - Busch-axcent pur	1721-276-500	1	piece
2CKA001754A4437	Cover Frame 1gang white glass - Busch-axcent pur	1721-280	1	piece
2CKA001754A4409	Cover Frame 1gang black - Busch-axcent	1721-281	1	piece
2CKA001753A4126	Cover Frame 1gang black - Busch-axcent flat	1721-281/11	1	piece
2CKA001754A4543	Cover Frame 1gang brown glass - Busch-axcent pur	1721-283	1	piece
2CKA001754A4331	Cover Frame 1gang studio white - Busch-axcent	1721-284	1	piece
2CKA001753A4121	Cover Frame 1gang studio white - Busch-axcent flat	1721-284/11	1	piece
2CKA001754A4334	Cover Frame 1gang yellow - Busch-axcent	1721-285	1	piece
2CKA001754A4337	Cover Frame 1gang green - Busch-axcent	1721-286	1	piece
2CKA001754A4340	Cover Frame 1gang red - Busch-axcent	1721-287	1	piece
2CKA001754A4343	Cover Frame 1gang blue - Busch-axcent	1721-288	1	piece
2CKA001754A4805	Cover Frame 1gang slate grey - Busch-axcent pur	1721-290	1	piece
2CKA001754A4471	Cover Frame 1gang entrée grey - Busch-axcent	1721-291-500	1	piece
2CKA001754A4491	Cover Frame 1gang château-black - Busch-axcent	1721-295-500	1	piece
2CKA001754A4795	Cover Frame 1gang concrete grey - Busch-axcent pur	1721-298	1	piece
2CKA001754A4481	Cover Frame 1gang maison-beige - Busch-axcent	1721-299-500	1	piece
2CKA001754A4505	Cover Frame 1gang ivory - impuls	1721-72-500	1	piece
2CKA001754A4514	Cover Frame 1gang chrome - impuls	1721-726-500	1	piece
2CKA001754A4507	Cover Frame 1gang solar gold - impuls	1721-73-500	1	piece
2CKA001754A4513	Cover Frame 1gang alpine white - impuls	1721-74-500	1	piece
2CKA001754A4222	Cover Frame 1gang alpine white - impuls	1721-74-507	1	piece
2CKA001754A4429	Cover Frame 1gang studio white matt - impuls	1721-774	1	piece
2CKA001754A4430	Cover Frame 1gang studio white matt - impuls	1721-774-507	1	piece
2CKA001754A4424	Cover Frame 1gang black matt - impuls	1721-775	1	piece

2CKA001754A4510	Cover Frame 1gang champagne metallic - impuls	1721-79-500	1	piece
2CKA001754A4225	Cover Frame 1gang champagne metallic - impuls	1721-79-507	1	piece
2CKA001754A4535	Cover Frame 1gang chrome - solo	1721-80-500	1	piece
2CKA001754A4538	Cover Frame 1gang chrome gloss - solo	1721-80G-500	1	piece
2CKA001754A4442	Cover Frame 1gang white glass - carat	1721-811	1	piece
2CKA001754A4820	Cover Frame 1gang porcelain anthracite - carat	1721-815	1	piece
2CKA001754A4258	Cover Frame 1gang bronze - carat	1721-821	1	piece
2CKA001754A4356	Cover Frame 1gang gold - carat	1721-823-101	1	piece
2CKA001754A4322	Cover Frame 1gang glass black - carat	1721-825	1	piece
2CKA001754A4360	Cover Frame 1gang chrome - carat	1721-826-101	1	piece
2CKA001754A4605	Cover Frame 1gang anthracite - Busch-Dynasty	1721-831-500	1	piece
2CKA001754A4600	Cover Frame 1gang ivory white - Busch-Dynasty	1721-832-500	1	piece
2CKA001754A4575	Cover Frame 1gang polished brass decor anthracite - Busch-Dynasty	1721-833-500	1	piece
2CKA001754A4565	Cover Frame 1gang polished brass anthracite - Busch-Dynasty	1721-835-500	1	piece
2CKA001754A4570	Cover Frame 1gang polished brass decor ivory white - Busch-Dynasty	1721-836-500	1	piece
2CKA001754A4560	Cover Frame 1gang polished brass ivory white - Busch-Dynasty	1721-838-500	1	piece
2CKA001754A4595	Cover Frame 1gang antique brass decor anthracite - Busch-Dynasty	1721-843-500	1	piece
2CKA001754A4536	Cover Frame 1gang studio white - solo	1721-84-500	1	piece
2CKA001754A4585	Cover Frame 1gang antique brass anthracite - Busch-Dynasty	1721-845-500	1	piece
2CKA001754A4590	Cover Frame 1gang antique brass decor ivory white - Busch-Dynasty	1721-846-500	1	piece
2CKA001754A4580	Cover Frame 1gang antique brass ivory white - Busch-Dynasty	1721-848-500	1	piece
2CKA001754A4254	Cover Frame 1gang stainless steel - carat	1721-860	1	piece
2CKA001754A4500	Cover Frame 1gang stainless steel - Pure Stainless Steel	1721-866K-500	1	piece
2CKA001754A4531	Cover Frame 1gang studio white matt - future linear	1721-884K-500	1	piece
2CKA001754A4532	Cover Frame 1gang black matt - future linear	1721-885K-500	1	piece
2CKA001754A4374	Cover Frame 2gang platinum - alpha exclusive	1722 KA-20	1	piece
2CKA001754A4383	Cover Frame 2gang bronze - alpha exclusive	1722 KA-21	1	piece
2CKA001754A3849	Cover Frame 2gang ivory - alpha exclusive	1722 KA-22G	1	piece
2CKA001754A2999	Cover Frame 2gang studio white - alpha exclusive	1722 KA-24G	1	piece
2CKA001754A4116	Cover Frame 2gang palladium - alpha exclusive	1722 KA-260	1	piece
2CKA001754A4523	Cover Frame 2gang titanium - alpha exclusive	1722 KA-266-500	1	piece
2CKA001754A2239	Cover Frame 2gang white - Busch-Duro 2000	1722 NS-212	1	piece
2CKA001754A2163	Cover Frame 2gang alpine white - Reflex SI	1722 NS-214	1	piece
2CKA001754A4094	Cover Frame 2gang white - Busch-Duro 2000 SI Linear	1722 NSKA-212	1	piece
2CKA001754A4059	Cover Frame 2gang alpine white - Reflex SI Linear	1722 NSKA-214	1	piece
2CKA001754A4066	Cover Frame 2gang studio white - alpha exclusive	1722 NSKA-24G	1	piece
2CKA001754A4714	Cover Frame 2gang red - future linear	1722-12-182K-101	1	piece
2CKA001754A4241	Cover Frame 2gang anthracite - future linear	1722-181K	1	piece
2CKA001754A4169	Cover Frame 2gang ivory white - future	1722-182	1	piece
2CKA001754A4231	Cover Frame 2gang ivory white - future linear	1722-182K	1	piece
2CKA001754A4530	Cover Frame 2gang aluminium silver - future linear	1722-183K-500	1	piece

2CKA001754A4174	Cover Frame 2gang studio white - future	1722-184	1	piece
2CKA001754A4508	Cover Frame 2gang studio white - future	1722-184-500	1	piece
2CKA001754A4499	Cover Frame 2gang studio white - future linear	1722-184K-500	1	piece
2CKA001754A4524	Cover Frame 2gang platinum - alpha nea	1722-20-500	1	piece
2CKA001754A1710	Cover Frame 2gang bronze - alpha nea	1722-21	1	piece
2CKA001754A4776	Cover Frame 2gang glass purple - Busch-axcent pur	1722-223	1	piece
2CKA001754A4761	Cover Frame 2gang glass sun - Busch-axcent pur	1722-225	1	piece
2CKA001754A4771	Cover Frame 2gang glass avocado - Busch-axcent pur	1722-226	1	piece
2CKA001754A4766	Cover Frame 2gang glass coral - Busch-axcent pur	1722-227	1	piece
2CKA001754A4756	Cover Frame 2gang glass ocean - Busch-axcent pur	1722-228	1	piece
2CKA001754A4781	Cover Frame 2gang glass oyster - Busch-axcent pur	1722-229	1	piece
2CKA001754A3799	Cover Frame 2gang ivory - alpha nea	1722-22G	1	piece
2CKA001754A4791	Cover Frame 2gang paper brown - Busch-axcent pur	1722-243	1	piece
2CKA001754A4801	Cover Frame 2gang glass black - Busch-axcent pur	1722-245	1	piece
2CKA001754A4786	Cover Frame 2gang paper blue - Busch-axcent pur	1722-248	1	piece
2CKA001754A4511	Cover Frame 2gang studio white - alpha nea	1722-24G-500	1	piece
2CKA001754A4401	Cover Frame 2gang palladium - alpha nea	1722-260	1	piece
2CKA001754A4392	Cover Frame 2gang titanium - alpha nea	1722-266	1	piece
2CKA001754A4689	Cover Frame 2gang platinum - Busch-axcent pur	1722-270-500	1	piece
2CKA001754A4709	Cover Frame 2gang black matt - Busch-axcent pur	1722-275-500	1	piece
2CKA001754A4699	Cover Frame 2gang titanium - Busch-axcent pur	1722-276-500	1	piece
2CKA001754A4438	Cover Frame 2gang white glass - Busch-axcent pur	1722-280	1	piece
2CKA001754A4410	Cover Frame 2gang black - Busch-axcent	1722-281	1	piece
2CKA001753A4127	Cover Frame 2gang black - Busch-axcent flat	1722-281/11	1	piece
2CKA001754A4544	Cover Frame 2gang brown glass - Busch-axcent pur	1722-283	1	piece
2CKA001754A4332	Cover Frame 2gang studio white - Busch-axcent	1722-284	1	piece
2CKA001753A4122	Cover Frame 2gang studio white - Busch-axcent flat	1722-284/11	1	piece
2CKA001754A4335	Cover Frame 2gang yellow - Busch-axcent	1722-285	1	piece
2CKA001754A4338	Cover Frame 2gang green - Busch-axcent	1722-286	1	piece
2CKA001754A4341	Cover Frame 2gang red - Busch-axcent	1722-287	1	piece
2CKA001754A4344	Cover Frame 2gang blue - Busch-axcent	1722-288	1	piece
2CKA001754A4806	Cover Frame 2gang slate grey - Busch-axcent pur	1722-290	1	piece
2CKA001754A4472	Cover Frame 2gang entrée grey - Busch-axcent	1722-291-500	1	piece
2CKA001754A4492	Cover Frame 2gang château-black - Busch-axcent	1722-295-500	1	piece
2CKA001754A4796	Cover Frame 2gang concrete grey - Busch-axcent pur	1722-298	1	piece
2CKA001754A4482	Cover Frame 2gang maison-beige - Busch-axcent	1722-299-500	1	piece
2CKA001754A4313	Cover Frame 2gang ivory - impuls	1722-72	1	piece
2CKA001754A4134	Cover Frame 2gang chrome - impuls	1722-726	1	piece
2CKA001754A3542	Cover Frame 2gang solar gold - impuls	1722-73	1	piece
2CKA001754A4525	Cover Frame 2gang alpine white - impuls	1722-74-500	1	piece
2CKA001754A4226	Cover Frame 2gang alpine white - impuls	1722-74-507	1	piece
2CKA001754A4431	Cover Frame 2gang studio white matt - impuls	1722-774	1	piece

2CKA001754A4432	Cover Frame 2gang studio white matt - impuls	1722-774-507	1	piece
2CKA001754A4425	Cover Frame 2gang black matt - impuls	1722-775	1	piece
2CKA001754A2528	Cover Frame 2gang champagne metallic - impuls	1722-79	1	piece
2CKA001754A4537	Cover Frame 2gang chrome - solo	1722-80-500	1	piece
2CKA001754A4327	Cover Frame 2gang chrome gloss - solo	1722-80G	1	piece
2CKA001754A4443	Cover Frame 2gang white glass - carat	1722-811	1	piece
2CKA001754A4821	Cover Frame 2gang porcelain anthracite - carat	1722-815	1	piece
2CKA001754A4259	Cover Frame 2gang bronze - carat	1722-821	1	piece
2CKA001754A4357	Cover Frame 2gang gold - carat	1722-823-101	1	piece
2CKA001754A4323	Cover Frame 2gang glass black - carat	1722-825	1	piece
2CKA001754A4361	Cover Frame 2gang chrome - carat	1722-826-101	1	piece
2CKA001754A4606	Cover Frame 2gang anthracite - Busch-Dynasty	1722-831-500	1	piece
2CKA001754A4601	Cover Frame 2gang ivory white - Busch-Dynasty	1722-832-500	1	piece
2CKA001754A4576	Cover Frame 2gang polished brass decor anthracite - Busch-Dynasty	1722-833-500	1	piece
2CKA001754A4566	Cover Frame 2gang polished brass anthracite - Busch-Dynasty	1722-835-500	1	piece
2CKA001754A4571	Cover Frame 2gang polished brass decor ivory white - Busch-Dynasty	1722-836-500	1	piece
2CKA001754A4561	Cover Frame 2gang polished brass ivory white - Busch-Dynasty	1722-838-500	1	piece
2CKA001754A4596	Cover Frame 2gang antique brass decor anthracite - Busch-Dynasty	1722-843-500	1	piece
2CKA001754A4539	Cover Frame 2gang studio white - solo	1722-84-500	1	piece
2CKA001754A4586	Cover Frame 2gang antique brass anthracite - Busch-Dynasty	1722-845-500	1	piece
2CKA001754A4591	Cover Frame 2gang antique brass decor ivory white - Busch-Dynasty	1722-846-500	1	piece
2CKA001754A4581	Cover Frame 2gang antique brass ivory white - Busch-Dynasty	1722-848-500	1	piece
2CKA001754A4255	Cover Frame 2gang stainless steel - carat	1722-860	1	piece
2CKA001754A4501	Cover Frame 2gang stainless steel - Pure Stainless Steel	1722-866K-500	1	piece
2CKA001754A4415	Cover Frame 2gang studio white matt - future linear	1722-884K	1	piece
2CKA001754A4534	Cover Frame 2gang black matt - future linear	1722-885K-500	1	piece
2CKA001754A4376	Cover Frame 3gang platinum - alpha exclusive	1723 KA-20	1	piece
2CKA001754A4385	Cover Frame 3gang bronze - alpha exclusive	1723 KA-21	1	piece
2CKA001754A3856	Cover Frame 3gang ivory - alpha exclusive	1723 KA-22G	1	piece
2CKA001754A3021	Cover Frame 3gang studio white - alpha exclusive	1723 KA-24G	1	piece
2CKA001754A4118	Cover Frame 3gang palladium - alpha exclusive	1723 KA-260	1	piece
2CKA001754A4127	Cover Frame 3gang titanium - alpha exclusive	1723 KA-266	1	piece
2CKA001754A3708	Cover Frame 3gang white - Busch-Duro 2000	1723 NS-212	1	piece
2CKA001754A3724	Cover Frame 3gang alpine white - Reflex SI	1723 NS-214	1	piece
2CKA001754A4096	Cover Frame 3gang white - Busch-Duro 2000 SI Linear	1723 NSKA-212	1	piece
2CKA001754A4061	Cover Frame 3gang alpine white - Reflex SI Linear	1723 NSKA-214	1	piece
2CKA001754A4068	Cover Frame 3gang studio white - alpha exclusive	1723 NSKA-24G	1	piece
2CKA001754A4242	Cover Frame 3gang anthracite - future linear	1723-181K	1	piece
2CKA001754A4170	Cover Frame 3gang ivory white - future	1723-182	1	piece
2CKA001754A4232	Cover Frame 3gang ivory white - future linear	1723-182K	1	piece
2CKA001754A4533	Cover Frame 3gang aluminium silver - future linear	1723-183K-500	1	piece
2CKA001754A4175	Cover Frame 3gang studio white - future	1723-184	1	piece

2CKA001754A4366	Cover Frame 3gang studio white - future linear	1723-184 NSK	1	piece
2CKA001754A4502	Cover Frame 3gang studio white - future linear	1723-184K-500	1	piece
2CKA001754A1637	Cover Frame 3gang platinum - alpha nea	1723-20	1	piece
2CKA001754A1728	Cover Frame 3gang bronze - alpha nea	1723-21	1	piece
2CKA001754A4777	Cover Frame 3gang glass purple - Busch-axcent pur	1723-223	1	piece
2CKA001754A4762	Cover Frame 3gang glass sun - Busch-axcent pur	1723-225	1	piece
2CKA001754A4772	Cover Frame 3gang glass avocado - Busch- axcent pur	1723-226	1	piece
2CKA001754A4767	Cover Frame 3gang glass coral - Busch-axcent pur	1723-227	1	piece
2CKA001754A4757	Cover Frame 3gang glass ocean - Busch-axcent pur	1723-228	1	piece
2CKA001754A3807	Cover Frame 3gang ivory - alpha nea	1723-22G	1	piece
2CKA001754A4792	Cover Frame 3gang paper brown - Busch-axcent pur	1723-243	1	piece
2CKA001754A4802	Cover Frame 3gang glass black - Busch-axcent pur	1723-245	1	piece
2CKA001754A4787	Cover Frame 3gang paper blue - Busch-axcent pur	1723-248	1	piece
2CKA001754A4518	Cover Frame 3gang studio white - alpha nea	1723-24G-500	1	piece
2CKA001754A4403	Cover Frame 3gang palladium - alpha nea	1723-260	1	piece
2CKA001754A4394	Cover Frame 3gang titanium - alpha nea	1723-266	1	piece
2CKA001754A4690	Cover Frame 3gang platinum - Busch-axcent pur	1723-270-500	1	piece
2CKA001754A4710	Cover Frame 3gang black matt - Busch-axcent pur	1723-275-500	1	piece
2CKA001754A4700	Cover Frame 3gang titanium - Busch-axcent pur	1723-276-500	1	piece
2CKA001754A4439	Cover Frame 3gang white glass - Busch-axcent pur	1723-280	1	piece
2CKA001754A4411	Cover Frame 3gang black - Busch-axcent	1723-281	1	piece
2CKA001753A4128	Cover Frame 3gang black - Busch-axcent flat	1723-281/11	1	piece
2CKA001754A4545	Cover Frame 3gang brown glass - Busch-axcent pur	1723-283	1	piece
2CKA001754A4333	Cover Frame 3gang studio white - Busch-axcent	1723-284	1	piece
2CKA001753A4123	Cover Frame 3gang studio white - Busch-axcent flat	1723-284/11	1	piece
2CKA001754A4336	Cover Frame 3gang yellow - Busch-axcent	1723-285	1	piece
2CKA001754A4339	Cover Frame 3gang green - Busch-axcent	1723-286	1	piece
2CKA001754A4342	Cover Frame 3gang red - Busch-axcent	1723-287	1	piece
2CKA001754A4345	Cover Frame 3gang blue - Busch-axcent	1723-288	1	piece
2CKA001754A4807	Cover Frame 3gang slate grey - Busch-axcent pur	1723-290	1	piece
2CKA001754A4473	Cover Frame 3gang entrée grey - Busch-axcent	1723-291-500	1	piece
2CKA001754A4493	Cover Frame 3gang château-black - Busch- axcent	1723-295-500	1	piece
2CKA001754A4797	Cover Frame 3gang concrete grey - Busch-axcent pur	1723-298	1	piece
2CKA001754A4483	Cover Frame 3gang maison-beige - Busch-axcent	1723-299-500	1	piece
2CKA001754A4314	Cover Frame 3gang ivory - impuls	1723-72	1	piece
2CKA001754A4135	Cover Frame 3gang chrome - impuls	1723-726	1	piece
2CKA001754A3591	Cover Frame 3gang solar gold - impuls	1723-73	1	piece
2CKA001754A2437	Cover Frame 3gang alpine white - impuls	1723-74	1	piece
2CKA001754A4433	Cover Frame 3gang studio white matt - impuls	1723-774	1	piece
2CKA001754A4426	Cover Frame 3gang black matt - impuls	1723-775	1	piece
2CKA001754A2536	Cover Frame 3gang champagne metallic - impuls	1723-79	1	piece
2CKA001754A4540	Cover Frame 3gang chrome - solo	1723-80-500	1	piece
2CKA001754A4328	Cover Frame 3gang chrome gloss - solo	1723-80G	1	piece

2CKA001754A4444	Cover Frame 3gang white glass - carat	1723-811	1	piece
2CKA001754A4260	Cover Frame 3gang bronze - carat	1723-821	1	piece
2CKA001754A4358	Cover Frame 3gang gold - carat	1723-823-101	1	piece
2CKA001754A4324	Cover Frame 3gang glass black - carat	1723-825	1	piece
2CKA001754A4362	Cover Frame 3gang chrome - carat	1723-826-101	1	piece
2CKA001754A4607	Cover Frame 3gang anthracite - Busch-Dynasty	1723-831-500	1	piece
2CKA001754A4602	Cover Frame 3gang ivory white - Busch-Dynasty	1723-832-500	1	piece
2CKA001754A4577	Cover Frame 3gang polished brass decor anthracite - Busch-Dynasty	1723-833-500	1	piece
2CKA001754A4567	Cover Frame 3gang polished brass anthracite - Busch-Dynasty	1723-835-500	1	piece
2CKA001754A4572	Cover Frame 3gang polished brass decor ivory white - Busch-Dynasty	1723-836-500	1	piece
2CKA001754A4562	Cover Frame 3gang polished brass ivory white - Busch-Dynasty	1723-838-500	1	piece
2CKA001754A4597	Cover Frame 3gang antique brass decor anthracite - Busch-Dynasty	1723-843-500	1	piece
2CKA001754A4541	Cover Frame 3gang studio white - solo	1723-84-500	1	piece
2CKA001754A4587	Cover Frame 3gang antique brass anthracite - Busch-Dynasty	1723-845-500	1	piece
2CKA001754A4592	Cover Frame 3gang antique brass decor ivory white - Busch-Dynasty	1723-846-500	1	piece
2CKA001754A4582	Cover Frame 3gang antique brass ivory white - Busch-Dynasty	1723-848-500	1	piece
2CKA001754A4256	Cover Frame 3gang stainless steel - carat	1723-860	1	piece
2CKA001754A4319	Cover Frame 3gang stainless steel - Pure Stainless Steel	1723-866K	1	piece
2CKA001754A4416	Cover Frame 3gang studio white matt - future linear	1723-884K	1	piece
2CKA001754A4421	Cover Frame 3gang black matt - future linear	1723-885K	1	piece
2CKA001754A4378	Cover Frame 4gang platinum - alpha exclusive	1724 KA-20	1	piece
2CKA001754A4387	Cover Frame 4gang bronze - alpha exclusive	1724 KA-21	1	piece
2CKA001754A4151	Cover Frame 4gang ivory - alpha exclusive	1724 KA-22G	1	piece
2CKA001754A4155	Cover Frame 4gang studio white - alpha exclusive	1724 KA-24G	1	piece
2CKA001754A4120	Cover Frame 4gang palladium - alpha exclusive	1724 KA-260	1	piece
2CKA001754A4129	Cover Frame 4gang titanium - alpha exclusive	1724 KA-266	1	piece
2CKA001754A4183	Cover Frame 4gang alpine white - Reflex SI/SI Linear	1724 NS-214 MU	1	piece
2CKA001754A4098	Cover Frame 4gang white - Busch-Duro 2000 SI Linear	1724 NSKA-212	1	piece
2CKA001754A4063	Cover Frame 4gang alpine white - Reflex SI Linear	1724 NSKA-214	1	piece
2CKA001754A4243	Cover Frame 4gang anthracite - future linear	1724-181K	1	piece
2CKA001754A4171	Cover Frame 4gang ivory white - future	1724-182	1	piece
2CKA001754A4233	Cover Frame 4gang ivory white - future linear	1724-182K	1	piece
2CKA001754A4309	Cover Frame 4gang aluminium silver - future linear	1724-183K	1	piece
2CKA001754A4176	Cover Frame 4gang studio white - future	1724-184	1	piece
2CKA001754A4367	Cover Frame 4gang studio white - future linear	1724-184 NSK	1	piece
2CKA001754A4238	Cover Frame 4gang studio white - future linear	1724-184K	1	piece
2CKA001754A1645	Cover Frame 4gang platinum - alpha nea	1724-20	1	piece
2CKA001754A1736	Cover Frame 4gang bronze - alpha nea	1724-21	1	piece
2CKA001754A4778	Cover Frame 4gang glass purple - Busch-axcent pur	1724-223	1	piece
2CKA001754A4763	Cover Frame 4gang glass sun - Busch-axcent pur	1724-225	1	piece
2CKA001754A4768	Cover Frame 4gang glass coral - Busch-axcent pur	1724-227	1	piece

2CKA001754A3815	Cover Frame 4gang ivory - alpha nea	1724-22G	1	piece
2CKA001754A4793	Cover Frame 4gang paper brown - Busch-axcent pur	1724-243	1	piece
2CKA001754A4803	Cover Frame 4gang glass black - Busch-axcent pur	1724-245	1	piece
2CKA001754A4788	Cover Frame 4gang paper blue - Busch-axcent pur	1724-248	1	piece
2CKA001754A2908	Cover Frame 4gang studio white - alpha nea	1724-24G	1	piece
2CKA001754A4405	Cover Frame 4gang palladium - alpha nea	1724-260	1	piece
2CKA001754A4396	Cover Frame 4gang titanium - alpha nea	1724-266	1	piece
2CKA001754A4691	Cover Frame 4gang platinum - Busch-axcent pur	1724-270-500	1	piece
2CKA001754A4711	Cover Frame 4gang black matt - Busch-axcent pur	1724-275-500	1	piece
2CKA001754A4701	Cover Frame 4gang titanium - Busch-axcent pur	1724-276-500	1	piece
2CKA001754A4440	Cover Frame 4gang white glass - Busch-axcent pur	1724-280	1	piece
2CKA001754A4412	Cover Frame 4gang black - Busch-axcent	1724-281	1	piece
2CKA001753A4129	Cover Frame 4gang black - Busch-axcent flat	1724-281/11	1	piece
2CKA001754A4546	Cover Frame 4gang brown glass - Busch-axcent pur	1724-283	1	piece
2CKA001754A4346	Cover Frame 4gang studio white - Busch-axcent	1724-284	1	piece
2CKA001753A4124	Cover Frame 4gang studio white - Busch-axcent flat	1724-284/11	1	piece
2CKA001754A4348	Cover Frame 4gang yellow - Busch-axcent	1724-285	1	piece
2CKA001754A4350	Cover Frame 4gang green - Busch-axcent	1724-286	1	piece
2CKA001754A4352	Cover Frame 4gang red - Busch-axcent	1724-287	1	piece
2CKA001754A4354	Cover Frame 4gang blue - Busch-axcent	1724-288	1	piece
2CKA001754A4808	Cover Frame 4gang slate grey - Busch-axcent pur	1724-290	1	piece
2CKA001754A4474	Cover Frame 4gang entrée grey - Busch-axcent	1724-291-500	1	piece
2CKA001754A4494	Cover Frame 4gang château-black - Busch-axcent	1724-295-500	1	piece
2CKA001754A4798	Cover Frame 4gang concrete grey - Busch-axcent pur	1724-298	1	piece
2CKA001754A4484	Cover Frame 4gang maison-beige - Busch-axcent	1724-299-500	1	piece
2CKA001754A4315	Cover Frame 4gang ivory - impuls	1724-72	1	piece
2CKA001754A4136	Cover Frame 4gang chrome - impuls	1724-726	1	piece
2CKA001754A3641	Cover Frame 4gang solar gold - impuls	1724-73	1	piece
2CKA001754A2445	Cover Frame 4gang alpine white - impuls	1724-74	1	piece
2CKA001754A4224	Cover Frame 4gang alpine white - impuls	1724-74-507	1	piece
2CKA001754A4434	Cover Frame 4gang studio white matt - impuls	1724-774	1	piece
2CKA001754A4435	Cover Frame 4gang studio white matt - impuls	1724-774-507	1	piece
2CKA001754A4427	Cover Frame 4gang black matt - impuls	1724-775	1	piece
2CKA001754A2544	Cover Frame 4gang champagne metallic - impuls	1724-79	1	piece
2CKA001754A4223	Cover Frame 4gang champagne metallic - impuls	1724-79-507	1	piece
2CKA001754A4107	Cover Frame 4gang chrome - solo	1724-80	1	piece
2CKA001754A4329	Cover Frame 4gang chrome gloss - solo	1724-80G	1	piece
2CKA001754A4445	Cover Frame 4gang white glass - carat	1724-811	1	piece
2CKA001754A4261	Cover Frame 4gang bronze - carat	1724-821	1	piece
2CKA001754A4359	Cover Frame 4gang gold - carat	1724-823-101	1	piece
2CKA001754A4325	Cover Frame 4gang glass black - carat	1724-825	1	piece
2CKA001754A4363	Cover Frame 4gang chrome - carat	1724-826-101	1	piece
2CKA001754A4608	Cover Frame 4gang anthracite - Busch-Dynasty	1724-831-500	1	piece
2CKA001754A4603	Cover Frame 4gang ivory white - Busch-Dynasty	1724-832-500	1	piece
2CKA001754A4578	Cover Frame 4gang polished brass decor anthracite - Busch-Dynasty	1724-833-500	1	piece

2CKA001754A4568	Cover Frame 4gang polished brass anthracite - Busch-Dynasty	1724-835-500	1	piece
2CKA001754A4573	Cover Frame 4gang polished brass decor ivory white - Busch-Dynasty	1724-836-500	1	piece
2CKA001754A4563	Cover Frame 4gang polished brass ivory white - Busch-Dynasty	1724-838-500	1	piece
2CKA001754A4112	Cover Frame 4gang studio white - solo	1724-84	1	piece
2CKA001754A4598	Cover Frame 4gang antique brass decor anthracite - Busch-Dynasty	1724-843-500	1	piece
2CKA001754A4588	Cover Frame 4gang antique brass anthracite - Busch-Dynasty	1724-845-500	1	piece
2CKA001754A4593	Cover Frame 4gang antique brass decor ivory white - Busch-Dynasty	1724-846-500	1	piece
2CKA001754A4583	Cover Frame 4gang antique brass ivory white - Busch-Dynasty	1724-848-500	1	piece
2CKA001754A4257	Cover Frame 4gang stainless steel - carat	1724-860	1	piece
2CKA001754A4320	Cover Frame 4gang stainless steel - Pure Stainless Steel	1724-866K	1	piece
2CKA001754A4417	Cover Frame 4gang studio white matt - future linear	1724-884K	1	piece
2CKA001754A4422	Cover Frame 4gang black matt - future linear	1724-885K	1	piece
2CKA001754A4380	Cover Frame 5gang platinum - alpha exclusive	1725 KA-20	1	piece
2CKA001754A4389	Cover Frame 5gang bronze - alpha exclusive	1725 KA-21	1	piece
2CKA001754A4153	Cover Frame 5gang ivory - alpha exclusive	1725 KA-22G	1	piece
2CKA001754A4157	Cover Frame 5gang studio white - alpha exclusive	1725 KA-24G	1	piece
2CKA001754A4122	Cover Frame 5gang palladium - alpha exclusive	1725 KA-260	1	piece
2CKA001754A4131	Cover Frame 5gang titanium - alpha exclusive	1725 KA-266	1	piece
2CKA001754A4244	Cover Frame 5gang anthracite - future linear	1725-181K	1	piece
2CKA001754A4172	Cover Frame 5gang ivory white - future	1725-182	1	piece
2CKA001754A4234	Cover Frame 5gang ivory white - future linear	1725-182K	1	piece
2CKA001754A4310	Cover Frame 5gang aluminium silver - future linear	1725-183K	1	piece
2CKA001754A4177	Cover Frame 5gang studio white - future	1725-184	1	piece
2CKA001754A4517	Cover Frame 5gang studio white - future linear	1725-184K-500	1	piece
2CKA001754A1652	Cover Frame 5gang platinum - alpha nea	1725-20	1	piece
2CKA001754A1744	Cover Frame 5gang bronze - alpha nea	1725-21	1	piece
2CKA001754A3823	Cover Frame 5gang ivory - alpha nea	1725-22G	1	piece
2CKA001754A4794	Cover Frame 5gang paper brown - Busch-axcent pur	1725-243	1	piece
2CKA001754A4804	Cover Frame 5gang glass black - Busch-axcent pur	1725-245	1	piece
2CKA001754A2932	Cover Frame 5gang studio white - alpha nea	1725-24G	1	piece
2CKA001754A4407	Cover Frame 5gang palladium - alpha nea	1725-260	1	piece
2CKA001754A4398	Cover Frame 5gang titanium - alpha nea	1725-266	1	piece
2CKA001754A4692	Cover Frame 5gang platinum - Busch-axcent pur	1725-270-500	1	piece
2CKA001754A4712	Cover Frame 5gang black matt - Busch-axcent pur	1725-275-500	1	piece
2CKA001754A4702	Cover Frame 5gang titanium - Busch-axcent pur	1725-276-500	1	piece
2CKA001754A4441	Cover Frame 5gang white glass - Busch-axcent pur	1725-280	1	piece
2CKA001754A4413	Cover Frame 5gang black - Busch-axcent	1725-281	1	piece
2CKA001753A4130	Cover Frame 5gang black - Busch-axcent flat	1725-281/11	1	piece
2CKA001754A4547	Cover Frame 5gang brown glass - Busch-axcent pur	1725-283	1	piece
2CKA001754A4347	Cover Frame 5gang studio white - Busch-axcent	1725-284	1	piece
2CKA001753A4125	Cover Frame 5gang studio white - Busch-axcent flat	1725-284/11	1	piece

2CKA001754A4349	Cover Frame 5gang yellow - Busch-axcent	1725-285	1	piece
2CKA001754A4351	Cover Frame 5gang green - Busch-axcent	1725-286	1	piece
2CKA001754A4353	Cover Frame 5gang red - Busch-axcent	1725-287	1	piece
2CKA001754A4355	Cover Frame 5gang blue - Busch-axcent	1725-288	1	piece
2CKA001754A4809	Cover Frame 5gang slate grey - Busch-axcent pur	1725-290	1	piece
2CKA001754A4475	Cover Frame 5gang entrée grey - Busch-axcent	1725-291-500	1	piece
2CKA001754A4495	Cover Frame 5gang château-black - Busch-axcent	1725-295-500	1	piece
2CKA001754A4799	Cover Frame 5gang concrete grey - Busch-axcent pur	1725-298	1	piece
2CKA001754A4485	Cover Frame 5gang maison-beige - Busch-axcent	1725-299-500	1	piece
2CKA001754A4316	Cover Frame 5gang ivory - impuls	1725-72	1	piece
2CKA001754A4137	Cover Frame 5gang chrome - impuls	1725-726	1	piece
2CKA001754A3690	Cover Frame 5gang solar gold - impuls	1725-73	1	piece
2CKA001754A2452	Cover Frame 5gang alpine white - impuls	1725-74	1	piece
2CKA001754A4436	Cover Frame 5gang studio white matt - impuls	1725-774	1	piece
2CKA001754A4428	Cover Frame 5gang black matt - impuls	1725-775	1	piece
2CKA001754A2551	Cover Frame 5gang champagne metallic - impuls	1725-79	1	piece
2CKA001754A4108	Cover Frame 5gang chrome - solo	1725-80	1	piece
2CKA001754A4330	Cover Frame 5gang chrome gloss - solo	1725-80G	1	piece
2CKA001754A4609	Cover Frame 5gang anthracite - Busch-Dynasty	1725-831-500	1	piece
2CKA001754A4604	Cover Frame 5gang ivory white - Busch-Dynasty	1725-832-500	1	piece
2CKA001754A4579	Cover Frame 5gang polished brass decor anthracite - Busch-Dynasty	1725-833-500	1	piece
2CKA001754A4569	Cover Frame 5gang polished brass anthracite - Busch-Dynasty	1725-835-500	1	piece
2CKA001754A4574	Cover Frame 5gang polished brass decor ivory white - Busch-Dynasty	1725-836-500	1	piece
2CKA001754A4564	Cover Frame 5gang polished brass ivory white - Busch-Dynasty	1725-838-500	1	piece
2CKA001754A4113	Cover Frame 5gang studio white - solo	1725-84	1	piece
2CKA001754A4599	Cover Frame 5gang antique brass decor anthracite - Busch-Dynasty	1725-843-500	1	piece
2CKA001754A4589	Cover Frame 5gang antique brass anthracite - Busch-Dynasty	1725-845-500	1	piece
2CKA001754A4594	Cover Frame 5gang antique brass decor ivory white - Busch-Dynasty	1725-846-500	1	piece
2CKA001754A4584	Cover Frame 5gang antique brass ivory white - Busch-Dynasty	1725-848-500	1	piece
2CKA001754A4321	Cover Frame 5gang stainless steel - Pure Stainless Steel	1725-866K	1	piece
2CKA001754A4418	Cover Frame 5gang studio white matt - future linear	1725-884K	1	piece
2CKA001754A4423	Cover Frame 5gang black matt - future linear	1725-885K	1	piece
2CKA001754A4375	Cover Frame 2gang platinum - alpha exclusive	1732 KA-20	1	piece
2CKA001754A4384	Cover Frame 2gang bronze - alpha exclusive	1732 KA-21	1	piece
2CKA001754A3864	Cover Frame 2gang ivory - alpha exclusive	1732 KA-22G	1	piece
2CKA001754A3054	Cover Frame 2gang studio white - alpha exclusive	1732 KA-24G	1	piece
2CKA001754A4117	Cover Frame 2gang palladium - alpha exclusive	1732 KA-260	1	piece
2CKA001754A4126	Cover Frame 2gang titanium - alpha exclusive	1732 KA-266	1	piece
2CKA001754A2213	Cover Frame 2gang white - Busch-Duro 2000	1732 NS-212	1	piece
2CKA001754A2171	Cover Frame 2gang alpine white - Reflex SI	1732 NS-214	1	piece
2CKA001754A4095	Cover Frame 2gang white - Busch-Duro 2000 SI Linear	1732 NSKA-212	1	piece
2CKA001754A4060	Cover Frame 2gang alpine white - Reflex SI Linear	1732 NSKA-214	1	piece

2CKA001754A4067	Cover Frame 2gang studio white - alpha exclusive	1732 NSKA-24G	1	piece
2CKA001754A4368	Cover Frame 2gang studio white - future linear	1732-184 NSK	1	piece
2CKA001754A1660	Cover Frame 2gang platinum - alpha nea	1732-20	1	piece
2CKA001754A1751	Cover Frame 2gang bronze - alpha nea	1732-21	1	piece
2CKA001754A3757	Cover Frame 2gang ivory - alpha nea	1732-22G	1	piece
2CKA001754A4528	Cover Frame 2gang studio white - alpha nea	1732-24G-500	1	piece
2CKA001754A4402	Cover Frame 2gang palladium - alpha nea	1732-260	1	piece
2CKA001754A4393	Cover Frame 2gang titanium - alpha nea	1732-266	1	piece
2CKA001754A4377	Cover Frame 3gang platinum - alpha exclusive	1733 KA-20	1	piece
2CKA001754A4386	Cover Frame 3gang bronze - alpha exclusive	1733 KA-21	1	piece
2CKA001754A3872	Cover Frame 3gang ivory - alpha exclusive	1733 KA-22G	1	piece
2CKA001754A3088	Cover Frame 3gang studio white - alpha exclusive	1733 KA-24G	1	piece
2CKA001754A4119	Cover Frame 3gang palladium - alpha exclusive	1733 KA-260	1	piece
2CKA001754A4128	Cover Frame 3gang titanium - alpha exclusive	1733 KA-266	1	piece
2CKA001754A3716	Cover Frame 3gang white - Busch-Duro 2000	1733 NS-212	1	piece
2CKA001754A3732	Cover Frame 3gang alpine white - Reflex SI	1733 NS-214	1	piece
2CKA001754A4097	Cover Frame 3gang white - Busch-Duro 2000 SI Linear	1733 NSKA-212	1	piece
2CKA001754A4062	Cover Frame 3gang alpine white - Reflex SI Linear	1733 NSKA-214	1	piece
2CKA001754A4069	Cover Frame 3gang studio white - alpha exclusive	1733 NSKA-24G	1	piece
2CKA001754A4369	Cover Frame 3gang studio white - future linear	1733-184 NSK	1	piece
2CKA001754A1678	Cover Frame 3gang platinum - alpha nea	1733-20	1	piece
2CKA001754A1769	Cover Frame 3gang bronze - alpha nea	1733-21	1	piece
2CKA001754A3765	Cover Frame 3gang ivory - alpha nea	1733-22G	1	piece
2CKA001754A2734	Cover Frame 3gang studio white - alpha nea	1733-24G	1	piece
2CKA001754A4404	Cover Frame 3gang palladium - alpha nea	1733-260	1	piece
2CKA001754A4395	Cover Frame 3gang titanium - alpha nea	1733-266	1	piece
2CKA001754A4379	Cover Frame 4gang platinum - alpha exclusive	1734 KA-20	1	piece
2CKA001754A4388	Cover Frame 4gang bronze - alpha exclusive	1734 KA-21	1	piece
2CKA001754A4152	Cover Frame 4gang ivory - alpha exclusive	1734 KA-22G	1	piece
2CKA001754A4156	Cover Frame 4gang studio white - alpha exclusive	1734 KA-24G	1	piece
2CKA001754A4121	Cover Frame 4gang palladium - alpha exclusive	1734 KA-260	1	piece
2CKA001754A4130	Cover Frame 4gang titanium - alpha exclusive	1734 KA-266	1	piece
2CKA001754A4101	Cover Frame 4gang alpine white - Reflex SI/SI Linear	1734 NS-214 MU	1	piece
2CKA001754A4099	Cover Frame 4gang white - Busch-Duro 2000 SI Linear	1734 NSKA-212	1	piece
2CKA001754A4064	Cover Frame 4gang alpine white - Reflex SI Linear	1734 NSKA-214	1	piece
2CKA001754A4370	Cover Frame 4gang studio white - future linear	1734-184 NSK	1	piece
2CKA001754A1686	Cover Frame 4gang platinum - alpha nea	1734-20	1	piece
2CKA001754A1777	Cover Frame 4gang bronze - alpha nea	1734-21	1	piece
2CKA001754A3773	Cover Frame 4gang ivory - alpha nea	1734-22G	1	piece
2CKA001754A2809	Cover Frame 4gang studio white - alpha nea	1734-24G	1	piece
2CKA001754A4406	Cover Frame 4gang palladium - alpha nea	1734-260	1	piece
2CKA001754A4397	Cover Frame 4gang titanium - alpha nea	1734-266	1	piece
2CKA001754A4381	Cover Frame 5gang platinum - alpha exclusive	1735 KA-20	1	piece
2CKA001754A4390	Cover Frame 5gang bronze - alpha exclusive	1735 KA-21	1	piece
2CKA001754A4154	Cover Frame 5gang ivory - alpha exclusive	1735 KA-22G	1	piece
2CKA001754A4158	Cover Frame 5gang studio white - alpha exclusive	1735 KA-24G	1	piece
2CKA001754A4123	Cover Frame 5gang palladium - alpha exclusive	1735 KA-260	1	piece

2CKA001754A4132	Cover Frame 5gang titanium - alpha exclusive	1735 KA-266	1	piece
2CKA001754A1694	Cover Frame 5gang platinum - alpha nea	1735-20	1	piece
2CKA001754A1785	Cover Frame 5gang bronze - alpha nea	1735-21	1	piece
2CKA001754A3781	Cover Frame 5gang ivory - alpha nea	1735-22G	1	piece
2CKA001754A2833	Cover Frame 5gang studio white - alpha nea	1735-24G	1	piece
2CKA001754A4408	Cover Frame 5gang palladium - alpha nea	1735-260	1	piece
2CKA001754A4399	Cover Frame 5gang titanium - alpha nea	1735-266	1	piece
2CKA001799A0162	Label Holder clear transparent - Reflex SI	1760	1	piece
2CKA001799A0154	Label Holder Without imprint clear transparent - Reflex SI	1761	1	piece
2CKA001730A0275	Cover Frame 1gang brown - Allwetter 44 (IP 44)	2101-31	1	piece
2CKA001730A0258	Cover Frame 1gang white - Allwetter 44 (IP 44)	2101-32	1	piece
2CKA001730A0282	Cover Frame 1gang white - Allwetter 44 (IP 44)	2101-32-500	1	piece
2CKA001730A0276	Cover Frame 1gang aluminium silver - Allwetter 44 (IP 44)	2101-33	1	piece
2CKA001730A0191	Cover Frame 1gang alpine white - Allwetter 44 (IP 44)	2101-34	1	piece
2CKA001730A0281	Cover Frame 1gang alpine white - Allwetter 44 (IP 44)	2101-34-500	1	piece
2CKA001730A0225	Cover Frame 1gang anthracite - Allwetter 44 (IP 44)	2101-35	1	piece
2CKA001730A0277	Cover Frame 2gang brown - Allwetter 44 (IP 44)	2102-31	1	piece
2CKA001730A0266	Cover Frame 2gang white - Allwetter 44 (IP 44)	2102-32	1	piece
2CKA001730A0284	Cover Frame 2gang white - Allwetter 44 (IP 44)	2102-32-500	1	piece
2CKA001730A0278	Cover Frame 2gang aluminium silver - Allwetter 44 (IP 44)	2102-33	1	piece
2CKA001730A0209	Cover Frame 2gang alpine white - Allwetter 44 (IP 44)	2102-34	1	piece
2CKA001730A0283	Cover Frame 2gang alpine white - Allwetter 44 (IP 44)	2102-34-500	1	piece
2CKA001730A0233	Cover Frame 2gang anthracite - Allwetter 44 (IP 44)	2102-35	1	piece
2CKA001730A0279	Cover Frame 3gang brown - Allwetter 44 (IP 44)	2103-31	1	piece
2CKA001730A0274	Cover Frame 3gang white - Allwetter 44 (IP 44)	2103-32	1	piece
2CKA001730A0280	Cover Frame 3gang aluminium silver - Allwetter 44 (IP 44)	2103-33	1	piece
2CKA001730A0217	Cover Frame 3gang alpine white - Allwetter 44 (IP 44)	2103-34	1	piece
2CKA001730A0241	Cover Frame 3gang anthracite - Allwetter 44 (IP 44)	2103-35	1	piece
2CKA001725A0662	Cover Frame 1gang white - Busch-Duro 2000	2511 JH-212	1	piece
2CKA001725A1009	Cover Frame 1gang alpine white - Reflex SI	2511 JH-214	1	piece
2CKA001725A1552	Cover Frame 1gang white - Busch-Duro 2000	2511-212-500	1	piece
2CKA001725A0613	Cover Frame 1gang white - Busch-Duro 2000	2511-212-506	1	piece
2CKA001725A1463	Cover Frame 1gang white - Busch-Duro 2000	2511-212-507	1	piece
2CKA001725A1549	Cover Frame 1gang white - Busch-Duro 2000 SI2511-212K-102 Linear	-500	1	piece
2CKA001725A1536	Cover Frame 1gang alpine white - Reflex SI	2511-214-500	1	piece
2CKA001725A1464	Cover Frame 1gang alpine white - Reflex SI	2511-214-507	1	piece
2CKA001725A1539	Cover Frame 1gang alpine white - Reflex SI2511-214K-102 Linear	-500	1	piece
2CKA001725A1033	Cover Frame 1gang black - Reflex SI	2511-215	1	piece
2CKA001725A1563	Cover Frame 1gang red - Reflex SI	2511-217-101	1	piece
2CKA001725A1531	Cover Frame 1gang entrée grey - Basic55	2511-91-507	1	piece
2CKA001725A1484	Cover Frame 1gang white - Basic55	2511-92-507	1	piece
2CKA001725A1501	Cover Frame 1gang champagne - Basic55	2511-93-507	1	piece

2CKA001725A1479	Cover Frame 1gang alpine white - Basic55	2511-94-507	1	piece
2CKA001725A1506	Cover Frame 1gang château-black - Basic55	2511-95-507	1	piece
2CKA001725A1511	Cover Frame 1gang chalet white - Basic55	2511-96-507	1	piece
2CKA001725A1516	Cover Frame 1gang foyer red - Basic55	2511-97-507	1	piece
2CKA001725A1521	Cover Frame 1gang bistro-blue - Basic55	2511-98-507	1	piece
2CKA001725A1526	Cover Frame 1gang maison-beige - Basic55	2511-99-507	1	piece
2CKA001725A1553	Cover Frame 2gang white - Busch-Duro 2000	2512-212-500	1	piece
2CKA001725A1465	Cover Frame 2gang white - Busch-Duro 2000	2512-212-507	1	piece
2CKA001725A1550	Cover Frame 2gang white - Busch-Duro 2000 SI	2512-212K-102 Linear -500	1	piece
2CKA001725A1537	Cover Frame 2gang alpine white - Reflex SI	2512-214-500	1	piece
2CKA001725A1466	Cover Frame 2gang alpine white - Reflex SI	2512-214-507	1	piece
2CKA001725A1540	Cover Frame 2gang alpine white - Reflex SI	2512-214K-102 Linear -500	1	piece
2CKA001725A1066	Cover Frame 2gang black - Reflex SI	2512-215	1	piece
2CKA001725A1532	Cover Frame 2gang entrée grey - Basic55	2512-91-507	1	piece
2CKA001725A1485	Cover Frame 2gang white - Basic55	2512-92-507	1	piece
2CKA001725A1502	Cover Frame 2gang champagne - Basic55	2512-93-507	1	piece
2CKA001725A1480	Cover Frame 2gang alpine white - Basic55	2512-94-507	1	piece
2CKA001725A1507	Cover Frame 2gang château-black - Basic55	2512-95-507	1	piece
2CKA001725A1512	Cover Frame 2gang chalet white - Basic55	2512-96-507	1	piece
2CKA001725A1517	Cover Frame 2gang foyer red - Basic55	2512-97-507	1	piece
2CKA001725A1522	Cover Frame 2gang bistro-blue - Basic55	2512-98-507	1	piece
2CKA001725A1527	Cover Frame 2gang maison-beige - Basic55	2512-99-507	1	piece
2CKA001725A1554	Cover Frame 3gang white - Busch-Duro 2000	2513-212-500	1	piece
2CKA001725A0639	Cover Frame 3gang white - Busch-Duro 2000	2513-212-506	1	piece
2CKA001725A1468	Cover Frame 3gang white - Busch-Duro 2000	2513-212-507	1	piece
2CKA001725A1551	Cover Frame 3gang white - Busch-Duro 2000 SI	2513-212K-102 Linear -500	1	piece
2CKA001725A1538	Cover Frame 3gang alpine white - Reflex SI	2513-214-500	1	piece
2CKA001725A1541	Cover Frame 3gang alpine white - Reflex SI	2513-214K-102 Linear -500	1	piece
2CKA001725A1090	Cover Frame 3gang black - Reflex SI	2513-215	1	piece
2CKA001725A1533	Cover Frame 3gang entrée grey - Basic55	2513-91-507	1	piece
2CKA001725A1486	Cover Frame 3gang white - Basic55	2513-92-507	1	piece
2CKA001725A1503	Cover Frame 3gang champagne - Basic55	2513-93-507	1	piece
2CKA001725A1481	Cover Frame 3gang alpine white - Basic55	2513-94-507	1	piece
2CKA001725A1508	Cover Frame 3gang château-black - Basic55	2513-95-507	1	piece
2CKA001725A1513	Cover Frame 3gang chalet white - Basic55	2513-96-507	1	piece
2CKA001725A1518	Cover Frame 3gang foyer red - Basic55	2513-97-507	1	piece
2CKA001725A1523	Cover Frame 3gang bistro-blue - Basic55	2513-98-507	1	piece
2CKA001725A1528	Cover Frame 3gang maison-beige - Basic55	2513-99-507	1	piece
2CKA001725A0647	Cover Frame 4gang white - Busch-Duro 2000	2514-212-500	1	piece
2CKA001725A1492	Cover Frame 4gang white - Busch-Duro 2000 SI	2514-212K-102 Linear	1	piece
2CKA001725A1543	Cover Frame 4gang alpine white - Reflex SI	2514-214-500	1	piece
2CKA001725A1497	Cover Frame 4gang alpine white - Reflex SI	2514-214K-102 Linear	1	piece
2CKA001725A1534	Cover Frame 4gang entrée grey - Basic55	2514-91-507	1	piece
2CKA001725A1487	Cover Frame 4gang white - Basic55	2514-92-507	1	piece
2CKA001725A1504	Cover Frame 4gang champagne - Basic55	2514-93-507	1	piece
2CKA001725A1482	Cover Frame 4gang alpine white - Basic55	2514-94-507	1	piece
2CKA001725A1509	Cover Frame 4gang château-black - Basic55	2514-95-507	1	piece

2CKA001725A1514	Cover Frame 4gang chalet white - Basic55	2514-96-507	1	piece
2CKA001725A1519	Cover Frame 4gang foyer red - Basic55	2514-97-507	1	piece
2CKA001725A1524	Cover Frame 4gang bistro-blue - Basic55	2514-98-507	1	piece
2CKA001725A1529	Cover Frame 4gang maison-beige - Basic55	2514-99-507	1	piece
2CKA001725A0654	Cover Frame 5gang white - Busch-Duro 2000	2515-212-500	1	piece
2CKA001725A1467	Cover Frame 5gang white - Busch-Duro 2000	2515-212-507	1	piece
2CKA001725A1493	Cover Frame 5gang white - Busch-Duro 2000 SI Linear	2515-212K-102	1	piece
2CKA001725A0969	Cover Frame 5gang alpine white - Reflex SI	2515-214	1	piece
2CKA001725A1498	Cover Frame 5gang alpine white - Reflex SI Linear	2515-214K-102	1	piece
2CKA001725A1535	Cover Frame 5gang entrée grey - Basic55	2515-91-507	1	piece
2CKA001725A1488	Cover Frame 5gang white - Basic55	2515-92-507	1	piece
2CKA001725A1505	Cover Frame 5gang champagne - Basic55	2515-93-507	1	piece
2CKA001725A1483	Cover Frame 5gang alpine white - Basic55	2515-94-507	1	piece
2CKA001725A1510	Cover Frame 5gang château-black - Basic55	2515-95-507	1	piece
2CKA001725A1515	Cover Frame 5gang chalet white - Basic55	2515-96-507	1	piece
2CKA001725A1520	Cover Frame 5gang foyer red - Basic55	2515-97-507	1	piece
2CKA001725A1525	Cover Frame 5gang bistro-blue - Basic55	2515-98-507	1	piece
2CKA001725A1530	Cover Frame 5gang maison-beige - Basic55	2515-99-507	1	piece
2CKA001726A0222	Decorative Styling Frame attica / pigeon blue - Basic55	2516-901-507	1	piece
2CKA001726A0223	Decorative Styling Frame silver metallic - Basic55	2516-902-507	1	piece
2CKA001726A0224	Decorative Styling Frame light green - Basic55	2516-903-507	1	piece
2CKA001726A0225	Decorative Styling Frame orange - Basic55	2516-904-507	1	piece
2CKA001726A0226	Decorative Styling Frame yellow - Basic55	2516-905-507	1	piece
2CKA001726A0227	Decorative Styling Frame apricot - Basic55	2516-906-507	1	piece
2CKA001726A0228	Decorative Styling Frame luminous - Basic55	2516-907-507	1	piece
2CKA001726A0220	Decorative Styling Frame white - Basic55	2516-92-507	1	piece
2CKA001726A0230	Decorative Styling Frame champagne - Basic55	2516-93-507	1	piece
2CKA001726A0218	Decorative Styling Frame alpine white - Basic55	2516-94-507	1	piece
2CKA001726A0232	Decorative Styling Frame château-black - Basic55	2516-95-507	1	piece
2CKA001726A0234	Decorative Styling Frame chalet white - Basic55	2516-96-507	1	piece
2CKA001719A0111	Cover Frame 1gang white - Busch-Duro 2000	2518-212	1	piece
2CKA001719A0061	Cover Frame 1gang alpine white - Reflex SI	2518-214	1	piece

Catégories

Produits basse tension → Home and Building Automation → KNX → User Operation → Ocean → Push Button Coupling Units with Integrated Bus Coupler

