

# Circulus Maxi















220-240V, 50/60Hz, 30W




1




2




3












4




5



5



6



**NO:** Kan kun installeres og vedlikeholdes av en registrert installasjonsvirksomhet.

**DK:** Må kun installeres og vedligeholdes af uddannet elektriker.

**SE:** Skall installeras och underhållas av behörig elektriker.

**EN:** Only to be installed and maintained by an authorized electrician.

**FR:** Doit être installé et maintenu par un électricien qualifié.

**NL:** Mag alleen geïnstalleerd en onderhouden worden door een bevoegde elektricien.

**DE:** Dieses Produkt darf nur durch autorisiertes Personal (z.B. Elektro-Installateur) angeschlossen, in Betrieb genommen und gewartet werden.

**FI:** Asentaa ja huolttaa saa vain valtuutettu sähköasentaja

**NO:** Skru av strømmen før montering.

**DK:** Sluk for strømmen inden montering.

**SE:** Stäng av strømmen innan montering.

**EN:** Turn off power before installing.


**FR:** Couper le courant avant l'installation.

**NL:** Stroom uitschakelen voor u het toestel installeert.

**DE:** Vor Installationsarbeiten den Strom abschalten.

**FI:** Sammuta virta ennen kytkemistä

**Dipswitch**



|    | ON  | ON  | ON  | Standard |
|----|-----|-----|-----|----------|
|    | 1   | 2   | 1   | 2        |
| mA | 500 | 600 | 700 | 800      |
| Im | 63% | 75% | 88% | 100%     |

**NORWAY**  
SG Armaturen AS

Skytterheia 25  
N-4790 Lillesand

Tel: +47 37 50 03 00  
firmapost@sg-as.no  
www.sg-as.no

**SWEDEN**  
SG Armaturen AB  
Tel: +46 31 81 71 10  
info@sg-ab.se  
www.sg-ab.se

**FINLAND**  
SG Armaturen Oy  
info@sg-oy.fi  
www.sg-oy.fi

**DENMARK**  
SG Armaturen A/S  
Tel: +45 70 70 72 13  
info@sg-as.dk  
www.sg-as.dk

**UNITED KINGDOM**  
SG Lighting LTD  
Tel: +47 37 50 03 00  
info@sglighting.co.uk  
www.sglighting.co.uk

**FRANCE**  
SG Lighting SA/NV  
Tel: +33(0) 4 94 93 00 00  
info.france@sglighting.fr  
www.sglighting.net

**BENELUX**  
SG Lighting SA/NV  
Tel: +32(0) 15 20 72 71  
info.benelux@sglighting.net  
www.sglighting.net

**GERMANY**  
SG Leuchten GmbH  
Tel: +49 40 23 99 44 59  
info@sg-leuchten.de  
www.sg-leuchten.de

**INTERNATIONAL**  
SG Lighting Co Ltd.  
Tel: +86 769 88 49 20 88  
cindy@sgdgc.com  
www.sg-as.com

# ELP Emergency



3h: LDM90HOST + B084

1h: LDM90HOST/1HR + B068

220-240V, 50/60Hz, Self-test



**Installation/Replacement of battery**

Date dd.mm.yy Sign. Signature

Date \_\_\_\_\_ Sign. \_\_\_\_\_

or:

**MAX 2 MONTHS**

|  |         |                               |
|--|---------|-------------------------------|
|  |         | System OK/main operation mode |
|  | 2 sec   | Duration test/comissioning    |
|  | 0,5 sec | Function test                 |
|  |         | LED luminaire fault           |
|  | 2 sec   | Battery/test failure          |
|  | 0,5 sec | Battery charging failure      |

**4-5 years**

Please also consider local requirements.

Rev: 29.05.2019

**NORWAY** SG Armaturen AS  
Tlf: +47 37 50 03 00  
firmapost@sg-as.no  
www.sg-as.no

**SWEDEN** SG Armaturen AB  
Tel: +46 31 81 71 10  
info@sg-ab.se  
www.sg-ab.se

**FRANCE** SG Lighting SA/NV  
Tel: +33(0) 4 94 93 00 00  
info.france@sglighting.fr  
www.sglighting.net

**GERMANY** SG Leuchten GmbH  
Tel: +49 40 23 99 44 59  
info@sg-leuchten.de  
www.sg-leuchten.de

**DENMARK** SG Armaturen A/S  
Tel: +45 70 70 72 13  
info@sg-as.dk  
www.sg-as.dk

**FINLAND** SG Armaturen Oy  
info@sg-oy.fi  
www.sg-oy.fi

**BENELUX** SG Lighting SA/NV  
Tel: +32(0) 15 20 72 71  
info.benelux@sglighting.net  
www.sglighting.net

**INTERNATIONAL** SG Lighting Co Ltd.  
Tel: +86 769 88 49 20 88  
cindy@sgdgc.cn  
www.sg-as.com

Test log



|       |               | 1 <sup>st</sup> year |      | 2 <sup>nd</sup> year |      | 3 <sup>rd</sup> year |      | 4 <sup>th</sup> year |      |
|-------|---------------|----------------------|------|----------------------|------|----------------------|------|----------------------|------|
| Month | Test          | Sign                 | Date | Sign                 | Date | Sign                 | Date | Sign                 | Date |
| 1     | Function test |                      |      |                      |      |                      |      |                      |      |
| 2     | Function test |                      |      |                      |      |                      |      |                      |      |
| 3     | Function test |                      |      |                      |      |                      |      |                      |      |
| 4     | Function test |                      |      |                      |      |                      |      |                      |      |
| 5     | Function test |                      |      |                      |      |                      |      |                      |      |
| 6     | Function test |                      |      |                      |      |                      |      |                      |      |
| 7     | Function test |                      |      |                      |      |                      |      |                      |      |
| 8     | Function test |                      |      |                      |      |                      |      |                      |      |
| 9     | Function test |                      |      |                      |      |                      |      |                      |      |
| 10    | Function test |                      |      |                      |      |                      |      |                      |      |
| 11    | Function test |                      |      |                      |      |                      |      |                      |      |
| 12    | Function test |                      |      |                      |      |                      |      |                      |      |




# ELP Emergency



3h: LDM90HOST + B084

1h: LDM90HOST/1HR + B068

220-240V, 50/60Hz, Self-test



|  |         |                               |
|--|---------|-------------------------------|
|  |         | System OK/main operation mode |
|  | 2 sec   | Duration test/comissioning    |
|  | 0,5 sec | Function test                 |
|  |         | LED luminaire fault           |
|  | 2 sec   | Battery/test failure          |
|  | 0,5 sec | Battery charging failure      |

## NORWAY

SG Armaturen AS

Skytterheia 25  
N-4790 Lillesand

Tel: +47 37 50 03 00  
firmapost@sg-as.no  
www.sg-as.no

## SWEDEN

SG Armaturen AB  
Tel: +46 31 81 71 10  
info@sg-ab.se  
www.sg-ab.se

## FINLAND

SG Armaturen Oy  
Tel: +358 02 07 30 39 60  
info@sg-oy.fi  
www.sg-oy.fi

## DENMARK

SG Armaturen A/S  
Tel: +45 70 70 72 13  
info@sg-as.dk  
www.sg-as.dk

## UNITED KINGDOM

SG Lighting LTD  
Tel: +47 37 50 03 00  
info@sglighting.co.uk  
www.sglighting.co.uk

## FRANCE

SG Lighting SA/NV  
Tel: +33(0) 4 94 93 00 00  
info.france@sglighting.fr  
www.sglighting.net

## BENELUX

SG Lighting SA/NV  
Tel: +32(0) 15 20 72 71  
info.benelux@sglighting.net  
www.sglighting.net

## GERMANY

SG Leuchten GmbH  
Tel: +49 40 23 99 44 59  
info@sg-leuchten.de  
www.sg-leuchten.de

## INTERNATIONAL

SG Lighting Co Ltd.  
Tel: +86 769 88 49 20 88  
cindy@sgdgc.com  
www.sg-as.com

Rev: 28.06.2024

Test log



| Month | Test          | 1 <sup>st</sup> year |      | 2 <sup>nd</sup> year |      | 3 <sup>rd</sup> year |      | 4 <sup>th</sup> year |      |
|-------|---------------|----------------------|------|----------------------|------|----------------------|------|----------------------|------|
|       |               | Sign                 | Date | Sign                 | Date | Sign                 | Date | Sign                 | Date |
| 1     | Function test |                      |      |                      |      |                      |      |                      |      |
| 2     | Function test |                      |      |                      |      |                      |      |                      |      |
| 3     | Function test |                      |      |                      |      |                      |      |                      |      |
| 4     | Function test |                      |      |                      |      |                      |      |                      |      |
| 5     | Function test |                      |      |                      |      |                      |      |                      |      |
| 6     | Function test |                      |      |                      |      |                      |      |                      |      |
| 7     | Function test |                      |      |                      |      |                      |      |                      |      |
| 8     | Function test |                      |      |                      |      |                      |      |                      |      |
| 9     | Function test |                      |      |                      |      |                      |      |                      |      |
| 10    | Function test |                      |      |                      |      |                      |      |                      |      |
| 11    | Function test |                      |      |                      |      |                      |      |                      |      |
| 12    | Function test |                      |      |                      |      |                      |      |                      |      |