

**WXF052**  
Motion detector 2-wire 1.1 m

**WXF051**  
Motion detector 3-wire 1.1 m

gallery

gallery

**Safety instructions**

Electrical equipment may only be installed and assembled by a qualified electrician in accordance with the relevant installation standards, guidelines, regulations, directives, safety and accident prevention regulations of the country.

Failure to comply with these installation instructions may result in damage to the device, fire or other hazards.

These instructions are an integral component of the product and must be retained by the end user.

**Design and layout of the device (Figure 1)**

- (1) Modular supporting ring WXA45.. (not within scope of delivery)
- (2) Motion detectors
- (3) Design cover for motion detector WXD050.. (not within scope of delivery)
- (4) Frame WXP.. (not within scope of delivery)

**Function**

**Correct use**

- Automatic switching of lighting depending on heat motion and ambient brightness
- manual switching via integrated button
- Only suitable for use in indoor areas with no drip and no spray water.
- installation into wall box with at least 40 mm depth

**Product characteristics**

- integrated button for selecting operating modes and special functions
- Lockable integrated button
- Automatic, semi-automatic operating modes can be selected
- Display operating mode via LED
- Potentiometer for setting the response brightness, delay time and detection sensitivity
- Additional adjustment of the response brightness via Teach-In function
- Pulse encoder mode for current pulse/stairwell circuits
- Adjustable detection angle for adaptation of the detection area
- Party function




Figure 1: Design and layout of the device

GB

- Presence simulation
- optional extension unit operation via installation button
- Expansion of detection area possible in the case of WXF051 by means of stair motion detector (master/slave configuration)

**Operating modes**

The motion detector detects heat motion caused by people, animals, or objects.

**Automatic mode**

- The light will be switched on for the delay time, if movements are detected in the detection area and the set brightness threshold is undershot. Each detected movement restarts the delay time.
- The light will be switched off if no additional movements are detected in the detection area and the set delay time has elapsed.

**Semiautomatic mode:**

- The light is switched on manually for the delay time via the button on the device or an extension unit button. Each detected movement or pressed button restarts the delay time.
- The light will be switched off automatically if no additional movements are detected in the detection area and the set delay time has elapsed.

**Operation**

**Operating concept (Fig. 2)**

- (5) Button
  - (6) Status LED (behind lens)
- Operation is executed by pushing the button (5) on the motion detector:

- Keeping the button pressed activates special functions. Selection of the special functions is supported by the LED display (Fig. 3).
- Automatic mode:**
- A short press of the button switches the operating modes. The operating mode is displayed via the status LED behind the optics cover of the motion detector.

**Semiautomatic mode:**

- A short press of the button switches the lighting on




Figure 2: Operating and display elements

Funktion	Party function	Teach-In	Keylock	Presence simulation
LED display	Red	orange	Green	red
Hold time, operation button	> 5 s	>10 s	> 15 s	> 20 s

Figure 3: Selection of the special functions and LED display

**Selecting switching type via button (automatic mode)**

The operation button is not disabled (see Disabling/enabling switching type selection via button).

- Briefly press the button (5) repeatedly until the desired switching type is selected. (Table 1)

The status LED (6) indicates the selected switching type.

Button operation	LED display	Switching type
■ Repeated short press on button	—	Automatic
	green	Permanent ON
	red	Permanent OFF

Tabelle 1: Selection of switching type and LED display

**Disabling/enabling switching type selection via button**

The selection of the switching type via the button can be locked, e.g. for operation in public buildings.

- Keep the button pressed for more than 15 seconds, until the status LED is flashing green (Fig. 3).

Selection of the switching type via the button is disabled.

or if the button is locked:

- Keep the button pressed for more than 15 seconds, until the status LED is flashing green (Fig. 3).

Selection of the switching type via the button is possible again.




Figure 4: Installation location of the motion detectors and motion orientation

**Switch on lighting via push-button extension unit (table 2)**

Optionally the lighting can be switched on via a mechanical push-button extension unit. For extension unit operation, the lighting is switched on independently of the set response brightness.

Lighting state	Operation button	Performance of the insert
OFF	Short press	Load is switched on for the set delay time
ON	Short press	Extension of switch-on time by the set delay time

Tabelle 2: Operation via push-button extension unit

**Activating/interrupting party function**

The party function switches the lighting on for 2 hours. During this time no extension unit commands are executed.

- Keep the button pressed for more than 5 seconds, until the status LED is flashing red (Fig. 3).

The lighting is switched on for 2 hours. During this time the status LED is flashing red. Upon elapse of 2 hours, the motion detector switches to automatic/semi-automatic operation mode.

- Briefly press the button or extension unit.

The party function will be cancelled, the motion detector returns to automatic/semi-automatic operation mode.

**Activating/deactivating presence simulation**

During operation, the motion detector counts the motion detections in one full hour and saves the result. With active presence simulation at the beginning of the hour with the most detections saved, the light will be switched on for the duration of the delay time, even no motion is detected.

During the presence simulation, presence detection and extension unit commands will continue to be executed normally.




Figure 5: Detection area of the motion detector with nominal installation height 1.1 m

The presence simulation cannot be activated via the extension unit.

- Keep the button pressed for more than 20 seconds, until the status LED is slowly flashing red (figure 3).

The presence simulation is active. During this time the status LED lights orange. The motion detector switches the lighting on at the saved time.

To deactivate presence simulation:

- While presence simulation is active, keep the button pressed for more than 20 seconds, until the status LED is slowly flashing red (Fig. 3).

The presence simulation will be deactivated and the orange status LED will go out. The motion detector returns to the automatic/semi-automatic operating mode.

**Installation and electrical connection**

**Selecting installation location**

- Note recommended installation height of 1.1 m.
- Observe the motion orientation: a distinction is made between "direct approach" and "transverse motion". Motions transverse to the motion detector can be detected better than motions toward the motion detector (figure 4, figure5).
- Select an installation location that is free of vibration. Vibrations can cause undesired switching.
- Avoid sources of interference in the detection area (Fig. 5). Sources of interference, e.g. heating elements, ventilation systems, air conditioners and lamps that are cooling down can cause undesired switching (Fig. 4).

To avoid disturbing influences, the detection angle can be restricted (see Restriction of the detection area).

**DANGER!**  
Touching live parts can result in an electric shock!  
An electric shock can be lethal!  
Disconnect the connecting cables before working on the device and cover all live parts in the area!

**Connecting and installing the device**

- Screw supporting ring (1) to a wall box in the correct position.
- Connect motion detector (2) according to the connecting diagram (figure 6/7)
- Connecting the optional N-conductor on the 2-wire device has advantages for the switching performance in the case of LED loads and transformers.
- Snap motion detector (2) into the supporting ring.
- Snap cover (3).
- Fit frame (4).

**Commissioning**

**Basic settings**

The basic settings for commissioning can be made directly using the motion detector operating




Fig. 6: Connection of 2-wire motion detector




Fig. 7: Connection of 3-wire motion detector




Figure 8: Dismantling of cover




Figure 9: Operation and adjustment elements




Figure 10: Setting the detection angle

elements. The operating elements for commissioning are located underneath the cover (3).

**Removing cover**

- Remove cover by Hand. (Figure 8).

**Overview of operation and adjustment elements (figure 9)**

- (7) Button
- (8) Status LED
- (9) Detection angle adjuster
- (10) Response brightness potentiometer
- (11) Delay time potentiometer
- (12) Sensitivity potentiometer

**Setting the detection area**

The detection angle can be restricted for the right side and for the left side via each adjuster (figure 9, 9) between 45° ... 90° for each adjuster. This can be carried out on the device. Thus the detection angle can be between 90° and 180° (Fig. 10).

- Use the adjusters to set the detection angle for each side.

Further adjustments can be made to the detection area by activating/deactivating the motion sensors (see Setting the function of the detection sensors).

**Setting the detection performance**

Test mode must be used to test the detection performance. In test mode, the motion detector works independent of brightness. Each detection switches the lighting and status LED on for 1 second. Thereafter motion detection will be deactivated for 2 seconds.

The motion detector is connected and ready for operation.

- Set the response brightness potentiometer (Fig. 9, 10) to Test (T).

- Leave the detection area and observe the switching behaviour.

If the motion detector switches on without motion in the detection area, then sources of interference are present (see Installation location).

- Reduce the sensitivity if necessary and blank out sources of interference by adjusting the detection angle or removing them.

- Check the detection area using a detection test and adjust if necessary.

Test mode ends if no movement is detected for 3 minutes or a brightness value is set.

If the detection area of a motion detector is too small, it can be extended in the case of WXF051 by using stair motion detectors as extension units.

