

LL120Z MB-SW 2xEP CU7 WH


Mounting instructions

Instructions de montage
Montageanleitung
Montage instrukcija
Instruzioni di montaggio

Instrucciones de montaje
Instruções de montagem
Monteringsinstruktioner
Monteringsvejledning

Kokoonpano- ja kiinnitysohjeet
Montaj yönergeleri
Szerelési utasítások
Instrukcja montażu

Návod k montáži
Návod k montáži



~220V...240V
50 Hz/60 Hz



IP20

