



Instruction Leaflet
Montageanweisung
Notice d'installation
Instrucciones de montaje
Istruzioni per il montaggio
安装说明
Инструкция по монтажу

Montagehandleiding
Montagevejledning
Οδηγίες εγκατάστασης
Instruções de montagem
Monteringsanvisning
Asennusohje
Návod k montáži

Paigaldusjuhend
Szerelési utasítás
Montážas instrukcija
Montavimo instrukcija
Instrukcija montažu
Navodila za montažo
Návod na montáž

Монтажни инструкции
Instruccioni de montaj
Upute za montažu
Kullanma Talimatı
Инструкција за монтажу
Intruksjonsblad
Монтажна інструкція

PBHT-F

<p>2p</p>	<p>4p</p>
<p>80 A — 16mm² (400mm) 125 A — 35mm² (400mm)</p>	<p>0,5 Nm</p>
<p>PBHT OFF</p>	<p>PBHT + PLHT => OFF</p>
<p>1 2 3 Click</p>	<p>TEST every 6 months</p>
<p>PBHT/4P + PLHT/3P = 7-pole configuration</p>	

