
Photo



Descriptions

The catalyst coating on the honeycomb-structured frame captures small foul-smelling substances in the air, then breaks down the source of the odors with the power of the ozone generated in a plasma electrode unit.

pplicable Models

- MSZ-RW25VG
- MSZ-RW35VG
- MSZ-RW50VG
- MSZ-LN18VG2W
- MSZ-LN18VG2V
- MSZ-LN18VG2B
- MSZ-LN18VG2R
- MSZ-LN25VG2W
- MSZ-LN25VG2V
- MSZ-LN25VG2B
- MSZ-LN25VG2R


- MSZ-LN35VG2V
- MSZ-LN35VG2B
- MSZ-LN35VG2R
- MSZ-LN50VG2W
- MSZ-LN50VG2V
- MSZ-LN50VG2B
- MSZ-LN50VG2R
- MSZ-LN60VG2W
- MSZ-LN60VG2V
- MSZ-LN60VG2B
- MSZ-LN60VG2R
- MSZ-LN35VG2W

Specifications

	Filter: Aluminium Catalyst: MnO ₂ , SiO ₂ Frame: Polypropylen
Color (Filter)	Black

Dimensions

Unit : mm



How to Use / How to Install

Replacement of the air cleaning filter



- 1. Open the front panel.
- Note: You cannot remove the front panel.
- 2. Rotate the stoppers as indicated by the arrows until they click.
- 3. Lower the front panel slowly and it will be held open with the stoppers.
- 4. Pinch the tabs on the filters; slightly push them up and pull down toward you to remove the air cleaning filters
- 5. Install the new air cleaning filters
- 6. Close the front panel securely and press the positions indicated by the arrows.



Every 3 months:

- Remove dirt by a vacuum cleaner, or soak the framed filter in lukewarm water (30 to 40°C) for about 15 minutes. Rinse well.
- After washing, dry it well in shade.
- Deodorizing feature recovers by cleaning the filter.

When dirt or smell cannot be removed by cleaning:

· Replace it with a new air cleaning filter

