






SIDE VIEW

63-160 A

CABLE GLAND
 ISO 16 max: 14
 ISO 21 max: 10
 ISO 25 max: 6
 ISO 40 max: 3
 ISO 50 max: 2


BACK VIEW



CABLE GLAND
 ISO 16 max: 14
 ISO 21 max: 9
 ISO 25 max: 6
 ISO 40 max: 2
 ISO 50 max: 1


250 A

SIDE VIEW






CABLE GLAND
 ISO 16 max: 17
 ISO 21 max: 13
 ISO 25 max: 7
 ISO 40 max: 3
 ISO 50 max: 2

BACK VIEW




CABLE GLAND
 ISO 16 max: 20
 ISO 21 max: 12
 ISO 25 max: 9
 ISO 40 max: 2
 ISO 50 max: 1





63 A



63 A




2 Nm

PZ 2

PH 2

160 A




125 - 160 A



4 Nm

CH 4

250 A








250 A




4 Nm

CH 4


D




BOTTOM VIEW





10





E



PE




FE



XCP

13








CLOSE

CH8
2 Nm



14

15



3 Nm
PH2






XCM



14



15



Quando si installa la cassetta sulla linea XCM basso (160/250/315A AL e 250/315/400A CU) sono da togliere

When installing the tap of box on the low XCM (160/250/315A AL and 250/315/400A CU) they must be removed