

## WARNING

- This is a RDM DMX fixture .
- DMX addressing can be done with a RDM address writer connected on DMX input.
- Use Targetti address writer cod. 1E2767 or any RDM compatible address writer .
- Addressing should be made before final installation. RDM functionality could be not available due presence of not compatible RDM buffer/ splitter on final installation.
- This fixture has a diagnostic function :  
Powered fixtures that doesn't receive DMX signal for more than 10 seconds turn on red light at 25%.

This help to perform first power wiring check (without connect any DMX controller) and after to find incorrect DMX wiring fixtures.  
Always terminate DMX lines with 120 ohm 5% 1/4W resistor