
5 Channels RF receiver

09.09EAPD5.04704

Important: *Read All Instructions Prior to Installation*

Function introduction



Product Data

Input Voltage	Output Current	Output Power	Remarks	Size(LxWxH)
12-36VDC	5x5A	5x(60-180)W	Constant voltage	170x59x29mm

- Radio Frequency : 869.5/916.5/434mhz
- Waterproof grade: IP20

Safety & Warnings

- DO NOT install with power applied to device.
- DO NOT expose the device to moisture.


Pair/delete the pairing with RF remote

1.Do wiring according to connection diagram.
2.Pair RF Receiver with RF remote: please refer to the instruction of the remote that you would like to pair with.
3.Delete the pairing:
(1)Wire up the RF receiver correctly, power on.
(2)Press and hold down the **" Learning Key"** button on receiver for over 3 seconds until the connected light flashes, which means well deleted.

Receiver/Repeater setting jumper:

One receiver can connect multiple repeaters to realize perfect sync the sync distance can be over 100m no volt drop.

Wiring Diagram



Product Dimension

