


User Guide

Danfoss Δp Tool for RA-DV, RA-N, RA-U, Danfoss BIV



^{*} Steady height by all measurements





User Guide Danfoss Δp Tool for *Dynamic Valve*™ Type RA-DV


Pump Optimization with the Danfoss Δp Tool (example)


Make sure: 1) the pump is set in constant pressure


2) all the valves in the system are fully open

















7.


If the differential pressure **is constant** (XX=YY)* go one level down in the pump setting → DONE

If the differential pressure is not constant (XX≠YY) increase the pump setting and measure again. See 8 to 11.









Repeat 8-11 until the differential pressure is constant (AA=BB)*. Go one level down in the pump setting DONE

Danfoss Installer App Android ► Google Play iPhone ► App Store

Iller App
ogle Play
n Store

Danfoss ΔP Tool
YouTube video





Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed.

All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

VUFQA402 / 013R9583

^{*} The measured value at constant differential pressure is between 6 to 10 kPa