



THIS COPY IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTERESTS OF PANDUIT CORP. RAIL REMOVAL AND INSTALLATION FIGURE 1 RAIL REMOVAL STEPS (See Figure 1) RAII Remove any existing tray labels. 2. Depress latch upward from underneath.
3. Grip by finger rail grips.
4. Push rail to the left. 5. Lift rail up and away from enclosure. RAIL INSTALLATION STEPS (IF APPLICABLE) (See Figures 2 and 3) 6. Hold the bottom of the tray while installing the rail to the tray. 7. Engage triangular rail latch feature A into triangular opening B in tray. 8. While holding finger rail grips, install round rail feature C into slot opening D.

9. Push rail to the right to engage latch.

10. Verify central rail latch feature E is engaged.

11. Apply applicable port I.D. labels as needed.

12. Push tray back into the enclosure to the home position. GRIP RAIL HERE FIGURE 2 (SEE #4 ABOVE) FIGURE 3 RĀIL GRIP RAIL HERE (SEE #4 ABOVE) TRAY TRAY LATCH TITLE FLEXCORE ENCLOSURE TRAY RAIL KITS CUSTOMER DRAWING ITEM REVISION NAME 00582ELC/00 DATASET FILE NAME 00582ELC_DC/00B PART NO. UNLESS OTHERWISE SPECIFIED,
DIMENSIONAL TOLERANCES ARE: IN [mm] FLEXC-RAIL0*EN ALL DIMENSIONS ARE FOR REFERENCE ONLY DRAWING NUMBER: THIRD ANGLE 00582ELC-DC SEE SHEET 1 FOR REVISION HISTORY PROJECTION SCALE DRAWN BY DATE CHK APR REV DATE DESCRIPTION ECN SAT 08-11-22 TMSE NONE SHT 3 OF 3 2

ASIZE