

## Schneider OffGrid 330/500/730

### SAVE THESE INSTRUCTIONS

IMPORTANT SAFETY INSTRUCTIONS - This Safety Guide contains important instructions that should be followed during installation and maintenance of the Schneider Electric equipment and batteries.

It is intended for Schneider Electric customers who setup, install, relocate, or maintain Schneider Electric equipment. Refer to the product user manual for more information.

Read, understand, and follow ALL safety instructions contained in this guide. Failure to follow safety instructions and warnings could result in equipment damage, serious injury, or death.

Changes and modifications to this unit not expressly approved by Schneider Electric IT Corporation could void the warranty.

### General Safety Information

- This Schneider OffGrid is intended for indoor use. For outdoor applications, it is essential to adhere to the provided safety guidelines.
- Do not operate this unit in direct sunlight, in contact with fluids, or where there is excessive dust or humidity.
- Be sure the air vents on the Schneider OffGrid are not blocked. Allow adequate space for proper ventilation.
- Dispose of the packaging materials through recycling or retain them for future reuse or shipping purposes.
- This Safety Guide can be downloaded from Schneider Electric Website, [www.se.com](http://www.se.com)

### De-energizing Safety

- The Schneider OffGrid contains internal batteries and may present a shock hazard even when disconnected from AC and DC power.
- Do not handle any metallic connector before power has been disconnected.
- Do not touch the metallic connector of the cable immediately after using for charging the Schneider OffGrid. Allow sufficient time for the metal parts of the connector to cool.

### Schneider OffGrid Safety

- Schneider Electric Schneider OffGrid uses non-removable Lithium-Ion batteries. Under normal use and handling, there is no contact with the internal components of the battery.
- To reduce risk of injury, close supervision is necessary when children are present in the vicinity of the Schneider OffGrid.
- Do not expose the Schneider OffGrid to rain or snow.
- Use only recommended Schneider Electric accessories and chargers.

- Do not expose the Schneider OffGrid to excessive temperature or fire. Any such exposure to temperatures above 140 °F (60 °C) or fire may cause explosion.
- Do not use the Schneider OffGrid in places where flammable gases or fumes are present.
- Do not use the Schneider OffGrid if the wire or plug is found to be damaged.
- Use the Schneider OffGrid in a dry and well-ventilated environment. Be sure that the Schneider OffGrid has sufficient ventilation during use.
- During storage, keep the Schneider OffGrid in a dry and well-ventilated place to avoid moisture and electric shock.
- Do not disassemble, repair, or modify the Schneider OffGrid or the battery pack. Such acts may cause fire, explosion, injury, and unpredictable risks.
- The Schneider OffGrid has no serviceable parts.

 **CAUTION****RISK OF ELECTRIC SHOCK**

- Be sure that the plug, wire, and devices to be connected are in good condition before connecting them to the Schneider OffGrid.
- Do not remove cover, no user serviceable parts inside. Refer servicing to qualified service personnel.
- Do not overcharge the internal battery. See Instruction Manual.
- To reduce risk of damage to the electric plug and cord, pull the plug rather than the cord when disconnecting the power pack.
- Use of an attachment not recommended or sold by Schneider Electric may result in a risk of fire, electric shock, or injury to persons.
- Do not use the Schneider OffGrid if it is damaged or modified. Damage or modification of the Schneider OffGrid, including the lithium-ion battery pack inside the Schneider OffGrid, may exhibit unpredictable behavior resulting in fire, explosion, or risk of injury.

**Failure to follow these instructions could result in equipment damage and minor or moderate injury.**